

ASUS® PCI-DA2100

PCI-to-SCSI UltraWide RAID Controller Card

ASUS® PCI-DA2200

PCI-to-SCSI Ultra2/Wide RAID Controller Card

User's Manual



Copyright Information

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of ASUSTeK Computer Inc.

Disclaimer

ASUSTeK Computer Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, ASUSTeK Computer Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revisions or changes.

Trademarks

ASUS and ASUSTeK are registered trademarks of Computer Inc.

AMD is a trademark of Advanced Micro Devices, Inc.

DEC and Alpha are registered trademarks of DIGITAL Equipment Corporation in the U.S. and/or other countries.

Microsoft, Windows, Windows NT and MS-DOS are registered trademarks of Microsoft Corporation in the U.S. and other countries.

Novell and NetWare are registered trademarks of Novell, Inc. in the U.S. and/or other countries.

OS/2 and OS/2 Warp are registered trademarks of International Business Machines Corporation in the U.S.

Solaris is a trademark of Sun Microsystems, Inc.

SCO, OpenServer, and Unix Ware are trademarks or registered trademarks of The Santa Cruz Operation, Inc. in the U.S. and/or other countries.

All other names, brands, products or services are trademarks or registered trademarks of their respective companies.

Copyright © 1999 ASUSTeK Computer Inc. All Rights Reserved.

Product Name:	PCI-DA2100/PCI-DA2200
Manual Revision:	1.20
Release Date:	May 1999

Contact Information

ASUSTeK COMPUTER INC. (Asia-Pacific)

Marketing Address: 150 Li-Te Road, Peitou, Taipei,
Taiwan 112
Telephone: +886-2-2894-3447 ext. 507
Fax: +886-2-2894-3449
Email: info@asus.com.tw

Tech Support Tel (English): +886-2-2894-3447 ext. 706
Tel (Chinese): +886-2-2894-3447 ext. 113
Fax: +886-2-2895-9254
Email: tsd@asus.com.tw
Newsgroup: news2.asus.com.tw
WWW: www.asus.com.tw
FTP: ftp.asus.com.tw/pub/ASUS

ASUS COMPUTER INTERNATIONAL (America)

Marketing Address: 6737 Mowry Avenue, Mowry Business
Center, Building 2, Newark, California
94560, USA
Fax: +1-510-608-4555
Email: info-usa@asus.com.tw

Tech Support Fax: +1-510-608-4555
BBS: +1-510-739-3774
Email: tsd-usa@asus.com.tw
WWW: www.asus.com
FTP: ftp.asus.com.tw/pub/ASUS

ASUS COMPUTER GmbH (Europe)

Marketing Address: Harkort Str. 25, 40880 Ratingen, BRD,
Germany
Telephone: 49-2102-445011
Fax: 49-2102-442066
Email: sales@asuscom.de

Tech Support Hotline: 49-2102-499712
BBS: 49-2102-448690
Email: tsd@asuscom.de
WWW: www.asuscom.de
FTP: ftp.asuscom.de/pub/ASUSCOM

FCC & DOC Compliance

Federal Communications Commission Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING! The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003

Table of Contents

Chapter 1	Introduction	7
Chapter 2	Features.....	9
Chapter 3	Functional Description	11
3.1	RAID Management	11
3.2	Drive Failure Management	16
3.3	Disk Array Parameters.....	22
3.4	Cache Parameters.....	23
3.5	Drive-Side SCSI Parameters	24
3.6	Dynamic Logical Drive Expansion	27
Chapter 4	Hardware Installation.....	41
4.1	Card Layout and Jumpers.....	41
4.2	Installing DRAM SIMM.....	43
4.3	Basic Operational Set-Up.....	44
4.4	Configuration & Termination	46
Chapter 5	Quick Setup.....	51
5.1	Using the BIOS RAID Manager.....	51
Chapter 6	Configuring RAID.....	53
6.1	Starting to Build a RAID System Drive.....	53
6.2	How Does the RAID Controller Work?	54
Chapter 7	BIOS Configuration Utility.....	59
7.1	Configuration	60
7.2	Color/Monochrome	64
Chapter 8	Text RAID Manager User Interface.....	65
8.1	The Main Menu.....	65
8.2	Viewing and Editing Logical Drives	74
8.3	Viewing and Editing SCSI ID Map.....	87
8.4	Viewing and Editing SCSI Drives	93
8.5	Viewing and Editing SCSI Channels	99
8.6	Viewing and Editing Configuration Parameters	115
8.6	System Functions	127
8.8	Viewing System Information	134
Chapter 9	Remote Administration.....	135
9.1	GUI RAID Manager Using SNMP Service.....	135
Appendix A	Driver Installation	139
1	MS-DOS® ASPI Drivers Installation.....	139
2	NetWare® Driver Installation	141
2.1	Installing NetWare 3.1x	141
2.2	Installing NetWare 4.0x/4.1/4.11	143
3	Windows NT® 3.1/3.51 Driver Installation.....	151

3.1	Installing Driver During WinNT 3.1/3.51 Installation.....	151
3.2	Installing Driver in Existing WinNT 3.1/3.51 System	152
3.3	Updating Windows NT 3.1/3.51 Device Driver.....	154
3.4	Installing the Driver During WinNT 4.0 Installation.....	154
3.5	Installing Driver while Installing WinNT4(DEC Alpha)	157
3.6	Installing the Driver in Existing WinNT4 (DEC Alpha)	158
4	Windows® 95/98 Driver Installation	160
4.1	Installing Windows 95/98 and the Driver.....	160
4.2	Updating Device Driver for Windows 95/98	162
5	OS/2® Driver Installation	163
5.1	Installing Driver During OS/2 2.x or 3.0 Installation.....	163
5.2	Installing Driver in an Existing OS/2 2.x/3.0.....	164
5.3	Updating PCI-DA2100/2200 OS/2 Device Driver	164
5.4	DA2100/2200 OS/2 Driver Command-Line Options	165
6	Driver Installation for SCO OpenServer & UnixWare.....	168
6.1	Installing the SCO OpenServer Driver	168
7	Drivers and Utilities for Linux	170
7.1	Making Floppy Diskettes for Red Hat 5.1 Installation	170
7.2	Making Floppy Diskettes for SlackWare 3.2 Installation....	171
7.3	Installing Red Hat Linux.....	171
7.4	Installing SlackWare Linux	173
7.5	Running the ASUS Text RAID Manager for Linux.....	175
8	Drivers and Utilities for Sun Solaris™	176
8.1	Solaris 2.5.x and 2.6 (x86 platform).....	176
8.2	Installing x86 Driver & Text RAID Manager	177
8.3	Drivers & Utilities - Solaris 2.5.x/2.6 (SPARC)	178
8.4	Installing SPARC Driver & Text RAID Manager.....	180
8.5	Configuring RAID in Solaris with Text RAID Manager.....	181
Appendix B	SCSI Cable Specifications	183
Appendix C	Upgrading BIOS, Firmware, and Boot Record..	185
Appendix D	Sync. Clock Period/Frequency	187
Appendix E	Troubleshooting Guide.....	189
Appendix F	Specifications.....	191
Appendix G	Record the Settings	193
	View and Edit Logical Drives	193
	View and Edit Host LUNs	194
	View and Edit SCSI Drives.....	194
	View and Edit SCSI Channels	195
	View and Edit Configuration Parameters	195
Index.....		197

Chapter 1 Introduction

The ASUS PCI-DA2100/-DA2200 is a PCI-to-SCSI RAID controller specifically designed to provide RAID 0, 1, 3 or 5 capability to any host system equipped with a Little Endian PCI Local Bus interface. All the RAID functions of ASUS PCI-DA2100/-DA2200 are performed by an Intel486(PCI-DA2100) or AMD 5x86(PCI-DA2200) CPU coupled with high-speed DRAMs and firmware in flash memory. In effect, it endows the host system with the high-performance and fault-tolerant disk storage operation of RAID technology. It is also an ideal solution for weaving several hard disks into one contiguous volume.

The controller has comprehensive drive failure management that allows automatic reassignment of reserved blocks when a bad sector is encountered during a write. Hot-swapping is supported through automatic disconnection of a failed drive and detection of a reserved drive followed with background rebuilding of data. The controller also supports spare drive operation. Remarkably, all of these failure recovery procedures are transparent to the host system.

The ASUS PCI-DA2100/-DA2200 has been designed with ease of integration and maintenance in mind. The major features are described in the next chapter. The controller already includes all the major operational requirements for a RAID subsystem. The overall features of a fully-built RAID subsystem will, however, depend on the actual components used and the creativity of the integrator.

This page is left intentionally blank.

Chapter 2 Features

- ✓ Five operating modes:

Non-RAID	Disk Spanning
RAID-0	Disk Striping
RAID-1	Disk Mirroring and Striping (RAID 0+1)
RAID-3	Disk Striping with Dedicated Parity
RAID-5	Multiple Block Striping with Interspersed

Parity

- ✓ Comprehensive failure management including:
 - Automatic bad sector reassignment
 - Hot-swapping
 - Spare drive operation (Supports both Global Spare and Local Spare)
 - Background rebuilding (Rebuild priority selectable)
 - Verify-after-Write supported on normal writes, rebuild writes and/or RAID initialization writes
- ✓ PCI Rev. 2.1 compliant
- ✓ PCI form factor: 6.87”(L) X 4.2”(W) (PCI-DA2100)
 9.21”(L) x 4.2”(W) (PCI-DA2200)
- ✓ Supports up to 15 SCSI drives per channel
- ✓ Up to 8 logical drives, each with independent RAID modes
- ✓ Up to 8 partitions per logical drive
- ✓ Number of drives for each logical drive has no limitation
- ✓ Dynamic mapping of LUNs to logical drives
- ✓ Concurrent/Background logical drive initialization
- ✓ Performance optimization for Sequential or Random I/O
- ✓ Allows multiple drive failure and concurrent multiple drive rebuild of a RAID (0+1) logical drive
- ✓ Configuration of individual SCSI target parameters
- ✓ Prior to first disk access, it allows adjustment of delay time during controller initialization to enhance compatibility with slow-initial drives

2

- ✓ All channels are Ultra-Wide (PCI-DA2100) or Ultra2-Wide-SCSI (PCI-DA2200) (downward compatible to SCSI-1)
- ✓ Compatible and will automatically match any SCSI hard disks with SCSI-1, SCSI-2 or (Ultra)-Wide-SCSI (1 or 2) specification
- ✓ Full Ultra-Wide (PCI-DA2100) or Ultra2-Wide (PCI-DA2200) SCSI-2 implementation including Tagged Command Queuing and Multi-Threaded I/O
- ✓ Uses Intel 486DX2-100 (PCI-DA2100) or AMD 5x86-133 (PCI-DA2200) CPU with all executable firmware downloaded into high-speed DRAM
- ✓ EDO DRAM supported for enhanced performance
- ✓ Up to 64MB (PCI-DA2100) or 128MB (PCI-DA2200) of intelligent Read-Ahead/Write-Back cache
- ✓ Firmware resides in easy-to-update Flash Memory
- ✓ GUI RAID Manager and Text RAID Manager interfaces for RAID management

Chapter 3 Functional Description

The advantages of RAID are: Availability, Capacity and Performance. Choosing the right RAID level and drive failure management can increase Availability, subsequently increasing Performance and Capacity. The ASUS PCI-DA2100/-DA2200 RAID controller provides complete RAID functionality and enhanced drive failure management.

3.1 RAID Management

RAID stands for Redundant Array of Independent Drives. The advantages of using a RAID storage subsystem are:


- Provides disk spanning by weaving all connected drives into one single volume.
- Increases disk access speed by breaking data into several blocks when reading/writing to several drives in parallel. With RAID, storage speed increases as more drives are added.
- Provides fault-tolerance by mirroring or parity operation.

What are the RAID levels?

RAID Level	Description	Minimum Drives	Data Availability	Performance Sequential	Performance Random
NRAID	Non-RAID	1		Drive	Drive
RAID 0	Disk Striping	N	==NRAID	R: Highest W: Highest	R: High W: Highest
RAID 1 (0+1)	Mirroring Plus Striping (if N>1)	N+1	>>NRAID ==RAID 5	R: High W: Medium	R: Medium W: Low
RAID 3	Striping with Parity on dedicated disk	N+1	>>NRAID ==RAID 5	R: High W: Medium	R: Medium W: Low
RAID 5	Striping with interspersed parity	N+1	>>NRAID ==RAID 5	R: High W: Medium	R: High W: Low

3


NRAID Disk Spanning



NRAID	
Minimum Disks required	1
Capacity	N
Redundancy	No

NRAID stands for Non-RAID. The capacity of all the drives are combined to become one logical drive (no block striping). In other words, the capacity of the logical drive is the total capacity of the physical drives. NRAID does not provide data redundancy.

JBOD Single-drive Control




JBOD	
Minimum Disks required	1
Capacity	1
Redundancy	No

JBOD stands for Just a Bunch of Drives. The controller treats each drive as a stand-alone disk, therefore each drive is an independent logical drive. JBOD does not provide data redundancy.

RAID 0 Disk Striping


RAID 0	
Minimum Disks required	2
Capacity	N
Redundancy	No



RAID 0 provides the highest performance but no redundancy. Data in the logical drive is striped (distributed) across several physical drives.

RAID 1 Disk Mirroring

RAID 1	
Disks required	2
Capacity	N/2
Redundancy	Yes




RAID 1 mirrors the data stored in one hard drive to another. RAID 1 can only be performed with two hard drives. If there are more than two hard drives, RAID (0+1) will be performed automatically.

RAID (0+1)

Disk Striping with Mirroring

RAID (0+1)	
Minimum Disks required	4
Capacity	N/2
Redundancy	Yes



RAID (0+1) combines RAID 0 and RAID 1 - Mirroring and Striping. RAID (0+1) allows multiple drive failure because of the full redundancy of the hard drives. If there are more than two hard drives assigned to perform RAID 1, RAID (0+1) will be performed automatically.


IMPORTANT:

“RAID (0+1)” will not appear in the list of RAID levels supported by the controller. If you wish to perform RAID 1, the controller will determine whether to perform RAID 1 or RAID (0+1). This will depend on the drive number that has been selected for the logical drive.


RAID 3

Disk Striping with Dedicated Parity Disk

RAID 3	
Minimum Disks required	3
Capacity	N-1
Redundancy	Yes



RAID 3 performs Block Striping with Dedicated Parity. One drive member is dedicated to storing the parity data. When a drive member fails, the controller can recover or regenerate the lost data of the failed drive from the dedicated parity drive.



RAID 5


Striping with Interspersed Parity

RAID 5	
Minimum Disks required	3
Capacity	N-1
Redundancy	Yes


RAID 5 is similar to RAID 3 but the parity data is not stored in one dedicated hard drive. Parity information is interspersed across the drive array. In the event of a failure, the controller can recover/regenerate the lost data of the failed drive from the other surviving drives.


3.2 Drive Failure Management

3.2.1 Global and Local Spare Drive




Global Spare Drive does not only serve one specified logical drive. When a member drive from any of the logical drive fails, the Global Spare Drive will join that logical drive and automatically starts to rebuild.





The ASUS PCI-DA2100/-DA2200 RAID controller provides both Local Spare Drive and Global Spare Drive functions. On certain occasions, applying these two functions together will better fit various needs. Take note though that the **Local Spare Drive always has higher priority than the Global Spare Drive**.

In the example shown on the next page, the member drives in Logical Drive 0 are 9 GB drives, and the members in Logical Drives 1 and 2 are all 4 GB drives. It is not possible for the 4 GB Global Spare Drive to join Logical Drive 0 because of its insufficient capacity. However using a 9GB drive as the Global Spare drive for a failed drive that comes from Logical Drive 1 or 2 will bring huge amount of excess capacity since these logical drives require 4 GB only. In the settings below, the 9 GB Local Spare Drive will aid Logical Drive 0 once a drive in this logical drive failed. If the failed drive is in Logical Drive 1 or 2, the 4 GB Global Spare drive will immediately give aid to the failed drive.



3.2.2 Identifying Drives


Assuming there is a failed drive in the RAID 5 logical drive, make it a point to replace the failed drive with a new drive to keep the logical drive working.

When trying to remove a failed drive and you mistakenly removed the wrong drive, you will no longer be able to read/write the logical drive because the two drives may have already failed.

To prevent this from happening, the controller provides an easy way of identifying for the failed drive. That is, the read/write LED of the failed hard drive will light. This LED will prevent you from removing the wrong drive, and is also helpful when locating for a drive.


Flash Selected SCSI Drive

The Read/Write LED of the drive you selected will light steadily for about one minute.




Flash All SCSI Drives

The Read/Write LED of all connected drives will light for about one minute. If the LED of the defective drive did not light on the “Flash Selected SCSI Drive” function, use “Flash All SCSI Drives”. The “Flash All SCSI Drives” function will light LEDs of all the drives except the defective one.



3.2.3 Automatic Rebuild and Manual Rebuild

Automatic Rebuild



When a member drive in the logical drive failed, the controller will first check whether there is a Local Spare Drive assigned to this logical drive. If yes, it will automatically start to rebuild.

If there is no Local Spare Drive available, the controller will search for a Global Spare Drive. If there is a Global Spare Drive, it will automatically rebuild the logical drive.

If neither a Local Spare Drive nor a Global Spare Drive is available, and the "Periodic Auto-Detect Failure Drive Swap Check Time" is "Disabled," the controller will not try to rebuild unless the user applies a forced manual rebuild.


When the "Periodic Auto-Detect Failure Drive Swap Check Time" is enabled (i.e., a check time interval has been selected), the controller will detect whether or not the failed drive has been swapped (by checking the failed drive's channel/ID). Once the failed drive has been swapped, the rebuild will begin immediately.

If the failed drive is not swapped but a local spare drive is added to the logical drive, rebuilding will begin with the spare drive.

Manual Rebuild

When a user applies forced-manual rebuild, the controller will first check whether there is any Local Spare Drive assigned to this logical drive. If yes, it will automatically start to rebuild.

If there is no Local Spare Drive available, the controller will search for a Global Spare Drive. If there is a Global Spare Drive, it will automatically rebuild the logical drive.



If neither a Local Spare Drive nor a Global Spare Drive is available, the controller will detect the SCSI channel and ID of the failed drive. Once the failed drive has been replaced by a new drive/used drive, it starts to rebuild using the replaced drive. If there is no available drive for rebuilding, the controller will not try to rebuild again until the user applies another forced-manual rebuild.

3.2.4 Concurrent Rebuild in RAID (0+1)

RAID (0+1) allows multiple drive failure and concurrent multiple drive rebuild. Newly replaced drives must be scanned and set as Local Spare Drives. These drives will be rebuilt at the same time (you do not need to repeat the rebuilding process for each drive).

3.3 *Disk Array Parameters*

3.3.1 Rebuild Priority

Rebuilding time will depend on the capacity of the logical drive. The ASUS PCI-DA2100/-DA2200 RAID controller provides background rebuilding ability. Meaning, the controller is able to serve other I/O requests while rebuilding the logical drives. The rebuilding process is totally transparent to the host computer or the operating system.

The background rebuild process has four priority options:

- Low
- Normal
- Improved
- High

The default priority is “Low” which uses the controller’s minimum resources to rebuild. Choosing “Normal” or “Improved” will speedup the rebuilding process and choosing “High” will use the controller’s maximum resources to complete the rebuilding process at the shortest time.

Rebuild priority can be configured through either the Text RAID Manager or the GUI RAID Manager.

3.3.2 Verify-after-Write

The controller has the ability to force the hard drives to verify after data has been written to the media of the HDD. There are three selectable methods:

- Verification on LD Initialization Writes
Performs Verify-after-Write while initializing the logical drive.
- Verification on LD Rebuild Writes
Performs Verify-after-Write during the rebuilding process.
- Verification on LD Normal Drive Writes
Performs Verify-after-Write during normal I/O requests.

Each method can be enabled or disabled individually. Hard drives will perform Verify-after-Write according to the selected method.

IMPORTANT:

The “Verification on LD Normal Drive Writes” method will affect “write” performance during normal use.

3.4 Cache Parameters

3.4.1 Optimization for Sequential or Random I/O

When using RAID with applications such as video or image oriented applications, the application reads/writes from the drive using large-block, sequential files instead of small-block, random access files. The ASUS PCI-DA2100/-DA2200 RAID controller provides the options to optimize for large-sequential I/O or optimize for small-random I/O access.

“Optimization for Sequential I/O” provides a larger – 128K – stripe size (or “block” size, also known as “chunk” size) than does “Optimization for Random I/O” (with a size of 32K). A lot of the controller’s internal parameters will also be changed to optimize for sequential or random I/O. The change will take effect after the controller reboots.

If the existing logical drives were built with “Optimization for Random I/O”, these logical drives will not read/write when using “Optimization for Sequential I/O” (shows "INVALID") and vice versa because the stripe size is different. Change it back to the original setting and reset the controller to make available the logical drive data again.

IMPORTANT:

Changing the setting to “Optimization for Sequential I/O” or “Optimization for Random I/O” should be performed only when no logical drive exist. Otherwise, you will not be able to access the data in the logical drive later on.

3.5 Drive-Side SCSI Parameters

3.5.1 SCSI Motor Spin-up

When the power supply is unable to provide sufficient current for all the hard drives and controllers that are powered-up at the same time, spinning-up the hard drives serially is one of the best way of consuming lower power-up current.

By default, all hard drives will spin-up when powered-on. These hard drives can be configured so that all of them will not spin-up at power-on. There are 3 methods of spinning-up the hard drive's motor: Spin-up at power-on, Spin-up serially in random sequence or Spin-up by SCSI command. Please refer to the hard drive's user's manual for instructions on configuring the hard drive using the "Spin-up by SCSI command". The procedure for each brand/model of hard drive should vary.

Configure all the hard drives as above and enable "SCSI Motor Spin-Up" in Drive-Side SCSI Parameters. Power off all hard drives and controller, and power them on again. All the hard drives will not spin-up at this time. The controller will then spin-up the hard drives one by one at four seconds interval.

IMPORTANT:

If the drives are configured as "Delay Motor Spin-up" or "Motor Spin-up in Random Sequence," some of these drives may not be ready yet for the controller to access when the system powers up. Increase the disk access delay time so that the controller will wait a longer time for the drive to be ready.

3.5.2 SCSI Reset at Power Up

By default, when the controller is powered up, it will send a SCSI bus reset command to the SCSI bus. When disabled, it will not send a SCSI bus reset command on the next power-up.

When connecting dual host computers to the same SCSI bus, the SCSI bus reset will interrupt all the read/write requests that are being performed. This may cause some operating systems or host computers to act abnormally. Disable the "SCSI Reset at Power-up" to avoid this situation.

3.5.3 Disk Access Delay Time

Sets the delay time before the controller tries to access the hard drives after power-on. The default is 15 seconds.

3.5.4 SCSI I/O Timeout

The “SCSI I/O Timeout” is the time interval that the controller waits for a drive to respond. If the controller attempts to read data from or write data to a drive, but the drive does not respond within the SCSI I/O timeout value, the drive will be judged to be a failed drive.

When the drive itself detects a media error while reading from the drive platter, it will retry the previous reading or recalibrate the head. When the drive has encountered a bad block on the media, it has to reassign the bad block to another spare block. However, all of this takes time. The time to perform these operations can vary between different brands and models of drives.

During SCSI bus arbitration, a device with higher priority can utilize the bus first. A device with lower priority will sometimes get a SCSI I/O timeout when higher priority devices keep utilizing the bus.

The default setting for “SCSI I/O Timeout” is 7 seconds. It is highly recommended not to change this setting. Setting the timeout to a lower value will cause the controller to judge a drive as failed a drive is still retrying or while a drive is unable to arbitrate the SCSI bus. Setting the timeout to a greater value will cause the controller to keep waiting for a drive, and it may sometimes cause a host timeout.

3.5.5 Maximum Tag Count

The maximum number of tags that can be sent to each drive at the same time. A drive has a built-in cache that is used to sort all of the I/O requests (“tags”) which are sent to the drive, allowing the drive to finish the requests faster. The cache size and maximum number of tags varies between different brands and models of drive. Using the default setting – “32” – is highly recommended. Changing the maximum tag count to “Disable” will cause the internal cache of the drive to be ignored (i.e., not used).

3.5.6 Periodic Drive Check Time

The “Periodic Drive Check Time” is an interval for the controller to check all of the drives that were on the SCSI bus at controller startup (a list of all the drives that were detected can be seen under “View and Edit SCSI Drives”). The default value is “Disabled”. “Disabled” means that if a drive is removed from the bus, the controller will not be able to know – so long as no host accesses that drive. Changing the check time to any other value allows the controller to check – at the selected interval – all of the drives that are listed under “View and Edit SCSI Drives.” If any drive is then removed, the controller will be able to know – even if no host accesses that drive.

3.5.7 SAF-TE Enclosure Monitoring


What is SAF-TE?

SAF-TE stands for SCSI Accessed Fault-Tolerant Enclosures. It is an enclosure management technology that uses the SCSI bus to interact with the controller. A SAF-TE-compliant enclosure monitors the fan temperature, power supply, UPS and also provides drive status LED's.

How does it work?

The SAF-TE device, which is often a back-plane within a drive-bay enclosure, must occupy a connector on one of the drive channels' SCSI cables. The presence of a SAF-TE device will be detected and its presence will be displayed in the BIOS configuration utility, Text RAID Manager and the GUI RAID Manager programs. The RAID controller communicates with the SAF-TE enclosure with standard SCSI commands, polling the device in order to get SAF-TE information.

The default value for “Periodic SAF-TE Device Check Time” is “Disabled”. If the enclosure does have a SAF-TE device and features, enable the controller to poll the device by selecting a time interval. The RAID controller will then check the SAF-TE device status at that interval.



- The SAF-TE chipset connects to the drive channel of the controller together with the other SCSI drives.

3.5.8 Periodic Auto-Detect Failure Drive Swap Check Time

The “Drive-Swap Check Time” is the interval at which the controller checks to see whether a failed drive has been swapped. When a logical drive’s member drive fails, the controller will detect the failed drive (at the selected time interval). Once the failed drive has been swapped with a drive that has adequate capacity to rebuild the logical drive, the rebuild will begin automatically.

The default setting is “Disabled,” meaning that the controller will not Auto-Detect the swap of a failed drive. To enable this feature, select a time interval.

3.6 Dynamic Logical Drive Expansion

3.6.1 What Is It and How Does It Work?

Before Dynamic Logical Drive Expansion, increasing the capacity of a RAID system using traditional methods meant backing up, re-creating and then restoring. Dynamic Logical Drive Expansion allows


3

users to add new SCSI hard disk drives and expand a RAID 0, 3 or 5 Logical Drive without powering down the system.

3.6.2 Two Modes of Dynamic Logical Drive Expansion


There are two modes of Dynamic Logical Drive Expansion: Mode 1 and Mode 2.

On-line RAID Expansion



Mode 1 Expansion involves adding more SCSI hard disk drives to a logical drive, which may require that the user obtain an enclosure with more drive bays. The data will be re-stripped onto the original and newly added disks.


RAID Expansion - Mode 1



In the figure above, new drives are added to increase the capacity of a 4-Gigabyte RAID 5 logical drive. The two new drives increase the capacity to 8 Gigabytes.


Mode 2 Expansion, on the other hand, requires the same number of higher-capacity SCSI hard disk drives for a given logical drive.

RAID Expansion - Mode 2 (1/3)




The figure above illustrates expansion of the same 4-Gigabyte RAID 5 logical drive using Mode 2 Expansion. Drives are copied and replaced, one by one, onto three higher-capacity drives.

RAID Expansion - Mode 2 (2/3)



This results in a new 4-Gigabyte, RAID 5 logical drive composed of three physical drives. The 4 Gigabytes of increased capacity is in a new partition.

RAID Expansion - Mode 2 (3/3)



IMPORTANT:

- The increased capacity from Mode 1 and Mode 2 Expansion of a logical drive will be a new partition.
- Adding the extra capacity to the existing partition could crash the file system in most current operating systems, so this is not supported. Technically, the controller could easily combine the two partitions together. But, as this may compromise protection of the existing partition's data (due to the questions regarding OS capabilities), this function is not offered as a choice at this time.
- At the time of this printing, the firmware does not support the "Copy and Replace" function that is required for Mode 2 Expansion of logical drives. Third-party hard disk utilities may be used for Mode 2 Expansion of logical drives. Future versions of the firmware will support "Copy and Replace."

3.6.3 Example: RAID Expansion in Windows NT® Server

Limitations When Using Windows NT 4.0

1. Only the Windows NT Server Disk Administrator includes the Extend Volume Set function; Windows NT Workstation does not have this feature.
2. The system drive (boot drive) of a Windows NT system cannot be extended.
3. The drive that will be extended should be using the NTFS file system.

The Example:

The following example demonstrates the expansion of a 900MB RAID 0 logical drive. The Text RAID Manager software that comes with the ASUS PCI-DA2100/-DA2200 is used to communicate with the RAID controller.


The screenshot shows the RAIDman software window. At the top right, it says "Cache Status: Clean". Below this is a table with the following columns: LG, RAID, Size (MB), Status, # of, # of, # of, # of, and NAME. The first row shows LG 0, RAID 0, Size 900, Status GOOD, and # of 3, 2, -, 0. The remaining rows (1-7) show "NONE" in the RAID column. At the bottom, there are keyboard controls: Arrow Keys: Move Cursor, Enter: Select, Esc: Exit, Ctrl+F: Refresh Screen.

LG	RAID	Size (MB)	Status	# of	# of	# of	# of	NAME
0	RAID0	900	GOOD	3	2	-	0	
1	NONE							
2	NONE							
3	NONE							
4	NONE							
5	NONE							
6	NONE							
7	NONE							


Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+F: Refresh Screen

3

You can view information about this drive in the Windows NT Server's Disk Administrator.




Place the cursor on Disk 1, right-click your mouse, and select "Properties." You will see that the total capacity for the Drive E: is just under 900MB.




3


Follow the steps described in section 8.2.8 to add SCSI disk drives and perform Mode 1 Dynamic Logical Drive Expansion.



The 900MB logical drive has become a 1800MB logical drive. Place the cursor on that logical drive, and then press <Enter>.




From the menu, select Partition Logical Drive. You will see that the 1800MB logical drive is composed of two 900MB partitions.




Follow the directions in section 8.3.1 to map the new partition to a Host LUN. The new partition must be mapped to a host LUN in order for the HBA (host-bus adapter) to see it. Once you have mapped the partition, reboot Windows NT. The HBA should be able to detect an additional "disk."

3

Return to Windows NT Server's Disk Administrator. There now exists a Disk 2 with 900MB of free space. Click on Disk 2 to select it.




From the "Partition" menu, select "Extend Volume Set."




3

The screen will display that volume set of Drive E: has been extended by the 900MB in Disk2. Move the cursor to "Commit Changes Now" to confirm that you want the free space to become a part of the same logical drive.




Logical Drive E: is now composed of two 900MB partitions with a total volume of 1800MB. To see this, hold down on the <Ctrl> key and select both Disk 1 and Disk2; then right-click your mouse and select "Properties."



3

Drive E: now has a capacity just under 1800MB.



Chapter 4 Hardware Installation

4.1 Card Layout and Jumpers

4.1.1 PCI-DA2100

Title:
Layout DA2100-2200.fh8
Creator:
FreeHand 8.0.1
Preview:
This EPS picture was not saved
with a preview included in it.
Comment:
This EPS picture will print to a
PostScript printer, but not to
other types of printers.

JP1 and **JP2** on the PCI-DA2100 is for manufacturer's use and should be left open for normal operation.

JP6 PCI-DA2100 LED Connector for Hard Drive Activity Indicator

Pin	Symbol	Type	Description
1	VCC	P	+5V voltage input
2	BUSYLED	O	Front panel LED:"BUSY"
3	BUSYLED	O	Front panel LED:"BUSY"
4	VCC	P	+5V voltage input

4.1.2 PCI-DA2200

Title:

Layout DA2100-2200.fh8

Creator:

FreeHand 8.0.1

Preview:

This EPS picture was not saved with a preview included in it.

Comment:

This EPS picture will print to a PostScript printer, but not to other types of printers.

JP7 PCI-DA2200 LED Connector for Hard Drive Activity Indicator

Pin	Symbol	Type	Description
1	VCC	P	+5V voltage input
2	BUSYLED	O	Front panel LED:"BUSY"
3	BUSYLED	O	Front panel LED:"BUSY"
4	VCC	P	+5V voltage input

JP9 PCI-DA2200 I²C Connector

Pin	Symbol	Type	Description
1	I2CCLK	O	I ² C clock
2	GND	G	Signal ground
3	VCC	P	+5V voltage input
4	I2CDATA	O	I ² C data

4.2 Installing DRAM SIMM

IMPORTANT:


The ASUS PCI-DA2100/-DA2200 requires a minimum of 8 Mbytes of DRAM in one SIMM (with or without parity function) installed in SIMM socket to operate. The controller is normally delivered without any DRAM installed.

The following are guidelines with regards to DRAM:

- **Use 72-pin 60ns DRAM or 60ns EDO RAM SIMM modules.** EDO RAM is recommended to improve performance.
- DRAM with or without parity is auto-detected by ASUS PCI DA2100/-DA2200, but DRAM with parity is recommended for greater data integrity.
- PCI-DA2100: A minimum of 2 Mbytes DRAM is required to be installed in the SIMM socket, however 4 Mbytes is recommended for full functionality. Supports 8, 16, 32, and 64 Mbytes DRAM SIMM modules up to 64 Mbytes.
- PCI-DA2200: A minimum of 8 Mbytes DRAM is required to be installed in the SIMM socket, however 16 Mbytes is recommended for full functionality. Supports 8, 16, 32, 64, and 128 Mbytes DRAM SIMM modules up to 128 Mbytes.

To install DRAM SIMM

1. Power off the system and disconnect the power connector.
2. Insert the DRAM SIMM paralleled with the key to the left (1). Then push towards the back until the hooks on both sides of the socket snap into place (2) as shown below.




4.3 Basic Operational Set-Up


Some of the examples presented in this section are only illustrated for the ASUS PCI-DA2200. There are three major differences between the two RAID cards when referring to the following examples.

- PCI-DA2100 only supports UltraWide and earlier SCSI devices.
PCI-DA2200 supports both Ultra2 (LVD) and earlier SCSI devices.
- PCI-DA2100 has only a single external channel (0).
PCI-DA2200 has two external channels.
- PCI-DA2100 devices are terminated on the device (jumpers/switches)
PCI-DA2200 devices are terminated on the cable (external terminator)

Sample operational set-up: (PCI-DA2100)



Sample operational set-up: (PCI-DA2200)



All drives, terminators and SCSI cables should use Ultra2 Wide SCSI (LVD) devices only.

Important Notes for the ASUS PCI-DA2100/-DA2200:


- Only use Ultra2 (LVD) twisted SCSI cables and Ultra2 (LVD) SCSI terminators on the ASUS PCI-DA2200.
- SCSI nodes on the same channel have unique ID number. The SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 adapter and thus no drives should use ID 7.
- Both ends of all SCSI cables are properly terminated. Terminate the SCSI cable by installing an external terminator on the end connector of the ASUS PCI-DA2200. The ASUS PCI-DA2100 is terminated on the end device by using jumpers or switches. The terminators embedded in ASUS PCI-DA2100/-DA2200 should be enabled. The default state of terminators embedded on ASUS PCI-DA2100/-DA2200 controller are enabled and can be changed by running RAIDMAN.EXE or configured in the ASUS PCI-DA2100/-DA2200 BIOS settings
- The ASUS PCI-DA2200's Ultra2 Wide SCSI (LVD) is backward compatible with UltraWide SCSI devices (Single-ended). However, any Single-ended devices connecting to an LVD bus will cause all the other LVD devices on the same bus switch back to Single-ended mode. The cable length will also be limited to Single-ended standard instead of LVD standard, if any Single-ended devices connecting to an LVD SCSI bus.
- Since all non-disk SCSI devices are single-ended, it is not recommended to attach any non-disk devices to ASUS PCI-DA2200 PCI RAID controller if Ultra2 Wide SCSI drives (LVD) are attached.

IMPORTANT:


Changing any settings in "View and Edit SCSI Channels" requires a system reset to take effect.

4.4 Configuration & Termination

ASUS PCI-DA2100




ASUS PCI-DA2200



Each SCSI drive channel has embedded terminators. The termination on each channel can be enabled or disabled by user with Text RAID Manager in each operating system, or configured in the ASUS PCI-DA2100/-DA2200 BIOS settings.

4.4.1 Internal Drives Only (PCI-DA2200) (PCI-DA2100 only has external Ch.0 & is terminated by the end device.)




Termination should be enabled if only the internal SCSI connectors are used to connect the drives. All devices (including SCSI drives, cables and terminators) should be Ultra2 Wide LVD SCSI compliant.

It is not recommended to connect any Single-ended devices to the LVI drive SCSI bus directly.

4.4.2 External Drives Only (PCI-DA2200)


(PCI-DA2100 only has external Ch.0 & is terminated by the end device.)



Termination should be enabled if only the external SCSI connectors are used to connect the drives. All devices (including SCSI drives, cables and terminators) should be Ultra2 Wide LVD SCSI compliant.

It is not recommended to connect any Single-ended devices to the LVD drive SCSI bus directly.


4.4.3 Mixing Internal and External Drives (PCI-DA2200) (PCI-DA2100 only has external Ch.0 & is terminated by the end device.)



The termination should be disabled if both internal and external SCSi connectors of the same channel are being used.

All devices (including SCSi drives, cables and terminators) should be Ultra2 Wide LVD SCSi compliant. It is not recommended to connect any single-ended devices to the LVD drive SCSi bus directly.

4.4.4 Mixing LVD and Single-ended Devices (PCI-DA2200) (PCI-DA2100 only has external Ch.0 & is terminated by the end device.)



It is not recommended to connect any Single-ended devices to the LVD drive SCSI bus directly. Using a "single-ended to LVD converter" to convert the Single-ended device to LVD before connecting to the drive SCSI bus.

Any Single-ended devices connecting directly to the LVD SCSI bus will force all the devices switch back to single-ended mode. The cable length and maximum devices should follow Single-ended standard if the bus is operating in Single-ended mode.

IMPORTANT:

Changing any settings in "View and Edit SCSI Channels" requires a system reset to take effect.

Chapter 5 Quick Setup

NOTE:

A "Logical Drive" is a set of drives grouped together to operate under a given RAID level and appears as a single contiguous drive. The ASUS PCI-DA2100/-DA2200 is capable of grouping connected drives into 8 logical drives, each operating on the same or different RAID levels. The logical drive can be further divided into a maximum of 8 "Partitions". During operation, the host sees the logical drive or partition as one single drive.


5.1 Using the BIOS RAID Manager

1. When the system is powered on, the following text will appear:

```
ASUS PCI-DA2100/-DA2200 (PCI-TO-SCSI RAID) BIOS v1.17B
PCI Bus # = 00      Device # = 09  Port = E000  IRQ = 10  EDORAM=8 MB  FW=2.12
!! Press <Ctrl><I> for Configuration Utility, <Q> to Skip !!
```


2. Press <Ctrl><I> to enter the BIOS Configuration Utility.
3. Choose "Configure RAID" to enter the terminal emulation.
4. Move the cursor to "ANSI" (or another terminal emulation mode) and press **[Enter]** to see the main menu of the BIOS RAID Manager.
5. The keys used in the RAID Manager RAID operation are as follows:

← → ↑ ↓	Left, right, up and down arrow to select options.
[Enter]	To go into a submenu or to execute an option.
[Esc]	To escape and go back to the preceding menu.




Type **Q**, or use the \uparrow \downarrow keys, to select "Quick installation" and press **[Enter]**. Choose Yes to create the logical drive.

6. All the possible RAID levels will be displayed, choose a RAID level by using the \uparrow \downarrow keys to select a RAID level and press **[Enter]**. The spear drive assigned in this item is Local Spare drive, not Global Spare drive.




The controller will start initialization and automatically map the logical drive to LUN 0 of the first host channel.



Chapter 6 Configuring RAID

6.1 Starting to Build a RAID System Drive

The following figure is a basic flowchart when configuring a RAID system. Hardware installation must be completed before any configurations take place.



When power is turned on, the ASUS PCI-DA2100/-DA2200 RAID controller scans all the hard drives that are on all the drive channels. If a hard drive was connected after the controller completes initialization, use the "SCAN SCSI DRIVE" function to let the controller recognize the newly added hard drive and configure it as a member of a logical drive or a spare drive.

In accordance to your requirement, configure a logical drive to contain one or more hard drives based on the desired RAID level, and partition the logical drive into one or several partitions. Map each partition as one system drive (LUN). The host SCSI adapter will recognize the system drives after re-scanning the host SCSI bus.

Since the controller is totally operating system independent, the operating system of the host computer will not be able to find out whether the attached devices are physical hard drives or virtual system drives created by the RAID controller.


NOTE:

A "Logical Drive" is a set of drives grouped together to operate under a given RAID level and appears as a single contiguous drive. The ASUS PCI-DA2100/-DA2200 controller is capable of grouping connected drives to as many as 8 logical drives, each configured on the same or different RAID levels. A logical drive can be further divided into a maximum of 8 "Partitions". During operation, the host sees an unpartitioned logical drive or a partition of a partitioned logical drive as one single physical drive.

6.2 How Does the RAID Controller Work?


6.2.1 SCSI Channel, SCSI ID and LUN

A SCSI channel (SCSI bus) can connect up to 15 devices (the SCSI controller itself excluded) when the Wide function is enabled (16-bit SCSI). It can connect up to 7 devices (the SCSI controller itself excluded) when the Wide function is disabled (8-bit SCSI). Each device has one unique SCSI ID. Two devices having the same SCSI ID is not allowed.




The figure on the left illustrates this. To file a document into a cabinet, you must put the document into one of the drawers. Let's apply this metaphor to SCSI: the SCSI ID is the cabinet, and the drawers are the LUNs (LUN is short for logical unit number.) Each cabinet (SCSI ID) can have up to 32 drawers (LUNs). Data can be stored into one of the LUNs of the SCSI ID. Most SCSI host adapters treat a LUN like another SCSI device.


6.2.2 Understanding Step by Step



The physical connection should be similar to the one shown above. Install the ASUS PCI-DA2100/-DA2200 RAID controller into a vacant PCI slot in the host system, connect the drives to the SCSI channels on the ASUS PCI-DA2100/-DA2200.


A Logical Drive consists of a group of SCSI drives. Drives in one logical drive do not have to come from the same SCSI channel. Also, each logical drive can be configured a different RAID level.






A drive can be assigned as the Local Spare Drive of one specified logical drive, or as a Global Spare Drive.

You may divide a logical drive into several partitions, or use the entire logical drive as one single partition.



Map each partition to the host SCSI ID. Each SCSI ID will act as one individual hard drive to the host computer virtually.



This page is left intentionally blank.

Chapter 7 BIOS Configuration Utility

At system bootup, the ASUS PCI-DA2100/-DA2200 BIOS displays the following message:

```
ASUS PCI-DA2100/-DA2200 (PCI-TO-SCSI RAID) BIOS v1.17B
PCI Bus # = 00      Device # = 09  Port = E000  IRQ = 10  EDORAM=8 MB  FW=2.12
!! Press <Ctrl><I> for Configuration Utility, <Q> to Skip !!
```

PCI Bus#, Device #:

displays the PCI bus and PCI device number that has been assigned to ASUS PCI-DA2100/-DA2200. The numbers are in hexadecimal.

Port : shows the I/O port base address that has been assigned to ASUS PCI-DA2100/-DA2200.

IRQ : shows the Interrupt level that has been assigned to ASUS PCI-DA2100/-DA2200. The level is in decimal.

EDORAM : displays the cache RAM type and size that is been installed on ASUS PCI-DA2100/-DA2200.


FW : shows the firmware version number of ASUS PCI-DA2100/-DA2200.

The ASUS PCI-DA2100/-DA2200 BIOS waits 3 seconds for a keystroke. You can press **[Ctrl-I]** to enter the configuration utility, or press **Q** to skip waiting for a keystroke.


If **[Ctrl-I]** is pressed to enter configuration utility, the main menu will appear. There are two functions in the main menu: Configuration and Color/Monochrome.

7.1 Configuration

There are five functions in the Configuration Option: Configure BIOS, Configure Card, Configure SCSI, Configure RAID and Reset to Defaults.



7.1.1. Configure BIOS



Move the cursor to the item desired to change.

Enable BIOS INT 13H Function

Press [Space] to toggle between Yes or No.

BIOS Translation Mode

Press [Space] to toggle between Auto and Fixed. Use fixed mode together with disabling "Support for Disks > 1GB" for UNIX/DOS or UNIX/OS2 dual boot system. Use Auto mode for other OS'.

Auto mode :

BIOS detects the existing CHS mapping from the disk.

If any valid CHS mapping is found, BIOS uses it.

If no valid CHS mapping is found, BIOS uses Fixed mode.

Fixed mode :

If option "Support for Disks > 1 GB" is disabled, BIOS uses SectorsPerTrack = 32, TotalHeads = 64.

If option "Support for Disks > 1 GB" is enabled, For disk size <= 1GB, BIOS uses SectorsPerTrack = 32, TotalHeads = 64. For disk size > 1GB, BIOS uses SectorsPerTrack = 63, TotalHeads = 255.

Support for Disk > 1 GB

Press <Space> to toggle between Yes or No.

Support for 3 Disks or More (MS-DOS v5.0 or Above)

For MS-DOS version below 5.0, only supports up to 2 disks, don't set this option to "Yes" on such versions DOS system.

Support for NOT-ZERO SCSI LUN

Set this option to "Yes", if you want the BIOS to support all SCSI Target LUNs, 0 to 7.

Configure BIOS Devices

Logical Device SCSI ID	#0	#1	#2	#3	#4	#5	#6	#7
Scanned By BIOS	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Logical Device SCSI ID	#8	#9	#10	#11	#12	#13	#14	#15
Scanned By BIOS	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

If this option is selected, a status list of SCSI devices scanned by BIOS at BIOS initialization will appear. If a SCSI device is not scanned by BIOS, then it will not be installed by BIOS.


7.1.2. Configure Card

ISA Emulation Mode IO Port Address	Disabled
Disk Access Delay on Power-up (Sec)	15


ISA Emulation Mode

If you are going to use ASUS PCI-DA2100/-DA2200 device driver distributed by Infortrend, you MUST set the IO port address to "Disabled". You can select an IO Port address from a list by pressing [Enter].

7.1.3. Configure SCSI



If this option is selected, a list of physical SCSI channels will appear. Select a SCSI channel that you want to configure, then a new dialog box of SCSI Channel Configuration will appear.

**SCSI ID**


Use this option to change SCSI ID of SCSI Channel.

Enable SCSI Termination

Use this option to enable/disable SCSI termination.

Configure SCSI Devices

Use this option to change the low-level SCSI features of SCSI devices.



Please refer to Appendix D, *Sync. Clock Period & Sync. Clock Frequency*, for the Sync. Transfer Period calculation.


Enable Wide SCSI

Use this option to enable/disable wide SCSI.

7.1.4 Configure RAID

Configuration	Color/Monochrome
Configure BIOS	
Configure Card	
Configure SCSI	
Configure RAID	
Reset to Defaults	

Selecting this option starts the BIOS RAID Manager. The utility is identical in appearance and features to the Text RAID Manager. See chapter 8, *Text RAID Manager User Interface*, for complete details on the use of the BIOS RAID Manager.



7

7.1.5 Reset to Defaults

If this option is selected, all the configurations are reset to the manufacturer's defaults.

7.2 *Color/Monochrome*

Switches display mode between color and monochrome.


Chapter 8 Text RAID Manager User Interface

To operate Text RAID Manager, simply put the ASUS PCI-DA2100/-DA2200 driver diskette into your floppy disk drive. Change the directory to RAIDMAN. You will see directories for various operating systems. Change to the directory that corresponds to your operating system. For Windows® 95/98, Windows NT® and MS-DOS®, the program is called RAIDMAN.EXE. For NetWare®, the program is called RAIDMAN.NLM. Run the program.

In addition, all of the functions of the Text RAID Manager are available from a BIOS configuration utility. For complete instructions on starting the *BIOS RAID Manager*, please see section 7.1.4.

8.1 The Main Menu

8.1.1 The Initial Screen




- Cursor Bar:** Move the cursor bar to a desired item, then press **[Enter]** to select.
- Controller Name:** Identifies the type of controller.
- Transfer Rate Indicator:** Indicates the current data transfer rate.

8

- Gauge Range:** Use + or - keys to change the gauge range in order to view the transfer rate indicator.
- Cache Status:** Indicates the current cache status.
- PC Graphic (ANSI Mode):** Enters the Main Menu and operates in ANSI mode.
- Terminal (VT-100 Mode):** Enters the Main Menu and operates in VT-100 mode.
- PC Graphic (ANSI+Color Mode):** Enters the Main Menu and operates in ANSI color mode.
- Show Transfer Rate+Show Cache Status:** Press ENTER on this item to show the cache status and transfer rate.

8.1.1 Main Menu



Use the arrow keys to move the cursor bar through the menu item, then press **ENTER** to choose a menu, or **ESC** to return to the previous menu/screen.

8.1.3 Logical Drive's Status

Q	LG	RAID	Size (MB)	Status	0	#LN	#SB	#FL	NAME
▼	0	RAID5	2400	GOOD	R	3	0	0	
▼	1	NONE							
▼	2	NONE							
▼	3	NONE							
▼	4	NONE							
▼	5	NONE							
▼	6	NONE							
▼	7	NONE							

Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

LG Logical Drive number.

RAID RAID Level.

Size(MB) Capacity of the Logical Drive.

Status Logical Drive Status.

INITING The logical drive is now initializing.

INVALID The logical drive was created with “Optimization for Sequential I/O”, but the current setting is “Optimization for Random I/O”.

Or

The logical drive was created with “Optimization for Random I/O”, but the current setting is “Optimization for Sequential I/O”.


GOOD The logical drive is in good condition.

8

DRV FAILED	A drive member failed in the logical drive.
REBUILDING	Rebuilding the logical drive.
DRV ABSENT	One of the drives cannot be detected.
INCOMPLETE	Two or more drives failed in the logical drive.

#OnLine	Total drive members in the logical drive.
#STB	Standby drives available for the logical drive. This includes all the spare drives available for the logical drive.
#Fail	Failed drive member in the logical drive.
Name	Logical drive name.

8.1.4 SCSI Drive's Status




Slot	Slot number of the SCSI drive.
Chl	The SCSI Channel of the connected drive.

ID	The SCSI ID of the drive.
Size (MB)	Drive Capacity.
Speed	xxMB The maximum sync. transfer rate of this drive.
	Async The drive is using asynchronous mode.
LG_DRV	x The SCSI drive is a drive member of logical drive x. If the Status column showed “STAND-BY”, the SCSI drive is a Local Spare Drive of logical drive x.
	Global The SCSI drive is a Global Spare Drive.
Status	INITING Processing initialization.
	ON-LINE The drive is in good condition.
	REBUILD Processing Rebuild.
	STAND-BY Local Spare Drive or Global Spare Drive. The Local Spare Drive’s LG_DRV column will show the logical drive number. The Global Spare Drive’s LG_DRV column will show “Global”.
	NEW DRV The new drive has not been configured to any logical drive or as a spare drive.
	USED DRV The used drive has not been configured to any logical drive or as a spare drive.
	BAD Failed drive.
	ABSENT Drive does not exist.
	MISSING Drive once exist, but is missing now.
	SB-MISS Spare drive missing.
Vendor / Product ID	The vendor and product model information of the drive.

8

8.1.5 SCSI Channel's Status



Chl The SCSI channel's ID.

(ID number) The Primary Controller is using the SCSI ID for LUN mapping.

NA No SCSI ID applied (Drive Channel mode only).

DefSynClk Default SCSI bus sync clock:


??M The default setting of the SCSI channel is ??? Mhz in Synchronous mode.

Async The default setting of the SCSI channel is Asynchronous mode.

DefWid Default SCSI Bus Width:

	Wide	16-bit SCSI
	Narrow	8-bit SCSI
Term	Terminator Status:	
	On	Terminator is enabled.
	Off	Terminator is disabled.
CurSynClk	Current SCSI bus sync clock:	
	???.?M	The default setting of the SCSI channel is ??? Mhz in Synchronous mode.
	Async	The default setting of the SCSI channel is Asynchronous mode.
	<i>(empty)</i>	The default SCSI bus sync clock has changed. Reset the system for the changes to take effect.
CurWid	Current SCSI Bus Width:	
	Wide	16-bit SCSI
	Narrow	8-bit SCSI
	<i>(empty)</i>	The default SCSI bus width has changed. Reset the controller for the changes to take effect.

8.1.6 Viewing the Current Setting of Each Function




Most of the current settings of each function can be viewed in the menu.

In the example shown above:

- The current setting of “Write-Back Cache” is “Enabled”.
- The current setting of Optimization is “Optimization for Random I/O”.

IMPORTANT: Write-Back Cache is normally Enabled to increase performance. Write-Back Cache must be “Disabled” (to use write-through) when installing operating systems that automatically restarts the system during installation such as Microsoft Windows 95/98. Data in the cache may be cleared before writing to disk, thus resulting in data loss. Once the operating system is fully installed, the cache will be instructed to be written to disk before restarting or shutting down through the operating system.

WARNING: Using hardware restart or shut down (using buttons or switches on the chassis) will result in data loss if write-back cache is “Enabled.”




In the example shown above:


- The current setting of “SCSI Motor Spin-Up” is “Disabled”.
- The current setting of “SCSI Reset at Power-Up” is “Enabled”.
- The current setting of “Disk Access Delay Time” is “15 seconds”.
- The current setting of “Maximum Tag Count” is “32”.

8.2 Viewing and Editing Logical Drives


8.2.1 Creating a Logical Drive



Choose “View and Edit Logical Drives” in the Main Menu. The current logical drive configuration and status will be displayed on the screen. Choose a logical drive number that has not yet been defined, then press **[Enter]**. A prompt “Create Logical Drive?” will appear. Select “**Yes**” and press **[Enter]**.




A list of supported RAID levels will appear. Choose a RAID level for this logical drive.



8

The drives can be tagged for inclusion by positioning the cursor on the drive and then pressing [Enter] to select. An asterisk (*) will appear on the drive that has been selected. Press [ESC] when done.




To limit the capacity of each drive included in the logical drive, select “Maximum Drive Capacity”, and then enter the maximum capacity that will be used by each drive.


You can assign a Local Spare Drive by choosing “Assign Spare Drives” in the above screen. A list of available drives will be displayed on the screen. Mark an asterisk (*) on the drive(s) that will be assigned by moving the cursor bar to that device, then pressing [Enter]. Press [ESC] when done.

To exit this menu, press [ESC].

A prompt to confirm the changes will appear. Select **Yes** to create the logical drive, or **No** to cancel.




When a fault-tolerant RAID level (1, 3 or 5) has been selected, the controller will start initializing parity. A progress indicator will be displayed on the screen. After initialization is done, the created logical drive is also complete.



8.2.2 Viewing Logical Drives and Drive Members

Choose “View and Edit Logical Drives” in the Main Menu. The current logical drive configuration and status will be displayed on the screen. Refer to section 8.1.2, *Logical Drive’s Status*, for detailed descriptions.


To view the SCSI drive members of the logical drive, choose the logical drive by pressing [**Enter**].



Choose “View SCSI Drives”. The member drive information will be displayed on the screen. Refer to section 8.1.3, *SCSI Drive’s Status*, for the detailed descriptions of each item.


8.2.3 Deleting a Logical Drive

Choose the logical drive you wish to delete, then press **[Enter]**. Choose “Delete logical drive”. Choose **Yes** when prompted to confirm.




8.2.4 Partitioning a Logical Drive


Choose the logical drive you wish to partition, then press **[Enter]**. Choose “Partition logical drive”, then press **[Enter]**. Choose **Yes** to confirm.



The screen will display a partition table of up to 8 partitions with the last partition selected. Press **[Enter]** and type the desired size for the selected partition, then press **[Enter]**. The remaining size will be allotted to the next partition.




8.2.5 Deleting a Partition of a Logical Drive



Choose the logical drive of the partition you wish to delete, then press **[Enter]**. Choose "Partition logical drive". The current partition table of the logical drive will be displayed in tabulated form. Move the cursor bar to the partition you wish to delete, then press **[Enter]**. Enter "0" on the partition size to delete this partition.


The capacity of the deleted partition will be added into the last partition.



IMPORTANT:


- The capacity of the deleted partition will be added into the last partition.
- As long as a partition has been changed, it is necessary to re-configure all LUN mappings. All the LUN mappings will be removed with any partition change.

8.2.6 Assigning a Logical Drive Name




Choose the logical drive you wish to assign a logical drive name, then press **[Enter]**. Choose “logical drive name”, then press **[Enter]** again. The current logical drive name will be displayed on the screen. You may now enter the new logical drive name in this field. Enter the logical drive name, then press **[Enter]** to save the new name.

8.2.7 Rebuilding Logical Drive




Choose the logical drive that has a failed member drive, then press **[Enter]**. Choose “Rebuild logical drive”, then press **[Enter]**. When prompted with “Rebuild Logical Drive?”, select **Yes**. The rebuilding progress will be displayed on the screen.



8

When rebuilding has already started or the logical drive has been automatically rebuilt by a Local Spare Drive or Global Spare Drive, choose “Rebuild progress” to view the rebuilding progress.




IMPORTANT:


- The Rebuild function will appear only when a logical drive (with RAID level 1, 3 or 5) has a failed drive member.
- Refer to “3.2.3 Automatic Rebuild and Manual Rebuild” for more information.

8.2.8 Dynamic Logical Drive Expansion

From the main menu, select “View and Edit Logical Drives.” The logical drive that you wish to expand will be displayed. Move the cursor to that logical drive (if there is more than one) and press **[Enter]** to select it.




Before the logical drive can be expanded, a SCSI drive (or drives) must be added and scanned in (See section 8.4.1 for details on scanning in a SCSI drive). Use the arrow keys to select “Add SCSI Drives,” and then press **[Enter]**. SCSI drives that are available for ‘adding’ will be displayed. Select drives by highlighting them and then pressing **[Enter]**. An asterisk [*] is displayed by each drive selected. When you are finished selecting, press **[Esc]** to confirm.




8

You will be prompted to confirm that you would like to add the SCSI drives to the logical drive.



A bar will appear displaying the progress of adding the SCSI drives




IMPORTANT:


- Mode 1 Expansion can only be performed on RAID 0, 3 and 5 logical drives. Mode 1 Expansion cannot be performed on an NRAID or RAID 1 logical drive.
- Mode 1 Expansion (Expanding logical drives by adding more SCSI hard disk drives) cannot be canceled once started. If a power failure occurs, the Mode 1 Expansion will be paused and the controller will NOT automatically continue the expansion when the power comes back on. Resumption of the RAID expansion must be performed manually.
- If a member drive of the logical drive fails during RAID expansion, the Mode 1 expansion will be paused. The expansion will resume automatically after logical drive rebuild has been completed.

8.3 Viewing and Editing SCSI ID Map


8.3.1 Mapping a Logical Drive to an ID/LUN




Choose “View and Edit SCSI ID Map” in the Main Menu, then press [Enter]. When prompted to “Map Logical Drive?”, select **Yes**.




Choose the SCSI ID you wish to map, then press **[Enter]**.




A list of LUNs and their respective mappings will be displayed on the screen. To map a LUN to a logical drive's partition, select an available LUN (one not mapped yet) by moving the cursor bar to the LUN, then pressing **[Enter]**.



A list of available logical drives will be displayed on the screen. Move the cursor bar to the desired logical drive, then press **[Enter]**.




A partition table of the logical drive will be displayed on the screen. Move the cursor to the desired partition, then press **[Enter]**.



The prompt shown above will display the mapping you wish to create. Choose **Yes** to create the LUN mapping you selected. In the example above, partition 3 of logical drive 0 will map to LUN 0 of SCSI ID 3 on channel 0.


8.3.2 Viewing and Deleting the LUN Mappings

Choose the channel and SCSI ID of the LUN mapping you wish to view or delete.




A list of the current LUN mapping will be displayed on the screen. Move the cursor bar to the LUN mapping you wish to delete, then press **[Enter]**. Select **Yes** to delete the LUN mapping, or **No** to cancel.

8.4 Viewing and Editing SCSI Drives




Choose "View and Edit SCSI Drives" in the Main Menu. All drives attached to the drive channels will be displayed on the screen. Refer to "8.1.4 SCSI Drive's Status" for detailed descriptions of each column.

8.4.1 Scanning a New SCSI Drive




Choose a drive and press **[Enter]**. Choose "Scan SCSI drive", then press **[Enter]**. The menu may vary according to the drive status. Choose the drive channel and SCSI ID of the drive you wish to scan, then press **[Enter]**.

8.4.2 Viewing Drive Information




Choose the SCSI drive you wish to view, then press **[Enter]**. Select “View drive information”. The revision number, serial number and disk capacity (counts in block; one block refers to 512K) of the drive will be displayed on the screen.

8.4.3 Adding a Local Spare Drive



Move the cursor bar to the SCSI drive that has not yet been assigned to a logical drive or as a spare drive, then press **[Enter]**. Choose “Add Local Spare Drive”. A list of available logical drives will be displayed on the screen. Move the cursor bar to a logical drive, then press **[Enter]**. The unassigned SCSI drive will be assigned to this logical drive as the Local Spare Drive. When prompted with “Add Local Spare Drive?”, choose **Yes**.


8.4.4 Adding a Global Spare Drive




Move the cursor bar to the SCSI drive that has not yet been assigned to a logical drive or as a spare drive, then press **[Enter]**. Choose “Add Global Spare Drive”. When prompted with “Add Global Spare Drive?”, choose **Yes**.

8.4.5 Deleting a Spare Drive (Global / Local Spare)


Move the cursor to a Local Spare Drive or Global Spare Drive, then press **[Enter]**. Choose “Delete Global/Local Spare Drive”, then press **[Enter]** again. Choose **Yes**.



8.5 Viewing and Editing SCSI Channels



Choose “View and Edit SCSI Channels” in the Main Menu. A list of all the channels will be displayed on the screen. Refer to section 8.1.4, *SCSI Channel Status*, for detailed information.




8.5.1 Viewing and Editing a SCSI ID / Channel

Choose a channel, then press **[Enter]**. Choose “SCSI ID”. A list of the existing ID(s) will be displayed on the screen.

IMPORTANT:

Any changes to SCSI ID/channel settings require a system reset to take effect.

8.5.2 Setting a SCSI Channel’s Terminator




Choose the channel you wish the terminator enabled or disabled, then press **[Enter]**. Choose “SCSI Terminator”, then press **[Enter]**. A dialog box will appear. Choose **Yes**, then press **[Enter]**.

IMPORTANT:

Every time you change a SCSI channel's termination, you must reset the system for the changes to take effect.

8.5.3 Setting a Transfer Speed




Move the cursor bar to a channel, then press **[Enter]**. Choose “Sync Transfer Clock”, then press **[Enter]**. A list of the clock speed will appear. Move the cursor bar to the desired speed and press **[Enter]**. A dialog box “Change Sync Transfer Clock?” will appear. Choose **Yes**.

IMPORTANT:

- *Every time you change the SCSI Transfer Speed, you must reset the system for the changes to take effect.*

8.5.4 Setting a Transfer Width




Move the cursor bar to a channel, then press **[Enter]**. Select “Wide Transfer”, then press **[Enter]**. A dialog box “Disable Wide Transfer?” or “Enable Wide Transfer?” will appear. Choose **Yes**.


IMPORTANT:

- *Every time you change the SCSI Transfer Width, you must reset the system for the changes to take effect.*

8.5.5 Viewing and Editing SCSI Target / Drive Channel



Move the cursor bar to a Drive channel, then press **[Enter]**. Select “View and Edit SCSI Target”, then press **[Enter]**.



8

A list of all the SCSI targets and their current settings will appear. Press [Enter] on a SCSI target and a menu list will appear on the screen.

Slot Number


The screenshot shows the RAIDMAN utility window. At the top, there is a title bar with the text "RAIDMAN" and standard window controls. Below the title bar is a toolbar with icons for "Auto", "Refresh", "Save", "Add", "Delete", "Print", and "Help". The main area displays a table of SCSI targets with columns: Slot, Chl, ID, SyncClk, XfrWid, ParityChk, Disconnect, and TagCount. A context menu is open over the first row (Slot 0, Chl 0), listing options: "Slot number", "maximum sync. xfer Clock", "maximum xfer Width", "Parity check", "Disconnect support", "maximum Tag count", and "Restore to default setting". The "Slot number" option is highlighted. At the bottom of the window, a status bar shows keyboard shortcuts: "Arrow Keys:Move Cursor", "|Enter:Select", "|Esc:Exit", and "|Ctrl+L:Refresh Screen".

Slot	Chl	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount
	0	0	12	Wide	Enabled	Enabled	Def(32)
					bled	Enabled	Def(32)
					bled	Enabled	Def(32)
					bled	Enabled	Def(32)
					bled	Enabled	Def(32)
	0	5	12	Wide	Enabled	Enabled	Def(32)
	0	6	12	Wide	Enabled	Enabled	Def(32)
	0	8	12	Wide	Enabled	Enabled	Def(32)

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Slot Number is reserved from use.


Maximum Synchronize Transfer Clock



Choose “Maximum Sync. Xfer Clock”, then press **[Enter]**. A dialog box will appear on the screen. Enter the clock, then press **[Enter]**.


Please refer to Appendix D, Sync. Clock Period and Sync. Clock Frequency, for more information.

Wide Transfer




Choose “Wide Transfer”, then press **[Enter]**. Choose **Yes** in the dialog box to confirm the setting.

Parity Check



Choose “Parity Check”. Choose **Yes** in the dialog box that followed to confirm the setting.

Disconnecting Support




Choose “Disconnect Support”. Choose **Yes** in the dialog box that followed to confirm the setting.

SCSI I/O Timeout



Choose “SCSI I/O Timeout”, then press **[Enter]**. A list of available timeout intervals will appear. Move the cursor bar to an interval, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting.

Tag Command Queuing




Choose “Maximum Tag Count”, then press **[Enter]**. A list of available tag count numbers will appear. Move the cursor bar to a number, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting.

IMPORTANT:

- *Disabling the Maximum Tag Count will disable the internal cache of the SCSI drive.*
- *Disabling Tag Command Queuing will disable the Write-Back cache built in the hard drive.*

Idle Drive Failure Detection



From the "Drive-side SCSI Parameters" menu, select "Periodic Drive Time - Disable" and then press **[Enter]**. Choose the desired interval for idle drive failure detection.

IMPORTANT:


- *By choosing a time value to enable the "Periodic Drive Check Time", the controller will poll all of the connected drives in the controller's drive channels at the assigned interval. Drive removal will be detected even if a host does not attempt to access data on the drive.*
- *If the "Periodic Drive Check Time" is set to "Disabled" (the default setting is "Disabled"), the controller will not be able to detect any drive removal that occurs after the controller has been powered on. The controller will only be able to detect drive removal when a host attempts to access the data on the drive.*

SAF-TE Enclosure Monitoring




From the “Drive-side SCSI Parameters” menu, select “Periodic SAF-TE Device Check Time – Disabled” and then press **[Enter]**. Use the arrow keys to choose the desired SAF-TE status check interval.

Detection of Drive Hot Swap Followed by Auto Rebuild



From the "Drive-side SCSI Parameters" menu, select "Periodic Auto-Detect Failure Drive Swap Check Time - Disabled" and then press **[Enter]**. Use the arrow keys to select the desired interval for "Auto Checking Drive Hot Swap," and then press **[Enter]** to confirm. If a member drive of a logical drive fails, the controller will start to check the failed drive to check if it has been replaced (i.e., the controller checks the same drive channel and ID at the assigned interval.) Once the drive has been replaced with another drive, the controller will automatically start to rebuild to that replacement drive.

Restoring the Default Setting for Target




Choose “Restore to default setting”, then press [Enter]. Choose Yes in the dialog box that followed to restore all the settings of the SCSI target.

8.6 Viewing and Editing Configuration Parameters

8.6.1 Caching Parameters

Write-Back Cache Enable/Disable




Choose “Caching Parameters”, then press **[Enter]**. Select “Write-Back Cache”, then press **[Enter]**. “Enabled” or “Disabled” will display the current setting of the Write-Back Cache. Choose **Yes** in the dialog box that followed to confirm the setting.

IMPORTANT:

- *Every time you change the Cache Parameters, you must reset the system for the changes to take effect.*

Optimization for Random or Sequential I/O




Choose “Optimization for Random I/O” or “Optimization for Sequential I/O”, then press **[Enter]**. The “Random” or “Sequential” dialog box will appear, depending on the option you have selected. Choose **Yes** in the dialog box that followed to confirm the setting.

IMPORTANT:

- *Every time you change this setting, you must reset the system for the changes to take effect.*
- *Refer to “3.4.1 Optimal for Sequential or Random I/O” for more information.*


8.6.2 SCSI Parameters

Maximum Queued I/O Count




Choose “SCSI Parameters”, then press **[Enter]**. Choose “Maximum Queued I/O Count”, then press **[Enter]**. A list of available selections will appear. Move the cursor bar to an item, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting.

8.6.3 Drive-side SCSI Parameters




Choose “Drive-side SCSI Parameters”, then press **[Enter]**. The Drive-side SCSI parameters menu will appear.

SCSI Motor Spin-Up




Choose “SCSI Motor Spin-Up”, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting.

SCSI Reset at Power-Up




Choose “SCSI Reset at Power-Up”, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting. Please refer to section 3.5.2 for more information.

Disk Access Delay Time




Choose “Disk Access Delay Time”, then press **[Enter]**. A list of selections will appear. Move the cursor bar on a selection, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting. Please see section 3.5.3 for more information.

Maximum Tag Count




Choose “Maximum Tag Count”, then press **[Enter]**. A list of selections will appear. Move the cursor bar to a selection, then press **[Enter]**. Select **Yes** in the dialog box that followed, then press **[Enter]** to confirm the setting. Please see section 3.5.5 for more information.

8.6.4 Disk Array Parameters



Choose “Disk Array Parameters”, then press **[Enter]**. The Disk Array Parameters menu will appear.

Rebuild Priority



Choose “Rebuild Priority”, then press **[Enter]**. A list of the priority selections will appear. Move the cursor bar to a selection, then press **[Enter]**. Please see section 3.3.1 for more information.

Verification On Writes




Choose “Verification on Writes”, then press **[Enter]**. Move the cursor bar to an item, then press **[Enter]**. Choose **Yes** in the dialog box that followed to confirm the setting. (Refer to section 3.3.2 for more information.)

IMPORTANT:

- Every time you change this setting, you must reset the system for the changes to take effect.
- Refer to “3.5.2 SCSI Reset at Power-Up” for more information.

8.6.5 Controller Parameters

Controller Name




Choose “Controller Parameters”, then press **[Enter]**. The current controller name will be displayed. Press **[Enter]**. Enter the new controller name in the dialog box that followed, then press **[Enter]**.

Password Validation Timeout




From the “Controller Parameters” menu, select “Password Validation Timeout” and then press **[Enter]**. You may select an interval for password validation, “Always check,” or “Disabled.” Press **[Enter]** and then select **Yes** to confirm your selection.

8.6 System Functions




Choose “System Functions” in the Main Menu, then press [**Enter**]. The System Functions menu will appear. Move the cursor bar to an item, then press [**Enter**].

8.7.1 Mute Beeper



When the controller's beeper has been activated, choose "Mute beeper", then press **[Enter]**. Choose "Yes" and press **[Enter]** in the next dialog box to turn the beeper off temporarily. The beeper will still activate on the next event.

8.7.2 Change Password



Use the controller's password to protect the controller from unauthorized entry. Once the controller's password has been set, regardless of whether the Text RAID Manager or the GUI RAID Manager is used, the user can only configure and monitor the RAID controller by providing the correct password.

IMPORTANT:

- The controller will verify the password only when entering the Main Menu from the Initial screen. Always go back to the Initial screen when the controller is going to be unattended.
- The controller password and controller name are sharing a 16-character space. The maximum characters for the controller password is 15. When the controller name occupied 15 characters, there is only one character left for the controller password and vice versa.

8

Changing the Password


To set or change the controller password, move the cursor bar to “Change Password”, then press **[Enter]**.

If a password has previously been set, the controller will ask for the old password first. If the password has not yet been set, the controller will directly ask for the new password. The password can not be replaced unless a correct old password is provided.

Key-in the old password, then press **[Enter]**. If the password is incorrect, it will not allow you to change the password. Instead, it will display the message “Password incorrect!”, then go back to the previous menu.

If the password is correct, or there is no preset password, it will ask for the new password.

Setting a New Password




Enter the desired password in the column, then press **[Enter]**. The next dialog box will display “Re-Enter Password”. Enter the password again and press **[Enter]**.

The new password will now become the controller's password. Providing the correct password is necessary when entering the Main Menu from the Initial screen.

Disabling the Password

To disable or delete the password, press **[Enter]** only in the password column that is used for entering a new password. The existing password will be deleted. No password checking will occur when entering the Main Menu from the Initial screen.


8.7.3 Reset Controller



This function is not supported. The controller is reset when the system is reset.


8

8.7.4 Shutdown Controller




This function is not supported. The controller is shutdown when the system is shutdown.

8.7.5 Controller Maintenance



This function is not supported from within the Text RAID Manager. Controller maintenance functions – such as downloading new firmware – can be performed from the start-up menu of the Text RAID Manager.

8.8 Viewing System Information



To view the system's information, move the cursor bar to "View System Information", then press [Enter].


A list of information will appear.

CPU Type	The type of CPU installed in the RAID controller.
Total Cache Size	The total DRAM size installed in the controller.
Firmware Version	The version of the firmware.
Bootrecord Version	The version of the boot record.
Serial Number	The serial number of the controller.

Chapter 9 Remote Administration


The ASUS PCI-DA2100/-DA2200 RAID Controller can be administrated remotely. When there is an event, warning or controller notification happened, the ASUS PCI-DA2100/-DA2200 can inform the administrator to take measure in time.

9.1 GUI RAID Manager Using SNMP Service




Install the SNMP agent for the corresponded operating system on Host computer and enable the SNMP service. The client computer running with GUI RAID Manager will be able to administrate the ASUS PCI-DA2100/-DA2200 RAID Controller remotely.

How to establish the connection through SNMP?



Choose the “File” menu, click on “Connect” and choose “SNMP” from the pop up menu.




The image shows a dialog box titled "Settings of SNMP Interface". It contains the following fields and options:

- Agent Name or IP Address : [Empty text box]
- Community Name : [public]
- Agent-side Communication Type:
 - RS-232 Interface
 - COM Port # : [COM2]
 - BaudRate : [9600]
 - Host Bus Interface
 - Controller Index : [0]

At the bottom of the dialog box are two buttons: "OK" and "Cancel".

Enter the Agent name or the IP address and the Community name of the host computer in the first column.



Click on the select button in front of “Host Bus Interface” to select. Choose “0” if there is only one ASUS PCI-DA2100/-DA2200 RAID controller installed in the remote host computer. Press “OK” to establish the connection. After the connection established, all the operation will act exactly the same as executing the GUI RAID Manager from the host computer.

The “Controller Index” refers to the number of the ASUS PCI-DA2100/-DA2200 be found by the host computer. If there is only one controller installed in the host computer, “0” should be chosen. When more than one ASUS PCI-DA2100/-DA2200 RAID controller installed in the same host computer, the second ASUS PCI-DA2100/-DA2200 controller found by the host computer is numbered as “1”, and the third controller found by the host computer is numbered as “2”.

This page is left intentionally blank.

Appendix A Driver Installation

WARNING:

There are a few operating systems that will perform a system reset automatically during installation. The default setting of the ASUS PCI-DA2100/-DA2200 RAID controller is "Write-back Cache – Enabled." If the system resets while there is still data in the cache, the cache data will be cleared. What does all this mean? The system reset during installation will prevent OS installation from completing, since data in the write-back cache gets cleared before it has been written to the SCSI drives. So, it is recommended to "Disable" the write-back cache (i.e., use write-through mode) prior to OS installation. Following OS installation, the setting can be switched back to "Write-back Cache – Enabled." Please see section 8.6.1, Caching Parameters, for details on how to disable the write-back cache.

1 MS-DOS[®] ASPI Drivers Installation

The ASUS PCI-DA2100/-DA2200 can be used as a host adapter for SCSI tape drives and CD-ROM drives. To access such devices under MS-DOS, it is necessary to install the ASUS PCI-DA2100/-DA2200 MS-DOS ASPI Manager device driver.

The ASUS PCI-DA2100/-DA2200 MS-DOS ASPI Manager allows MS-DOS/Windows applications and OS Installation Programs to access CD-ROM drives or SCSI tape drives that are connected to and properly configured under the ASUS PCI-DA2100/-DA2200. The ASUS PCI-DA2100/-DA2200 MS-DOS ASPI Manager and CD-ROM Driver are installed as device drivers under MS-DOS by adding the following command lines to the CONFIG.SYS and AUTOEXEC.BAT files in the root directory of the boot drive:

In CONFIG.SYS file

```
DEVICE=[path1]DA2000.SYS  
DEVICE = [path1]ASPICDRM.SYS /d:[driver signature]  
LASTDRIVE = [logical drive]
```

In AUTOEXEC.BAT file

```
[path2]MSCDEX /d:[driver signature]
```

Appendix A

where:

[path1] - A complete DOS path string including logical drive identifier and subdirectories indicating where the file DA2000.SYS can be found.

[path2] - A complete DOS path string including logical drive identifier and subdirectories indicating where the Microsoft® CD-ROM extension program MSCDEX.EXE can be found.

[driver signature] - The signature for CD-ROM driver, the driver signature specified in CONFIG.SYS must match the driver signature specified in AUTOEXEC.BAT mscdex command.

[logical drive] - The next alphabet of the last logical drive been assigned to hard disk drives.

Example:

If there is a subdirectory, C:\ASUS, containing the ASUS PCI-DA2100/-DA2200 ASPI Manager file DA2000.SYS and CD-ROM Driver file ASPICDRM.SYS, a subdirectory, C:\DOS, containing the Microsoft CD-ROM extension program MSCDEX.EXE, and MS-DOS logical drives C: and D: have been assigned to hard disks, then the following lines should be added to the CONFIG.SYS and AUTOEXEC.BAT files respectively:

In CONFIG.SYS file

```
DEVICE=C:\ASUS\DA2000.SYS  
DEVICE = C:\ASUS\ASPICDRM.SYS /D:mscd001  
LASRDRIVE = E
```

In AUTOEXEC.BAT file

```
C:\DOS\MSCDEX /D:mscd001
```

Note that there are no restrictions with regard to where these lines are added in the CONFIG.SYS. Also note that the ASUS PCI-DA2100/-DA2200 ASPI Manager will automatically select an optimal configuration so no load line options are needed.

The ASUS PCI-DA2100/-DA2200 ASPI Manager and CD-ROM Driver can be "loaded high" should it be desirable to conserve system

memory space below 640K. Consult the manual for the particular memory manager installed on your system for details on how to install a device driver "high".

2 NetWare[®] Driver Installation

The ASUS PCI-DA2100/-DA2200 drivers diskette contains the following driver files for NetWare v3.1x, v4.0x, v4.1 and v4.11 respectively:

In sub-directory `netware\v3_1x`:

- RAIDASPI.DSK : ASPI manager for NetWare v3.1x
- DA2000.DDI : Installation Information File.
- DA2000.DSK : Disk Driver for NetWare v3.1x

In sub-directory `netware\v4_x`:

- RAIDASPI.DSK : ASPI manager for NetWare 4.0x, 4.1 and 4.11
- DA2000.DDI : Installation Information File.
- DA2000.DSK : Disk Driver for NetWare 4.0x, 4.1 and 4.11.

2.1 Installing NetWare 3.1x

Follow these procedures to install ASUS PCI-DA2100/-DA2200 drivers for NetWare 3.11 or 3.12.

1. Plug up to four ASUS PCI-DA2100/-DA2200 controllers into host PCI slots then power on. The ASUS PCI-DA2100/-DA2200 BIOS will show the following messages on the screen for each installed ASUS PCI-DA2100/-DA2200:

```
ASUS PCI-DA2100/-DA2200 (PCI-TO-SCSI RAID) BIOS vx.xx
PCI Bus # = 00 Device # = 0A Port = E800 IRQ = 11 EDORAM = 8MB FW=vx.xx
!! Press <Ctrl><I> for Configuration Utility, <Q> to Skip !!
```

2. Use the ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
3. Use ASUS Text RAID Manager to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200**

Appendix A

adapter and thus no logical drives or devices should be mapped to this SCSI ID.

4. Make sure the RAID configuration is properly set. (Refer to chapter 8, *ASUS Text RAID Manager User Interface*, for more information on configuring RAID).
5. Follow the instructions in the NetWare User's Manual to install the server.
6. Run the NetWare v3.11 or v3.12 SERVER.EXE program to start the server.
7. At the system console prompt, use load command to load the ASUS PCI-DA2100/-DA2200 driver by typing **load da2000.dsk** **[Enter]**
8. System console will display the following messages on the screen:

```
Loading module DA2000.DSK
ASUS PCI-DA2100/-DA2200 Disk Driver for NetWare v3.1x
Version x.xx  November 3, 1995
Auto-loading module DAASPI.DSK
DA ASPI Manager for NetWare v3.1x, v4.0x and v4.1
Version x.xx  October 27, 1995
Supported Slot values are 11
Slot: 11
```

The slot number(value) is auto-detected by the ASUS PCI-DA2100/-DA2200 driver according to which PCI slot the ASUS PCI-DA2100/-DA2200 has been plugged into. Write down the slot number for later using in STARTUP.NCF.

9. At this point, press **[Enter]**. If the ASUS PCI-DA2100/-DA2200 driver installs successfully, the system console will display the following messages on the screen:

```
PCI Bus # = 0, Device # = 9, Port = E400, IRQ = 10
DA2000 Disk Driver Installed Successfully
```

10. Load the driver "DA2000.DSK" once for each installed ASUS PCI-DA2100/-DA2200. This driver supports up to four ASUS PCI-DA2100/-DA2200 controllers.
11. After each instance of the ASUS PCI-DA2100/-DA2200 driver has been loaded successfully, continue with the operations of Novell NetWare server described in NetWare User's Manual.

Notes:

The correct syntax in STARTUP.NCF file to load the ASUS PCI-DA2100/-DA2200 drivers should resemble the following:

```
# load da2000 slot = x
```

x is the slot number of slot into which the ASUS PCI-DA2100/-DA2200 has been plugged. The slot number is auto-detected by ASUS PCI-DA2100/-DA2200 driver and shown on the system console screen during ASUS PCI-DA2100/-DA2200 driver loading.

2.2 Installing NetWare 4.0x/4.1/4.11

1. Use the ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 adapter and thus no logical drives or devices should be mapped to this SCSI ID.**
3. For installation of a new server, follow these procedures:
4. If your NetWare installation package is a CD-ROM version and the CD-ROM Drive used to perform the installation is connected to an ASUS PCI-DA2100/-DA2200 controller, make sure the ASUS PCI-DA2100/-DA2200 ASPI manager "DA2000.SYS", CD-ROM driver "ASPICDRM.SYS", and Microsoft® CD-ROM extension program "MSCDEX.EXE" are specified in the MS-DOS® files CONFIG.SYS and AUTOEXEC.BAT.
5. Plug up to four ASUS PCI-DA2100/-DA2200 controllers into host PCI slots then power on. ASUS PCI-DA2100/-DA2200 BIOS

Appendix A

will show the following messages on the screen for each installed ASUS PCI-DA2100/-DA2200 controller:

ASUS PCI-DA2100/-DA2200 (PCI-TO-SCSI RAID) BIOS vx.xx
 PCI Bus # = 00 Device # = 0A Port = E800 IRQ = 11 EDORAM = 8MB FW=vx.xx
 !! Press <Ctrl>< > for Configuration Utility, <Q> to Skip !!

6. Make sure the RAID configuration is properly set.(Refer to section 4 ASUS Text RAID Manager and RS-232 Terminal Interface Operation).
7. Change to sub-directory where the NetWare install program locate, then typing install and press Enter.

Example:

Assume the CD-ROM is mapped to MS-DOS® logical drive D, type the following at the DOS prompt:

```
CD D:\NETWARE.40\ENGLISH
install
```

8. Follow the instructions in the NetWare User's Manual until following screen appears:

NetWare Server Installation v4.x	NetWare loadable Module
----------------------------------	-------------------------

Load Disk Driver

Choose a disk driver that corresponding to the disk controller hardware in this server. Repeat this step for additional drivers.

▲	ISADISK.DSK	Novell ISADISK (AT Compatible) Driver
	MNS16S.DSK	Mountain Network Solutions, Inc - SCSI Controller Driver
	MNS8MM.DSK	Mountain Network Solutions, Inc - SCSI 8MM Device Driver
	MNSDAT.DSK	Mountain Network Solutions, Inc - SCSI DDS DAT Device Driver
▼	PM11NW40.DSK	DPT ISA SCSI HBA Driver


Use this driver with ESDI, MFM, and ST-506 drives that have adapter boards using the standard AT disk interface. The ISADISK driver can use controllers at both the primary and the secondary addresses. This allows two adapter cards to be installed in the host

Loaded Drivers


Load a disk driver listed	<Enter>	
Load a disk driver not listed	<Ins>	
Unload a disk driver		
Scroll help windows	<F5>(up) <F6>(dn)	Change lists <F2>
Help<F1>	Continue	<Alt><F10>
	<F10> Abort INSTALL	

Appendix A

9. Press **[Ins]** then wait for the following screen to appear:



10. Press **[F3]** then wait for the following screen to appear:



11. Insert the ASUS PCI-DA2100/-DA2200 Driver Diskette into floppy A: and give the ASUS PCI-DA2100/-DA2200 NetWare drivers path by typing **netware\v4.x** and press **[Enter]** then wait for the following screen to appear:

Appendix A

NetWare Server Installation v4.x	NetWare loadable Module
----------------------------------	-------------------------

Select a new disk driver to install:


DA2000.DSK	ASUS PCI-DA2100/-DA2200 PCI-TO-SCSI Disk Driver for NetWare v4.0x, v4.1
RAIDASPL.DSK	DA ASPI Manager for NetWare v3.1X, v4.0x and v4.1

This driver supports up to four ASUS PCI-DA2100/-DA2200 Controllers and multiple SCSI LUN.
When you load DA2000.DSK you have to specify which ASUS PCI-DA2100/-DA2200 controller you are loading the driver for by using the command line option 'SLOT=N'.


Loaded Drivers

Select multiple disk drivers	<F5>	
Load a driver listed	<Enter>	
Unload a driver		
Scroll help windows	<F7>(up) <F8>(dn)	Change lists <F2>
Help <F1> Previous screen	<Esc> Abort INSTALL	<Alt><F10>

12. Select DA2000.DSK as a new disk driver to install by pressing \uparrow key and pressing **[Enter]** then wait for the following screen to appear:



13. Press **[ALT] [ESC]** keys at the same time to switch to system console screen or wait for the NetWare installation program to time out. When it times out, the following screen will appear:




Appendix A

14. Press **[Enter]** to switch to system console screen.


```
LOAD C:\SERVER.40\DA2000.DSK
ASUS PCI-DA2100/-DA2200 Disk Driver for NetWare v4.0x, v4.1
  Version x.xx  October 27, 1995
  Auto-loading module DAASPI.DSK
  DA ASPI Manager for NetWare v3.1x, v4.0x and v4.1
  Version x.xx  October 27, 1995
Supported Slot values are 11
Slot: 11
```

The slot number(value) is auto-detected by the ASUS PCI-DA2100/-DA2200 driver according to which PCI slot the ASUS PCI-DA2100/-DA2200 controller been plugged into. Write down the slot number for later using in STARTUP.NCF.

15. Press **[Enter]** on system console screen



16. Press **[Enter]** to continue the installation



17. Select "Continue with installation" and press **[Enter]** to continue the installation.

Note:

The correct syntax in STARTUP.NCF file to load the ASUS PCI-DA2100/-DA2200 drivers should resemble the following:

```
# load da2000 slot = x
```

x is the slot number of slot into which where the ASUS PCI-DA2100/-DA2200 has been plugged. The slot number is auto-detected by ASUS PCI-DA2100/-DA2200 driver and shown on the system console screen during ASUS PCI-DA2100/-DA2200 driver loading.

Appendix A

3 Windows NT[®] 3.1/3.51 Driver Installation

Up to 4 ASUS PCI-DA2100/-DA2200 controllers can be installed in one computer. The following files are supplied for driver installation, to be found in the subdirectory \WINNT\V3_1 for Windows NT 3.1.

- DA2000.SYS: ASUS PCI-DA2100/-DA2200 Miniport Driver for Windows NT 3.1.
- PCIDA: Tag file for driver installation.
- OEMSETUP.INF: Information file for driver installation.
- TXTSETUP.OEM: Information file for driver installation.
- README.NT1: A text file describing the ASUS PCI-DA2100/-DA2200 miniport driver.

The following files are supplied for driver installation, they are put in the \WINNT\V3_5X subdirectory for Windows NT 3.5X.

- DA2000.SYS: ASUS PCI-DA2100/-DA2200 Miniport Driver for Windows NT 3.5X.
- PCIDA: Tag file for driver installation.
- OEMSETUP.INF: Information file for driver installation.
- TXTSETUP.OEM: Information file for driver installation.
- README.NT3: A text file describing the ASUS PCI-DA2100/-DA2200 miniport driver.

3.1 Installing Driver During WinNT 3.1/3.51 Installation

Follow these steps only if Windows NT is not installed on your computer or if you are upgrading to new version of Windows NT.

1. Use ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 controller and thus no logical drives or devices should be mapped to this SCSI ID.**

3. Prepare for the installation by using DISKCOPY (or any other disk-copy utility) to make a backup copy of ASUS PCI-DA2100/-DA2200 controller distribution diskette. If you are installing Windows NT 3.1, copy all files from \WINNT\V3_1 to root directory of the backup diskette. If you are installing Windows NT 3.5x, copy all files from \WINNT\V3_5X to root directory of the backup diskette. Use the backup copy as your working diskette.
4. If you are installing Windows NT from a floppy drive, insert the "Windows NT Disk #1" into floppy drive A. If you are installing Windows NT from a CD-ROM drive, insert the "Windows NT Setup Boot Disk" into floppy drive A.
5. Reset your computer.
6. When Prompted, select Custom Setup. If you are installing Windows NT 3.1 go to step 8.
7. Press **S** to skip mass storage devices detection.
8. Windows NT setup cannot find any adapter and displays NONE. Press **S** to specify additional SCSI controllers. From the list of SCSI adapters, select "Other (Requires disk provided by a hardware manufacturer)".
9. Insert the ASUS PCI-DA2100/-DA2200 distribution diskette into floppy drive A and press **[Enter]**. The screen displays "DA-2000 Series PCI-TO-SCSI RAID Miniport". Then, press **[Enter]** to select this driver.
10. Press **[Enter]** to continue Windows NT setup and follow the steps given in Windows NT Installation documentation.

3.2 *Installing Driver in Existing WinNT 3.1/3.51 System*

If you are adding an ASUS PCI-DA2100/-DA2200 controller to a computer that already has an ASUS PCI-DA2100/-DA2200 controller installed for Windows NT, then follow step 1 through step 2 only.

If you are adding an ASUS PCI-DA2100/-DA2200 controller to a computer that has no ASUS PCI-DA2100/-DA2200 controller installed for Windows NT, then follow all steps.

Appendix A

1. Use ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager to configure Logical Drives and SCSI Devices and map them to valid host SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 controller and thus no logical drives or devices should be mapped to this SCSI ID.**
3. Prepare for the installation by using DISKCOPY (or any other disk-copy utility) to make backup copy of ASUS PCI-DA2100/-DA2200 Controller distribution diskette. If you are installing Windows NT 3.1, copy all files from \WINNT\V3_1 to root directory of the backup diskette. If you are installing Windows NT 3.5x/4.0, copy all files from \WINNT\V3_5X to root directory of the backup diskette. Use the backup copy as your working diskette.
4. Boot Windows NT. Select the "Windows NT Setup" program from the "Main" program group.
5. Select the "Options" pull-down menu and then select "Add/Remove SCSI Adapters". The "SCSI Adapter Setup" displays a list of installed SCSI Adapters. Then select "Add" to add an ASUS PCI-DA2100/-DA2200 controllers to the list.
6. Select "OK" to make sure you want to add a SCSI adapter, "Windows NT Setup" displays "Select SCSI Adapter Option" and a list of SCSI adapters. Expand the list of SCSI adapters, select "Other (Requires disk provided by a hardware manufacturer)".
7. Insert ASUS PCI-DA2100/-DA2200 Distribution Diskette into floppy drive A and press **[Enter]**. The screen displays "DA-2000 Series PCI-TO-SCSI RAID Miniport". Then, select "OK" to select this driver, then select "Install".
8. Enter the path, normally it is A:\, to the directory with the device driver, then select "Continue". "Windows NT Setup" copies device driver to your disk and updates configuration to make new configuration take effect after system reboots.

9. Make sure the new added device driver is in the installed SCSI adapter list, then press "Close" to exit the "SCSI Adapter Setup". and then close the "Windows NT Setup" program. If you are not running Windows NT 3.1, go to step 11, or do step 10.
10. Select "Control Panel" program from "Main" program group. Select "Devices" program. A device list appears, select the ASUS PCI-DA2100/-DA2200 device, then click on the "Startup" button. Change Startup type to "System", then select "OK". Select "Close" to exit "Devices" program, then close the "Control Panel" program.
11. Shutdown Windows NT, then restart your computer. It is possible that some drive letter assignments may be different from previous configuration.

3.3 Updating Windows NT 3.1/3.51 Device Driver

1. Copy the new device driver from the distribution diskette to the directory [SystemRoot]\system32\drivers, where [SystemRoot] is the system root directory of Windows NT.

For example, if the system root directory is C:\WINNT, then type the following:

copy a:\winnt\v3_1\da2000.sys c:\winnt\system32\drivers

Skip step 2 if the version of your Windows NT is not v3.1.

2. If one of the ASUS PCI-DA2100/-DA2200 controllers control the system boot disk, use ATTRIB.EXE to disable the hidden, system and read only attributes of c:\ntbootdd.sys, then copy the same driver to c:\ntbootdd.sys and restore the attributes of c:\ntbootdd.sys.

For example,

attrib -h -r -s c:\ntbootdd.sys

copy a:\winnt\v3_1\da2000.sys c:\ntbootdd.sys

attrib +h +r +s c:\ntbootdd.sys

3. Shutdown Windows NT, then restart your computer.

Appendix A

3.4 Installing the Driver During WinNT 4.0 Installation

The following installations are covered in this section:

A. You want to first create a RAID logical drive and then install Windows NT 4.0 on it; and B. You want to install Windows NT on one of your SCSI hard disk drives. If you want to install Windows NT 4.0 on a RAID logical drive, begin at step 1 below; if you want install Windows NT 4.0 on a single SCSI hard disk drive, begin at step 10 below. (For either configuration, we assume that you have already installed the ASUS PCI-DA2100/-DA2200, attached the cable(s) to a channel(s), attached SCSI hard disk drives to the cable(s), attached the power supply cables to the drives, and then turned on the power supply for both the drives and the system.

The following files are supplied for driver installation, they are put in the \WINNT\V4_0X subdirectory for Windows NT 4.0

-DA2000.SYS: ASUS PCI-DA2100/-DA2200 Miniport Driver for Win NT 4.0

-PCIDA: Tag file for driver installation.

-OEMSETUP.INF: Information file for driver installation.

-TXTSETUP.OEM: Information file for driver installation.

-README.NT4: A text file describing the ASUS PCI-DA2100/-DA2200 miniport driver.

1. (For steps 1 through 5, it is assumed that you want to first create a RAID logical drive, and then want to install Windows NT 4.0 on that drive.) Insert the boot diskette and boot up your system. Remove the boot diskette and insert the ASUS PCI-DA2100/-DA2200 Text RAID Manager diskette.
2. At the prompt, type **A:\RAIDMAN\DOS\RAIDMAN.EXE** and then press <Enter>.
3. The ASUS Text RAID Manager should display the PCI address of the ASUS PCI-DA2100/-DA2200 RAID controller. You are prompted to select the controller. Press <Enter> to select.
4. You will see the Main Menu of the ASUS Text RAID Manager. Select View and Edit Logical Drives, and then press <Enter>. Create a logical drive and map it to a SCSI ID and LUN (see Chapter 6 for a detailed explanation.)

5. Press <Esc> and exit the ASUS Text RAID Manager. Remove the ASUS PCI-DA2100/-DA2200 driver diskette.
6. Insert the Windows NT 4.0 Installation Diskette #1. Reset the computer to begin installation of Windows NT.
7. You will be prompted to insert diskette #2 and diskette #3 (for detailed information about Windows NT 4.0 installation, see your Windows NT 4.0 User's Manual.) Installation diskette #3 will recognize an IDE CD-ROM (if you have one) and then ask if you want to specify SCSI adapters, other CD-ROM drives, or disk controllers. You want to specify the ASUS PCI-DA2100/-DA2200. Press "S".
8. Depending on your system, may be more than one device listed. Select **Other (Requires disk provided by a hardware manufacturer)**, and then press <Enter>.
9. You will be prompted to insert the disk from the hardware manufacturer. Insert the ASUS PCI-DA2100/-DA2200 driver diskette, and then press <Enter>.
10. Select **DA-2000 Series RAID Miniport for NT v4.0** from the list, and then press <Enter>. The Windows NT Setup screen will now indicate that it recognizes the RAID Miniport in addition to the IDE CD-ROM. Setup gives you the choice of specifying additional devices for use with Windows NT (press "S") or of not specifying additional devices (Press <Enter>). Press <Enter> to continue.
11. Remove the ASUS PCI-DA2100/-DA2200 driver diskette and re-insert Windows NT 4.0 Installation Diskette #3, as prompted. Confirm your system configuration and accept the Windows NT license agreement, as prompted. Setup will display the logical drive that you created on the SCSI adapter. Setup asks if you want to install Windows NT on that drive. Press <Enter> to begin installation on that logical drive. (At this point, Windows NT also gives the choice of partitioning the logical drive. To keep the example simple, we do not do this.) The rest of the installation is described in the Windows NT 4.0 User's Manual.

Appendix A

3.5 *Installing Driver while Installing WinNT4(DEC Alpha)*

The Windows NT 4.0 for DEC Alpha installation is almost identical to the installation for Windows NT 4.0 for x86. There are two differences. First, the ASUS PCI-DA2100/-DA2200 cannot be used as the boot device in Windows NT for DEC Alpha; and second, in step 10 (see *Installing the Driver During Windows NT 4.0 Installation*), you should choose the device driver called **DA-2000 Series RAID Miniport for Alpha NT v4.0**. See Section 3.4, steps 6 through 11, for instructions on installing Windows NT 4.0 for DEC Alpha.

The following files are supplied for driver installation, they are put in the \ALPHANT\V4_0 subdirectory for Windows NT 4.0

- DA2000.SYS: ASUS PCI-DA2100/-DA2200 Miniport Driver for Windows NT 4.0
- PCIDA: Tag file for driver installation.
- OEMSETUP.INF: Information file for driver installation.
- TXTSETUP.OEM: Information file for driver installation.
- README.ANT: A text file describing the ASUS PCI-DA2100/-DA2200 miniport driver.


3.6 Installing the Driver in Existing WinNT4 (DEC Alpha)

This section describes the procedure for installing the driver in a DEC Alpha system that is running Windows NT 4.0.

IMPORTANT:

Under Windows NT 4.0 for DEC Alpha, the ASUS PCI-DA2100/-DA2200 cannot be the boot device.


1. Go the **Control Panel** and select **SCSI Adapters**.



2. Choose the **Drivers** tab and select the "Add..." button.
3. Select the "Have Disk..." button.

Appendix A

4. Insert the ASUS PCI-DA2100/-DA2200 driver diskette, and then press <Enter>. Windows NT will check the floppy drive for a diskette. Files and directories on the diskette are displayed.
5. With your mouse, click on the folder icons for WINNT and then V4_0. Your selection of the **A:\WINNT\V4_0** directory will be indicated. (Note: for Windows NT 4.0 for DEC Alpha, you should select the A:\ALPHANT\V4_0 directory.)



6. You will see the **DA-2000 Series Miniport Driver for Windows NT 4.0** highlighted in gray. Press <Enter> to select it.
7. You will be asked which directory you want to install the driver from. Type in **A:\WINNT\V4_0** and then press <Enter>. (Note: for Windows NT 4.0 for DEC Alpha users should type in A:\ALPHANT\V4_0.)

4 Windows® 95/98 Driver Installation

The following files are supplied for driver installation, they are put in the \WIN95 subdirectory for Windows 95 or Windows 98.

- DA2000.MPD: ASUS PCI-DA2100/-DA2200 Miniport Driver for Windows 95 or Windows 98.
- DA2000.INF : Information file for driver installation.
- README.W95: A text file describing the ASUS PCI-DA2100/-DA2200 miniport driver.

4.1 Installing Windows 95/98 and the Driver

1. Use ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation Mode (default is disabled). To do this, at system bootup, press [Ctrl-I], select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager or RS-232 Terminal Interface to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 controller and thus no logical drives or devices should be mapped to this SCSI ID.
3. Follow the instructions in Windows 95/98 installation documentation to install Windows 95/98.
4. When Windows 95/98 installation is complete, restart Windows.
5. Click on the "Start" button on the task bar of Windows 95/98.
6. Select "Settings", and then click on "Control Panel".
7. Double-click on the "System" icon, then click on "Device Manager" tab.
8. Click on the plus sign next to the "Other devices" icon, then Double-click on the yellow question mark labeled "PCI SCSI Bus Controller" icon, then click on the "Driver" tab.

Appendix A

9. In the Driver tab, click on "Change Driver". When asked to select hardware type, select "SCSI Controllers".
10. Click on the "Have Disk" button and enter a:\win95 as the subdirectory to copy the manufacturer's file from. Insert ASUS PCI-DA2100/-DA2200 distribution diskette into drive A: and click on "OK".
11. Select "ASUS PCI-DA2100/-DA2200 PCI-to-SCSI RAID Adapter", and click on "OK".
12. Click on "OK". The driver is copied.
13. You must restart your system for the changes to take effect. Click on "Yes" to shutdown the system and restart your computer.
14. When the system is booting up, an "Unknown Device" warning window will be displayed, this is a normal behavior because a virtual target is registered by ASUS PCI-DA2100/-DA2200 Miniport Driver to support GUI RAID Manager. Please select "Do not install a driver", and click on "OK". Don't be alarmed by this message. It is perfectly normal to see this message when using the ASUS PCI-DA2100/-DA2200 under Windows 95/98.
15. Make sure that the ASUS PCI-DA2100/-DA2200 Miniport Driver is working properly by using Device Manager tab of System icon in Control Panel. Click on the plus sign next to the SCSI controllers icon, and double-click on the ASUS PCI-DA2100/-DA2200 PCI-to-SCSI RAID Adapter icon. Check the Device status. If the device is working properly, the driver is installed successfully. If not, the driver is not installed. Check your CONFIG.SYS to see if DA2000.SYS is installed. If it is installed, remove it, and restart your computer.

4.2 Updating Device Driver for Windows 95/98

1. Click on the "Start" button in the task bar of Windows 95/98.
2. Select "Settings", and then click on "Control Panel".
3. Double-click on the "System" icon, then click on "Device Manager" tab.
4. Click on the plus sign next to the "SCSI controller" icon, then Double-click on the "ASUS PCI-DA2100/-DA2200 PCI-to-SCSI RAID Adapter" icon. Click on the "Driver" tab.
5. On the "Driver" tab, click on "Change Driver".
6. Click on the "Have Disk" button and enter a:\win95 as the subdirectory to copy the manufacturer's file from. Click "OK".
7. Select ASUS PCI-DA2100/-DA2200 PCI-to-SCSI RAID Adapter, and click on "OK".
8. Click on "OK". The driver is copied.
9. You must restart your system for the changes to take effect. Click on "Yes" to shutdown the system and restart your computer.

Appendix A

5 OS/2[®] Driver Installation

Up to 4 ASUS PCI-DA2100/-DA2200 controllers can be installed in one computer. The following files are supplied for driver installation, they are put in the \OS2 subdirectory.

- DA2000.ADD : ASUS PCI-DA2100/-DA2200 OS/2 2.x and 3.0(Warp) Device Driver.
- DA2000.DDP : Device Driver Profile for driver installation.
- README.OS2 : An text file describing the ASUS PCI-DA2100/-DA2200 OS/2 driver.

5.1 Installing Driver During OS/2 2.x or 3.0 Installation

Follow these steps only if OS/2 2.x, 3.0 is not installed on your computer or if you are upgrading to OS/2 2.x or 3.0.

1. Use the ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager or RS-232 Terminal Interface Operation to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 adapter and thus no logical drives or devices should be mapped to this SCSI ID.**
3. Prepare for the installation by using DISKCOPY (or any other disk-copy utility) to make backup copy of IBM OS/2 installation diskette #1. Use this copy as your working diskette #1.
4. Copy DA2000.ADD from ASUS PCI-DA2100/-DA2200 controller distribution diskette to OS/2 installation diskette #1. Modify the CONFIG.SYS file on OS/2 installation diskette #1 to add the following line to the end of CONFIG.SYS:
BASEDEV=DA2000.ADD /V
5. Follow the steps from IBM for installing OS/2.

5.2 Installing Driver in an Existing OS/2 2.x/3.0

If you are adding an ASUS PCI-DA2100/-DA2200 controller to a computer that already has an ASUS PCI-DA2100/-DA2200 controller installed for OS/2 2.x/3.0, then follow step 1 through step 2 only. If you are adding an ASUS PCI-DA2100/-DA2200 controller to a computer that has no ASUS PCI-DA2100/-DA2200 controller installed for OS/2 2.x/3.0, then follow all steps.

1. Use the ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode(default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager or RS-232 Terminal Interface Operation to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 controller and thus no logical drives or devices should be mapped to this SCSI ID.**
3. Execute the program DDINSTALL by selecting the Device Driver Install icon within the System Setup folder of OS/2 System folder or by typing **DDINSTALL** at OS/2 prompt.
4. Insert the ASUS PCI-DA2100/-DA2200 distribution diskette in the appropriate floppy drive and follow the instructions from DDINSTALL. Set the source directory to a:\os2 and the destination path to the root directory of system drive while running DDINSTALL.
5. Reboot your system.

5.3 Updating PCI-DA2100/2200 OS/2 Device Driver

1. Copy the new device driver from the distribution diskette to the root directory of system drive where that OS/2 is installed.
For example, Driver
copy a:\os2\da2000.add c:

Appendix A

2. Shutdown OS/2, then restart your computer.

5.4 DA2100/2200 OS/2 Driver Command-Line Options

1. Driver Command Syntax :

BASEDEV=DA2000.ADD [Driver-Options][Adapter-Options][Unit-Options]

The command and options must be put in the CONFIG.SYS file. The changes of command-line option will not take effect until the system is restarted.

2. Command-Line Options :

- 1). Command-line options are case-insensitive.
- 2). All command-line options begin with the slash character (/).
- 3). The exclamation character (!) is a negation operator; that is, it negates the option that follows it.

3. Driver-Options :

/V

Verbose. Either Display the driver name, version number, date, adapter Information and device information if the driver loads successfully, or display error messages if the driver fails to initialize.

/(!)ET

(Disable) Enable Embedded Target Support. Makes the driver (disable) enable not-zero SCSI LUN support. Default setting is /ET.

/PCI:n

Maximum PCI Bus Number in the computer. Where n is a decimal value between 0 to 255. Default value is 255.

4. Adapter-Options :

/A:n

Adapter Identification. where n is a decimal value. This option specifies the ordering of adapters. Normally, adapters are numbered consecutively, starting at 0.

/BUS:n

PCI Bus Number which ASUS PCI-DA2100/-DA2200 Controller is plugged in. You can get the PCI bus number from the information that the ASUS PCI-DA2100/-DA2200 BIOS displays at system bootup. Note: the ASUS PCI-DA2100/-DA2200 BIOS displays bus number in hex value, you must translate that into decimal value.

/DEV:n

PCI Device Number into which the ASUS PCI-DA2100/-DA2200 is plugged. You can get the PCI device number from the information that the ASUS PCI-DA2100/-DA2200 BIOS displays at system bootup. Note: The ASUS PCI-DA2100/-DA2200 BIOS displays the device number in hex value, you must translate that into decimal value.

/(!)ET

(Disable) Enable Embedded Target Support. Makes the driver (disable) enable not-zero SCSI LUN support to the specified adapter by /A:n . Default setting is /ET.

/(!)DM

(Disable) Enable Direct Access Storage Device (DASD) Manager Support. (Disable) Enable all the units, connect to the adapter specified by /A:n, to be supported by the IBM-supplied DASD manager (OS2DASD.DMD) The default setting is /DM.

/(!)SM

(Disable) Enable SCSI Manager Support. (Disable) Enable all the units, connect to the adapter specified by /A:n, to be supported by the IBM-supplied SCSI manager (OS2SCSI.DMD). The default setting is /SM.

5. Unit-Options :

/(!)ET:i1,i2,i3....

(Disable) Enable Embedded Target Support. Where i1,i2,i3 is the specified SCSI Target ID . Makes the driver (disable) enable not-zero SCSI LUN support to the specified SCSI ID of the specified adapter by /A:n. Default setting is /ET.

/(!)DM:i1,i2,i3... OR /(!)DM:(i1,i1),(i2,i2)....

Appendix A

(Disable) Enable Direct Access Storage Device (DASD) Manager Support. Where i1,i2,i3 is the specified SCSI Target ID. (i1,l1),(i2,l2) is the specified SCSI Target ID-LUN. (Disable) Enable the specified SCSI Target ID(LUN) of the adapter specified by /A:n, to be supported by the IBM-supplied DASD manager (OS2DASD.DMD). The default setting is /DM. The boot device **MUST** be supported by DASD Manager, or the computer can not be able to boot OS/2.

/(!)SM:i1,i2,i3... OR /(!)SM:(i1,l1),(i2,l2)....

(Disable) Enable SCSI Manager Support. Where i1,i2,i3 is the specified SCSI Target ID. (i1,l1),(i2,l2) is the specified SCSI Target ID-LUN. (Disable) Enable the specified SCSI Target ID(LUN) of the adapter specified by /A:n, to be supported by the IBM-supplied SCSI manager (OS2SCSI.DMD). The default setting is /SM.

Note : The driver will find all the ASUS PCI-DA2100/-DA2200 controllers in your computer automatically, if no /BUS and /DEV options are specified.

6 Driver Installation for SCO OpenServer & UnixWare

The chapter describes how to install SCO UNIX BTLT (Boot Time Loadable Driver) for the ASUS PCI-DA2100/-DA2200.

6.1 Installing the SCO OpenServer Driver

1. Use the ASUS PCI-DA2100/-DA2200 BIOS Configuration Utility to disable ISA Mailbox Emulation mode (default is disabled). To do this, at system bootup, press **[Ctrl-I]**, select Configure Card option, then change IO Port Address to DISABLED.
2. Use ASUS Text RAID Manager (refer to chapter 6) to configure Logical Drives and SCSI Devices and map them to valid SCSI-IDs/LUNs. **Note that SCSI ID 7 is reserved for the ASUS PCI-DA2100/-DA2200 and thus no logical drives or devices should be mapped to this SCSI ID.**
3. Check IO devices, CD-ROM or TAPE drive is properly installed.
4. Insert the N1 boot diskette into the floppy drive and turn on the PC. When the "boot" message appears, type **link** as follows:

```
SCO UNIX System V/386
Boot: link <Enter>
```

5. Type **da2x** at the following prompt:

```
What packages do you need linked in the system,
or 'q' to quit?: da2x
```

6. You will be prompted to insert the DA BTLT diskette after a series of messages as follows:

```
Please insert the fd(x)da2x volume and press <RETURN>
or 'q' to quit:
```

7. After Insert the diskette, press **[Enter]**.

Appendix A

Follow the appropriate SCSI manual to install the SCO UNIX from the installation media (floppy, tape, or CD-ROM).

8. A message similar to the following will be displayed:

```
Please insert the da2x volume and press <ENTER>:
```

Insert the DA BTL D diskette again and press **[ENTER]**

9. At the following prompt, type "y":

```
The BTL D packages will now be added to the Link Kit.
```

```
The Link Kit is not installed.  
Do you wish to install it now?(y/n)
```

10. At the following prompt, press **[ENTER]**:

```
The following packages are on this diskette:
```

NAME	DESCRIPTION
da2x	ASUS PCI-DA2100/-DA2200 SCSI Disk Array Driver for SCO UNIX system

```
Please enter the names of the packages you  
wish to install or q to quit:_  
[default:da2x]
```

11. The ASUS PCI-DA2100/-DA2200 driver will now be linked into the SCO UNIX kernel.

7 Drivers and Utilities for Linux

The drivers and utilities for Linux can be found in the following directories:

```
\2101\Linux
  \Disk 1 - Linux SLACKWARE 3.5 BOOT
            DISK filename: IABL11F1 (disk 1)
  \Disk 2 - Linux RED HAT 5.1 BOOT DISK
            filename: IABL11F2 (disk 2)
  \Disk 3 - Linux Text RAID Manager, RAID SNMP TOOLS DISK
            filename: IABL11F3 (disk 3)
  \Disk 4 - Linux RED HAT 5.1 SUPPLEMENT DISK
            filename: IABL11F4 (disk 4)
```

NOTE:

The current driver version supports Linux 2.0.34 of Red Hat 5.1 and SlackWare 3.5. The Red Hat 5.2 (Linux 2.0.36) is not yet supported.

7.1 Making Floppy Diskettes for Red Hat 5.1 Installation

1. Prepare three formatted floppy diskettes.
2. Copy the files of Disk 2, Disk 3 and Disk 4 to a UNIX machine with a floppy drive.
3. Place the formatted disk into the floppy drive and use the UNIX "dd" command to make the driver floppy diskettes.

For example:

```
# dd if=iabl11f2 of=/dev/fd0 bs=1440k
# dd if=iabl11f3 of=/dev/fd0 bs=1440k
# dd if=iabl11f4 of=/dev/fd0 bs=1440k
```

4. Label each disk according to the above description.

Appendix A

7.2 Making Floppy Diskettes for SlackWare 3.2 Installation

1. Prepare two formatted floppy diskettes.
2. Copy the files of Disk 1 and Disk 3 to a UNIX machine with floppy drive.
3. Place the formatted disk into the floppy drive and use the UNIX "dd" command to make the driver floppy diskettes.

For example:

```
# dd if=iab111f1 of=/dev/fd0 bs=1440k
# dd if=iab111f3 of=/dev/fd0 bs=1440k
```

4. Label each disk according to the above description.

7.3 Installing Red Hat Linux

IMPORTANT:

- *ALWAYS CHANGE THE CACHE TO WRITE-BACK DISABLED BEFORE INSTALLING OPERATING SYSTEMS AND PARTITIONING.*
 - *The ASUS PCI-DA2100/-DA2200 is a high-performance PCI RAID controller with Write-Back cache enabled. During the installation of some operating systems, the installation program might reset the computer automatically while the cache still contains data not yet written to the drives. It might cause the installation or partitioning failure. To avoid the failure, always switch the cache mode to Write-Back DISABLED (Write-Through mode) before changing the drive partition (e.g., using MS-DOS FDISK) and before installing any operating systems.*
1. Follow these steps to change the cache mode to Write-back Disabled:
 - a) Using BIOS Text RAID Manager (PC platform only) to disable the Write-Back Cache. Power on the computer, press <CTRL><I> when the information appears.

- b) Choose "Configure RAID" from the menu and press <Enter> to enter a proper display mode (either ANSI, VT-100 or ANSI Color).
 - c) In the Main Menu, choose "View and Edit Configuration Parameters", then "Caching Parameters".
 - d) A sub-menu contains "Write Back Cache Enabled/Disabled" which refers to the Write Back mode is Enabled or Disabled. Press <ENTER> on it and choose "Yes" to change it.
 - e) After the cache mode has been changed, resetting the computer is required for the new setting to take effect. After the driver partitioning and operating system are installed, use the same procedure to *enable* the Write-Back cache – the high performance Write-Back Caching will bring your system into a higher performance level.
2. Connect CD-ROM drive to ASUS PCI-DA2100/-DA2200, remove or disable any other SCSI adapters from the system. (red hat 5.1 installation can only use one SCSI adapter during installation) (The IDE CD-ROM drive can be a substitute for the SCSI CD-ROM drive).
 3. If using ASUS PCI-DA2100/-DA2200 BIOS v1.17B, do not leave Red Hat CD disc in the CD-ROM drive during system reboot. The BIOS 1.17B has CD-ROM boot ability, it detects the CD in the CD-ROM drive, once it detects the CD disc is bootable, the system will boot from CD-ROM not from floppy.
 4. Insert "ASUS PCI-DA2100/-DA2200 Red Hat 5.1 Boot Disk" disk 2 into floppy, and power on the system.
 5. Insert the Red Hat 5.1 CD disc into the CD-ROM drive after the system boot up, follow the on-screen instruction to start the installation of Linux.

Appendix A

6. Choose "SCSI CD-ROM", the installation program will find ASUS PCI-DA2100/-DA2200 RAID controller, follow the on-screen instructions to continue.
7. Insert "ASUS PCI-DA2100/-DA2200 Red Hat 5.1 Supplement Disk" disk 4 into floppy drive when prompted.
8. When on-screen appears "Please insert the Disk 3 (Driver disk)", insert "ASUS PCI-DA2100/-DA2200 Text RAID Manager, RAIDSNMP for Linux" into the floppy drive.
9. Follow the on-screen instructions to complete the installation of Red Hat 5.1.

7.4 Installing SlackWare Linux

IMPORTANT:

- *ALWAYS CHANGE THE CACHE TO WRITE-BACK DISABLED BEFORE INSTALLING OPERATING SYSTEMS AND PARTITIONING.*
 - *The ASUS PCI-DA2100/-DA2200 is a high-performance PCI RAID controller with Write-Back cache enabled. During the installation of some operating systems, the installation program might reset the computer automatically while the cache still contains data not yet written to the drives. It might cause the installation or partitioning failure. To avoid the failure, always switch the cache mode to Write-Back DISABLED (Write-Through mode) before changing the drive partition (e.g., using MS-DOS FDISK) and before installing any operating systems.*
1. Follow these steps to change the cache mode to Write-back Disabled:
 - a) Using BIOS Text RAID Manager (PC platform only) to disable the Write-Back Cache. Power on the computer, press <CTRL><I> when the information appears.
 - b) Choose "Configure RAID" from the menu and press <Enter> to enter a proper display mode (either ANSI, VT-100 or ANSI Color).

- c) In the Main Menu, choose "View and Edit Configuration Parameters", then "Caching Parameters".
 - d) A sub-menu contains "Write Back Cache Enabled/Disabled" which refers to the Write Back mode is Enabled or Disabled. Press <ENTER> on it and choose "Yes" to change it.
 - e) After the cache mode has been changed, resetting the computer is required for the new setting to take effect. After the driver partitioning and operating system are installed, use the same procedure to *enable* the Write-Back cache – the high performance Write-Back Caching will bring your system into a higher performance level.
2. Follow the original procedure to create the SlackWare Boot Disk and Root Disk from the SlackWare CD-ROM.
 3. If using ASUS PCI-DA2100/-DA2200 BIOS v1.17B, do not leave SlackWare CD disc in the CD-ROM drive during system reboot. The BIOS 1.17B has CD-ROM boot ability, it detects the CD in the CD-ROM drive, once it detects the CD disc is bootable, the system will boot from CD-ROM not from floppy.
 4. Use "ASUS PCI-DA2100/-DA2200 Linux SlackWare 3.5 Boot Disk" disk 1 instead of the original boot disk, power on the system, let the system boot from the boot disk floppy.
 5. Insert the SlackWare 3.5 CD disc into the CD-ROM drive after the system boot up, follow the on-screen instruction to start the installation of Linux.
 6. Insert the Root Disk made from Linux SlackWare CD-ROM into floppy drive when prompted.
 7. Follow the on-screen instructions to complete the installation of SlackWare 3.5.

Appendix A

7.5 Running the ASUS Text RAID Manager for Linux

1. Insert "ASUS PCI-DA2100/-DA2200 Text RAID Manager, RAIDSNMP for Linux" (disk 3) into the floppy drive and mount it.

```
# mount -r /dev/fd0 /mnt
```

2. Execute the Raidman in the /tools directory.

```
# cd /mnt/tools  
# ./raidman
```

NOTE:

The current driver version supports Linux 2.0.34 of Red Hat 5.1 and SlackWare 3.5. The Red Hat 5.2 (Linux 2.0.36) is not yet supported.

8 Drivers and Utilities for Sun Solaris™

8.1 Solaris 2.5.x and 2.6 (x86 platform)

The drivers and utilities can be found in the following directory:

```
\2101\SOLARIS.X86
    \IAAS111D      - Driver diskette image in UNIX "dd" format.
    \IAAS111D_.Z  - Driver files packed by "tar" and "compress".
```

The files extracted from either one of above are exactly the same.

IMPORTANT:

The logical drive created on ASUS PCI-DA2100/-DA2200 RAID controller cannot be used as the Solaris boot drive.

8.1.1 Creating the Driver Diskette from the Image File

1. Find a UNIX system with floppy disk drive.
2. Under the command prompt, type:

```
# dd if=IAAS111D of=/dev/fd0 bs=1440k
```

where "/dev/fd0" is the floppy drive device where the driver diskette will extract to.

8.1.2 Extracting Driver Files Using "tar" and "uncompress"

1. Find a system with SUN Solaris 2.5/2.6 (for x86 platform) installed.
2. Make a temporary directory, and copy the file "IAAS111D_.Z" into it.

```
# cd
# mkdir 2101
# cp IAAS111D_.Z /2101
```

3. Make sure the last character of the filename "Z" is capitalized (not in lower case). If it is in lower case "z", change it to "Z".

```
# mv iaas111d_.z IAAS111D_.Z
```

Appendix A

4. Uncompress the file:

```
# uncompress IAAS111D_.Z
```

5. Use "tar" command to extract the files:

```
# tar xvf IAAS111D_
```

The driver files will be extracted into the current directory.

8.2 Installing x86 Driver & Text RAID Manager

A. Installing from the driver diskette created from image file

- A1. To install the driver from the driver diskette, type:

```
# pkgadd -d /floppy/floppy0
```

where "/floppy/floppy0" is the mounted driver diskette. Use Solaris Volume Manager and "volcheck" to mount the driver diskette, or mount it manually.

- A2. A list of selections will show as below, choose "3" to install the driver for ASUS PCI-DA2100/-DA2200.

The following packages are available:

```
1  dascx86      RAID In-band SCSI Driver for Solaris 2.5,2.6
                   (i386) 1.11a
2  mgrx86      ASUS Text RAID Management for Solaris 2.5,2.6
                   (i386) 1.51b
3  rhbax86     PCI-SCSI RAID Host Adapter Driver
                   (i386) 1.11d
4  snmpx86     RAID SNMP SUBAGENT for Solaris 2.5,2.6
                   (i386) 1.15b
```

Select package(s) you will to process (or 'all' to process all packages). (default: all) [?,??,q]: 3

- A3. After the driver installed, the same selections appear again. Choose "2" this time to install the ASUS Text RAID Manager for Solaris.
- A4. After the driver installed, the same selections appear again. Choose "4" this time to install the RAID SNMP sub-agent for Solaris. This step can be ignored if SNMP remote administration is not going to be used. If TCP/IP protocol and SNMP service have not yet installed on this system, it can be installed later after

the system TCP/IP and SNMP installed. The RAID SNMP sub-agent is not a must to be installed. Install it only when needed.

A5. Choose "q" to quit when the same list of selections appear again.

A6. Reboot the system.

```
# init 6
```

A7. After the system reboot, type "boot -r" in the boot screen to let the Solaris knows to look for new device drivers and incorporate them as part of the boot process.

B. Installing from the driver files extracted in the drive

B1. To install the driver from the directory where the files were extracted, type:

```
# pkgadd -d /2101
```

where "/2101" is the directory where the driver files were extracted.

B2. Follow the instructions from A2 to A7 of above to install the driver and the ASUS Text RAID Manager, and RAID SNMP sub-agent for Solaris.

8.3 Drivers & Utilities - Solaris 2.5.x/2.6 (SPARC)

The drivers and utilities can be found in the following directory:

```
\2101\SOLARIS.SPK  
  \IAAR111D   - Driver diskette image in UNIX "dd" format.  
  \sun_tar.Z  - Driver files packed by "tar" and "compress".
```

The files extracted from either one of above are exactly the same.

IMPORTANT:

The logical drive created on ASUS PCI-DA2100/-DA2200 RAID controller cannot be used as the Solaris boot drive.

Appendix A

8.3.1 Creating the Driver Diskette from the Image File

1. Find a UNIX system with floppy disk drive.
2. Under the command prompt, type:

```
# dd if=IAAR111D of=/dev/fd0 bs=1440k
```

Where "/dev/fd0" is the floppy drive device where the driver diskette will extract to.

8.3.2 Extracting the Driver Files Using "tar" and "uncompress"

1. Find a system with SUN Solaris 2.5/2.6 (for x86 platform) installed.
2. Make a temporary directory, and copy the file "IAAS111D_.Z" into it.

```
# cd  
# mkdir 2101  
# cp sun_tar.Z /2101
```

3. Make sure the last character of the filename "Z" is capitalized (not in lower case). If it is in lower case "z", change it to "Z".

```
# mv sun_tar.z sun_tar.Z
```

4. Uncompress the file:

```
# uncompress sun_tar.Z
```

5. Use "tar" command to extract the files:

```
# tar xvf sun_tar
```

The driver files will be extracted into the current directory.

8.4 Installing SPARC Driver & Text RAID Manager

A. Installing from the driver diskette created from image file

A1. To install the driver from the driver diskette, type:

```
# pkgadd -d /floppy/floppy0
```

where "/floppy/floppy0" is the mounted driver diskette. Use Solaris Volume Manager and "volcheck" to mount the driver diskette, or mount it manually.

A2. A list of selections will show as below, choose "3" to install the driver for ASUS PCI-DA2100/-DA2200.

The following packages are available:

- 1 RAID In-band SCSI Driver for Solaris 2.5,2.6
- 2 ASUS Text RAID Management for Solaris 2.5,2.6
- 3 PCI-SCSI RAID Host Adapter Driver
- 4 RAID SNMP SUBAGENT for Solaris 2.5,2.6

```
Select package(s) you will to process (or 'all' to process  
all packages). (default: all) [?,??,q]: 3
```

A3. After the driver has been installed, the same selections appear again. Choose "2" this time to install the ASUS Text RAID Manager for Solaris.

A4. After the driver installed, the same selections appear again. Choose "4" this time to install the RAID SNMP sub-agent for Solaris. This step can be ignored if SNMP remote administration is not going to be. If TCP/IP protocol and SNMP service have not yet installed on this system, it can be installed later after the system TCP/IP and SNMP installed. The RAID SNMP sub-agent is not a must to be installed. Install it only when needed.

A5. Choose "q" to quit when the same list of selections appear again.

A6. Reboot the system.

```
# init 6
```

A7. After the system reboot, type "boot -r" in the boot screen to let the Solaris knows to look for new device drivers and incorporate them as part of the boot process.

Appendix A

B. Installing from the driver files extracted in the drive

- B1. To install the driver from the directory where the files were extracted, type:

```
# pkgadd -d /2101
```

where "/2101" is the directory where the driver files were extracted.

- B2. Follow the instruction from A2 to A7 of above to install the driver and the ASUS Text RAID Manager, and RAID SNMP sub-agent for Solaris.

8.5 Configuring RAID in Solaris with Text RAID Manager

1. Change the current directory to where the ASUS Text RAID Manager is located.

```
# cd /usr/lib/raidsnmp
```

2. Execute the ASUS Text RAID Manager under command prompt:

```
# ./raidman
```

Please refer to chapter 6 for details on the operation of the ASUS Text RAID Manager.

Appendix B SCSI Cable Specifications

The recommended SCSI cable for an Ultra2 Wide SCSI operating at a transfer rate of 80 Mbytes/sec. is described below.

Maximum length	12 meters
Impedance	110Ω
Capacitance	15.9 pf / ft @ 1MHz
Propagation Delay	1.59ns / ft nom
DC Resistance	95Ω / 1000 ft @ 20°C
Delay Skew	0.035ns / ft (max.)

SCSI Standards, Cable Length and Corresponding Maximum Possible Drive Connections

	Single-Ended	LVD	*Maximum Devices
SCSI-1	6 m	-	8
SCSI-2	3 m	-	8
Wide SCSI-2	3 m	-	16
Ultra SCSI-2	1.5 m	-	8
Ultra SCSI-2	3m	-	4
Ultra Wide SCSI-2	-	-	16
Ultra Wide SCSI-2	1.5 m	-	8
Ultra Wide SCSI-2	3 m	-	4
Ultra2 Wide SCSI	-	12m	16

- * The maximum device count includes the controller. The controller must occupy one SCSI ID on each drive channel. The controller usually occupies ID 7.

SCSI Bus Width and Maximum Throughput

	Bus Width	SCSI Bus Sync. Frequency	Max. Bus Throughput
SCSI-1	8-bit	Asynchronous	5 MB/Sec
(Fast) SCSI-2	8-bit	10MHz	10 MB/Sec
(Fast) Wide SCSI-2	16-bit	10MHz	20 MB/Sec
Ultra SCSI-2	8-bit	20MHz	20 MB/Sec
Ultra Wide SCSI-2	16-bit	20MHz	40 MB/Sec
Ultra2 Wide SCSI-2	16-bit	40MHz	80 MB/Sec

Appendix B

This page is left intentionally blank.

Appendix C Upgrading BIOS, Firmware, and Boot Record


The BIOS, firmware and boot record (the section of code that boots the controller and allows for temporary download of firmware) of the ASUS PCI-DA2100/-DA2200 stored in flash memory can be updated via the Text RAID Manager under MS-DOS®. New releases of the BIOS/firmware/boot-record are available on the ASUS FTP server or in the form of an MS-DOS file on a 5.25" or 3.5" diskette (on request).

To perform the download, the following must be available:

- ASUS PCI-DA2100/-DA2200 plugged into a host PCI slot and properly functioning.
- RAIDMAN.EXE running under MS-DOS.

To perform the download, follow the following procedure:

1. Select "Controller Maintenance" menu option under "System Functions" via the Text RAID Manager.



2. Select the desired download option. If upgrading of both firmware and boot record is desired, first select "Advanced

Appendix C

Maintenance Functions" menu item then select "Download Boot Record with Firmware".

3. When prompted to confirm, select "Yes".
4. When prompted for a file name, enter the name of the file containing the code to be downloaded. If both firmware and boot record are being downloaded, enter the name of the boot record file.
5. If both firmware and boot-record are being downloaded, when downloading of boot record is complete, repeat step 4; then, when prompted for a file name, enter the name of firmware file.
6. When file transfer is complete, please wait a moment while the ASUS PCI-DA2100/-DA2200 burns the code into the flash memory.

IMPORTANT:

Allow the downloading process to finish. Do not reset or turn off the computer or the controller while it is downloading the file. Doing so may result in an unrecoverable error that requires the service of the manufacturer.

Appendix D Sync. Clock Period/Frequency

Changes to the SCSI Synchronous Clock Period of each SCSI target is a low-level control of the SCSI controller chip. There is no other selectable option. Only the Synchronous Clock Period is available in this field.

To calculate the Synchronous Clock Period, refer to the “Sample equation” to get the correct Synchronous Clock Period.

Sample equation:

In this example, where “20.8Mhz” is called the Synchronous Clock Frequency, and “12” is called the Synchronous Clock Period.

$$\frac{1}{20.8Mhz \times 4ns} = \frac{1}{20.8 \times 10^6 \times 4 \times 10^{-9}} = 12$$

$$\frac{1}{12 \times 4ns} = \frac{1}{12 \times 4 \times 10^{-9}} = 20.8Mhz$$

Synchronous Clock Period	Synchronous Clock Frequency	Synchronous Clock Period	Synchronous Clock Frequency
10*	40	62	4.0
11*	30	75	3.3
12*	20	88	2.8
15	16.6	100	2.5
18	13.8	110	2.2
25	10.0	120	2.0
31	8.0	135	1.8
37	6.7	0	Asynchronous
43	5.8		
50	5.0		

* These three clock periods aren't in accordance with the sample equation; they are specially defined in the SCSI-3 specification.

Appendix D

This page is left intentionally blank.

Appendix E Troubleshooting Guide

NOTE:

The following is a checklist of the common problems encountered during installation. For failures that occur during operation, refer to the failure recovery procedure in the "Disk Failure Management" section.

<u>PROBLEM</u>	<u>CHECK</u>
Text RAID Manager indicates a SCSI channel failure detected upon start-up (SCSI cables connected).	<ol style="list-style-type: none"> 1. Check ID numbers (must be unique for each device on the same SCSI channel). 2. Make sure terminators are properly installed. 3. Check the voltage output of the power supply.
Initialization failure	<ol style="list-style-type: none"> 1. Check ID numbers (must be unique for each device on the same SCSI channel). 2. Make sure terminators are properly installed.
Cannot detect SCSI drive	<ol style="list-style-type: none"> 1. Check drive power connections. 2. Check drive SCSI cable connections. 3. Check ID numbers (must be unique for each device on the same SCSI channel).
Parity error detected	<ol style="list-style-type: none"> 1. DRAM SIMM should be replaced.
Logical drive failure detected during boot-up	<ol style="list-style-type: none"> 1. Check proper installation or connection of the drives (use the "View SCSI drives" function to help locate the problem).

System is not stable after running for a period of time.

1. SCSI cable must be shorter than 2 meters.
2. Make sure terminators are proper installed.
3. Power supply voltage must be within specification.
4. Check the enclosure's inner temperature.

When using "Scan New SCSI Drive" and the desired ID is empty, an empty drive entry appears.

1. Refer to section 8.4.1, *Scan New SCSI Drive*, on how to remove the empty drive entry.

The logical drive states "INVALID".

1. "Optimization for I/O", when creating the logical drive in Cache Parameter, is different from the current setting.
2. Change "Optimization for I/O" to the opposite setting and reset the controller.

In "View and Edit SCSI Drives" or "View and Edit SCSI Channels", the speed is only "20.8Mhz", not "40Mhz"

1. "20.8Mhz" is SCSI sync frequency, not transfer rate.
2. Refer to Appendix B, *SCSI Cable Specifications*, for details.

All settings are too complex to remember.

1. After the system installation is completed, write down all of the settings and related information in Appendix G, *Record the Settings*, for future reference.

Appendix F**Specifications**

RAID level Operation	0, 1 (0+1), 3, 5 (or non-RAID disk spanning) Firmware on Flash Memory and DRAM running on AMD 5x86-133 CPU
Failure management	Bad sector reassignment, hot-swapping, spare drive operation (Global and Local Spare), background rebuilding
Failure indicator	Via Text RAID Manager or GUI RAID Manager
Host Interface	PCI Rev. 2.1
Cache size	Up to 128 Mbytes
Host interface	Ultra2 Wide SCSI
Hard disk interface	Ultra2 Wide SCSI
Hard disk channels	2
Channel Terminator	Active, software programmable
SCSI protocol	SCSI-1; SCSI-2; (Ultra)-Wide-SCSI-1 or SCSI-2 (auto-match); or U2 Wide SCSI
Ultra2 SCSI transfer rate	80 Mbytes/sec synchronous (max)
Max. SCSI drives	30
No. of logical drives	8, each capable of different RAID levels
Partitions	8 per logical drive, total of 64
No. of LUNs	Up to 32 LUNs per SCSI ID
Control	Via Text RAID Manager or GUI RAID Manager

Appendix F

U2 Wide-SCSI connectors	68-pin high-density internal connector 68-pin ultra-high-density external connect.
Ultra2 Wide-SCSI cabling	Low-voltage differential
Voltage	+5 Volts
Current	3 Amp
Operating Temperature	5 to 44°C
Relative Humidity	10-96%, non-condensing
Operating Altitude	Sea level to 10,000 ft.
Dimensions	9.21"(L) x 4.2"(W) x 0.56" (H)

Appendix G Record the Settings

View and Edit Logical Drives

Logical Drive Information

LG	RAID Level	#On-Line (DRV=)	#STB (SB=)	Logical Drive Name

Partition Information

LG	Partition	Size (MB)	LG	Partition	Size (MB)

View and Edit Host LUNs

LUN Mappings

Host Channel	Pri. / Sec. Controller	SCSI ID	LUN	Logical Drive	Partition	Size

View and Edit SCSI Drives

Slot	Chl	ID	Size (MB)	Ultra? (Y/N)	Wide? (Y/N)	LG DRV? Global Spare? Local Spare?	Vendor & Product ID
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	
						LG	

View and Edit SCSI Channels

Chl	Mode (Host / Drive)	Default Sync Clock	Default Wide	Terminator Diff/Enable/ Disable/	Current Sync Clock	Current Wide
0						
1						

View and Edit Configuration Parameters

Caching Parameters

Write-back Cache	Enabled	Disabled
Optimization for	Random I/O	Sequential I/O

Host Side SCSI Parameters

Maximum Queued I/O Count	Auto	_____
LUNs per Host SCSI ID	1 LUN	2 LUNs 4 LUNs 8 LUNs

Drive Side SCSI Parameters

SCSI Motor Spin-up	Enabled	Disabled
SCSI Reset at Power Up	Enabled	Disabled
Disk Access Delay Time	No Delay	_____ Seconds
Maximum Tag Count	Disabled	_____

Disk Array Parameters

Rebuild Priority	Low	Normal	Improved	High
Verifications on Writes				
Verifications on LD Initialization Writes	Enabled	Disabled		
Verifications on LD Rebuild Writes	Enabled	Disabled		
Verifications on Normal Drive Writes	Enabled	Disabled		

Define Peripheral Device Active Signal

Power Supply Fail Signal	Active High	Active Low
Fan Fail Signal	Active High	Active Low
Temperature Alert Signal	Active High	Active Low
UPS Power Fail Signal	Active High	Active Low

View System Information

Total Cache Size	EDO DRAM	Normal DRAM	_____ MB
Firmware Version			
Bootrecord Version			
Serial Number			

Index

A

ASPI, A-1

automatic rebuild, 3-9

B

bad sector reassignment, 2-1

basic operational set-up, 4-4

beeper

 mute, 8-60

BIOS

 RAID Manager, 5-1, 7-5, 8-1

BIOS configuration utility, 7-1

building a RAID system drive, 6-1

C

cable specifications

 SCSI, B-1

cache

 disable write-back during OS installation, A-1

 display of RAM type and size, 7-1

 enable write-back, 8-49

cache parameters, 3-12

 record of settings, G-3

capacitance, B-1

changing the password, 8-61, 8-62

concurrent rebuild

 in RAID (0+1), 3-10

Index

- configuration parameters
 - viewing and editing, 8-49
- configure
 - BIOS, 7-1
 - card, 7-1
 - SCSI, 7-1
- configuring RAID, 6-1
- controller
 - maintenance, 8-65
 - reset, 8-63
 - shutdown, 8-64
- controller name, 8-58
- controller parameters, 8-58
- CPU, 1-1, 2-2
- Ctrl-I, 7-1

D

- data cache, 2-2
- data rebuilding, 2-1
- DC resistance, B-1
- DEC Alpha/Windows NT
 - installing driver during NT v4.0 installation, A-18
 - installing driver in existing NT v4.0 system, A-19
- default setting
 - restoring, 7-1, 8-48
- delay skew, B-1
- Device #, 7-1
- disable
 - write-back, 8-49
- disabling the password, 8-63
- disconnecting support, 8-43

disk access delay time, 3-13, 3-14, 8-54

disk array parameters, 3-11
 record of settings, G-3

DOS ASPI drivers
 installation, A-1

drive failure management, 3-5

drives
 identifying, 3-7

drive-side SCSI parameters, 3-12, 8-52
 record of settings, G-3

dynamic logical drive expansion, 3-16, 8-20

F

firmware, 1-1, 2-2
 display of version number, 7-1

flash
 all SCSI drives, 3-8
 selected SCSI drive, 3-8

form factor, 2-1

G

global spare drive, 3-5
 adding one, 8-32
 deleting, 8-32

H

hardware installation, 4-1

hot swap, drive
 detection of followed by auto rebuild, 8-47

hot-swapping, 2-1

How does it work?

Index

logical drive expansion, 3-16
SAF-TE, 3-15
the RAID controller, 6-2

I

I/O port base address, 7-1

identifying drives, 3-7

idle drive

failure detection, 8-46

impedance, B-1

installation

DOS ASPI drivers, A-1

hardware, 4-1

NetWare v4.0x/v4.1/v4.11, A-5

OS/2 driver, A-23

Windows 95 driver, A-20

Installation

SCO Unix and UnixWare, A-27

IRQ, 7-1

J

JBOD, 3-2

K

keys

for navigation in Text RAID Manager, 5-1

L

Linux

drivers and utilities for, A-29

drivers and utilities for SPARC platform, A-36

- installing Red Hat, A-30
 - installing SlackWare, A-32
 - making floppy disks for Red Hat, A-29
 - making floppy disks for SlackWare, A-30
 - Text RAID Manager, A-33

 - local spare drive, 3-5
 - adding one, 8-31
 - deleting, 8-32

 - logical drive, 2-1
 - assigning a name, 8-18
 - creating, 8-10
 - defined, 5-1
 - deleting, 8-15
 - deleting a partition, 8-17
 - expansion, 3-16, 8-20
 - expansion – example using Windows NT, 3-19
 - explained, 6-3
 - mapping to an ID/LUN, 8-23
 - partitioning, 8-15
 - rebuilding, 8-19
 - record of settings, G-1
 - status, 8-3
 - viewing and editing, 8-10
 - viewing drives and drive members, 8-14

 - LUN, 2-1
 - defined, 6-2

 - LUN mappings
 - record of settings, G-2
 - viewing and deleting, 8-27
-

M

- main menu, 8-1, 8-2
 - manual rebuild, 3-9
 - maximum queued I/O count, 8-51
 - maximum synchronize transfer clock, 8-40
 - maximum tag count, 8-45, 8-54
 - maximum transfer width, 8-41
-

Index

- mirroring
 - RAID 1, 3-3
 - mode 1 expansion, 3-17
 - mode 2 expansion, 3-17
 - mute beeper, 8-60
-

N

- NetWare
 - v4.0x installation, A-5
 - v4.1 installation, A-5
 - v4.11 installation, A-5
 - NRAID, 3-2
-

O

- optimization
 - for sequential or random I/O, 3-12
 - OS/2
 - command-line options of IFT-2101U2 OS/2 driver, A-25
 - driver installation, A-23
 - installing driver during v2.x/3.0 installation, A-23
 - installing driver in an existing v2.x/3.0 system, A-24
 - updating IFT-2101U2 OS/2 device driver, A-24
-

P

- parameters
 - cache, 3-12, 8-49
 - controller, 8-58
 - disk array, 3-11
 - drive-side SCSI, 3-12
 - SCSI, 8-51
 - parity check, 8-42
 - partition
 - record of settings, G-1
-

partitions, 2-1
 mapping them to LUNs, 6-4

password
 changing it, 8-61, 8-62
 disabling it, 8-63
 setting a new one, 8-62
 validation timeout, 8-59

PCI bus #, 7-1

periodic drive check time, 8-46

periodic drive swap auto check, 3-16, 8-47

peripheral device active signal
 record of settings, G-4

port
 I/O, 7-1

propagation delay, B-1

Q

queued I/O count
 maximum, 8-51

quick setup, 5-1

R

RAID
 (0+1), 3-4
 0, 3-3
 1, 3-3
 3, 3-4
 5, 3-5
 a definition, 3-1
 configuring, 6-1

RAID level, 5-1

RAID levels, 3-1

RAID management, 3-1

Index

- random I/O
 - optimization for, 3-12, 8-50
 - rebuild
 - automatic, 3-9
 - manual, 3-9
 - rebuild priority, 3-11, 8-56
 - rebuild, concurrent
 - in RAID (0+1), 3-10
 - remote administration, 9-1
 - reset controller, 8-63
-

S

- SAF-TE, 3-15
 - periodic check time, 8-47
 - SCO Unix
 - driver installation, A-27
 - SCSI
 - I/O timeout, 3-13, 8-44
 - SCSI bus
 - maximum throughput, B-1
 - width, B-1
 - SCSI channel, 6-2
 - record of settings, G-3
 - setting the terminator, 8-35
 - status, 8-6
 - viewing and editing, 8-33, 8-34
 - SCSI drive
 - record of settings, G-2
 - scanning a new one, 8-29
 - status, 8-4
 - viewing and editing, 8-28
 - viewing information, 8-30
 - SCSI drive channel
 - viewing and editing, 8-38
-

- SCSI ID, 6-2
 - viewing and editing, 8-34
- SCSI ID map
 - viewing and editing, 8-23
- SCSI motor spin-up, 3-12, 8-52
- SCSI parameters, 8-51
 - drive-side, 8-52
- SCSI reset at power-up, 3-13, 8-53
- SCSI standards, B-1
- SCSI target
 - viewing and editing, 8-38
- sequential I/O
 - optimization for, 3-12, 8-50
- set-up
 - basic operation, 4-4
- shutdown controller, 8-64
- single-drive control
 - JBOD, 3-2
- slot number, 8-39
- SNMP
 - establishing the connection, 9-1
 - GUI RAID Manager via, 9-1
- Solaris
 - drivers and utilities for x86 platform, A-34
 - installing SPARC platform driver and Text RAID Manager, A-37
 - installing x86 platform driver and text RAID Manager, A-35
 - Text RAID Manager, A-38
- spanning
 - NRAID, 3-2
- spare drive
 - adding a global, 8-32
 - adding a local, 8-31
 - global, 3-5
 - local, 3-5
 - priority, 3-6

Index

- spare drive deleting, 8-32
 - spare drive operation, 2-1
 - status
 - SCSI channel, 8-6
 - SCSI drive, 8-4
 - striping
 - RAID 0, 3-3
 - striping with dedicated parity disk
 - RAID 3, 3-4
 - striping with interspersed parity
 - RAID 5, 3-5
 - striping with mirroring
 - RAID (0+1), 3-4
 - synchronize transfer clock
 - maximum, 8-40
 - synchronous clock
 - frequency, D-1
 - period, D-1
 - system functions, 8-60
 - system information
 - record of settings, G-4
 - viewing, 8-66
-

T

- tag command queuing, 8-45
 - tag count
 - maximum, 3-14, 8-45, 8-54
 - Text RAID Manager, 8-1
 - keys, 5-1
 - transfer rate, B-1
 - transfer speed
 - setting it, 8-36
 - transfer width
-

- maximum, 8-41
- setting it, 8-37

troubleshooting, E-1

U

UnixWare

- driver installation, A-27

V

verification on writes, 8-57

verify-after-write, 3-11

viewing current settings, 8-8

viewing system information, 8-66

VT-100 terminal, 5-1

W

Windows 95

- driver installation, A-20
- updating device driver, A-22

Windows NT

- example of RAID expansion, 3-19
- installing driver during DEC Alpha v4.0 installation, A-18
- installing driver during v4.0 installation, A-16
- installing driver in existing DEC Alpha v4.0 system, A-19
- updating device driver in v3.1/3.51 system, A-15

This page is left intentionally blank.

GUI RAID Manager

For ASUS Disk Array Controllers

User's Guide

Revision 1.5



Copyright Information

Copyright © 1999

This edition first published 1999

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of ASUSTeK Computer Inc.

Disclaimer

ASUSTeK Computer Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, ASUSTeK Computer Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revisions or changes.

Trademarks

ASUS and ASUSTeK are registered trademarks of Computer Inc.

Microsoft, Windows, Windows NT and MS-DOS are registered trademarks of Microsoft Corporation in the U.S. and other countries.

Novell and NetWare are registered trademarks of Novell, Inc. in the U.S. and/or other countries.

OS/2 and OS/2 Warp are registered trademarks of International Business Machines Corporation in the U.S.

Solaris is a trademark of Sun Microsystems, Inc.

SCO, OpenServer, and Unix Ware are trademarks or registered trademarks of The Santa Cruz Operation, Inc. in the U.S. and/or other countries.

All other names, brands, products or services are trademarks or registered trademarks of their respective companies.

Table of Contents

About this Guide	v
Overview of the User's Guide	vi
1 Introduction	1
1.1 System Description.....	2
1.2 Feature Summary.....	3
1.3 Feature Highlights	6
2 Installation	1
2.1 System Requirements	2
2.2 Hardware Setup.....	3
2.3 In-band SCSI.....	8
2.4 Software Setup.....	22
2.5 Upgrading Firmware	27
3 Basic Operations at Startup	1
3.1 Starting the GUI RAID Manager.....	1
3.2 Connecting and Disconnecting from a Disk Array.....	4
3.3 Setting Up Security.....	13
3.4 Displaying and Hiding the Toolbar	14
3.5 Displaying and Hiding the Status Bar	16
3.6 Working with Windows.....	18
3.7 Exiting GUI RAID Manager	37
4 Array Management	1
4.1 Background Information.....	3
4.2 Operation without Spare Drives	5
4.3 Before you Start	7
4.4 Defining Enclosures	8
4.5 Setting Controller Configuration	11
4.6 Setting Channel Configuration	13
4.7 Scanning in Drives.....	17
4.8 Creating and Deleting Logical Drives	19
4.9 Assigning Spare Drives.....	22
4.10 Rebuilding Logical Drives	24
4.11 Creating and Deleting Logical Volumes.....	25
4.12 Creating and Deleting Partitions.....	28
4.13 Mapping Logical Volumes/Partitions to Host LUNs.....	32
4.14 Displaying the Event Log	34
4.15 Monitoring Statistics.....	36
4.16 Dynamic Logical Drive Expansion.....	37

ASUS GUI RAID Manager: Table of Contents

4.17	Redundant Controller	50
5	Notification Configuration.....	1
5.1	Introduction	1
5.2	Before You Begin.....	2
5.3	Notification Levels	9
5.4	Configuring Notification Options	11
5.5	Configuring a Pager Notification	13
5.6	Configuring a Fax Notification.....	21
5.7	Configuring an E-Mail Notification.....	24
5.8	Configuring a Broadcast Message Notification.....	27
6	Running in Demo Mode.....	1
6.1	Introduction	2
6.2	Starting the Demo Program.....	3
6.3	Failing a Drive.....	5
6.4	Exiting the Demo Program	8
A	Command Summary	1
	Menu Commands	1
	Command Buttons	6
B	Troubleshooting	1
	Startup Errors	2
	Notification Errors	3
	SNMP Errors	5
C	RAID Levels.....	1
	RAID Description	1
	Non-RAID Storage.....	1
	RAID 0.....	2
	RAID 1.....	3
	RAID 1(0+1)	4
	RAID 3.....	5
	RAID 5.....	6

About this Guide

Congratulations on your decision to use ASUS' GUI RAID Manager disk array management program. This management program allows you to control and monitor disk array systems, either from a local host, or from a remote station connected through a local area network (LAN), telephone line, or the Internet.

This guide discusses how to install and use the GUI RAID Manager to manage disk array systems incorporating ASUS' PCI-to-SCSI or SCSI-to-SCSI controllers.

In addition to the GUI RAID Manager, you can also use the on-board RS-232 menu interface (SCSI-to-SCSI controllers only) or the text-based RAID Managers available for various operating systems to manage disk array systems incorporating ASUS' disk array controllers. For information about these programs, see the documentation that comes with your hardware.

Overview of the User's Guide

- ◆ Chapter 1, *Introduction*. Provides information about the GUI RAID Manager, including the system description, feature summary, and feature highlights.
- ◆ Chapter 2, *Installation*. Discusses how to install the GUI RAID Manager to your computer. Discussions include the system requirements, setting up the hardware, software installation, and how to update your software through software downloading from ASUS' FTP site.
- ◆ Chapter 3, *Basic Operations at Startup*. Discusses the basic operations at system startup. These include starting the GUI RAID Manager, connecting and disconnecting from a disk array system, setting up the system security, displaying and hiding the toolbar and status bar, working with various disk array windows, and exiting from the program.
- ◆ Chapter 4, *Array Management*. Provides information on disk array management, including defining enclosures, setting the controller and channel configurations, scanning in drives, creating and deleting logical drives, assigning spare drives, rebuilding logical drives, creating and deleting logical volumes, defining volume partitions, mapping logical volumes to host LUNs, deleting LUN mappings, displaying the contents of the log file, and monitoring the disk array statistics.
- ◆ Chapter 5, *Notification Configuration*. Describes how to configure the GUI RAID Manager notification functions for the pager, fax, e-mail, and broadcast. Information about the supported notification levels are also provided to aid in the explanation of these functions.

- ◆ Chapter 6, *Running in Demo Mode*. Provides information on how to run the GUI RAID Manager in demo mode. You can use the demo mode as a tool for learning the basics of disk array system management and for demonstrating the GUI RAID Manager functionality without connecting to a real disk array.
- ◆ Appendix A, *Command Summary*. Summarizes the available commands and command buttons in the GUI RAID Manager.
- ◆ Appendix B, *Troubleshooting*. Provides troubleshooting tips for some problems you may encounter while using the GUI RAID Manager.
- ◆ Appendix C, *RAID Levels*. Provides information about the various RAID levels.

1 Introduction

This chapter provides information about the GUI RAID Manager management program. These include the following topics:

- ◆ System description
- ◆ Feature summary
- ◆ Feature highlights

1.1 *System Description*

The ASUS' GUI RAID Manager is a Windows-based program specifically designed for use in managing disk array systems implemented using any of ASUS' line of PCI-to-SCSI or SCSI-to-SCSI controllers (GUI stands for graphic user interface.) The GUI RAID Manager provides a user-friendly interface that facilitates understanding of the relationship between disk array elements and simplifies the normally complicated process of array configuration. The GUI RAID Manager also provides real-time reporting on the status of the entire array, thus making the task of monitoring disk arrays virtually effortless.

The GUI RAID Manager complements the on-board console interface found on the ASUS' SCSI-to-SCSI controllers and a line of host-based, text-based RAID Managers providing the same functionality, but with greater ease of use. The following sections describe the outstanding features of the GUI RAID Manager.

1.2 Feature Summary

The list below summarizes the GUI RAID Manager features.

- ◆ User-friendly graphical interface running under the Windows NT or Windows 95/98 environment
- ◆ Supports the entire new line of ASUS' SCSI-to-SCSI and PCI-to-SCSI RAID controllers
- ◆ Communicates with the controllers via the RS-232 cable, over a LAN, telephone line, Internet, over the PCI bus (PCI-to-SCSI controllers only), or over the SCSI bus (SCSI-to-SCSI controllers only)
- ◆ Supports multiple instances of RAID managers over the network, allowing multiple management sessions with a disk array system
- ◆ Illustrates graphically and clearly the relationship between various disk array elements
- ◆ *At a glance* monitoring of the entire disk array status
- ◆ Supports remote management over the network of host/agent running Windows NT or Windows 95/98 via the Simple Network Management Protocol (SNMP)
- ◆ Supports remote management over the telephone line via a pair of modems; one directly connected to the RS-232 interface of the controller, the other connected to the serial port of the remote station running the GUI RAID Manager
- ◆ Provides standard disk array functions, including examining and modifying controller configuration; viewing and monitoring configuration and status of physical drives; scanning in new physical drives; creating, deleting, and monitoring configuration and status of

ASUS GUI RAID Manager: Introduction

logical drives; rebuilding logical drives; defining spare drives; creating, deleting, and partitioning logical volumes; and mapping logical volume partitions to specific host channels/LUNs

- ◆ Enclosure management functions, including defining multiple customizable enclosures, dimensions, and number of drives; monitoring physical drives, power supply, fan, and temperature status; displaying relative location of failed physical drives for reduced risk of replacing the wrong drives
- ◆ Provides a log file for logging in various event occurrences, including the time when an event occurs, event severity, and event description; log file can be accessed using any text editor program
- ◆ Supports statistics monitoring for displaying I/O throughput history
- ◆ Provides innovative, user-configurable event notification functions
 - Configurable severity level qualifying the event severity that will initiate the selected notification sequence
 - Configurable latency time between event occurrence and notification sequence initiation provides local administrator the option to abort issuance of the notification sequence
 - Pager/telephone notification via a local modem:
 - Provides user-configurable address book for keeping names and numbers to be paged/called, and message to be sent

- Optional notification retransmission until addressee responds locally at the console or remotely over the Local Area Network (LAN), Internet, or modem
- Configurable latency time between notification retransmission; can be set to different values at different times of the day
- E-Mail notification via the MAPI service of Windows NT or Windows 95/98:
 - Provides user-configurable address book for keeping names, E-mail addresses, and messages to be sent
- Broadcast notification over the LAN:
 - Provides user-configurable address book containing names/groups and network addresses to which the specified message will be broadcasted
 - Broadcasts user-configurable message along with the event description
- Facsimile (FAX) notification via a local FAX/modem:
 - Provides user-configurable address book containing names, FAX numbers, and messages to be sent
 - User-configurable FAX messages sent along with the event description
 - Automatic message retransmission in the event previous transmission attempts fail

- ◆ Provides password protection for guarding against unauthorized modification of disk array configuration.
- ◆ Provides Demo mode for use as a learning tool and for demonstration purposes. You can perform experimentation on various disk array configurations and monitor the performance of the system under such conditions. This Demo supports both the SCSI-to-SCSI and PCI-to-SCSI controllers.

1.3 **Feature Highlights**

This section explains in detail the important features of the GUI RAID Manager.

1.3.1 Graphical User Interface

The GUI RAID Manager's graphical interface is based on the Windows specifications. It draws symbolic icons representing physical and logical drives, and logical volumes on the screen to identify the current configuration of a disk array system. Pull-down and pop-up menus are used with all command options listed. You just point and click the mouse button to select an icon or command. The program also identifies the current status of various drives by changing the colors of their respective icons.

With the Windows interface, complicated disk array operations such as logical drive and logical volume creation, drive partitioning, and drive partition mapping to host channels/LUNs only involve a few mouse clicks.


1.3.2 Enclosure Management

The GUI RAID Manager provides a window dedicated to enclosure management. Multiple customizable enclosures can be defined within this window, including the number of drives

per row and column, and drive orientation. Once an enclosure is defined, drives can be dragged and dropped into their respective drive bays corresponding to their actual locations. In this way, drives can be monitored in an enclosure-relative context.

The enclosure window provides real-time reporting of the status of the connected physical drives. When a drive fails, the system highlights the corresponding icon of the failed drive by placing a red **X** mark on it; when you remove a drive, its icon is removed from the enclosure window. This feature is particularly useful in cases where a drive fails, and you need to identify its exact location for subsequent replacement.

In addition to monitoring drives in the enclosure, the enclosure window also allows you to monitor the status of the power supply, fan, temperature inside the enclosure, and the status of the uninterruptible power supply (UPS) supplying power to the enclosure.




1.3.3 Powerful Event Notification Function

The GUI RAID Manager sends notifications to administrators for reporting event occurrences and status changes of the disk array system. These notifications can be sent via a local modem to a pager or telephone, via the Internet as E-mail messages, via

ASUS GUI RAID Manager: Introduction


a LAN as broadcast packets, or via FAX/modem as FAX messages. Any number of notification destinations can be set with messages user-configurable through the address book. Optional notification retransmission can be activated for each destination to ensure message reception by the intended addressee. Furthermore, you can specify retry periods depending on your specific needs.




1.3.4 Remote Management via SNMP or Modem

The GUI RAID Manager supports remote management of the ASUS' disk array controllers over a LAN using SNMP, or over the telephone line using a dial-up modem. Management over the LAN is achieved through the exchanges of SNMP management packets between the remote GUI RAID Manager station and the SNMP agent on the Windows NT or Windows 95/98 local host. The remote GUI RAID Manager sends management requests to the SNMP agent, which in turn checks the connected controller,

and then sends back a reply to the requesting manager. The following figure shows a typical SNMP connection:



Alternatively, for management at even greater distances, the RS-232 port on the RAID controller can be directly connected to a modem and a GUI RAID Manager running on a remote station can dial in and manage the array over the telephone line. See the figure below for information.



1.3.5 Password Protection

The GUI RAID Manager comes with password protection to prevent unauthorized users from maliciously modifying the configuration of the disk array system. This security feature is put into effect the first time an attempt is made to modify the disk array configuration after turning on the GUI RAID Manager station or after the station comes back from a period of inactivity.

With the password security feature, you have the luxury of leaving your GUI RAID Manager station unattended knowing that the currently managed disk array system is safe from any unauthorized modifications.

1.3.6 Demo Mode

The GUI RAID Manager provides a Demo program for use as a learning tool and for demonstration purposes. This tool allows you to experiment on various disk array configurations and monitor how the system responds and operates under such conditions without connecting to a real disk array.

This Demo program supports all management functions available in the GUI RAID Manager, making your imaginary system as real as possible. You can select the controller for your imaginary system, the number of hosts (for SCSI-to-SCSI controller only) and drive channels, the number of physical drives, configure your logical drives and volumes, partition logical volumes, and map partitions to hosts. You can even force drives to fail and observe the system's reaction.



2 Installation

This chapter contains information about software setup and hardware setup for local and remote management. The following topics are discussed:

- ◆ System requirements
- ◆ Hardware setup
- ◆ Software setup
- ◆ Downloading new releases of the GUI RAID Manager program

2.1 System Requirements

The minimum hardware and software requirements for the GUI RAID Manager are listed below.

System running the GUI RAID Manager

- ◆ IBM-compatible 386 or above running Windows NT or Windows 95/98
- ◆ At least 8 MB of RAM
- ◆ At least 3 MB of free hard disk space
- ◆ VGA monitor
- ◆ Microsoft-compatible mouse
- ◆ At least one available RS-232 port (if remote management over the telephone line is desired)
- ◆ Hayes-compatible modem (if pager/telephone event notification is desired) or FAX/modem (if FAX event notification is desired)
- ◆ SNMP service for Windows NT (if SNMP remote management is desired)

Local host running ASUS' SNMP agent (for SNMP remote management only)

- ◆ IBM-compatible 386 or above running Windows NT or Windows 95/98
- ◆ SNMP service for Windows NT/Windows 95/98 (if SNMP agent is under Windows NT or Windows 95/98 environment)

2.2 Hardware Setup

The GUI RAID Manager supports both local and remote management of the ASUS' disk array system. Local management refers to management of the disk array from a local host – management transactions traverse the PCI bus (for PCI-to-SCSI controller) or an RS-232 cable (for SCSI-to-SCSI controller) connected between the controller and the host's serial interface. Remote management refers to management of the disk array from a remote station connected to the controller either via a modem or through a network cable.


Typically, management will be done locally. A local host runs the GUI RAID Manager to configure and monitor the connected controller. Local management is simpler than remote management for it requires less hardware in its configuration. Remote management is more complicated than local management but provides the following benefits:

- ◆ Allows management even at distant remote places. Since remote management utilizes the network cable or the telephone line, management anywhere around the globe is possible. All you need is a simple attachment to an existing network where the disk array's host exists, or dial up the number of the modem connected to the controller.
- ◆ Allows multiple instances of GUI RAID Manager stations over the network managing concurrently a particular disk array system.

Depending on your specific needs and configuration requirements, you may perform management either from a local host or from a remote station. The following sections describe how to set up your hardware for local and remote management.

2.2.1 Local Management

For local management, the controller is either installed in (for PCI-to-SCSI controller) or connected to (for SCSI-to-SCSI controller) the host. The following figure illustrates a typical setup for a PCI-to-SCSI controller:




Since the controller is already installed in the host, no extra connection is necessary. Just load the necessary driver for the controller and then run the GUI RAID Manager from the local host to start management of the disk array system.

► **Setting up a SCSI-to-SCSI controller using RS-232**

1. Connect the RS-232 port of the SCSI-to-SCSI controller to a null modem using the appropriate RS-232 cable. Do the same to the serial interface of the local host. If your local host has more than one serial interface, write down the corresponding port number of the selected port (that is, COM1, COM2, etc.).

2. Configure the RS-232 serial communication port of the local host to correspond to that of the interface on the controller. You will only need to set the baud rate; the GUI RAID Manager automatically sets the other communications parameters. If you want to modify the baud rate setting on the controller, use the on-board console interface or the GUI RAID Manager. For information on the latter, see Chapter 4, *Array Management*.


Your hardware should be set up as shown in the following figure:



2.2.2 Remote Management


You can set up your hardware two ways in remote management: network and telephone. Network setup provides a faster data transfer rate than the telephone setup for it utilizes the network bandwidth of 10 Mbps (million bits per second) for Ethernet, 100 Mbps for Fast Ethernet, and so on; the telephone setup is restricted to the speed of the modem, which is 38.4 Kbps maximum (currently). Another advantage of using the network is you can have your GUI RAID Manager station manage other disk array systems on the network. Alternatively, you can manage the disk array system from other GUI RAID Manager stations on the network.

Network setup requires running the GUI RAID Manager on the target manager station(s), and enabling the SNMP service on the local host. The following figure illustrates a typical network setup:



Management via the telephone line is slower but it allows management of the disk array system even from distant remote locations. As long as you have a telephone line and a modem, you can perform management anywhere around the globe. The following figure displays the hardware configuration for management via the telephone line:

ASUS GUI RAID Manager: Installation



To manage the disk array system, just dial in the number of the modem connected to the SCSI-to-SCSI controller.

NOTES: Ensure that the baud rates of the RS-232 port and the modem are set accordingly; otherwise, you will encounter communication problems.

The PCI-to-SCSI controller does not support direct connection to a modem for remote management. To manage this controller using the modem, you will need to connect the modem instead to the local host's serial interface. This user's guide does not provide information on this type of configuration.

2.3 *In-band SCSI*

What is it and what is it used for?

These days more and more external devices require communication with the host computer for device monitoring and administration. This is usually done through RS-232C ports.

An alternative means of communication is now available for SCSI-to-SCSI RAID controllers—In-band SCSI. The traditional way for SCSI controllers to communicate with the host computer has been via software (such as the GUI RAID Manager) using an RS-232C connection. With In-band SCSI, integrators have more flexibility. They may use RS-232C or the existing SCSI cable instead.


How is it able to use the SCSI cable? In-band SCSI technology translates the original commands into standard SCSI commands. These SCSI commands are then sent to and received from the SCSI raid controller. The GUI RAID Manager can administrate the RAID controller just as it could before via RS-232C. (Note: It is assumed that users of In-band SCSI possess the following: a third-party SCSI adapter and a channel on their ASUS RAID controller that can be designated as a host channel.) Both of these are required for In-band SCSI communication between the host and the RAID controller.)

2.3.1 How Do You Configure the GUI RAID Manager to Use In-band SCSI?

RAID Controller Adjustments

Don't disconnect your RS-232C cable yet! It is required for another 10 minutes or so. Some adjustments must be made to the RAID

controller and to the host computer's SNMP settings before the two can communicate using SCSI commands. (Note: The SNMP settings must be changed prior to installation of the GUI RAID Manager. See *SNMP Settings* below for a detailed explanation.) The RAID controller settings can be changed using the Front Panel. (Your front panel may be different in appearance from the one shown in this example.)



From the Main Menu, press ▼ or ▲ to select "View and Edit Configuration Parameters."

View and Edit
Config Parm's

Press <Enter>; and then use the ▼ or ▲ to select "Host-side SCSI Parameters." Then press <Enter>.

Host-side SCSI
Parameters ..

You will need to make adjustments in the following four submenu's: Peripheral Device Type, Peripheral Device Qualifier, Device Support for Removable Media, and LUN Application. Different host operating systems require different adjustments. Look at the table below to find the proper settings for your host operating system.

**Peripheral Device Type Parameters Reference
for Various Operating Systems:**

Operating System	Peripheral Device Type	Peripheral Device Qualifier	Device Support for Removable Media	LUN Applicability
NT 4.0	3	connected	disabled	All Undefined LUNs
NT 5.0	3	connected	enabled	All Undefined LUNs
NetWare 4.x	1f	connected	disabled	All Undefined LUNs
SCO Unix 5.0x	7f	connected	either is okay	All Undefined LUNs
UnixWare 2.1x	3	connected	either is okay	All Undefined LUNs
Solaris 2.5.x/2.6	7f	connected	either is okay	All Undefined LUNs

Peripheral Device Type Settings:

Device Type	Setting
No Device Present	7f
Direct-access Device	0
Sequential-access Device	1
CD-ROM Device	5
Scanner Device	6
MO Device	7
Unknown Device	1f
Processor Type	3

Example: Settings for Windows NT 4.0

The settings for Windows NT 4.0 are provided here as an example. For the settings for other operating systems, please refer to the table above, *Peripheral Device Type Parameters Reference for Various Operating Systems*.

On the front panel, use ▼ or ▲ to select "Peripheral Device Type Parameters"; and then press <Enter>.

Periph	Dev
Type Parameters	

ASUS GUI RAID Manager: Installation

(For this example, we assume that there are currently no peripheral devices.)

```
Device Type -  
No Device (0x7f)
```

Press ▼ or ▲ to choose "Unknown Device - 1f".

```
Set Device Type?  
Unknown (0x1f)
```

Press <Enter> to confirm the selection. Now that we have changed the Peripheral Device Type, let us set the Peripheral Device Qualifier. Press <Esc> to return to the sub-menu's mentioned above. Use the arrow keys to scroll down to Device Qualifier., press ▼ or ▲ to select "Device Qualifier Connected. "

The default setting is "Connected." If your Front Panel reads "Disconnected," press <ENT> and you will be prompted to change to "Connected". If your Device Qualifier setting reads "Connected," press <Esc> to return to the Host-side SCSI submenu's.

```
Device Qualifier  
Connected
```

Use the ▼ or ▲ to select Support for Removable Media. The default setting

```
SupportRemovable  
Media - Disabled
```

is "Disabled." If the LCD reads "Enabled," press <Enter> and you will be prompted to accept a change. If the screen reads "Disabled," press <Esc> to return to the Host-side SCSI submenu's.

Press ▼ or ▲ to select "LUN Application"; and then press <Enter>. The default setting is "All Undefine LUN."

LUN Application-
All Undefine LUN

Press <Enter> and use ▼ or ▲ to select "Undefine LUN-0's."

Applies to ?
Undefine LUN-0's

Press <Enter> to accept. The screen should display the following message.

LUN Application-
Undefine LUN-0's

The RAID controller adjustments necessary to use In-band SCSI have been completed. For locally accessing the host computer (see section 4.10.3.1, *Local Connection — SNMP Not Required*), all steps


ASUS GUI RAID Manager: Installation

have been completed. For remotely accessing the host computer, further adjustments must be made (see section 4.10.3.2, *Remote Connection — SNMP Required*).

2.3.2 Using In-band SCSI in GUI RAID Manager


Local Connection — SNMP Not Required

If you are using the GUI RAID Manager on the host computer that is using In-band SCSI -- ie., 'local access' -- SNMP service is not required. You may now connect by going to FILE>CONNECT and selecting the port address.



Remote Connection — SNMP Required

SNMP Service is required to administrate a RAID controller installed in a remote computer. This passage describes how to establish a connection from the GUI RAID Manager to a RAID controller that is connected to a remote host via In-band SCSI. For information regarding other operations and of the GUI RAID Manager, please refer to the *GUI RAID Manager User Guide*.



In the figure above, the "Agent Site" is a host computer connected to a RAID controller via a SCSI cable. The "Manager Site" is a Windows NT system with the GUI RAID Manager. The Agent Site could be running an operating system other than Windows NT. ASUS provides the In-band SCSI SNMP agents for the following operating systems:

- ◇ Windows NT
- ◇ NetWare
- ◇ SCO Unix OpenServer
- ◇ SCO UnixWare
- ◇ Sun Solaris

ASUS GUI RAID Manager: Installation

The Manager Site should be a Windows NT Workstation or Server with SNMP service and the GUI RAID Manager installed.

Basic Procedures to Establish the Connection

The following criteria must be met for the Agent Site and Manager Site:

Checklist for Agent Site

1. The host computer is connected to the RAID controller via the host SCSI cable (the cable which is used to transfer data between the host computer and the RAID — there's no need for an extra SCSI cable.)
2. The host computer's operating system has SNMP service installed.
3. The host computer has the In-band SCSI SNMP agent installed for the corresponding operating system. (The example described herein is Windows NT.)
4. The host computer is up and running.

IMPORTANT:

This following applies to Windows NT 4.0 with Service Pack 3: if the "SNMP Service" is installed after the Service Pack 3 has been installed, Service Pack 3 must be re-installed in order for the SNMP service to work properly.

Checklist for Manager Site

1. The system is running Windows NT (Workstation or Server) and has SNMP Service installed.
2. The ASUS GUI RAID Manager was installed with the "SNMP Manager Site" option selected.
3. The GUI RAID Manager is running.

IMPORTANT:

This following applies to Windows NT 4.0 with Service Pack 3: if the "SNMP Service" is installed after the Service Pack 3 has been installed, Service Pack 3 must be re-installed in order for the SNMP service to work properly.

Example Settings for Agent Site Using Windows NT

1. Install SNMP Service in Windows NT. Look for the "Network" icon in the Control Panel. Double click on the "Network" icon to open it.

ASUS GUI RAID Manager: Installation



The Properties window appears. Choose the "Service" tab. If the SNMP Service is already installed, please go ahead to step called "Install the SNMP Agent and GUI RAID Manager." If the SNMP Service is not yet installed, click on "Add" and choose "SNMP Service" to install.


IMPORTANT:

This following applies to Windows NT 4.0 with Service Pack 3: if the "SNMP Service" is installed after the Service Pack 3 has been installed, Service Pack 3 must be re-installed in order for the SNMP service to work properly.

2. Install the SNMP Agents and GUI RAID Manager. The GUI RAID Manager can install the In-band SCSI SNMP Agent during installation. During GUI RAID Manager installation, be sure to select both the "SNMP Manager Site" and "SNMP Agent Site" options. Complete the installation by following the on-screen instructions.


Example Settings for Manager Site

1. Install the SNMP manager and GUI RAID Manager. During the installation of GUI RAID Manager, click to select the option "SNMP Manager Site." Complete the installation by following the on-screen instructions.




1. Run the GUI RAID Manager. Start the connection by choosing FILE>CONNECT>SNMP.

ASUS GUI RAID Manager: Installation



2. The "Setting of SNMP Interface" window appears. Enter the IP address and community name of the Agent Site. For "Agent-site Communication Type," choose "SCSI Bus Interface." The "Controller Index" refers to the sequence of the RAID controller which is going to be administrated. If only one RAID controller is installed in the agent site computer, choose "0". If there is more than one RAID controller installed in the agent site computer, choose "1" to administrate the second RAID controller. Choose "2" to administrate the third RAID controller, etc.



3. After the connection is established, all of the operations in the GUI RAID Manager are the same as before (please refer to the *GUI RAID Manager User Guide* for complete details on its operation.)

2.4 Software Setup

This section discusses how to set up the GUI RAID Manager in your system. Before proceeding with the setup procedure, read through the notes listed in the *Before you Start* section. You will need the information provided in this section to complete setup successfully.

2.4.1 Before you Start

Before starting with setup, read through the notes listed below, and ensure that you understand each. These notes will help facilitate the setup process for you. If you need additional information, see the *Hardware Setup* section in this chapter.

ASUS GUI RAID Manager: Installation

- ◆ Ensure that your system meets the minimum hardware and software requirements listed in the *System Requirements* section.
- ◆ Ensure that the disk array system is installed properly. For the installation procedure, see the documentation that came with the controller.
- ◆ For local management (that is, management from the local host) and remote management via the telephone line, you will only need to set up for a Local Manager Site. For fast setup, just accept the default values presented by the setup program.
- ◆ For remote management over the network using SNMP, ensure that the remote manager station has Windows NT. You will need to set up for an SNMP Manager Site on the remote station, and SNMP Agent Site on the local host. The setup program helps you achieve these tasks by providing setup options.

2.4.2 Setting up the GUI RAID Manager

Follow these steps to set up the GUI RAID Manager on your system:

1. Insert DISK1 into the appropriate disk drive.
2. Run SETUP.EXE from DISK1. The setup welcome screen appears:




3. If you are currently running other applications, close them first before proceeding with the setup process. This will minimize the possibility of encountering system errors during setup. Then, click OK to continue.



4. To accept the default destination directory, click on the setup button at the top left portion of the screen; to specify a different directory, click on the Change Directory button and then specify the directory you want. The following screen will then appear:


ASUS GUI RAID Manager: Installation




5. Select the appropriate option for the type of system on which you are setting up the GUI RAID Manager. If you are setting up on a host where array management will be performed, you only need the Local Manager Site option (selected by default); for a local host where SNMP transactions from remote manager stations will be processed, you need the SNMP Agent Site option; for a remote manager station where array management will be performed over the network, you need the SNMP Manager Site option.

To select an option, just check its corresponding check box. You may select more than one option if you want; be reminded though that the more options you select, the bigger the disk space requirement will be. Click Continue to proceed.

6. If you select the SNMP Agent Site option, the following message will appear:



If you select the same option, and the SNMP service is not installed to your system, this message appears:



Follow the instruction displayed on the screen. Click OK to continue.

Setup will then start copying the necessary files to the selected directory. After copying the files, the following screen will be displayed:



7. Click OK.
8. If necessary, restart the SNMP service.

Setup is complete. You may now start managing the disk array system. For information on first time operating instructions, see Chapter 3, *Basic Operations at Startup*.

2.4.3 Program Updates

As ASUS' valued customer, you are entitled to free program updates. You can download the latest GUI RAID Manager program from ASUS' FTP sites at ftp.ASUS.com in the U.S.A., or ftp.ASUS.com.tw in Taiwan. For more information about this service, call ASUS or call the local distributor or dealer in your area.

2.5 *Upgrading Firmware*

The SCSI-to-SCSI RAID controllers' firmware resides in Flash Memory that can be updated through the COM ports or In-band SCSI. New releases of the firmware are available in the form of a DOS file, which is located in the "pub" directory of ASUS' FTP site or on a 5.25" or 3.5" diskette. The file available at the FTP site is usually a self-extracting file that contains the following:

- FW30Bxyz Firmware Binary (where "xyz" refers to the firmware version)

- B30Buvw Boot Record Binary (where "uvw" refers to the boot record version)

- README.TXT Read this file first before upgrading the firmware or boot record. It contains the most up-to-date information which is very important to the firmware upgrade and usage.

These files must be extracted from the compressed file and copied to directory in drive C.

IMPORTANT:

- *Allow the downloading process to finish. Do not reset or turn off the computer or the controller while it is downloading the file. Doing so may result in an unrecoverable error that requires the service of the manufacturer.*
- *While the firmware is new, the boot record that comes with it may be the same version as the one in the controller. If this is the case, there is no need to upgrade the Boot Record Binary.*


Upgrading the firmware using In-band SCSI + GUI RAID Manager

The In-band SCSI connection and the ability to upgrade the firmware via In-band SCSI are supported in ASUS GUI RAID Manager, version 1.61B and later versions. This version of the GUI RAID Manager is for use with the firmware 2.11. If the firmware currently in the controller is earlier than 2.11, In-band SCSI is not supported.


Establish the In-band SCSI connection in GUI RAID Manager

Please refer to section 4.10.3 for details on establishing the In-band SCSI connection in GUI RAID Manager.

Upgrade Both Boot Record and Firmware Binaries



1. Double click on the controller panel to get the menu appears. Choose "Controller Maintenance" > "Advanced Maintenance" - > "Download Boot Record and Firmware".
2. Provide the boot record binary filename, the GUI RAID Manager will start to download the boot record binary to the controller.
3. After the boot record download completed, provide the firmware filename to the GUI RAID Manager. It will start to download the firmware to the controller.
4. Shutdown the system which is accessing the RAID, then reset the controller in order to use the new downloaded firmware.

Upgrade the Firmware Binary Only

1. Double click on the controller panel to get the menu appears. Choose "Controller Maintenance". If both boot record and firmware are desired to upgrade, choose "Download Firmware".
2. Provide the firmware filename to the GUI RAID Manager. It will start to download the firmware to the controller.
3. Shutdown the system which is accessing the RAID, then reset the controller in order to use the new downloaded firmware.

3 Basic Operations at Startup

This chapter discusses the basic operations you may want to learn first and tasks you may want to take care of when you start the GUI RAID Manager for the first time. These include the following topics:

- ◆ Starting the GUI RAID Manager
- ◆ Connecting and disconnecting from a disk array system
- ◆ Setting up security
- ◆ Displaying and hiding the toolbar
- ◆ Displaying and hiding the status bar
- ◆ Working with various system windows
- ◆ Exiting from the GUI RAID Manager

3.1 *Starting the GUI RAID Manager*

Depending on your hardware setup, you can start the GUI RAID Manager in various ways. For local management, your task is quite simple. Please refer to the appropriate section below for information.

▶ **Starting the GUI RAID Manager under the Windows 95/98 or Windows NT 4.0 environment**

1. From the **Start** menu, select **Programs → ASUS GUI RAID Manager**.

-or-

ASUS GUI RAID Manager: Basic Operations at Startup

Double-click on the ASUS GUI RAID Manager icon. The ASUS GUI RAID Manager main window appears on the screen.

2. Connect to the disk array system. For information on how to connect, see the *Connecting and Disconnecting from a Disk Array System* section of this chapter.

▶ **Starting the GUI RAID Manager under the Windows NT 3.5x environment**

1. Open the ASUS GUI RAID Manager group window from the Program Manager, if not yet open.
2. From the ASUS GUI RAID Manager group window, double-click on the ASUS GUI RAID Manager icon. The ASUS GUI RAID Manager main window appears on the screen.
3. Connect to the disk array system. For information on how to connect, see the *Connecting and Disconnecting from a Disk Array System* section of this chapter.

For remote management, see the appropriate section below.

▶ **Starting the GUI RAID Manager for remote management via network**

1. Turn on the local host and enable the appropriate SNMP service. For information on how to enable the SNMP service for Windows NT, Windows 95/98, or Novell NetWare, see their respective manuals.
2. Check to ensure that the local host is properly connected on the network. Take note of its IP address (or SNMP agent's name) and community names.

ASUS GUI RAID Manager: Basic Operations at Startup

3. Run the GUI RAID Manager on the remote station. If you are using Windows 95/98 or Windows NT 4.0, follow these steps:

- 3a. From the **Start** menu, select **Programs** → **ASUS GUI RAID Manager**.

-or-

Double-click on the ASUS GUI RAID Manager icon. The ASUS GUI RAID Manager main window appears on the screen.

If you are using Windows NT 3.5x, perform these steps:

- 3a. Open the ASUS GUI RAID Manager group window from the Program Manager, if not yet open.

- 3b. From the ASUS GUI RAID Manager group window, double-click on the ASUS GUI RAID Manager icon. The ASUS GUI RAID Manager main window appears on the screen.

4. Connect to the disk array system. For information on how to connect, see the *Connecting and Disconnecting from a Disk Array System* section of this chapter.

▶ **Starting the GUI RAID Manager for remote management via telephone line**

1. Ensure that a modem is connected to the RS-232 port of your SCSI-to-SCSI controller, and to the serial interface of your GUI RAID Manager station. Check that the baud rates of the ports and the modems are set accordingly.
2. From the GUI RAID Manager station, dial in the number of the modem connected to the controller.

3. When a link is established, connect to the disk array system. For information on how to connect, see the *Connecting and Disconnecting from a Disk Array System* section of this chapter.

3.2 **Connecting and Disconnecting from a Disk Array**

The GUI RAID Manager provides a feature that facilitates connection and disconnection from disk array systems. Before management can be performed on a particular disk array system, you need to establish first a connection between your GUI RAID Manager station and the target system. Once a connection is established successfully, management can be started.

Disconnection is used for breaking the link between the GUI RAID Manager station and the array system. This option is particularly useful in cases where multiple disk array systems are being managed at the same time – instead of restarting the GUI RAID Manager every time you need to switch to another system, you just need to disconnect from the current system and then connect to a new one.


The following discusses the various ways of connecting to a disk array system. Information on disconnection is provided at the latter part of this section.

▶ **Connecting to a PCI-to-SCSI controller from the local host**

1. From the **File** menu, select **Connect**.

-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:



Note that there will be one *PCI Bus* entry for each PCI-to-SCSI controller installed. If none are installed, then no *PCI Bus* entries will be displayed.

2. Select the corresponding entry for a PCI-to-SCSI controller. Based on the previous figure, the entry should be **PCI Bus #0 PCI Dev#12 Port:D000 Irq:11**.

The enabling of the toolbar buttons signifies a successful connection.


► **Connecting to a SCSI-to-SCSI controller from the local host**

1. From the **File** menu, select **Connect**.


-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:

ASUS GUI RAID Manager: Basic Operations at Startup



2. Select **RS-232**. The Settings of RS-232 Interface dialog box appears:



3. From the **COM Port#** drop-down list box, select which COM port on the local host is connected to the controller via the RS-232 cable. To select a different COM port, click on the down-arrow button at the right of the box, then select the desired option.
4. From the **Baud Rate** drop-down list box, select the baud rate setting on the RS-232 port of the controller. To select, perform the same procedure described in step 3.

You can modify the baud rate on the controller through the on-board console interface or through the GUI RAID Manager. For information on the latter, see Chapter 4, *Array*

Management. For information about the console interface, see the documentation that came with the controller.

5. Click OK.

The enabling of the toolbar buttons signifies a successful connection.

► **Connecting to a PCI-to-SCSI controller from a remote station (via network)**


1. From the **File** menu, select **Connect**.

-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:



2. Select **SNMP**. The Settings of SNMP Interface dialog box appears on the screen:



3. In the **Agent Name or IP Address** text box, type in the IP address of the local host where the target disk array system is connected. Alternatively, you may specify the host name of the local host.
4. In the **Community Name** text box, type in one of the community names of the SNMP agent. Community names act as passwords that screen accesses to the SNMP agent of a particular network device. Before access is granted to a requesting station, this station must incorporate a valid community name to its request; otherwise, the SNMP agent will deny access to the system.

By default, most network devices use “public” as one of their community names. This value is case-sensitive.

5. In the **Agent-side Communication Type** section, click on the **Host Bus Interface** option button. Then, select the corresponding index of the controller in the **Controller Index** drop-down list box. To select, click on the down-

arrow button at the right of the box, then select the option you need.

6. Click OK.

The enabling of the toolbar buttons signifies a successful connection.

► **Connecting to a SCSI-to-SCSI controller from a remote station (via network)**


1. From the **File** menu, select **Connect**.

-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:



2. Select **SNMP**. The Settings of SNMP Interface dialog box appears on the screen:



3. In the **Agent Name or IP Address** text box, type in the IP address of the local host where the target disk array system is connected. Alternatively, you may specify the host name of the local host.
4. In the **Community Name** text box, type in one of the community names of the SNMP agent. Community names act as passwords that screen accesses to the SNMP agent of a particular network device. Before access is granted to a requesting station, this station must incorporate a valid community name to its request; otherwise, the SNMP agent will deny access to the system.

By default, most network devices use “public” as one of their community names. This value is case-sensitive.

5. In the **Agent-side Communication Type** section, click on the **RS-232 Interface** option button. Then, specify the COM port number and the baud rate.

From the **COM Port#** drop-down list box, specify which COM port on the local host is used to connect to the disk array system. To select, click on the down-arrow button at the right of the box, then select the option you need.

From the **Baud Rate** drop-down list box, select the baud rate setting on the RS-232 port of the controller. To select, perform the same procedure described previously. If you wish to modify the baud rate setting on the controller, use the on-board console interface or the GUI RAID Manager. For information on the latter, see Chapter 4, *Array Management*.

6. Click OK.


The enabling of the toolbar buttons signifies a successful connection.

► **Connecting to a SCSI-to-SCSI controller from a remote station (via telephone line)**

1. From the **File** menu, select **Connect**.


-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:



ASUS GUI RAID Manager: Basic Operations at Startup

2. Select **RS-232**. The Settings of RS-232 Interface dialog box appears on the screen:



3. From the **COM Port#** drop-down list box, select which COM port on your GUI RAID Manager station you connected the modem. To select, click on the down-arrow button at the right of the box, then select the option you need.
4. From the **Baud Rate** drop-down list box, specify the baud rate of the modem connected to your GUI RAID Manager station. To select, perform the same procedure described in step 3.
5. Click OK.

The enabling of the toolbar buttons signifies a successful connection.

► **Disconnecting from the disk array system**

- From the **File** menu, select **Disconnect**.

All toolbar buttons, except the **Connect/Open** and **Notification** command buttons, turn gray signifying disconnection from the current disk array system.

3.3 *Setting Up Security*

The GUI RAID Manager provides password protection to prevent unauthorized modification of the system configuration. This protection, which is implemented on the GUI RAID Manager station, prompts a user for the station password the first time he or she attempts to modify the disk array settings after turning on the GUI RAID Manager station or after the station comes back from a period of inactivity. Specifying the correct password gives the user full control over the disk array system; specifying otherwise, only allows the user to view the current configuration of the system.


By default, the GUI RAID Manager station comes without any password, thus when prompted for the password for the first time, just press ENTER. After gaining control, set a password to provide security to the managed disk array system. The set password will be saved into the memory of the GUI RAID Manager station.

You can also set an inactivity time, which will determine when to reactivate the password security feature after a period of station inactivity. If, within the specified period, there is no activity from the keyboard or mouse, this security feature will be put back into effect – prompting again for the station password the first time there is an attempt to modify the disk array configuration. This feature is particularly useful in protecting unattended GUI RAID Manager stations.

▶ **Setting a password for the GUI RAID Manager station**

1. Display the Physical Drives window by clicking on the **Physical Drives** command button or selecting the **Physical Drives** command from the **Open** menu.
2. From the Physical Drives window, double-click on the displayed controller (that is, front panel for a SCSI-to-SCSI

controller or card layout for a PCI-to-SCSI controller). The Controller Settings dialog box appears:



3. Check the **Change Password** check box.
4. Type in the password you want in the **New Password** text box taking note that the password is case-sensitive.
5. Type in again the password in the **Verify Password** text box to confirm.
6. Click OK.

3.4 *Displaying and Hiding the Toolbar*

The GUI RAID Manager provides a toolbar located just beneath the menu bar for displaying the available command buttons. These buttons serve various purposes, which are described in detail in the *Working with Windows* section of this chapter.

ASUS GUI RAID Manager: Basic Operations at Startup

You have the option to display or hide the toolbar depending on your specific needs. If you need bigger working space for viewing the various disk array elements or for executing various management operations, hide the toolbar; if you need to use the command buttons for simplified operations, unhide the toolbar.

You also have the option to hide the status bar located beneath the windows display area for even bigger working space. For information about this option, see the *Displaying and Hiding the Status Bar* section next.

▶ **Hiding the toolbar**

- From the **View** menu, click on **Toolbar** until the check mark “√” next to this command disappears.

The toolbar will disappear from the ASUS GUI RAID Manager main window.

▶ **Unhiding the toolbar**

- From the **View** menu, click on **Toolbar** until a check mark “√” appears next to this command.

The toolbar is displayed back in the ASUS GUI RAID Manager main window.

3.5 ***Displaying and Hiding the Status Bar***

The status bar at the bottom of the windows display area supplies information about the results of the different disk array operations, and errors that occur on the system.

You can hide or display the status bar depending on your particular needs. If you need bigger working space, you can hide the status bar; if you are closely monitoring the status of the disk array system, unhide the status bar for a real-time report on the condition of the system.

You also have the option to hide the toolbar found just beneath the menu bar for even bigger working space. For information about this option, see the previous section, *Displaying and Hiding the Toolbar*.

▶ **Hiding the status bar**

- From the **View** menu, click on **Status Bar** until the check mark “√” next to this command disappears.

The status bar will disappear from the ASUS GUI RAID Manager main window.

▶ **Unhiding the status bar**

- From the **View** menu, click on **Status Bar** until a check mark “√” appears next to this command.

The status bar will reappear in the ASUS GUI RAID Manager main window.


3.6 Working with Windows

Just like any other Windows-based applications, the GUI RAID Manager works entirely with windows to facilitate various disk array operations. These windows follow the standard MS Windows specifications, thus steps for manipulating elements and windows within any GUI RAID Manager windows conform to the standard MS Windows procedures.

This section describes how to work with the GUI RAID Manager windows.

3.6.1 Using the Main Window

After starting the GUI RAID Manager, the ASUS GUI RAID Manager main window appears on the screen. All management operations pertaining to the disk array system will be performed within the main window. The following describes the various components found on the main window:




- ◆ The *menu bar* displays the available menus. Except for **Options**, all menus provide a list of commands for invoking various disk array and Windows-related

ASUS GUI RAID Manager: Basic Operations at Startup

operations. Most commonly used commands such as **Statistics** and **Event Log** come with command buttons to facilitate their execution – you can either select the command from the menu, or click on its respective command button on the toolbar. For a summary of the available commands, see Appendix A, *Command Summary*.

- ◆ The GUI RAID Manager provides *command buttons* to assist in the execution of most commonly used commands. These buttons are displayed on the toolbar, which can be hidden if bigger working space is required for certain management operations. For information on how to hide the toolbar, see the *Displaying and Hiding the Toolbar* section of this chapter.

The following figure displays the command buttons on the toolbar:



- The **Connect/Open** command button is used for connecting to a disk array system when you start the GUI RAID Manager. This button has the same function as the **Connect** command in the **File** menu. After establishing a connection with the target disk array system, this button changes to an **Open** button; this time, providing the same function as **Open** in the menu bar.


- The **Tile In-Sequence** command button arranges the displayed windows next to each other, with arrangement based on their uses, and each window reduced to fit all elements within its width. This button, however, only affects the Enclosure, Physical Drives, Logical Drives, Volume, Host LUN Assignment, and Statistics windows. This button has the same function as the **Tile In-Sequence** command in the **Window** menu.
- The **Enclosure** command button displays the Enclosure window for defining customizable enclosures. This button provides the same function as the **Enclosure** command in the **Open** menu.
- The **Physical Drives** command button displays the Physical Drives window for configuring the controller and the physical drives included in the disk array system. This button provides the same function as the **Physical Drive** command in the **Open** menu.
- The **Logical Drives** command button displays the Logical Drives window for creating and configuring logical drives in the disk array system. This button provides the same function as the **Logical Drive** command in the **Open** menu.
- The **Logical Volume** command button displays the Volume window for defining and configuring logical volumes in the disk array system. This button provides the same function as the **Logical Volume** command in the **Open** menu.
- The **Host LUN Assignment** command button displays the Host LUN Assignment window for assigning logical volume partitions to various host LUNs. This button provides the same function as the **Host LUN Assignment** command in the **Open** menu.

- The **Event Log** command button displays the Event Log window for viewing the contents of the log file. This button provides the same function as the **Event Log** command in the **Open** menu.
- The **Notification** command button allows you to specify the notification configuration of the disk array system. This button provides the same function as **Notification** in the menu bar.
- The **Statistics** command button displays the Statistics window for monitoring the performance of the disk array system. This button has the same function as the **Statistics** command in the **Open** menu.
- ◆ The *windows display area* is where the system displays the GUI RAID Manager windows. You have the option to arrange the displayed windows on this area in various ways depending on your specific needs. The **Window** menu provides you with the commands you will need to arrange these windows. For information on how to do this, see the *Arranging Windows* section of this chapter.
- ◆ The *status bar* displays results of various disk array operations, error messages, and information about specific elements in the system. You have the option to hide the status bar to free some space on the windows display area. For information on how to hide the status bar, see the *Displaying and Hiding the Status Bar* section of this chapter.
- ◆ The *scroll bars* let you move parts of a window into view when the entire window does not fit into the windows display area.

3.6.2 Using the Enclosure Window

The Enclosure window appears when you click on the **Enclosure** command button or select the **Enclosure** command from the **Open** menu. The Enclosure window allows you to define customizable enclosures for creating an exact replica of the disk array's drive bays, displaying the exact location of the physical drives, power supply, and fan. In addition, the Enclosure window helps you monitor the temperature inside the drive bays. (Chapter 4, *Array Management*, provides detailed information on how to create enclosures.)


The Enclosure window is particularly useful in monitoring the status of the physical drives. It provides you with a real-time report on the drive status, using symbols and colors to represent various conditions. The following figure illustrates how the GUI RAID Manager represents the various drive conditions:



The system places an **X** mark on the icon of a failed drive. Spare drives appear with their colors darker (shaded) than normal drives (for example, for the first logical drive, normal drives appear in yellow while the spare appears in dark yellow). When you remove a drive from the drive bay, its corresponding icon on the Enclosure window disappears.

NOTE: The Physical Drives window also provides you with a real-time report on the drive status, using the same symbols and colors to represent various conditions. What you see on the Enclosure window is also reflected on the Physical Drives window. These windows though differ in the way physical drives are presented; in the Enclosure window, the drives are arranged according to their actual locations in the drive bays, while in the Physical Drives window, the drives are arranged according to the connectors they connect onto.

You can also display some information about a particular drive by simply placing the mouse pointer on its respective icon. A table similar to the following appears:



Slot	Chl	ID	Capacity	Status	Xfer Rate	LD	Vendor / Product ID
	2	6	1010MB	On-line	10MB	0	


This table displays the current configuration of the drive, including the drive's slot number, the channel number of the connector on the controller to which the drive's SCSI cable is connected, the ID number of the connector on the SCSI cable where the drive is installed, the drive's capacity, status, transfer rate, the ID number of the logical drive where the drive belongs (if there is one), and the drive's manufacturer (if available).

To facilitate management of the Enclosure window, the GUI RAID Manager supports the drag-and-drop function for moving objects within the Enclosure window. If you need to move an object to a different location within the window, just drag its corresponding icon to the target destination.

3.6.3 Using the Physical Drives Window

The Physical Drives window is where you view and modify the configuration of the controller and manage physical drives. This window provides almost the same function as the Enclosure window, using the same symbols and colors to represent various drive conditions (for information about these symbols and colors, see the previous section, *Using the Enclosure Window*). The main difference between these two windows is in the way they present the physical drives; the Enclosure window presents the drives according to their actual locations in the drive bays, while the Physical Drives window presents them based on the connectors they connect onto.

To display the Physical Drives window, you can either click on the **Physical Drives** command button or select the **Physical Drives** command from the **Open** menu. A window similar to the following will appear on the screen:




Depending on the controller you are using, this window displays either the front panel of a SCSI-to-SCSI controller or the card layout of a PCI-to-SCSI controller. The front panel display

ASUS GUI RAID Manager: Basic Operations at Startup

reflects what appears on the actual front panel of a SCSI-to-SCSI controller.

Also shown in this window are the physical drives and hosts (for SCSI-to-SCSI controllers only) connected to the controller. How they are connected and configured, including their current status (for drives only), are all depicted on the screen. If you need information about a particular object in this window, simply place the mouse pointer on its respective icon. Letting the mouse pointer hover over the front panel displays the following table:



This table shows some information about the controller, including the total cache size, the version of the firmware currently stored in the Flash memory, the boot record version, serial number, and the CPU type.

Letting the mouse pointer hover over a SCSI Channel displays a table similar to the following:

Chl	Mode	ID	DefClk	DefWid	Term	CurClk	CurWid
1	Drive	7	10.0MHz	Wide	Off	10.0MHz	Wide




This table provides information pertaining to the current configuration of the SCSI channel. This includes the channel

ASUS GUI RAID Manager: Basic Operations at Startup

number, channel mode (that is, host or drive), SCSI ID, the default and current transfer clock rate, and the default and current transfer width.

Letting the mouse pointer hover over a drive displays a table similar to the following:



Slot	Chl	ID	Capacity	Status	Xfer Rate	LD	Vendor / Product ID
	1	2	1010MB	New	10MB	None	

This table displays the current configuration of the drive, including the drive's slot number, the channel number of the SCSI channel to which the drive is connected, the SCSI ID of the drive, the drive's capacity, current status, transfer rate, the ID number of the logical drive to which the drive belongs (if it belongs to one), and the drive vendor and product identifier strings (if available).

The Physical Drives window also allows you to modify the configuration of the controller and the SCSI channels, and scan in newly added or replaced physical drives. For more information about this feature, see Chapter 4, *Array Management*.

Fault Bus

In addition to displaying the SCSI channels, the Physical Drives window also displays the status of the Fault Bus.

ASUS GUI RAID Manager: Basic Operations at Startup


Fault Bus is a proprietary enclosure management interface. It



will warn the user if a dangerous situation occurs within the RAID system. Fault Bus gathers the failure signals from the cooling fans, redundant power supply, enclosure temperature sensor and UPS device. In the GUI RAID Manager, it reports this failure information to the user by displaying a red “X” on whichever device has failed.



Fault Bus only collects the failure signals; it does not detect the temperature, fan rotation, power supply failure or the UPS power failure. Either a user-designed circuit or a 3rd-party circuit is necessary for Fault Bus. This circuit must be configured properly for Fault Bus to work. To configure the user-designed/3rd-party circuit, double-click on the Fault Bus icon with your mouse.




The user is given the choice of enabling or disabling failure signals. In addition, each signal must be configured as either **High** or **Low** (refer to your 3rd-party circuit's manual for the proper settings.)

SAF-TE Enclosure Management

What is SAF-TE?

SAF-TE stands for SCSI Accessed Fault-Tolerant Enclosures. It is an enclosure management technology. A SAF-TE-compliant enclosure monitors the fan temperature, power supply, UPS and also provides drive status LED's. (Note: the system integrator must connect the cables from the SAF-TE device to the drive status LED's in the drive cannisters.) The SAF-TE enclosure connects to the RAID Controller via a SCSI connector. The RAID controller communicates with the SAF-TE enclosure with standard SCSI commands.




- SAF-TE chipset connects to the drive channel of the controller together with the other SCSI drives.

How Does SAF-TE work?


The SAF-TE device (often a back plane within a drive-bay enclosure) must occupy a connector on one of the drive channels' SCSI cables. The presence of a SAF-TE device will be detected and its presence will be displayed in the GUI RAID Manager program in place of the Fault Bus icon.

ASUS GUI RAID Manager: Basic Operations at Startup

SAF-TE is configured by selecting the "SAF-TE Polling Period" under the "SCSI" menu.



Intervals ranging from .05 to 60 seconds are available. The default polling period is "Disabled."



3.6.4 Using the Logical Drives Window

The Logical Drives window is where you perform management on the logical drives of the disk array system. Logical drives are combinations of physical drives, which are used to create logical volumes. These volumes (or their partitions) can then be mapped to various host LUNs.


The Logical Drives window allows you to create logical drives, delete existing ones, and rebuild failed drives. It uses unique colors to distinguish between logical drives. When a physical drive within a logical drive fails, the system notifies you by darkening the color of the affected logical drive. The logical drive will remain in this state until either a spare is detected and rebuilding is automatically started, or the drive is replaced and rebuilding is manually initiated.

While rebuilding a logical drive, the GUI RAID Manager reports the progress of the rebuilding process by filling in the color of the logical drive accordingly. After rebuilding is complete, the logical drive will display its normal color, signifying on-line condition.

To facilitate management of the Logical Drives window, the GUI RAID Manager supports drag-and-drop operations to establish certain associations. For example, to assign a particular physical drive as a spare to a logical drive, just drag the desired physical drive over to the logical drive window and drop it into the target logical drive.

To display the Logical Drives window, you can either click on the **Logical Drives** command button or select the **Logical Drives** command from the **Open** menu. A window similar to the following will appear on the screen:

ASUS GUI RAID Manager: Basic Operations at Startup



If you need information about a particular logical drive, just let the mouse pointer hover over its corresponding icon. A table similar to the following will appear:

ID	RAID Level	Capacity	Status	# Drives	# Spares	# Failed
2	RAID 5	2020MB	Good	3	0	1

This table displays the ID number of the logical drive, the RAID level, total capacity, current status, total number of physical drives combined to create this logical drive, number of spare drives, and number of failed drives.

For more information on how to create, delete, and rebuild logical drives, see Chapter 4, *Array Management*.

3.6.5 Using the Volume Window


The GUI RAID Manager provides a Volume window for use in the management of logical volumes in the disk array system.

Logical volumes are a grouping of multiple logical drives combined together into one large unit. This unit is, in turn, mapped entirely or by parts (that is, by partitions) to various host LUNs.

NOTE: A logical volume can contain a maximum of eight logical drives with dissimilar RAID levels.

The Volume window helps you create logical volumes, delete existing ones, and define partitions. It supports the drag-and-drop operation to simplify management of these disk array elements – you simply drag logical drives over to the Volume window and drop them into the logical volume being created.


To display the Volume window, you can either click on the **Logical Volume** command button or select the **Logical Volume** command from the **Open** menu. A window similar to the following will appear on the screen:



The GUI RAID Manager uses a book icon to represent a particular volume, with the binding displaying the respective colors of the logical drives used to create this particular volume. The relative size of the colored area reflects the capacity of the respective logical drive relative to the total capacity of the logical volume.

Logical volumes that have been partitioned appear with dotted lines on them. The relative position of a dotted line indicates the location of the boundary between partitions within the volume. Moving this line will change the location of the boundary thereby changing the size of the partitions so bounded.

If you need information about a particular logical volume, simply let the mouse pointer hover over its corresponding icon. A table similar to the following will appear:



Logical Volume Partition Table		
Volume ID:1		Capacity:9090MB
Idx	Base Offset	Part Size
0	0MB	4848MB
1	4848MB	1616MB
2	6464MB	2626MB

This table displays information about the existing partitions of a logical volume. These include the total number of partitions into which the volume has been divided and their respective sizes. This table also displays the volume ID and its total capacity.


For information on how to create, delete, and set partitions for logical volumes, see Chapter 4, *Array Management*.

3.6.6 Using the Host LUN Assignment Window

The Host LUN Assignment window depicts the Logical Unit Numbers (LUNs) for the existing host channels in the disk array system with their current logical volume and/or partition assignments. Depending on the type of controller used in the system, this window displays one or more host channels; the PCI-to-SCSI controller only supports one host channel (that is, the PCI bus itself). Each host LUN appears to the host on one access letter with a capacity equal to the mapped volume (or partition).

ASUS GUI RAID Manager: Basic Operations at Startup

To display the Host LUN Assignment window, you can either click on the **Host LUN Assignment** command button or select the **Host LUN Assignment** command from the **Open** menu. A window similar to the following appears on the screen:



This window displays the available host channels and their respective LUN assignments. LUNs with mapped volumes or partitions appear with book icons on their connectors. These icons are similar to those used for logical volumes only that they appear smaller. If you need information on any of these mappings, just place the mouse pointer on the target book icon. A table similar to the following appears on the screen:

Scsi Chl	LUN	LV Idx	Part Idx	Capacity
0	1	1	0	1000MB

LUN 1

This table displays the SCSI number for the respective host channel, the LUN number, the index number of the logical volume used in this mapping, the partition index, and the capacity.

For information on mapping logical volumes and/or partitions to host LUNs, and deleting existing mappings, see Chapter 4, *Array Management*.

3.6.7 Arranging Windows

The Window menu provides you with commands for rearranging the displayed GUI RAID Manager windows (excluding the main window) in various ways. You have the option to cascade these windows so that they will overlap with each other making their title bars visible, arrange the open windows in smaller sizes to fit next to each other on the screen, or display the windows in such a way that they appear according to their uses and the maximum number of elements are displayed.

All commands in the **Window** menu are standard MS Windows commands, except for **Tile In-Sequence**. The **Tile In-Sequence** command is specifically designed for disk array management. It arranges the open windows based on their uses, with each window reduced to fit all elements within its width. Since all elements within the width are displayed, a horizontal scroll bar is not necessary for each window; however, for the main window, it might be necessary specially when multiple windows are displayed.

▶ Arranging windows using the **Tile In-Sequence** command

- From the **Window** menu, select **Tile In-Sequence**.

-or-

Click on the **Tile In-Sequence** command button.

▶ Cascading the displayed windows

- From the **Window** menu, select **Cascade**.

- ▶ **Arranging windows using the Tile Horizontal command**
 - From the **Window** menu, select **Tile Horizontal**.
- ▶ **Arranging windows using the Tile Vertical command**
 - From the **Window** menu, select **Tile Vertical**.

3.7 *Exiting GUI RAID Manager*

Exiting from the GUI RAID Manager terminates the current management session with the disk array system. When you exit, the system automatically saves the disk array configuration for use later when connecting to the same system. The system also releases all used or occupied resources for use by other applications.

- ▶ **Exiting from the GUI RAID Manager**
 - From the **File** menu, select **Exit**.

4 Array Management

This chapter describes the steps on how to manage a disk array system. The topics include the following:

- ◆ Background information about disk array management
- ◆ Defining enclosures
- ◆ Setting controller configuration
- ◆ Setting channel configuration
- ◆ Scanning in drives
- ◆ Creating logical drives
- ◆ Assigning spare drives
- ◆ Deleting logical drives
- ◆ Rebuilding logical drives
- ◆ Creating logical volumes
- ◆ Defining volume partitions
- ◆ Deleting volume partitions
- ◆ Deleting logical volumes
- ◆ Mapping logical volumes or partitions to host LUNs
- ◆ Deleting LUN mapping
- ◆ Displaying the contents of the event log
- ◆ Monitoring performance statistics

If this is your first time to manage a disk array system, we recommend that you read through the first section of this

ASUS GUI RAID Manager: Array Management

chapter, *Background Information*, to get basic information about disk array management. You will need this basic knowledge to be able to effectively use the GUI RAID Manager.

4.1 **Background Information**

Redundant Arrays of Independent Disks (RAID) is a storage technology used to improve the processing capability of storage systems. This technology is designed to provide reliability in disk array systems and to take advantage of the performance gains multiple disks can offer.

RAID comes with a redundancy feature that ensures fault-tolerant, uninterrupted disk storage operations. In the event of a disk failure, disk access will still continue normally with the failure transparent to the host system.

RAID has six levels: RAID 0 ~ 5. RAID levels 1, 3 and 5 are the most commonly used levels, while RAID levels 2 and 4 are the less popular ones. Appendix C, *RAID Levels*, gives information about these levels, including the benefits of each.

ASUS disk array controllers support hot-swapping where a failed drive can be replaced while the disk array system continues to function. Spares can also be assigned so that, as soon as a drive fails, the spare will be automatically configured into the array and reconstruction will commence.

4.1.1 Definition of Terms

This section describes some of the disk array terms used in this documentation.

- ◆ **Physical drives.** These are the actual SCSI drives installed on the connectors of the SCSI cables. These drives are displayed on the Physical Drives window.
- ◆ **Spare drives.** These are physical drives that serve as backups. When a drive fails, the spare is automatically configured into the array, and data reconstruction will

immediately commence. Spare drives appear in darker (shaded) colors than normal drives.

- ◆ **Replacement drives.** These are physical drives that are manually configured into the array to replace failed drives. In the absence of spare drives, you will need to use replacement drives to replace defective drives before rebuilding can be performed.
- ◆ **Failed drives.** These are physical drives that fail due to errors of some type. Failed drives appear with **X** marks on their respective icons.
- ◆ **Logical drives.** These drives are created using physical drives. Combining physical drives into one logical drive gives you a disk array with a certain RAID level. To view logical drives, use the Logical Drives window.
- ◆ **Logical volumes.** These volumes are created using logical drives. Combining logical drives into one logical volume gives you a single logical unit with even larger capacity. Logical volumes or their partitions are mapped to various host LUNs. To view logical volumes, use the Volume window.

4.1.2 Operation with Spare Drives

You can assign spare drives to a particular logical drive to serve as backup drives. When a drive fails within the logical drive, one of the spares will be automatically configured into the logical drive, and data reconstruction onto it will immediately commence.

The following are guidelines for disk failure recovery when a spare drive is available:

- ◆ If a spare drive exists in the same logical drive, the controller will automatically mount the spare drive and start data rebuilding in the background.
- ◆ Depending on the design of the system external to the controller, it may be possible to remove a defective drive and replace it with a new drive without shutting down the system (hot-swapping). Alternatively, the system can be shut down at a convenient time and the failed drive replaced.
- ◆ The replacement drive must then be assigned as a new spare drive.

4.2 *Operation without Spare Drives*

The following are guidelines for disk failure recovery when a spare drive is not available:

- ◆ Depending on the design of the system, it may be possible to remove a defective drive and replace it with a new drive without shutting down the system (hot-swapping). Alternatively, the system can be shut down at a convenient time and the failed drive replaced.
- ◆ If the replacement drive is installed on the same channel and SCSI ID, you can then proceed with data rebuilding.
- ◆ If the replacement drive is installed on a different channel or SCSI ID, you need to scan in the new drive first then assign it as a spare drive of the logical drive. Data rebuilding will have to be manually initiated.

IMPORTANT: Although the RAID system provides uninterrupted disk access even after a disk failure, do not leave a failed drive unattended to. Without replacement, the system will not survive a failure of a second drive on the

same logical drive. A defective drive must be promptly replaced and data rebuilt.

CAUTION: When performing hot-swapping, be sure to remove only the defective drive. Removing the wrong drive will result in unrecoverable data loss. Use the Enclosure or Physical Drives window to locate the exact location of the failed drive.

4.3 ***Before you Start***

The GUI RAID Manager station comes with password protection that prevents unauthorized modification of the disk array configuration. During first attempts at modifying the system configuration after starting up the GUI RAID Manager or after the GUI RAID Manager comes back from a period of inactivity, the configuration will be password protected. After specifying the correct password, all subsequent configuration modifications will be permitted without any password protection; however, if there is no station activity within a specified period of time, the password will be put back into effect.

By default, the GUI RAID Manager station comes without any password. For information on how to set a password and other security features, see the *Setting Up Security* section of Chapter 3, *Basic Operations at Startup*.

4.4 Defining Enclosures


You create custom enclosures to facilitate management of the physical drives in the disk array system. These enclosures can replicate closely real enclosures with real drive bays, depicting the exact locations and positions of the physical drives. When a drive fails, determining which drive to replace is simply a matter of checking the Enclosure window for the exact location of the failed drive (a failed drive appears with an **X** mark on its icon).

▶ Creating an enclosure

1. Display the Enclosure window, if not yet displayed. To display it, click on the **Enclosure** command button or select the **Enclosure** command from the **Open** menu.

If you have not defined an enclosure yet for the disk array system, the Enclosure window will be blank; otherwise, the existing enclosures appear in the window. If you want to delete an existing enclosure, see the instructions below.

2. Double-click on an empty space within the Enclosure window. The following menu will appear:



3. Depending on the orientation of your drive bays, select either **Create Vertical Enclosure** or **Create Horizontal Enclosure**. One of the following enclosure icons will appear on the screen:




4. Resize the enclosure icon to display the exact number of drive bays you need. To resize, place the mouse pointer on the bottom-side or right-side of the icon and press and hold the left mouse button. When the mouse pointer changes to a double-headed arrow, drag the mouse pointer until the desired number of drive bays is displayed. As you drag the mouse pointer, the number of drive bays will change dynamically.
5. Repeat the same procedure for the other drive bays you may still have in your configuration.
6. To fill in the drive bays in the enclosure just created, display the Physical Drives window. To display this window, click on the **Physical Drives** command button or select the **Physical Drives** command from the **Open** menu.
7. From the Physical Drives window, drag the physical drives to their respective drive bays in the Enclosure window.
8. Check to ensure that all drives are in their respective drive bays. To check, let the mouse pointer hover over each drive icon. A table will appear displaying some information about the drive.

NOTE: If you have placed the wrong drive in a drive bay, just drag over the correct drive from the Physical Drive window over and drop it into the correct drive bay.

► **Removing a drive bay from an enclosure**

ASUS GUI RAID Manager: Array Management

1. Double-click on the target drive bay. The following menu will appear on the screen:




2. Select **Remove Bay from Enclosure**.

► Moving an enclosure

1. Place the mouse pointer on the left-side or top-side of the enclosure icon and press and hold the left mouse button.
2. Drag the icon to the desired location within the Enclosure window. When you have reached the target location, release the mouse pointer to drop the enclosure icon.

► Deleting an enclosure

1. Double-click on any area of the enclosure icon, except on occupied drive bays. The following message will appear on the screen:



2. Click OK to delete the entire enclosure.

4.5 **Setting Controller Configuration**

The GUI RAID Manager enables you to modify the configuration of the disk array controller from your manager console. You can enable or disable the write-back cache of the system, set whether or not the controller will reset the SCSI bus during power-on, stagger the drives' motor spin-up sequence, set the baud rate of the controller's RS-232 port, and modify the station password.


The following describes the user-configurable parameters:

- ◆ **Write-Back.** This parameter allows you to enable or disable the write-back cache of the system. The write-back cache allows write data to be stored in the cache memory prior to writing to the disk, thereby pipelining the I/O write process.
- ◆ **SCSI Reset on Power-up.** This parameter determines whether or not the controller will assert SCSI bus reset during power-on initialization.
- ◆ **Staggered Drive Spin-Up.** This parameter determines whether or not the controller will sequence the drives to start spinning in succession at five-second intervals. Enabling staggered drive spin-up can help prevent overloading the power supply when many drives spin up at the same time.
- ◆ **RS-232 Baud Rate.** This parameter sets the baud rate of the RS-232 port on the controller. When connecting a host computer, terminal, or other device (such as a modem) onto this port, ensure that their baud rates are set accordingly; otherwise, there will be communication problems.

- ◆ **Change Password.** This parameter allows you to modify the current password of the GUI RAID Manager station. This password prevents any unauthorized modifications on the system configuration. For more information about the station password and other security issues, see the *Setting Up Security* section of Chapter 3, *Basic Operations at Startup*.

▶ **Setting the controller configuration**

1. Display the Physical Drives window by clicking on the **Physical Drives** command button or selecting the **Physical Drives** command from the **Open** menu.
2. From the Physical Drives window, double-click on the displayed controller (that is, front panel for a SCSI-to-SCSI controller or card layout for a PCI-to-SCSI controller). The Controller Settings dialog box will appear:



3. From the **Write-Back** drop-down list box, select the write-back cache state. To select, click on the down-arrow button at the right of the box, then select the option you need. To

enable the write-back cache, select **Enabled**; to disable, select **Disabled**.

4. If you want a SCSI bus reset to be issued on the drive channels every time you power on or reset the disk array system, set the **SCSI Reset on Power-Up** parameter to **Enabled**. Otherwise, set this parameter to **Disabled**.
5. To avoid overloading the power supply when several drives spin up at the same time, set the **Staggered Drive Spin-Up** parameter to **Enabled**. If a fast system startup is needed, and the power supply is capable of handling all the power requirements of the drives at the same time, set this parameter to **Disabled**.
6. Use the **RS-232 Baud Rate** drop-down list box to set the baud rate of the RS-232 port on the controller. If you have a host computer, terminal, or other device (such as a modem) connected to this port, specify here the baud rate of the connected device, or set the port's baud rate here and make the baud rate of the device correspond to this value.
7. If you want to modify the password, check the **Change Password** check box, and then specify the new password in the provided text box. You will need to confirm your password.
8. Click OK to save the new controller configuration. If you specified a new password, this value will be saved into the non-volatile memory on the disk array controller.

4.6 **Setting Channel Configuration**

From within the GUI RAID Manager, you can modify the configuration of any channel on the controller. You can set the

channel operation mode to host or drive, enable or disable the channel termination, set its SCSI ID, set the transfer clock rate for synchronous communication, and select the transfer width.

The following describes the user-configurable parameters:

- ◆ **Channel Mode.** This parameter sets the operation mode of a particular channel on the SCSI-to-SCSI controller. It configures the operation mode to either host or drive, where a host channel is used when connecting to a host, while a drive channel is for connecting to SCSI drives. Any SCSI channel on the SCSI-to-SCSI controller can serve as either a host or a drive channel. Channel 0 is the default host channel with SCSI ID number 0.

For a PCI-to-SCSI controller, this parameter is permanently set to **Drive**.

- ◆ **Termination.** This parameter enables or disables SCSI channel termination. SCSI cables must be properly terminated at both ends; that is, when connecting one end of a SCSI cable to a channel, the termination of the channel must be enabled. Note that the other end of the cable must also be properly terminated.

You can terminate the other end of the cable by installing or enabling termination on the SCSI drive farthest from the controller or by installing an external terminator on the end connector. The latter method is recommended so that removal of the drives will not affect cable termination. All other terminators must be removed or disabled making sure that only one terminator is installed on each end.

- ◆ **SCSI ID.** This parameter sets the SCSI ID of the channel. Each channel must have a unique SCSI ID in order to work properly. SCSI ID ranges from 0 up to 15, with 0

assigned as the default value for host channels, and 7 for drive channels.

- ◆ **Default Sync Clock (MHz), Default Xfer Width.** These parameters set the data transfer clock rate for synchronous communication over the SCSI bus, and enable or disable wide transfer, respectively. For a detailed description of these parameters, see the discussion below.

Data that is transferred across the SCSI bus in synchronous transfer mode is clocked using a synchronous transfer clock signal. The frequency of this signal determines the rate at which data is transferred. If, for example, the synchronous transfer clock is 10 MHz, data transfer rate will be 10 million bytes per second (assuming narrow transfer).

Data transfer across the SCSI bus can be either 8 bits or 16 bits at a time. The former is referred to as *narrow* transfer, while the latter is referred to as *wide* transfer. At the same synchronous transfer clock rate, data transfer rate using *wide* transfer will be double that using *narrow*. With synchronous transfer clock of 10 MHz, data transfer rate will be 10 Mbytes/second under *narrow* transfer, and 20Mbytes/second for *wide*.


Occasionally, under conditions in which SCSI signal quality is poor, such as long cables, poor connections, or bad termination, it may be necessary to reduce the synchronous transfer clock to allow the SCSI channel to function normally. Under worst conditions, it may be necessary to switch to asynchronous communication mode.

Furthermore, certain older SCSI devices may only support *narrow* transfer and behave abnormally when an attempt to negotiate *wide* transfer is made. Under such conditions,

wide transfer may need to be disabled, forcing the controller to use *narrow* transfer mode with that device.

► **Setting the configuration of a channel**

1. Display the Physical Drives window by clicking on the **Physical Drives** command button or selecting the **Physical Drives** command from the **Open** menu.
2. From the Physical Drives window, double-click on the corresponding SCSI Channel icon of the target channel. SCSI Channel icons are displayed on the card layout of a PCI-to-SCSI controller, or just below the front panel of a SCSI-to-SCSI controller. The Channel Setting dialog box will appear:



3. If you are using a SCSI-to-SCSI controller, select the channel mode from the **Channel Mode** drop-down list box. To select, click on the down-arrow button at the right of the box, then select the option you want. If you want to configure the selected channel as a host channel, select **Host**; to configure as a drive channel, select **Drive**.

4. From the **Termination** drop-down list box, specify whether to enable the channel termination or not. To enable, select **Enabled**; to disable, select **Disabled**.
5. If you want to assign a different SCSI ID to the selected channel, specify the new ID in the **SCSI ID** drop-down list box. When selecting a value, be sure that it does not conflict with the other SCSI devices on the channel.
6. To change the speed of the SCSI bus synchronous transfer clock, type in the new value in the **Default Sync Clock (MHz)** text box.
7. From the **Default Xfer Width** drop-down list box, select whether to use *narrow* or *wide* transfer. To use *narrow* transfer, select **Narrow**; to use *wide* transfer, select **Wide**.
8. Click OK to save the new channel configuration into the non-volatile memory of the controller.

4.7 Scanning in Drives

Disk scanning is a process in which a newly installed drive is introduced to the disk array system. You need to scan in a drive when:

- ◆ The drive is a new one. A drive is considered a new drive if it is not yet displayed in the Physical Drives window.
- ◆ The drive is a replacement for a failed drive which is installed on a different channel or has a different SCSI ID.

If you do not scan in the drive on such occasions, the system will not be able to see the drive, rendering the drive useless.

▶ **Scanning in a drive**

1. Display the Physical Drives window by clicking on the **Physical Drives** command button or selecting the **Physical Drives** command from the **Open** menu.
2. From the Physical Drives window, double-click on the connector corresponding to the SCSI ID of the drive being scanned. A confirmation message similar to the following will appear on the screen:



3. Click OK. The system will scan for a drive with the specified ID and then will display either a successful message or an error message.
4. Click OK.

The GUI RAID Manager will place a drive icon on the respective connector if the scanning process is successful.

4.8 *Creating and Deleting Logical Drives*

You can create logical drives by simply combining physical drives together. The GUI RAID Manager provides you with two options for creating logical drives: automatic and manual. In the automatic method, the GUI RAID Manager automatically selects all available (that is, unassigned) drives in the system and then recommends the appropriate RAID level. Drives can be manually deselected and/or a different RAID level can be selected if so desired.

In the manual method, you select the drives you want to be included in and the RAID level of the logical drive. To assist in the selection of the RAID level, the GUI RAID Manager recommends a RAID level based on the number of drives you have selected. You can either accept the recommended RAID level or specify the one you prefer.

The GUI RAID Manager also provides you with the option to delete logical drives. Before deleting though, be sure that the stored data on the target logical drive is no longer needed. Deleting a logical drive erases all stored information.


NOTE: When you delete a logical drive, all assigned physical drives to this drive will be released, making them available again for logical drive creation.

► **To create a logical drive**

1. Display the Logical Drives window by clicking on the **Logical Drives** command button or selecting the **Logical Drives** command from the **Open** menu. If you intend to use the manual method, display also the Physical Drives window by clicking on the **Physical Drives** command button or selecting the **Physical Drives** command from the same menu.
2. From the Logical Drives window, double-click on an unused logical drive icon.

-or-

Double-click the right mouse button on an unused logical drive icon and then select **Create** from the displayed menu. The Logical Drive Creation dialog box will appear:




3. If you want to use the automatic method, check the **Auto Drive Selection** check box and then proceed to step 8.
4. If you want to use the manual method, uncheck the **Auto Drive Selection** check box.

5. From the Physical Drives window, click on the target drives. Be sure to select only unassigned drives (those that appear in gray). The **Number of Drives Selected** field displays the number of selected drives.
6. If you want to modify the recommended RAID level, specify the level you prefer in the **RAID Level** drop-down list box. To select, click on the down-arrow button at the right of this box and then select the option you want. The **1+Spare**, **3+Spare**, and **5+Spare** options are RAID 1, RAID 3, and RAID 5 levels respectively, each with a spare drive. For information on the various RAID levels, see Appendix C, *RAID Levels*.
7. The value in the **Max Drive Capacity (MB)** text box determines how much capacity from each drive will be used in the logical drive. It may be useful to utilize this parameter to restrict capacity when the possibility exists that replacement drives acquired in the future might have slightly less capacity than the drives to be included in the logical drive. Type in the desired capacity in this box.
8. Click OK.

► **To delete a logical drive**

1. Display the Logical Drives window by clicking on the **Logical Drives** command button or selecting the **Logical Drives** command from the **Open** menu.
2. From the Logical Drives window, double-click the right mouse button on the target logical drive. The following menu will appear on the screen:



3. Select **Delete**.

4.9 **Assigning Spare Drives**


You can assign spare drives to a logical drive to serve as backups for failed drives. In the event of a drive failure, the spare drive will be automatically configured into the array and reconstruction (or rebuilding) will immediately commence.

Logical drives can support multiple spare drives; this configuration however is rarely used due to its high cost and uncommon occurrences of drive failures. A practical configuration calls for one spare drive per logical drive – after rebuilding on this drive, just replace the failed drive and then configure the replacement as the new spare drive of the logical drive.

NOTE: Adding a spare drive can be done automatically by selecting the **1+Spare**, **3+Spare** or **5+Spare** option from the Logical Drive Selection dialog box when creating a logical drive. These options however only apply to RAID 1, RAID 3, and RAID 5 levels respectively.

► Assigning a spare drive

1. Display the Physical Drives and Logical Drives windows. To display the former, click on the **Physical Drives** command button or select the **Physical Drives** command from the **Open** menu. To display the Logical Drives window, click on the **Logical Drives** command button or select the **Logical Drives** command from the same menu.
2. From the Physical Drives window, position the mouse pointer on the icon of the drive you wish to be the spare drive and press and hold the left mouse button.
3. Drag the drive icon over to the destination logical drive and then release the mouse button. The following message will appear on the screen:



4. Click OK.


4.10 Rebuilding Logical Drives

Depending on whether or not there is a spare drive, rebuilding is initiated automatically or manually. In the presence of a spare drive, the system automatically rebuilds onto the spare drive. This process is done in the background, thus it appears transparent to the user.

In the absence of a spare drive, rebuilding must be initiated manually. Before initiating a manual rebuild, you need to first replace the failed drive. If you install the replacement drive on the same connector (that is, same channel and SCSI ID), then you can proceed with the rebuilding process; otherwise, you need to scan in the drive first.

► To rebuild a logical drive

1. Display the Logical Drives window by clicking on the **Logical Drives** command button or selecting the **Logical Drives** command from the **Open** menu.
2. From the Logical Drives window, double-click the right mouse button on the degraded logical drive. The following menu will appear on the screen:



3. Select **Rebuild**.


4.11 *Creating and Deleting Logical Volumes*

You can create and delete logical volumes from your GUI RAID Manager station. Logical volumes are created by simply combining unassigned logical drives together. You can combine logical drives with different capacities and RAID levels into one logical volume. Alternatively, you can delete existing logical volumes. Before deleting though, be sure that the data stored in the logical volume is no longer needed. Deleting a logical volume erases all stored information.

NOTE: When you delete a logical volume, all assigned logical drives to this volume will be released, making them available again for logical volume creation.

▶ **To create a logical volume**

1. Display the Logical Drives and Volume windows. To display the former, click on the **Logical Drives** command button or select the **Logical Drives** command from the **Open** menu. To display the Volume window, click on the **Logical Volume** command button or select the **Logical Volume** command from the same menu.
2. From the Logical Drives window, position the mouse pointer on the icon of a logical drive you wish to include in creating the logical volume and press and hold the left mouse button.
3. Drag the icon over to the target logical volume and then release the mouse button.
4. Repeat steps 2 ~ 3 for the remaining logical drives you want to include in the logical volume.
5. Double-click the right mouse button on the target logical volume. The following menu will appear:




6. Select **Volume**. Then, from the next menu, select **Create LV**.

The logical volume is now created. You may now define its partitions. See the *Creating and Deleting Partitions* section of this chapter.

► **To delete a logical volume**

1. Display the Volume window by clicking on the **Logical Volume** command button or selecting the **Logical Volume** command from the **Open** menu.
2. Double-click the right mouse button on the target logical volume. The following menu will appear:



3. Select **Volume**. Then, from the next menu, select **Delete LV**.


4.12 *Creating and Deleting Partitions*

Depending on your specific needs, you can either partition a logical volume into smaller sizes or just leave it at its default size (that is, one large partition covering the entire volume). If you intend to map the entire logical volume to a single host LUN, then partitioning becomes irrelevant; however, if the volume is to be mapped to multiple host LUNs, then you need to define partitions for later mapping to specific LUNs.


NOTE: You can create a maximum of eight partitions per logical volume.

► **Creating partitions for a logical volume**

1. Display the Volume window by clicking on the **Logical Volume** command button or selecting the **Logical Volume** command from the **Open** menu.
2. Double-click the right mouse button on the target logical volume. The following menu will appear:



3. Select **Partition**. The following menu will appear on the screen:



4. Select **Create Partition**. A table similar to the following will appear displaying the current partition layout:

Logical Volume Partition Table		
Volume ID:1 Capacity:6060MB		
Idx	Base Offset	Part Size
0	0MB	3164MB
1	3164MB	2896MB

5. Adjust the partition size using the vertical scroll bar on the displayed table. Click OK when the desired size is achieved.

You can also adjust the partition size by placing the mouse pointer on the logical volume icon and then moving the displayed dotted line. As you move the line, the partition size changes accordingly. The table reflects the changes on the size of the affected partition. Click the mouse button when the desired size is reached or move the mouse pointer over to the vertical scroll bar for micro adjustment then click OK.

6. If you wish to create a subpartition for an already existing partition, double-click the right mouse button anywhere within its area. Then, repeat steps 3 ~ 5.


You can create up to eight partitions per logical volume.

7. After defining the desired partitions, double-click the right mouse button on the current logical volume.
8. From the displayed menu, select **Partition**. Then, select **Set Partition**.


The logical volume is now ready for mapping to host LUNs. See the *Mapping Logical Volumes/Partitions to Host LUNs* section of this chapter.

▶ Deleting logical volume partitions

1. Display the Volume window by clicking on the **Logical Volume** command button or selecting the **Logical Volume** command from the **Open** menu.
2. Double-click on the partition you wish to delete. The following menu appears on the screen:



3. Select **Partition**. The following menu will appear on the screen:



4. Select **Delete Partition**.
5. Repeat the same procedure to delete the other unwanted partitions.
6. After deleting partitions, double-click the right mouse button on the current logical volume.
7. From the displayed menu, select **Partition**. Then, select **Set Partition**.

4.13 Mapping Logical Volumes/Partitions to Host LUNs

After creating a logical volume, you can map it as is to a host LUN if you prefer; or, if partitions are set, you can map each partition to specific host LUNs. Each host supports 32 LUNs, each of which appears as a single drive letter to the host if mapped to a logical volume (or its partition).

Alternatively, you can delete existing host LUN mappings. In cases where certain mappings are found useless, or disk array reconfiguration is needed, you can delete unwanted mappings in your system.

► Mapping an entire logical volume to a host LUN

1. Display the Volume and Host LUN Assignment windows. To display the former, click on the **Logical Volume** command button or select the **Logical Volume** command from the **Open** menu. To display the Host LUN Assignment window, click on the **Host LUN Assignment** command button or select the **Host LUN Assignment** command from the same menu.
2. From the Volume window, position the mouse pointer on the icon of the logical volume you wish to map and press and hold the left mouse button.
3. Drag the icon over to the target host LUN and then release the mouse button.

► Mapping logical volume partitions to host LUNs


1. Display the Volume and Host LUN Assignment windows. To display the former, click on the **Logical Volume** command button or select the **Logical Volume** command from the **Open** menu. To display the Host LUN Assignment

window, click on the **Host LUN Assignment** command button or select the **Host LUN Assignment** command from the same menu.

2. From the Volume window, position the mouse pointer on the partition you wish to map and press and hold down the left mouse button.
3. Drag the partition over to the target host LUN and then release the mouse button.
4. Repeat the same procedure for the other remaining partitions on the logical volume to be mapped.

▶ Deleting a host LUN mapping

1. Display the Host LUN Assignment window by clicking on the **Host LUN Assignment** command button or selecting the **Host LUN Assignment** command from the **Open** menu.
2. From the Host LUN Assignment window, double-click on the icon of the mapped logical volume. The following confirmation message appears on the screen:



3. Click OK.


4.14 Displaying the Event Log

The GUI RAID Manager keeps a log file for documenting all events that occurred in the disk array system ranging from simple notifications, to warnings, to alerts.

The GUI RAID Manager saves the system log into a file named EVENT.LOG in the GUI RAID Manager directory. You can view the contents of this text file using any text editor program such as Windows' NOTEPAD application. You can also print out the contents of the log file on a printer for reference purposes. In the event of a system failure, you can use the print-outs for diagnosis.

► **To display the event log**

1. Click on the **Event Log** command button or select the **Event Log** command from the **Open** menu. The Event Log window will appear:



The screenshot shows a window titled "Event Log" with a close button in the top right corner. The window contains a table with three columns: "Date", "Time", and "Event Description". The table lists ten entries, all of which are "Controller Initialization Complete" events, sorted chronologically from top to bottom.

Date	Time	Event Description
12/05/96	21:07:30	Controller Initialization Complete
12/06/96	17:20:57	Controller Initialization Complete
12/06/96	19:16:39	Controller Initialization Complete
12/08/96	07:24:57	Controller Initialization Complete
12/08/96	15:26:37	Controller Initialization Complete
12/08/96	16:29:23	Controller Initialization Complete
12/09/96	17:18:55	Controller Initialization Complete
12/09/96	17:22:19	Controller Initialization Complete
12/11/96	19:23:05	Controller Initialization Complete

The events in the window are sorted according to the date and time they occurred. Description for each event is also provided to facilitate reference.


2. To scroll through the list, use the vertical scroll bars.

4.15 Monitoring Statistics

The GUI RAID Manager comes with a statistics monitoring feature to report on the overall performance of the disk array system. This feature provides a real-time report on the current throughput of the system, displaying the number of bytes being read and written per second. These values are displayed in a graphical format to facilitate reference.

▶ **To monitor the current data traffic on the disk array system**

- Click on the **Statistics** command button or select the **Statistics** command from the **Open** menu. The Statistics window appears:



The Statistics window displays the amount of data being read from and written to the disk array system, in MB per second. Read values appear in green, and are displayed under Write values which appear in red.

NOTE: The program automatically adjusts the y-axis to fit the entire graph snugly in the Statistics window.

4.16 Dynamic Logical Drive Expansion


What Is It and How Does It Work?

Before Dynamic Logical Drive Expansion, increasing the capacity of a RAID system using traditional methods meant backing up, re-creating and then restoring. Dynamic Logical Drive Expansion (a new feature of firmware version 2.11) allows users to add new SCSI hard disk drives and expand a RAID 0, 3 or 5 Logical Drive without powering down the system.


4.16.1 Two Modes of Dynamic Logical Drive Expansion

There are two modes of Dynamic Logical Drive Expansion: Mode 1 and Mode 2.

Dynamic Logical Drive Expansion




Mode 1 Expansion involves adding more SCSI hard disk drives to a logical drive, which may require that the user obtain an enclosure with more drive bays. The data will be re-stripped onto the original and newly added disks.



In the figure above, new drives are added to increase the capacity of a 4-Gigabyte RAID 5 logical drive. The two new drives increase the capacity to 8 Gigabytes.


Mode 2 Expansion, on the other hand, requires the same number of higher-capacity SCSI hard disk drives for a given logical drive.

RAID Expansion - Mode 2 (1/3)



The figure above illustrates expansion of the same 4-Gigabyte RAID 5 logical drive using Mode 2 Expansion. Drives are copied and replaced, one by one, onto three higher-capacity drives.

RAID Expansion - Mode 2 (2/3)




Copy and Replace the other member drives one by one until all the member drives have been replaced

Copy and Replace each member drive. After all the member drives have been replaced, execute the "RAID Expansion" to use the additional capacity.



This results in a new 4-Gigabyte, RAID 5 logical drive composed of three physical drives. The 4 Gigabytes of increased capacity is in a new partition.

RAID Expansion - Mode 2 (3/3)



After the RAID Expansion, the additional capacity will appear as another partition. Adding the extra capacity into the existing partition requires OS support.





IMPORTANT:

- *The increased capacity from Mode 1 Expansion of a logical drive will be a new partition.*
- *At the time of this printing, Firmware version 2.11 does not support the "Copy and Replace" function that is required for Mode 2 Expansion. Third-party hard disk utilities may be used for Mode 2 Expansion of logical drives. Later versions of the firmware will support "Copy and Replace."*

Example: RAID Expansion in Windows NT Server

Limitations When Using Windows NT 4.0

1. Only the Windows NT Server Disk Administrator includes the Extend Volume Set function; Windows NT Workstation does not have this feature.
2. The system drive (boot drive) of a Windows NT system cannot be extended.
3. The drive that will be extended should be using the NTFS file system.

ASUS GUI RAID Manager: Array Management

The Example:


The following example demonstrates the expansion of a 900MB RAID 0 logical drive. The GUI RAID Manager is used to connect to the RAID controller.

ID	RAID Level	Capacity	Status	# Drives	# Spares	# Failed
0	RAID 5	900MB	Creating	3	0	0


LD 0 (P)



You can view information about this drive in the Windows NT Server's Disk Administrator.




Place the cursor on Disk 1, right-click your mouse, and select "Properties." You will see that the total capacity for the Drive E: is just under 900MB.



ASUS GUI RAID Manager: Array Management

Three new drives are scanned in (see section 4.7 for details on scanning in new drives.) To add the drives to the logical drive, first right-click on the logical drive icon, and then select "Add SCSI Drive."



The logical drive icon will appear to be degraded while the new drives are being added to the logical drive. The color will return to normal once the adding the drives has been completed.



When you rest the mouse on the logical drive icon, you now see that the capacity has increased from 900MB to 1800MB.

ID	RAID Level	Capacity	Status	# Drives	# Spares	# Failed
0	RAID 5	1800MB	Creating	6	0	0


LD 0 (P)



From the menu, select Partition Logical Drive. You will see that the 1800MB logical drive is composed of two 900MB partitions.


Follow the directions in section 4.13 to map the new partition to a Host LUN. The new partition must be mapped to a host LUN in order for the HBA (host-bus adapter) to see it. Once you have mapped the partition, reboot Windows NT. The HBA should be able to detect an additional "disk."

Return to Windows NT Server's Disk Administrator. There now exists a Disk 2 with 900MB of free space. Click on Disk 2 to select it.




ASUS GUI RAID Manager: Array Management

From the "Partition" menu, select "Extend Volume Set."




The screen will display that volume set of Drive E: has been extended by the 900MB in Disk2. Move the cursor to "Commit Changes Now" to confirm that you want the free space to become a part of the same logical drive.




ASUS GUI RAID Manager: Array Management

Logical Drive E: is now composed of two 900MB partitions with a total volume of 1800MB. To see this, hold down on the <Ctrl> key and select both Disk 1 and Disk2; then right-click your mouse and select "Properties."




Drive E: now has a capacity just under 1800MB.



4.17 Redundant Controller

Redundant Controllers

For the SCSI-to-SCSI controllers, the GUI RAID Manager is capable of monitoring a redundant controller configuration.



5 Notification Configuration

This chapter discusses how to configure notifications. The topics include the following:

- ◆ Description of the notification function
- ◆ Notification levels
- ◆ Configuring notification options
- ◆ Configuring a pager notification
- ◆ Configuring a fax notification
- ◆ Configuring an e-mail notification
- ◆ Configuring a broadcast notification

5.1 Introduction

A management program is almost useless without reporting or notification function ability. For this reason, the GUI RAID Manager enables you to configure notifications to occur in response to various disk array events. For example, if you configure an e-mail notification, the GUI RAID Manager will send an e-mail to selected computers on the network if the event (that just occurred) falls within the selected notification level. If the notification is detailed enough, the recipient can respond accordingly.

The notification function makes it possible to manage (or monitor) the disk array system even when the administrator is away from the manager station. When properly configured, this function can notify the administrator of event occurrences in the managed disk array system instantly even when he or she is at home, or in other places around the globe.

ASUS GUI RAID Manager: Notification Configuration

The GUI RAID Manager provides four methods of sending notifications:

- ◆ Pager
- ◆ Fax
- ◆ E-mail
- ◆ Broadcast

You can use any of the notification methods mentioned above; be reminded though that before you can use a particular method, you should have the proper hardware (like a modem for the pager notification) and software (like Windows NT for the broadcast message notification) installed in your system.

5.2 ***Before You Begin...***

Before the GUI's event notification can be used, some adjustments may need to be made to the Windows NT configuration.

5.2.1 Pre-configuring for a Pager Notification in Windows NT 4.0

There are no special steps required for using pager notification; however, the modem must be properly installed. (The same is true for Fax Notification; *see section 5.2.2.*) Please follow all of the instructions in the modem's user guide for correctly installing it for use with Windows NT 4.0.

Please see section 5.5 for complete details on *Configuring a Pager Notification*.

5.2.2 Pre-configuring the Fax Service in Windows NT 4.0

Microsoft Windows NT 4.0 ships without fax service. Administrators who desire fax notification have two choices: one, installing a MAPI-compliant fax software; or two, obtaining the file FAX_I386.EXE from Microsoft, which – at the time of this printing – is freely available from their web server at the following URL:

<http://www.microsoft.com/networkstation/fax.htm>

The following are instructions for installing fax service using the FAX_I386.EXE file.

ASUS GUI RAID Manager: Notification Configuration

1. From the Windows Start bar, run the file FAX_I386.EXE. Enter information regarding your desired fax configuration as prompted.



2. Open the Control Panel and click on the Mail icon.




ASUS GUI RAID Manager: Notification Configuration

3. The Windows Messaging Settings Properties window will be displayed. The profile now displays two new services – Fax Address Book and Fax Mail Transport.



ASUS GUI RAID Manager: Notification Configuration

4. The format of the fax can be configured by selecting Fax Mail Transport and clicking on Properties. The user can select whether or not to include a cover page as well as the fax's font and size.



Please see section 5.6 for complete details on *Configuring a Fax Notification*.

5.2.3 Pre-configuring E-Mail Service in Windows NT 4.0

Microsoft Windows NT 4.0 ships with the Internet Mail E-mail service. Administrators who desire E-mail notification have two choices: one, using the Internet Mail service which ships with NT 4.0; or two, installing a third-party, MAPI-compliant E-mail software.

The following are instructions for installing the Internet Mail service in Windows NT 4.0:

1. Open the Control Panel and click on the Mail icon.




2. The Windows Messaging Settings Properties window will be displayed. If no services have been selected for this profile, click on the "Add" button.



ASUS GUI RAID Manager: Notification Configuration

3. Select “Internet Mail,” and then click on “OK.”



4. Fill in all of the fields with the settings for your Internet account, and then click on “OK.”



5. Repeat steps 1 through 3, selecting “Personal Address Book” and “Personal Folders” at step 3.

Please see section 5.7 for complete details on *Configuring an E-Mail Notification*.

5.2.4 Pre-configuring Broadcast in Windows NT 4.0

To broadcast a message to another computer on a network, the following criteria must be met:

- ◆ The GUI RAID Manager station has a network card and is properly connected to the network
- ◆ The recipient(s) of the broadcast are connected to the same network
- ◆ The correct computer name(s) are entered for the recipient(s) of the broadcast

Please see section 5.8 for complete details on *Configuring a Broadcast Message Notification*.

5.3 Notification Levels

The GUI RAID Manager classifies disk array events into three levels depending on their severity. These include Level 1, Level 2, and Level 3. The first event level covers notifiational events such as initialization of the controller and initiation of the rebuilding process; Level 2 includes events which require the issuance of warning messages; Level 3 is the highest level, and covers events the need immediate attention (and action) from the administrator. The following lists sample events for each level:

Level 1 Sample Events

- ◆ Controller Initialization Complete

ASUS GUI RAID Manager: Notification Configuration

- ◆ Rebuild Initiated
- ◆ Rebuild Complete
- ◆ Rebuild Failed
- ◆ Logical Drive Initialization Started
- ◆ Logical Drive Initialization Complete
- ◆ Logical Drive Initialization Failed

Level 2 Sample Events

- ◆ SCSI Target Select Timeout
- ◆ SCSI Target Phase/Signal Error
- ◆ SCSI Target Unexpected Disconnect
- ◆ SCSI Target Negotiation Error
- ◆ SCSI Target Timed Out
- ◆ SCSI Target Parity Error
- ◆ SCSI Bus Reset Issued
- ◆ SCSI Target Not Ready Error
- ◆ SCSI Target Media Error
- ◆ SCSI Target Hardware Error
- ◆ SCSI Target Unit Attention
- ◆ SCSI Target Unexpected Sense Data
- ◆ SCSI Target Block Reassignment Failure
- ◆ SCSI Target Unexpected Data Over/Underrun
- ◆ Drive SCSI Unrecognized Event

Level 3 Sample Events

- ◆ SCSI Drive Failure

You select the notification level from the RAID Manager Options dialog box. Selecting a relatively low level also selects the level(s) above it; thus, selecting Level 1 events, for example, will also select Levels 2 and 3 events. Since Level 3 is the highest level, selecting this will only select Level 3 events.

5.4 *Configuring Notification Options*

The RAID Manager Options dialog box allows you to enable or disable the notification function of the GUI RAID Manager, select the notification level, specify the event countdown limit, and stop all on-going pager notifications. Event countdown is the latency time between event occurrence and notification sequence initiation; this helps administrators to abort issuance of the notification sequence should they be on-site already.

▶ **To configure notification options**

1. Select **Options** from the menu bar. The RAID Manager Options dialog box appears:

ASUS GUI RAID Manager: Notification Configuration



2. To enable the notification function of the GUI RAID Manager, select the **Enable** option button in the **Event Notification** field. To disable, select the **Disable** option button.
3. From the **RAID Event Level** drop-down list box, select the notification level. To select, click on the down-arrow button at the right of this box, then select the option you want. The **All Events** option includes Levels 1, 2, and 3 events; **Warning** covers Levels 2 and 3 events; **Alert** covers Level 3 events. Default notification level is **Alert**.
4. In the **Event Countdown Limit** text box, type in the latency time you need. This determines how long to wait after the occurrence of the event before actually sending the configured notification.
5. To stop all on-going pager notifications, check the **Stop All In-Progress Event Notification** check box. Since the pager notification function repeatedly sends the notification at a

user-configurable time interval, you can stop subsequent transmissions with this check box. Be reminded though that this will only affect the current event; for succeeding events, this check box will revert to its default state of disabled (no check mark).

You can also stop the on-going pager notification to a specific recipient through the Personal Information: Pager dialog box. For information, see the *Configuring a Pager Notification* section of this chapter.

6. Click OK to save the new notification option settings.

5.5 Configuring a Pager Notification

You can configure a pager notification that will send a message to a paging device when a specific disk array event occurs in the system.

It is recommended that a unique number be assigned to identify a specific disk array system. Since messages received on a pager may vary widely, you need to assign a number to facilitate reference. For example, if the disk array system in the Accounting Department of your company has 01131965 assigned to it, when this number is sent to the pager, the recipient knows that the message is from the disk array system in the Accounting Department.

For pager notification to work, you should have a modem connected to the RS-232 of your manager station. This modem should then be connected to a working telephone line. The communication parameters of both the modem and the RS-232 port on the computer should be set accordingly.

5.5.1 Selecting the Destinations


You can configure the pager notification function to send a notification to multiple pagers. This is achieved through the pager address book provided by the GUI RAID Manager. From this book, you can add and remove entries, and select which of these entries will receive notification from the system.

► **To maintain the pager address book**

1. From the **Notification** menu, select **Pager** → **Address Book**.

-or-

Click on the **Notification** command button and then select **Pager** → **Address Book**. The Address Book for Pager Notification dialog box appears:



The list box on the left of this dialog box displays the current contents of the pager address book.

2. Click on the **Add** button to add a new entry. The Personal Information: Pager dialog box appears:

Personal Information : Pager

Full Name :

Pager Number :

Message :

Enable Disable

Stop In-Progress Event Notification

Error Recovery Status : Stand-by

3. In the **Full Name** text box, type in the name of the notification recipient. This only serves for reference purposes in the address book.
4. Enter the pager number in the **Pager Number** text box, including the area code. If you want to add a delay between the sending of this number and the sending of the actual message, add commas at the end of the pager number. The more commas you add, the longer the delay is. You can also add commas in front of the message.
5. Type in the appropriate message in the **Message** text box. If you want to add a delay between the sending of the pager number and the sending of this message, add commas in front of this value. The more commas you add, the longer the delay is. You can also add commas at the end of the pager number.

ASUS GUI RAID Manager: Notification Configuration

6. To enable pager notification for this particular entry, select the **Enable** option button. To disable, select the **Disable** option button.
7. If you want to check the reachability of the specified destination, click on the **Test** button. Then, check whether or not the notification is received successfully on the pager.
8. Click OK to add the specified destination to the address book.
9. Repeat the same procedure to add the other entries you want.
10. If you want to delete an entry from the address book, select it from the list box and then click on the **Remove** button.
11. If you want to modify the settings of a particular entry, select it and then click on the **Properties** button. From the displayed dialog box, modify the parameters you want.

5.5.2 Prescheduling Pager Notification

You can preschedule the pager notification for a particular destination to occur automatically at specific intervals. This notification will be sent regardless of the events occurring in the disk array system.


NOTE: The prescheduled pager notification does not affect in any way the configured pager notification – prescheduled pager notification is triggered by time, while configured pager notification is triggered by events based on the selected notification level.

► **To preschedule a pager notification**

1. From the **Notification** menu, select **Pager** → **Address Book**.

-or-

Click on the **Notification** command button and then select **Pager** → **Address Book**. The Address Book for Pager Notification dialog box appears:



The list box on the left of this dialog box displays the current contents of the pager address book.

2. From the list box, select the target entry, then click on the **Properties** button. The Personal Information: Pager dialog box appears:

ASUS GUI RAID Manager: Notification Configuration

Personal Information : Pager

Full Name : Peter

Pager Number : 5014387

Message : 911


Enable Disable

Stop In-Progress Event Notification

Error Recovery Status : Stand-by

OK Cancel Test Period

3. Click on the **Period** button. The Scheduled Period for Calling Pager dialog box appears:



4. In the **From** and **To** text boxes, specify the time ranges you want.
5. For each time range, specify the notification frequency in the respective **Period (Min)** text box. For example, if you want to send a notification to the selected destination every hour from 1:00 AM up to 5:00 AM, set **From** and **To** to 0100 and 0500, respectively, and **Period (Min)** to 60.
6. Click OK.

5.5.4 Stopping On-going Pager Notification

Once initiated, the pager notification function will repeatedly send the notification to the destination pagers at a specific time interval. You have the option though to stop subsequent

ASUS GUI RAID Manager: Notification Configuration

retransmissions for a particular destination, or for all destinations.

► **To stop any on-going pager notification to a particular destination**

1. From the list box in the Address Book for Pager Notification dialog box, select the target entry, then click on the **Properties** button. The Personal Information: Pager dialog box appears displaying the current settings of the selected entry:

Personal Information : Pager

Full Name : Peter

Pager Number : 5014387

Message : 911

Enable Disable

Stop In-Progress Event Notification

Error Recovery Status : Stand-by

OK Cancel Test Period

To determine if there is any on-going pager notification on the selected pager, check the **Error Recovery Status** field. If this field displays **Active**, it means that there is; if this displays **Stand-by**, it means that there is none.

2. If there is on-going pager notification and you want to stop subsequent retransmissions, check the **Stop In-Progress Event Notification** check box.
3. Click OK.

You can also stop on-going pager notification for all destination pagers through the RAID Manager Options dialog box. For information about this feature, see the *Configuring Notification Options* section of this chapter.

5.6 **Configuring a Fax Notification**

The GUI RAID Manager sends fax messages to specific destinations using the fax service that is installed to the MAPI of Windows NT. If your manager station does not have this service, install it first before using the fax notification function of the system. You will also need to connect a fax/modem to your computer. Installing a fax/modem can be a tricky process, so consult your operating system manuals for instructions on how to install your fax/modem software.

Since the GUI RAID Manager depends largely on the fax service installed to the MAPI of Windows NT for the delivery of fax messages, most fax notification parameters are configured through this software package. The GUI RAID Manager only allows you to select which users will receive the notification messages, and specify the notification message for each recipient.

For information on how to configure users for fax reception and other pertinent information about the fax service, refer to the fax service's documentation. Ensure that the fax service is properly configured in your computer before using the fax notification function of the GUI RAID Manager.

5.6.1 Selecting the Destinations


You can configure the fax notification function to send a notification to multiple users. This is achieved through the fax address book provided by the GUI RAID Manager. From this book, you can add and remove entries, and select which of these entries will receive notification from the system.

► **To maintain the fax address book**

1. From the **Notification** menu, select **Fax → Address Book**.


-or-

Click on the **Notification** command button and then select **Fax → Address Book**. The Address Book for Fax Notification dialog box appears:



The list box on the left of this dialog box displays the current contents of the fax address book.

2. Click on the **Add** button to add a new entry. The Personal Information: Fax dialog box appears:



3. In the **Display Name** text box, type in the name of the user that will receive a fax notification. If you specify a name that does not have an account on Fax Exchange yet, the program will prompt you to create one for this particular user.
4. In the **Message** text box, specify the fax message you want to relay to the selected user.
5. To enable fax notification for this particular entry, select the **Enable** option button. To disable, select the **Disable** option button.
6. If you want to check the reachability of the selected user, click on the **Test** button.
7. Click OK to add the specified entry to the address book. The Choose Profile dialog box appears on the screen.
8. To accept the MS Fax Exchange default setting, click OK. To choose another profile, click the **New** button. For assistance on how to proceed from here, refer to your Windows manual.

9. Repeat the same procedure to add the other entries you want.
10. If you want to delete an entry from the address book, select it from the list box and then click on the **Remove** button.
11. If you want to modify the settings of a particular entry, select it and then click on the **Properties** button. From the displayed dialog box, modify the parameters you want.
12. To put the Fax notification function into effect, start the MS Fax Exchange.

5.7 *Configuring an E-Mail Notification*

The GUI RAID Manager sends e-mail messages to specific people on the network or Internet using the Microsoft Internet Mail service or third-party, MAPI-compliant e-mail service. You will need these services to enable the e-mail notification function of the GUI RAID Manager. In addition to this, you will also need a network interface card or modem to connect your manager station to the network or Internet.

Since the GUI RAID Manager depends largely on services mentioned above for the delivery of e-mail messages, most e-mail notification parameters are configured through these packages. The GUI RAID Manager only allows you to select the users who will receive the notification messages, and specify the notification message for each recipient.

For information on how to configure users for e-mail reception and other pertinent information about the Microsoft Internet Mail service in Windows NT, refer to the Windows NT manual. Be sure that these services are configured properly, and functioning before using the e-mail notification function of the GUI RAID Manager.

5.7.1 Selecting the Destinations


You can configure the e-mail notification function to send a notification to multiple users. This is achieved through the e-mail address book provided by the GUI RAID Manager. From this book, you can add and remove entries, and select which of these entries will receive notification from the system.

► **To maintain the e-mail address book**

1. From the **Notification** menu, select **E-mail → Address Book**.


-or-

Click on the **Notification** command button and then select **E-mail → Address Book**. The Address Book for E-mail Notification dialog box appears:



The list box on the left of this dialog box displays the current contents of the e-mail address book.

2. Click on the **Add** button to add a new entry. The Personal Information: E-mail dialog box appears:



3. In the **Display Name** text box, type in the name of the user that will receive an e-mail notification. Typing the e-mail address directly may work; it all depends on the e-mail program that you are using. You can enter the destination e-mail address in this box if you are using the Microsoft Internet Mail service.
4. In the **Message** text box, specify the message you want to send to the selected user.
5. To enable e-mail notification for this particular entry, select the **Enable** option button. To disable, select the **Disable** option button.
6. If you want to check the reachability of the selected user, click on the **Test** button.
7. Click OK to add the specified entry to the address book. The Choose Profile dialog box appears on the screen.
8. To accept the MS Exchange default setting, click OK. To choose another profile, click the **New** button. For assistance

on how to proceed from here, refer to your Windows manual.

9. Repeat the same procedure to add the other entries you want.
10. If you want to delete an entry from the address book, select it from the list box and then click on the **Remove** button.
11. If you want to modify the settings of a particular entry, select it and then click on the **Properties** button. From the displayed dialog box, modify the parameters you want.
12. To put the E-mail notification function into effect, start Microsoft Internet Mail (or your third-party, MAPI-compliant e-mail service).

5.8 *Configuring a Broadcast Message Notification*

The GUI RAID Manager provides a way to notify selected users on the network by sending broadcast messages to their respective stations. This notification method only works on Windows NT stations with the Windows NT Messenger service installed. If your system does not have these programs, you will not be able to use this method. In addition to these programs, your station also needs a network interface card to connect to an existing network. Be sure that the adapter is properly installed and configured, and the correct driver is used.

For information on how to configure users for broadcast message reception in Windows NT and other pertinent information about this software, refer to the Windows NT manual.

Windows 95/98 systems cannot receive broadcast messages unless the program WINPOPUP.EXE is running. If the intended recipient for a broadcast message is a Windows 95/98 system, it

ASUS GUI RAID Manager: Notification Configuration

is necessary to first execute WINPOPUP.EXE on that system. WINPOPUP.EXE is located in the Windows directory.

5.8.1 Selecting the Destinations


You can configure the broadcast message notification function to send messages to multiple users. This is achieved through the broadcast message address book provided by the GUI RAID Manager. From this book, you can add and remove entries, and select which of these entries will receive notification from the system.

► To maintain the broadcast message address book

1. From the **Notification** menu, select **Broadcast → Address Book**.


-or-

Click on the **Notification** command button and then select **Broadcast → Address Book**. The Address Book for Messenger Information dialog box will appear:



The list box on the left of this dialog box displays the current contents of the broadcast message address book.

2. Click on the **Add** button to add a new entry. The Personal Information: Broadcast dialog box will appear:



3. In the **Computer Name** text box, type in the computer name for the computer that will receive a broadcast message. Be sure that the name you specify has a network account with Windows NT.
4. In the **Message** text box, specify the message you want to send to the selected computer.
5. To enable broadcast message notification for this particular entry, select the **Enable** option button. To disable, select the **Disable** option button.
6. If you want to check the reachability of the selected computer, click on the **Test** button.

7. Click OK to add the specified entry to the address book.
8. Repeat the same procedure to add the other entries you want.
9. If you want to delete an entry from the address book, select it from the list box and then click on the **Remove** button.
10. If you want to modify the settings of a particular entry, select it and then click on the **Properties** button. From the displayed dialog box, modify the parameters you want.

5.8.2 Prescheduling Broadcast Message Notification

You can preschedule the broadcast message notification for a particular destination to occur automatically at specific intervals. This notification will be sent regardless of the events occurring in the disk array system.


NOTE: The prescheduled broadcast message notification does not affect in any way the configured broadcast message notification – prescheduled broadcast message notification is triggered by time, while configured broadcast message notification is triggered by events based on the selected notification level.

► To preschedule a broadcast message notification

1. From the **Notification** menu, select **Broadcast** → **Address Book**.

-or-

Click on the **Notification** command button and then select **Broadcast** → **Address Book**. The Address Book for Messenger Information dialog box appears:




The list box on the left of this dialog box displays the current contents of the broadcast message address book.

2. From the list box, select the target entry, then click on the **Properties** button. The Personal Information: Broadcast dialog box appears:



3. Click on the **Period** button. The Scheduled Period for Broadcast dialog box appears:



4. In the **From** and **To** text boxes, specify the time ranges you want.
5. For each time range, specify the notification frequency in the respective **Period (Min)** text box. For example, if you want to send a notification to the selected destination every hour from 1:00 AM up to 5:00 AM, set **From** and **To** to 0100 and 0500, respectively, and **Period (Min)** to 60.
6. Click OK.


5.8.3 Stopping On-going Broadcast Notification

The broadcast message notification function automatically retransmits the message to a destination computer until an ACK (acknowledgment) message is received from it. This ensures

message reception by the intended administrator. If, however, the destination computer is off-line, you can terminate subsequent message retransmissions to cut back in the processing time of your computer, and also to lessen traffic on the network.

► To stop message retransmission to a particular destination

1. From the list box in the Address Book for Messenger Information dialog box, select the target entry, then click on the **Properties** button. The Personal Information: Broadcast dialog box appears displaying the current settings of the selected entry:



To determine if there is any on-going broadcast message notification to the selected computer, check the **Error Recovery Status** field. If this field displays **Active**, it means that there is; if this displays **Stand-by**, it means that there is none.

ASUS GUI RAID Manager: Notification Configuration

2. If there is on-going broadcast message notification and you want to stop subsequent retransmissions, check the **Stop In-Progress Event Notification** check box.
3. Click OK.

6 Running in Demo Mode

This chapter provides information on how to run the GUI RAID Manager in Demo mode. These include the following topics:

- ◆ Introduction about the Demo program
- ◆ Starting the Demo program
- ◆ Failing a drive
- ◆ Exiting the Demo program

6.1 *Introduction*

The GUI RAID Manager provides a Demo program for use as a learning tool and for demonstration purposes. This program allows you to experiment with various disk array configurations and check how the system responds and operates under various conditions.

The Demo program supports all management functions available in the actual GUI RAID Manager, making management of the virtual disk array system as real as possible. You can select the controller for your virtual system, the number of host (for SCSI-to-SCSI controller only) and drive channels, the number of physical drives, configure your logical drives and volumes, partition logical volumes, and map partitions to hosts. You can even fail drives to check how the particular system configuration reacts under such a condition.

6.2 Starting the Demo Program


You can use the Demo program any time, even without a real disk array system (that is, a controller and SCSI drives) installed in your computer. Since the Demo program only simulates management of a disk array system, you will not need any of these devices.

▶ To start the Demo program


1. Start the GUI RAID Manager by performing the appropriate startup procedure described in the *Starting the GUI RAID Manager* section of Chapter 3, *Basic Operations at Startup*.
2. From the **File** menu, select **Connect**.

-or-

Click on the **Connect/Open** command button. The following submenu appears on the screen:



3. Select **Demo Mode**. The Demo Configuration Options dialog box appears:



4. In the **Controller Type** section, select the type of controller you want to use. To use a PCI-to-SCSI controller, select the **Host Adapter** option button; to use a SCSI-to-SCSI controller, select **Target Controller**.
5. From the **Channel Count** drop-down list box, select the total number of channels you want to assign to the selected controller. To select, click on the down-arrow button at the right of the box. Then, select the option you want from the displayed list. Maximum setting for each controller is eight.

As you select a value, the program enables the corresponding number of **Channel x Mode** (where x is the channel number) sections below.

6. If you selected **Host Adapter** in step 4, proceed to the next step; otherwise, select the channel mode for each enabled **Channel x Mode** section. To configure the channel as a host channel, select the **Host** option button; to configure it as a drive channel, select **Drive**.
7. Click OK.

The Demo program creates a virtual disk array system based on the configuration specified in the Demo Configuration Options dialog box. For each drive channel, the program places four SCSI drives, which you can increase if you want by simply scanning in drives from unoccupied connectors.

You may now start managing the selected disk array system using the available commands. Try experimenting on various commands to see how the system reacts, and also to help clarify the use of such commands. All disk array icons on the screen respond accordingly – just like a real system. For information on disk array management, see Chapter 4, *Array Management*.

NOTE: The management operations you perform and settings you specify in Demo mode do not have any effect on the actual disk array system installed in your computer, assuming you have one installed. Everything you do under the Demo mode is only a simulation.

6.3 *Failing a Drive*

The Demo program comes with a Fail One Drive function that allows you to fail a drive (that is, one physical drive) from any existing logical drives in the system. This function is particularly useful in testing the response of the selected disk array system when there is failure in one of its drives.

ASUS GUI RAID Manager: Running in Demo Mode


During a drive failure, the system responds differently depending on the current array configuration. The following describes the possible scenarios:

- ◆ If there is a spare drive assigned to the selected logical drive, the virtual controller will automatically start data rebuilding in the background onto the spare drive.
- ◆ If there is no spare drive assigned to the selected logical drive, the failed drive must be replaced and rebuilding must be initiated manually. If the replacement drive is installed on a different connector, you will need to first scan in the drive and assign it as a spare drive for the affected logical drive before rebuilding can be initiated.

While the logical drive is being rebuilt, its respective icon on the Logical Drives window reflects the rebuilding status. The Physical Drives window also reflects the rebuilding status through the assigned spare drive.

► **To fail a drive**

1. Display the Logical Drives window by clicking on the **Logical Drives** command button or selecting the **Logical Drives** command from the **Open** menu.
2. From the Logical Drives window, double-click the right mouse button on the target logical drive. The following menu will appear on the screen:



3. Select **Fail One Drive**.

The Demo program fails one of the drives belonging to the selected logical drive. The Physical Drives window, and the Enclosure window if implemented, displays which drive has failed. The Logical Drives window displays the selected logical drive in degraded mode.

The system will then react to this situation based on its current configuration; that is, whether or not a spare drive exists. For information, see the discussion earlier in this section.

If you want to fail drives from other existing logical drives, follow the same procedure.

6.4 *Exiting the Demo Program*

If you are done with the Demo program and you want to manage the real disk array system installed in your computer, quit from the Demo program and then connect to your disk array system. Quitting from the Demo program only requires disconnecting from it.

▶ **Exiting from the Demo program**

- From the **File** menu, select **Disconnect**.

All toolbar buttons, except the **Connect/Open** and **Notification** command buttons, turn gray signifying termination of the Demo program.

A Command Summary

This appendix describes the available commands in the GUI RAID Manager disk array management program. These commands are presented either in menus or command buttons.

Menu Commands

This section lists and explains in tabular form the commands available from the menus in the menu bar. Keyboard strokes for commands that can also be executed from the keyboard are indicated in the tables inside angle brackets. For example:

Connect <C>

means that you can connect to a disk array system by selecting Connect from the File menu or by pressing the C key on your keyboard.



File Open View Window Notification Options Help

File Menu Commands

Command	Description
Connect <C>	Connects the GUI RAID Manager station to a particular disk array system for management. This command has the same function as the Connect/Open command button found on the toolbar.
Disconnect <D>	Disconnects from the current disk array system, terminating the current management session with the device.
Exit <X>	Exits the GUI RAID Manager.

ASUS GUI RAID Manager: Command Summary

Open Menu Commands

Command	Description
Enclosure <E>	Displays the Enclosure window. This command has the same function as the Enclosure command button found on the toolbar.
Physical Drive <P>	Displays the Physical Drives window. This command has the same function as the Physical Drives command button found on the toolbar.

ASUS GUI RAID Manager: Command Summary

Command	Description
Logical Drive <L>	Displays the Logical Drives window. This command has the same function as the Logical Drives command button found on the toolbar.
Logical Volume <V>	Displays the Volume window. This command has the same function as the Logical Volume command button found on the toolbar.
Host LUN Assignment <H>	Displays the Host LUN Assignment window. This command has the same function as the Host LUN Assignment command button found on the toolbar.
Event Log <L>	Displays the Event Log window. This command has the same function as the Event Log command button found on the toolbar.
Statistics <S>	Displays the Statistics window. This command has the same function as the Statistics command button found on the toolbar.

View Menu Commands

Command	Description
Toolbar <I>	Toggles between displaying and hiding the toolbar. To display the toolbar, select this option until a check mark "√" appears next to it; to hide, remove the displayed check mark.
StatusBar <S>	Toggles between displaying and hiding the status bar. To display the status bar, select this option until a check mark "√" appears next to it; to hide, remove the displayed check mark.

Window Menu Commands

Command	Description
---------	-------------

ASUS GUI RAID Manager: Command Summary

Tile In-Sequence <S>	A command specifically designed for disk array management. This command arranges the displayed windows horizontally based on their uses, with each window reduced to fit all elements within its width. Has the same function as the Tile In-Sequence command button found on the toolbar.
Cascade <C>	A standard Windows command that cascades windows in such a way that they overlap with each other, making their title bars visible.
Tile Horizontal <H>	A standard Windows command that arranges windows into smaller sizes, fitting them horizontally next to each other.
Tile Vertical <V>	A standard Windows command that arranges windows into smaller sizes, fitting them vertically next to each other.

Notification Menu Commands

Command	Description
Pager <P>	Configures pager notification.
Fax <F>	Configures fax notification.
E-Mail <E>	Configures e-mail notification.
Broadcast 	Configures broadcast notification.

Options Command


Command	Description
Options	This command allows you to configure the system notification function. From this command, you can enable or disable the notification function, select the event severity, specify the event countdown limit, and stop all on-going pager notifications.

Help Menu Commands

Command	Description
Contents	Displays the GUI RAID Manager on-line help manual.
About RAID Manager	Displays some information about the GUI RAID Manager program.

Command Buttons

This section describes the various command buttons provided by the system to facilitate execution of commonly used commands. These buttons can be found on the toolbar.



Command Button	Description
Connect/Open	Connects your GUI RAID Manager station to a particular disk array system for management. Has the same function as the Connect command in the File menu. After connection to a disk array system has been established successfully, this button becomes the Open button, providing the same function as Open in the menu bar.

ASUS GUI RAID Manager: Command Summary

Command Button	Description
Tile In-Sequence	A command button specifically designed for disk array management. This button arranges the displayed windows horizontally based on their uses, with each window reduced to fit all elements within its width. Has the same function as the Tile In-Sequence command found in the Window menu.
Enclosure	Displays the Enclosure window. This button has the same function as the Enclosure command in the Open menu.
Physical Drives	Displays the Physical Drives window. Has the same function as the Physical Drive command found in the Open menu.
Logical Drives	Displays the Logical Drives window. Has the same function as the Logical Drive command found in the Open menu.
Logical Volume	Displays the Volume window. This button has the same function as the Logical Volume command in the Open menu.
Host LUN Assignment	Displays the Host LUN Assignment window. Has the same function as the Host LUN Assignment command found in the Open menu.
Event Log	Displays the Event Log window. This button has the same function as the Event Log command found in the Open menu.
Notification	Allows you to configure system notifications. This button provides the same function as Notification in the menu bar.

ASUS GUI RAID Manager: Command Summary

Command Button	Description
Statistics	Displays the Statistics window. Has the same function as the Statistics command in the Open menu.

B Troubleshooting

This appendix provides troubleshooting tips for common problems you may encounter while using the GUI RAID Manager. These include the following topics:

- ◆ Startup errors
- ◆ Notification errors
- ◆ SNMP errors

Startup Errors

Error Message1: *Error encountered during OPEN: Unable to Connect to Controller*

Cause1: The GUI RAID Manager was not able to establish a link with the target disk array system. This may be caused by one (or more) of the following: a wrong baud rate or communication port setting, no disk array controller is installed, bad RS-232 cable, bad connection, or no null modem is installed.

Solution1: Specify the correct baud rate and/or COM port in the Settings of RS-232 Interface dialog box. Ensure that the settings you specify correspond to the actual settings on the RS-232 port. Check also for the required hardware and cable connection.

Error Message2: *Error encountered during OPEN: Selected Port Not Available*

Cause2: The COM Port you selected does not exist in your system.

Solution2: Specify the correct COM port in the Settings of RS-232 Interface dialog box. Be sure to select the port to which the disk array system is actually connected.

Error Message3: *Error encountered during OPEN: Selected Port Already in Use*

Cause3: The selected COM port is in use by another program or device.

Solution3: Select an unused COM port from the Settings of RS-232 Interface dialog box and connect the controller to this COM port. Or, locate the program or device that is using the port and disable or remove it.

Error Message4: *Error in loading DLL*

Cause4: The GUI RAID Manager cannot find one of its components.

Solution4: Re-install the GUI RAID Manager.

Notification Errors

Error Condition1: Pager notification does not work

Cause1: This error can be caused by one (or more) of the following: no modem is connected, the modem is not properly connected to the RS-232 port of the computer, modem is not connected to a telephone line, bad telephone line, wrong pager number, selected COM port is currently in use by another program or device, or modem initialization string is not properly set.

Solution1: Check the modem, the modem's RS-232 connection, telephone line, etc. Check also if the specified pager number is correct. If the selected COM port is in use by another program or device, select a different COM port from the Settings for Modem dialog box. Or, locate the program or device that is using the port and disable or remove it. Check the documentation that comes with the modem for information on how to set properly the modem initialization string. To check whether or not your modem settings are correct, use the **Test** button on the mentioned dialog box.

Error Condition2: Some numbers are missing from the message displayed on the pager

Cause2: There is not enough delay between the start of dialing and the actual sending out of the message.

Solution2: Add commas between the pager number and the message number in the Personal Information: Pager dialog box. You may place the commas at the end of the pager number, or in front of

ASUS GUI RAID Manager: Troubleshooting

the message number. If your pager number is 1234567, for example, and the message you want to send is 911, you can specify one of the following:

1234567 , , , (in the **Pager Number** text box)

-or-

, , , 911 (in the **Message** text box)

You can specify as many commas as you want; be reminded though that as you increase the number of commas, the more delay you are adding between these processes. Use the **Test** button on the mentioned dialog box to check whether or not the pager notification is functioning properly.

Error Condition3: Fax notification does not work

Cause3: This error can be caused by one (or more) of the following: the Microsoft Fax Exchange is not properly installed in your system, there is no modem connected, modem is not properly connected to the RS-232 port of the computer, modem is not connected to a telephone line, bad telephone line, Fax transmission is not supported by the modem (you should be using a Fax/modem), wrong Fax number, selected COM port is currently in use by another program or device, or modem is configured incorrectly.

Solution3: Install the Microsoft Fax Exchange (if not yet installed), check to verify that the Microsoft Fax Exchange settings are correct, check the system modem settings by selecting the Modem Settings option from the Control Panel, check the connected modem for any connection related errors, and check the Fax number. If the selected COM port is currently in use by another program or device, select another port, or disable or remove the program (or device). Use the **Test** button on the Personal Information: Fax dialog box to check the Fax notification functionality.

Error Condition4: E-mail notification does not work

Cause4: This error can be caused by one (or more) of the following: the Microsoft Exchange, Microsoft Mail and/or Microsoft Internet Mail is not properly installed in your system, there is problem with your Internet connection, E-mail address is not correct, or the recipient's Mail Server is not active.

Solution4: Check the Microsoft Exchange, Mail and Internet Mail settings, check the Internet connectivity of the local host (specifically the network interface card and driver programs), and E-mail address. Use the **Test** button on the Personal Information: E-mail dialog box to check the reachability of the selected destinations.

Error Condition5: LAN Broadcast notification does not work

Cause5: This error can be caused by one (or more) of the following: the system you are using is not a Windows NT station, the Windows NT Messenger Service is not properly installed, the local host is not properly connected to the network, destination station is not connected to the LAN, or the computer name is not set.

Solution5: Check that you have the required software installed in your system. Check also the Internet connectivity of the local host (specifically the network interface card and driver programs) and the destination computers, and computer name. Use the **Test** button on the Personal Information: Message dialog box to check the reachability of the selected destinations.

SNMP Errors

Error Message1: *SNMP service not installed*

Cause1: The SNMP service of the local host or the remote manager station is not installed.

ASUS GUI RAID Manager: Troubleshooting

Solution1: Install the appropriate SNMP service for the environment you are using for the local host or the remote manager station. You can get this service from the software provider; that is, Microsoft for Windows NT and Windows 95, and Novell for NetWare.

Error Message2: *Failed to open SNMP agent comm*

Cause2: This error can be caused by one (or more) of the following: the SNMP agent is not reachable over the LAN or WAN, the SNMP service is not properly installed on the local host and/or the remote manager station, the GUI RAID Manager's SNMP agent software is not installed on the local host, or the disk array controller is not installed or properly connected.

Solution2: Check the LAN/WAN connections, install the required software to the local host and/or remote manager station, check the SNMP service settings, and check that the controller is properly installed and connected.

C RAID Levels

This appendix provides a functional description of Redundant Array of Independent Disks (RAID). This includes information about RAID and available RAID levels.

RAID Description

Redundant Array of Independent Disks (RAID) is a storage technology used to improve the processing capability of storage systems. This technology is designed to provide reliability in disk array systems and to take advantage of the performance gains multiple disks can offer.

RAID comes with a redundancy feature that ensures fault-tolerant, uninterrupted disk storage operations. In the event of a disk failure, disk access will still continue normally with the failure transparent to the host system.

RAID has six levels: RAID 0 ~ 5. RAID levels 1, 3 and 5 are the most commonly used levels, while RAID levels 2 and 4 are virtually never used. The following sections described in detail each of the commonly used RAID levels.

Non-RAID Storage


One common option for expanding disk storage capacity is simply to install multiple disk drives into the system and then combine them end to end. This method is called *disk spanning*.

In disk spanning, the total disk capacity is equivalent to the sum of the capacities of all SCSI drives in the combination. This combination appears to the system as a single logical drive. Thus, combining four 1GB SCSI drives in this way, for example,

ASUS GUI RAID Manager: RAID Levels

would create a single logical drive with a total disk capacity of 4GB.

Disk spanning is considered non-RAID due to the fact that it neither provides redundancy nor improves performance. Disk spanning is inexpensive, flexible, and easy to implement; however, it does not improve the performance of the drives and any disk failure could result to total data loss.




RAID 0

RAID 0 implements *block striping* where data is broken into logical blocks and striped across several drives. Although called RAID 0, this is not a true implementation of RAID because there is no facility for redundancy. In the event of a disk failure, data is lost.

In block striping, the total disk capacity is equivalent to the sum of the capacities of all SCSI drives in the combination. This combination of drives appears to the system as a single logical drive.

RAID 0 provides the highest performance without redundancy. It is fast because data can be simultaneously transferred to/from

multiple disks. Furthermore, for I/Os that do not span more than one drive, read/writes to different drives can be processed concurrently.




RAID 1

RAID 1 implements *disk mirroring* where a copy of the same data is recorded onto two sets of striped drives. By keeping two copies of data on separate disks or arrays, data is protected against a disk failure. If, at any time, a disk on either side fails, the good disks can provide all of the data needed, thus preventing downtime.

In disk mirroring, the total disk capacity is equivalent to half the sum of the capacities of all SCSI drives in the combination. Thus, combining four 1GB SCSI drives, for example, would create a single logical drive with a total disk capacity of 2GB. This combination of drives appears to the system as a single logical drive.

RAID 1 is simple and easy to implement; however, it is more expensive as it doubles investment required for a non-redundant disk array implementation.



In addition to the data protection RAID 1 provides, this RAID level also improves performance. In cases where multiple concurrent I/Os are occurring, these I/Os can be distributed between two disk copies thus reducing total effective data access time.


RAID 1(0+1)

RAID 1(0+1) combines RAID 0 and RAID 1 -- *Mirroring and Disk Striping*. RAID (0+1) allows multiple drive failure because of the full redundancy of the hard disk drives. If more than two hard disk drives are chosen for RAID 1, RAID (0+1) will be performed automatically.



IMPORTANT:

RAID (0+1) will not appear in the list of RAID levels supported by the controller. If you wish to perform RAID 1, the controller will determine whether to perform RAID 1 or RAID (0+1). This will depend on the drive number that has been selected for the logical drive.




RAID 3

RAID 3 implements *block striping with dedicated parity*. This RAID level breaks data into logical blocks, the size of a SCSI disk block, and then stripes these blocks across several drives. One drive is dedicated to parity. In the event a disk fails, the original data can be reconstructed from the parity information.

In RAID 3, the total disk capacity is equivalent to the sum of the capacities of all SCSI drives in the combination, excluding the parity drive. Thus, combining four 1GB SCSI drives, for example, would create a single logical drive with a total disk capacity of 3GB. This combination appears to the system as a single logical drive.

RAID 3 provides increased data transfer rates when data is being accessed in large chunks or sequentially. However, in write operations that do not span multiple drives, performance is reduced since the information stored in the parity drive needs to be re-calculated and re-written every time new data is written to any of the data disks.




RAID 5

RAID 5 implements *multiple-block striping with distributed parity*. This RAID level offers the same redundancy available in RAID 3; though the parity information this time is distributed across all disks in the array. Data and relative parity are never stored on the same disk. In the event a disk fails, original data can be reconstructed using the available parity information.

For small I/Os, as few as one disk may be activated for improved access speed.

RAID 5 offers both increased data transfer rates when data is being accessed in large chunks or sequentially and reduced total effective data access time for multiple concurrent I/O's that do not span multiple drives.



Index

—A—

address book 1-4, 1-5, 1-8, 5-14,
5-15, 5-16, 5-17, 5-22, 5-23, 5-
24, 5-25, 5-26, 5-27, 5-28, 5-29,
5-30, 5-31

—B—

baud rate 2-5, 2-7, 3-3, 3-6, 3-10,
3-11, 3-12, 4-11, 4-13, B-2
block striping with dedicated parity
C-5

—C—

cache 3-25, 4-11, 4-12
card layout 3-14, 3-24, 4-16
channel configuration 4-1, 4-17
channel mode 3-26, 4-16, 6-5
COM port 3-6, 3-10, 3-11, 3-12,
B-2, B-3, B-4
command buttons 3-12, 3-15, 3-
19, 6-8, A-1, A-6
community name 3-2, 3-8, 3-10
Connect command 3-19, A-6
Connect/Open command button
3-4, 3-5, 3-7, 3-9, 3-11, 3-19, 6-
3, A-1
controller configuration 4-1, 4-
12, 4-13
controllers 1-2, 1-3, 1-6, 1-8, 3-
25, 4-3
creating logical drives 4-19

—D—

data traffic 4-36
data transfer clock rate 4-15
dedicated parity C-5
deleting partitions 4-31
disk mirroring C-3
disk spanning C-1
Dynamic Logical Drive Expansion
4-37

—E—

Enclosure command button 3-22,
4-8, A-2
enclosure management 1-6, 3-27
Event Log command button 3-21,
4-34, A-3
Expansion
in Windows NT 4-41
Mode 1 4-38
Mode 2 4-39
external terminator 4-14

—F—

failed drive 1-7, 3-22, 3-31, 3-32,
4-3, 4-4, 4-5, 4-8, 4-17, 4-22, 4-
24, 6-6
Fault Bus 3-26
fax notification 5-1, 5-21, 5-23,
A-4

ASUS GUI RAID Manager: Index

Firmware

upgrading 2-27

front panel 3-13, 3-24, 4-12

FTP sites 2-26

—G—

graphical interface 1-3, 1-6

—H—

hardware setup 2-1, 3-1

Host LUN Assignment command
button 3-20, 3-35, 4-32, 4-33,
A-3

Host LUN Assignment window
3-20, 3-34, 3-35, 4-32, 4-33, A-
3, A-7

—I—

In-band SCSI 2-8

IP address 3-2, 3-8, 3-10

—L—

latency time 1-5, 5-11, 5-12

local management 2-3, 2-4, 2-23,
3-1

Logical Drive

expansion 4-37

Logical Drive command 3-20, A-
7

logical drives 1-4, 1-6, 1-10, 3-
20, 3-31, 3-33, 4-1, 4-4, 4-19, 4-
25, 6-2, 6-5

Logical Drives command button
3-20, 3-31, 4-20, 4-21, 4-23, 4-
24, 4-25, 6-7, A-3

Logical Drives window 3-20, 3-
31, 4-4, 4-20, 4-21, 4-23, 4-24,
6-6, 6-7, A-3, A-7

Logical Volume command button
3-20, 4-25, 4-27, 4-28, 4-30, 4-
32, A-3

logical volume partitions 1-4, 3-
20, 4-30, 4-32

logical volumes 1-4, 1-6, 1-10, 3-
20, 3-32, 3-33, 3-34, 3-36, 4-1,
4-25, 6-2

—M—

main window 3-1, 3-3, 3-16, 3-
17, 3-18, 3-36

management functions 1-4, 1-10,
6-2

mapping logical volume 1-4, 3-36

menu bar 3-18, 3-19, 5-11, A-1

monitoring physical drives 1-4

multiple management sessions 1-
3

—N—

narrow transfer 4-15, 4-17

Notification command button 3-
12, 5-14, 5-17, 5-22, 5-25, 5-28,
5-31, 6-8

notification destinations 1-8

notification methods 5-2

notification retransmission 1-5, 1-
8

—P—

pager notification 5-1, 5-2, 5-11, 5-12, 5-13, 5-14, 5-16, 5-17, 5-19, 5-20, 5-21, A-4, A-5, B-4
pager number 5-15, B-3
partitions 1-4, 3-20, 3-31, 3-33, 3-34, 3-35, 3-36, 4-1, 4-26, 4-28, 4-30, 4-31, 4-32, 4-33, 6-2
password protection 1-6, 1-10, 3-13, 4-7
Peripheral Device Type
 Parameters Reference 2-11
 Settings 2-12
Physical Drive command 3-20, A-7
physical drives 1-3, 1-4, 1-7, 1-10, 3-20, 3-22, 3-23, 3-24, 3-25, 3-26, 3-32, 4-3, 4-4, 4-8, 4-9, 4-19, 6-2
Physical Drives command button 3-13, 3-20, 3-24, 4-9, 4-12, 4-16, 4-18, 4-20, 4-23
Physical Drives window 3-13, 3-20, 3-23, 3-24, 3-26, 4-3, 4-6, 4-9, 4-12, 4-16, 4-17, 4-18, 4-20, 4-21, 4-23, 6-6, 6-7, A-2, A-7
program updates 2-26

—R—

RAID 0 4-3, C-1, C-2, C-4
RAID 1 4-21, 4-23, C-3, C-4
RAID 1(0+1) C-4
RAID 3 4-21, 4-23, C-5, C-6
RAID 5 4-21, 4-23, C-6
RAID levels 3-33, 4-3, 4-21, 4-25, C-1, C-4

rebuilding logical drives 1-4
Redundant Controller 4-50
remote management 1-3, 1-8, 2-1, 2-2, 2-3, 2-6, 2-7, 2-23, 3-2, 3-3
replacement drives 4-4, 4-21

—S—

SAF-TE
 enclosure management 3-28
 polling period 3-30
scroll bars 3-21, 4-35
SCSI ID 3-26, 4-5, 4-14, 4-17, 4-18, 4-24
SNMP errors B-1
software requirements 2-2, 2-23
software setup 2-1
spare drive 1-4, 3-32, 4-1, 4-4, 4-5, 4-21, 4-22, 4-23, 4-24, 6-6, 6-7
Statistics command button 4-36, A-3
statistics monitoring 1-4, 4-36
status bar 3-1, 3-15, 3-16, 3-17, 3-21
synchronous transfer mode 4-15

—T—

termination 4-14, 4-16
Tile Horizontal command 3-37
Tile Vertical command 3-37
troubleshooting B-1

—U—

Upgrading Firmware 2-27

ASUS GUI RAID Manager: Index

—V—

Volume window 3-20, 3-33, 4-25, 4-27, 4-28, 4-30, 4-32, 4-33, A-3, A-7

—W—

wide transfer 4-15, 4-17
windows display area 3-15, 3-16, 3-21