

# **ASUS<sup>®</sup> AP1600R-E2** **(BA2/BI2)**

**1U Rackmount Barebone Server**

## **User Guide**



E1850

First Edition V2

August 2005

**Copyright © 2005 ASUSTeK COMPUTER INC. All Rights Reserved.**

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. (“ASUS”).

ASUS provides this manual “as is” without warranty of any kind, either express or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose. In no event shall ASUS, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of use or data, interruption of business and the like), even if ASUS has been advised of the possibility of such damages arising from any defect or error in this manual or product.

Specifications and information contained in this manual are furnished for informational use only, and are subject to change at any time without notice, and should not be construed as a commitment by ASUS. ASUS assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual, including the products and software described in it.

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners’ benefit, without intent to infringe.

# Contents

- Notices ..... vii
- Safety information ..... viii
- About this guide ..... ix
  
- Chapter 1: Product introduction ..... 1-1**
  - 1.1 System package contents ..... 1-2
  - 1.2 System specifications ..... 1-3
  - 1.3 Front panel features ..... 1-4
  - 1.4 Rear panel features ..... 1-4
  - 1.5 Internal features ..... 1-5
  - 1.6 LED information ..... 1-6
    - 1.6.1 Front panel LEDs ..... 1-6
    - 1.6.2 Rear panel LEDs ..... 1-6
  
- Chapter 2: Hardware setup ..... 2-1**
  - 2.1 Chassis cover ..... 2-2
    - 2.1.1 Removing the cover ..... 2-2
    - 2.1.2 Installing the cover ..... 2-3
  - 2.2 Central Processing Unit (CPU) ..... 2-4
    - 2.2.1 Removing the CPU heatsink ..... 2-4
    - 2.2.2 Installing a CPU ..... 2-5
    - 2.2.3 Installing the CPU heatsink ..... 2-6
  - 2.3 System memory ..... 2-7
    - 2.3.1 Overview ..... 2-7
    - 2.3.2 Memory configurations ..... 2-7
    - 2.3.3 Installing a DIMM ..... 2-8
    - 2.3.4 Removing a DIMM ..... 2-8
  - 2.4 Hard disk drives ..... 2-9
    - 2.4.1 Installing a SATA HDD (BA2 model) ..... 2-9
    - 2.4.2 Installing an IDE HDD (BI2 model) ..... 2-11
  - 2.5 Expansion slot ..... 2-13
    - 2.5.1 Installing an expansion card ..... 2-13
    - 2.5.2 Configuring an expansion card ..... 2-15
  - 2.6 Cable connections ..... 2-16
  - 2.7 Removable components ..... 2-17
    - 2.7.1 System fans ..... 2-17
    - 2.7.2 Device fan ..... 2-17

2.7.3	Power supply module .....	2-18
2.7.4	Optical drive .....	2-19
2.7.5	Motherboard .....	2-21
2.8	SATA backplane cabling .....	2-24
<b>Chapter 3: Installation options .....</b>		<b>3-1</b>
3.1	Rackmount rail kit items .....	3-2
3.2	Rack rails assembly .....	3-2
3.3	Attaching the rails to the rack .....	3-3
3.4	Rackmounting the server .....	3-4
<b>Chapter 4: Motherboard information .....</b>		<b>4-1</b>
4.1	Motherboard layout .....	4-2
4.2	Jumpers .....	4-4
4.3	Connectors .....	4-8
<b>Chapter 5: BIOS SETUP .....</b>		<b>5-1</b>
5.1	Managing and updating your BIOS .....	5-2
5.1.1	Creating a bootable floppy disk .....	5-2
5.1.2	AFUDOS utility .....	5-3
5.1.3	ASUS CrashFree BIOS 2 utility .....	5-6
5.1.4	ASUS Update utility .....	5-8
5.2	BIOS setup program .....	5-11
5.2.1	BIOS menu screen .....	5-12
5.2.2	Menu bar .....	5-12
5.2.3	Navigation keys .....	5-12
5.2.4	Menu items .....	5-13
5.2.5	Sub-menu items .....	5-13
5.2.6	Configuration fields .....	5-13
5.2.7	Pop-up window .....	5-13
5.2.8	Scroll bar .....	5-13
5.2.9	General help .....	5-13
5.3	Main menu .....	5-14
5.3.1	System Time [xx:xx:xxxx] .....	5-14
5.3.2	System Date [Day xx/xx/xxxx] .....	5-14
5.3.3	Legacy Diskette A [1.44M, 3.5 in.] .....	5-14
5.3.4	Primary, Third and Fourth IDE Master/Slave .....	5-15
5.3.5	IDE Configuration .....	5-16
5.3.6	System Information .....	5-17

5.4	Advanced menu .....	5-18
5.4.1	USB Configuration .....	5-18
5.4.2	MPS Configuration .....	5-19
5.4.3	Remote Access Configuration .....	5-20
5.4.4	CPU Configuration .....	5-22
5.4.5	Chipset .....	5-23
5.4.6	Onboard Devices Configuration .....	5-24
5.4.7	PCI PnP .....	5-25
5.5	Power menu .....	5-27
5.5.1	ACPI APIC Support [Enabled] .....	5-27
5.5.2	APM Configuration .....	5-28
5.5.3	Hardware Monitor .....	5-30
5.6	Boot menu .....	5-32
5.6.1	Boot Device Priority .....	5-32
5.6.2	Boot Settings Configuration .....	5-33
5.6.3	Security .....	5-34
5.7	Exit menu .....	5-37
<b>Chapter 6: Driver installation .....</b>		<b>6-1</b>
6.1	RAID .....	6-2
6.1.1	RAID configurations .....	6-2
6.1.2	Installing hard disk drives .....	6-2
6.1.3	Setting the RAID item in BIOS .....	6-3
6.1.4	RAID configuration utility .....	6-3
6.1.5	Creating a RAID driver disk .....	6-21
6.1.6	Installing the Intel® 6300ESB RAID controller driver .....	6-22
6.2	LAN .....	6-29
6.2.1	Windows® 2000/2003 Server .....	6-29
6.2.3	Red Hat® Linux 9.0 .....	6-31
6.2.4	Novell NetWare Server .....	6-33
6.2.5	Solaris .....	6-36
6.2.6	UNIX .....	6-38
6.3	VGA .....	6-41
6.3.1	Windows® 2000 Server .....	6-41
6.3.2	Windows® 2003 Server .....	6-42
6.3.3	Red Hat® Linux 9.0 .....	6-42

# Notices

## Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



---

**WARNING!** The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

---

## Canadian Department of Communications Statement

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

**This Class A digital apparatus complies with Canadian ICES-003.**

# Safety information

## Electrical Safety

- Before installing or removing signal cables, ensure that the power cables for the system unit and all attached devices are unplugged.
- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- When adding or removing any additional devices to or from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your dealer.

## Operation Safety

- Any mechanical operation on this server must be conducted by certified or experienced engineers.
- Before operating the server, carefully read all the manuals included with the server package.
- Before using the server, make sure all cables are correctly connected and the power cables are not damaged. If any damage is detected, contact your dealer as soon as possible.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Place the server on a stable surface.



---

This product is equipped with a three-wire power cable and plug for the user's safety. Use the power cable with a properly grounded electrical outlet to avoid electrical shock.

---

### Lithium-Ion Battery Warning

**CAUTION!** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

### CD-ROM Drive Safety Warning

**CLASS 1 LASER PRODUCT**

### Heavy System

**CAUTION!** This server system is heavy. Ask for assistance when moving or carrying the system.

# About this guide

## Audience

This user guide is intended for system integrators, and experienced users with at least basic knowledge of configuring a server.

## Contents

This guide contains the following parts:

### 1. Chapter 1: Product Introduction

This chapter describes the general features of the server, including sections on front panel and rear panel specifications.

### 2. Chapter 2: Hardware setup

This chapter lists the hardware setup procedures that you have to perform when installing or removing system components.

### 3. Chapter 3: Installation options

This chapter describes how to install optional components into the barebone server.

### 4. Chapter 4: Motherboard information

This chapter gives information about the motherboard that comes with the server. This chapter includes the motherboard layout, jumper settings, and connector locations.

### 5. Chapter 5: BIOS information

This chapter tells how to change system settings through the BIOS Setup menus and describes the BIOS parameters.

### 6. Chapter 6: Driver installation

This chapter provides instructions for creating and configuring RAID, and installing the necessary drivers for different system components.



## Conventions

To make sure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



**WARNING:** Information to prevent injury to yourself when trying to complete a task.



**CAUTION:** Information to prevent damage to the components when trying to complete a task.



**IMPORTANT:** Instructions that you **MUST** follow to complete a task.



**NOTE:** Tips and information to aid in completing a task.

## References

Refer to the following sources for additional information, and for product and software updates.

### 1. **ASUS Server Web-based Management (ASWM) user guide**

This manual tells how to set up and use the proprietary ASUS server management utility.

### 2. **ASUS websites**

The ASUS websites worldwide provide updated information for all ASUS hardware and software products. Refer to the ASUS contact information.



# Chapter 1

This chapter describes the general features of the barebone server. It includes sections on front panel and rear panel specifications.



ASUS AP1600R-E2 (BA2/B12)

# Product introduction

## 1.1 System package contents

The items in the ASUS AP1600R-E2 (BA2/BI2) product package vary depending on the model you purchased. Check your package for the standard items listed in the following table.

Package items	BA2 model	BI2 model
ASUS AR14 1U rackmount chassis with:		
• ASUS NCLV-D motherboard	✓	✓
• 500W power supply, 115V-230V	✓	✓
• SATA backplane	✓	
• Fan control board		✓
• Optical drive	✓	✓
• System fan	✓	✓
• Device fan	✓	✓
• 2 x internal HDD trays	✓	✓
• Pre-connected device/power cables	✓	✓
CPU heatsink (2 pcs.)	✓	✓
SATA cable	✓	
IDE cable		✓
Rackmount rail kit	✓	✓
Accessory box		
• AP1600R-E2 drivers and utilities CD	✓	✓
• AP1600R-E2 user guide	✓	✓
• CA Anti-virus software CD	✓	✓
• Bag of screws	✓	✓

\* **BA2 model** - supports up to two internal SATA hard disks

\* **BI2 model** - supports up to two internal IDE hard disks



Contact your dealer immediately if any of the items is damaged or missing.


## 1.2 System specifications

The ASUS AP1600R-E2 (BA2/BI2) is a 1U barebone server system featuring the ASUS NCLV-D motherboard. The server supports dual Intel® Xeon™ processors, and includes the latest technologies through the chipsets embedded on the motherboard.

<b>Chassis</b>	Rackmount 1U (AR14)
<b>Motherboard</b>	ASUS NCLV-D
<b>Chipset</b>	North Bridge: Intel® E7320 Memory Controller Hub (MCH) South Bridge: Intel® 6300ESB
<b>Processor</b>	Supports dual Intel® Xeon™ 3.6 GHz processors with L2 1MB and L3 1MB caches via two 604-pin sockets
<b>Memory</b>	4 x 184-pin DDR sockets for up to 16GB system memory Supports DDR 333 registered ECC DIMMs
<b>LAN</b>	Broadcom® BCM5721 64-bit Gigabit LAN controller Broadcom® BCM5705E 32-bit Gigabit LAN controller
<b>VGA</b>	ATI RAGE-XL PCI-based VGA controller Supports 8MB display memory
<b>Expansion slots</b>	1 x PCI-X 66 MHz/64-bit slot (PCI-X 1.0) 1 x Mini-PCI socket for the ASUS Server Management Board
<b>Storage</b>	Intel® 6300ESB South Bridge supports: - 2 x Ultra DMA 100/66/33 HDDs - 2 x SATA HDDs with RAID 0/1 configuration
<b>Management</b>	ASUS Server Web-based Management (ASWM)
<b>Hardware monitors</b>	Voltage, temperature, and fan speed monitoring Automatic System Restart (ASR) feature
<b>Power supply</b>	500W power supply, 115V~230V, 50Hz~60Hz
<b>Dimensions</b>	600 mm (l) x 445 mm (w) x 43.6 mm (h))

## 1.3 Front panel features

The front panel displays a simple yet stylish front panel with easily accessible features. The power and reset buttons, LED indicators, location switch, optical drive, and two USB ports are located on the front panel.




Refer to section “1.6.1 Front panel LEDs” for the LED descriptions.

## 1.4 Rear panel features

The rear panel includes the expansion slot, system power socket, and rear fans. The middle part includes the I/O shield with openings for the rear panel connectors on the motherboard.




The ports for the PS/2 keyboard, PS/2 mouse, USB, VGA, and Gigabit LAN do not appear on the rear panel if motherboard is not present.



## 1.5 Internal features

The barebone system includes the basic components as shown.



- |                             |                        |
|-----------------------------|------------------------|
| 1. PCI-X riser card bracket | 6. System fans         |
| 2. Rear fans                | 7. SATA backplane      |
| 3. NCLV-D motherboard       | 8. Hot-swap HDD tray 1 |
| 4. Power supply             | 9. Hot-swap HDD tray 2 |
| 5. Device fan               | 10. Optical drive      |




---

The barebone server does not include a floppy disk drive. Connect an external floppy disk drive (USB interface) to any of the USB ports on the front or rear panel if you need to use a floppy disk.

---


## 1.6 LED information

### 1.6.1 Front panel LEDs



LED	Display status	Description
Power LED	ON	System power ON
HDD Access LED	OFF Blinking	No activity Read/write data into the HDD
Message LED	OFF Blinking	System is normal; no incoming event ASWM indicates a HW monitor event
Location LED	OFF ON	Normal status Location switch is pressed (Press the location switch again to turn off)
LAN LEDs	OFF Blinking ON	No LAN connection LAN is transmitting or receiving data LAN connection is present

### 1.6.2 Rear panel LEDs



ACT/LINK LED		SPEED LED	
Status	Description	Status	Description
OFF	No link	OFF	10Mbps connection
Green	Linked	Orange	100Mbps connection
Blinking	Linking	Green	1000Mbps connection



# Chapter 2

This chapter lists the hardware setup procedures that you have to perform when installing or removing system components.



ASUS AP1600R-E2 (BA2/B12)

# Hardware setup


## 2.1 Chassis cover

### 2.1.1 Removing the cover

1. Use a Phillips screwdriver to remove the screw on each front end of the top cover.



2. Loosen the two thumbscrews on the rear panel to release the top cover from the chassis.



3. Firmly hold the cover and slide it toward the rear panel for about half an inch until it is disengaged from the chassis.




4. Lift the cover from the chassis.

## 2.1.2 Installing the cover


1. Position the cover on top of the chassis with the thumbscrews on the rear, and leaving a gap of about half an inch from the front panel.



2. Make sure that the side markings on the cover (two on each side) are aligned to the grooves on the chassis.




3. Slide the cover toward the front until it snaps in place.
4. Tighten the thumbscrews on the rear to secure the cover.



## 2.2 Central Processing Unit (CPU)

The motherboard comes with two surface mount 604-pin Zero Insertion Force (ZIF) socket and designed for the Intel® Xeon™ processors.




1. The motherboard supports either one or two CPUs. If you are installing only one CPU, you **MUST** install it in CPU socket 1.
2. If you are installing two CPUs, install in the CPU socket 2 first.

### 2.2.1 Removing the CPU heatsink

If you have previously installed CPUs and heatsinks, follow these steps to remove the heatsinks before proceeding to the next section.

To remove the CPU heatsink:

1. Use a Phillips (cross) screwdriver to loosen the four screws that secure the heatsink until it is released.
2. Carefully lift the heatsink from the motherboard.




You don't need to detach the screws from the heatsink.

## 2.2.2 Installing a CPU

To install the CPUs:

1. Locate the CPU sockets on the motherboard. Flip up the socket lever and push it all the way to the other side.




Socket for CPU1

2. Carefully insert the CPU into the socket as shown until it fits in place.




The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to prevent bending the pins and damaging the CPU!



Marked corner  
(gold arrow)


3. Carefully push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked.
4. Apply the thermal interface material (thermal grease) to the top of the CPU. This thermal grease should come with the CPU package.
5. Repeat steps 1 to 4 if you wish to install a second CPU.




## 2.2.3 Installing the CPU heatsink

To install the CPU heatsink:


1. Carefully place the heatsink on top of the installed CPU (CPU1).



2. Twist each of the four screws with a Philips (cross) screwdriver just enough to attach the heatsink to the motherboard. When the four screws are attached, tighten them one by one to completely secure the heatsink.



3. Follow steps 1 and 2 to install the second CPU heatsink.




Heatsink for CPU2

## 2.3 System memory

### 2.3.1 Overview

The motherboard comes with four Double Data Rate (DDR) Dual Inline Memory Modules (DIMM) sockets. These sockets support up to 16 GB system memory using 184-pin registered ECC DDR 333 DIMMs.



NCLV-D 184-Pin DDR DIMM sockets

### 2.3.2 Memory configurations

You may install 256 MB, 512 MB, 1 GB, 2GB, and 4GB registered ECC DDR DIMMs into the DIMM sockets.




- Always install DIMMs with the same CAS latency. For optimum compatibility, it is recommended that you obtain memory modules from the same vendor. Refer to the DDR Qualified Vendors List on the following URL for details.
- Due to chipset resource allocation, the system may detect less than 16 GB system memory when you installed four 4 GB DDR memory modules.
- This motherboard does not support memory modules made up of 128 Mb chips or double sided x16 memory modules.

### 2.3.3 Installing a DIMM




Make sure to unplug the power supply before adding or removing DIMMs or other system components. Failure to do so may cause severe damage to both the motherboard and the components.

1. Unlock a DIMM socket by pressing the retaining clips outward.
2. Align a DIMM on the socket such that the notch on the DIMM matches the break on the socket.



A DDR DIMM is keyed with a notch so that it fits in only one direction. DO NOT force a DIMM into a socket to avoid damaging the DIMM.


3. Firmly insert the DIMM into the socket until the retaining clips snap back in place and the DIMM is properly seated.



### 2.3.4 Removing a DIMM

Follow these steps to remove a DIMM.

1. Simultaneously press the retaining clips outward to unlock the DIMM.



Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged when it flips out with extra force.

2. Remove the DIMM from the socket.



## 2.4 Hard disk drives


### 2.4.1 Installing a SATA HDD (BA2 model)

To install a SATA HDD:


1. Release a drive tray by pushing the spring lock to the right, then pulling the tray lever outward. The drive tray ejects slightly after you pull out the lever.




2. Firmly hold the tray lever and pull the drive tray out of the bay.




3. Take note of the drive tray holes. Each side has three holes to fit different types of hard disk drives. Use two screws on each side to secure the hard disk drive.



4. Place a SATA hard disk drive on the tray, then secure it with four screws.



- Carefully insert the drive tray and push it all the way to the depth of the bay until just a small fraction of the tray edge protrudes.



**SATA interface  
on the backplane**



---

When installed, the SATA connector on the drive connects to the SATA interface on the backplane.

---

- Push the tray lever until it clicks, and secures the drive tray in place. The drive tray is correctly placed when its front edge aligns with the bay edge.
- Repeat steps 1 to 6 if you wish to install a second SATA drive.




- Connect the bundled SATA cables to the connectors on the SATA backplane. Refer to section “2.7 SATA backplane cabling” for information on the SATA backplane cable connections.


## 2.4.2 Installing an IDE HDD (BI2 model)

To install an IDE HDD:


1. Disconnect all the cables from the fan control board. Use a Phillips (cross) screwdriver to remove the five screws that secure the fan control board.




Fan control board screws



2. Remove the screw that secures the hard disk tray to the chassis. Slide the tray backward until the two tray lock tabs are disengaged. Lift the tray from the bay.




Lock tab




3. Place a hard disk drive on the drive tray, and secure it with four screws.




- Carefully place the tray with installed hard disk drive into the drive bay. Slide it forward until the front end aligns with the front panel, and the screw hole matches the standoff.



- Secure the tray with a screw.
- Repeat steps 2 to 5 if you wish to install a second HDD; otherwise, proceed to step 7.



- Reinstall the fan control board. Secure the board with five screws.



- Connect the 40-pin IDE cable and a 4-pin power plug to their respective connectors on the back of the drive.



**40-pin IDE cable**  
**4-pin power plug**



The other end of the IDE cable is pre-connected to the primary IDE connector on the motherboard.


## 2.5 Expansion slot

### 2.5.1 Installing an expansion card


The barebone server comes with a riser card bracket. You need to remove the bracket if you wish to install a PCI-X expansion card.

To install a PCI-X card:


1. Use a Phillips (cross) screwdriver to remove the screw that secures the riser card to the standoff.




2. Firmly hold a riser card bracket, then pull it up to detach it from the PCI-X slot on the motherboard.





3. Remove the screw that secures the slot metal cover.



4. Install a PCI-X card to the bracket as shown, then secure the card with a screw.




5. Take note of the holes on the riser card bay. The two pegs on the riser card bracket should match these holes to ensure that the bracket is properly in place.




**Peg on the riser card bracket**

6. Install the riser card bracket with the card into the PCI-X slot on the motherboard.
7. Make sure that the golden connectors completely fit the slot and the bracket aligns with the rear panel.



8. Secure the riser card to the standoff.
9. Connect the cable(s) to the card, if applicable.



## 2.5.2 Configuring an expansion card

After installing the expansion card, configure the it by adjusting the software settings.

1. Turn on the system and change the necessary BIOS settings, if any. See Chapter 5 for information on BIOS setup.
2. Assign an IRQ to the card. Refer to the following tables.
3. Install the software drivers for the expansion card.

### Standard interrupt assignments

IRQ	Priority	Standard Function
0	1	System Timer
1	2	Keyboard Controller
2	N/A	Programmable Interrupt
3*	11	Communications Port (COM2)
4*	12	Communications Port (COM1)
5*	13	Sound Card (sometimes LPT2)
6	14	Floppy Disk Controller
7*	15	Printer Port (LPT1)
8	3	System CMOS/Real Time Clock
9*	4	ACPI Mode when used
10*	5	IRQ Holder for PCI Steering
11*	6	IRQ Holder for PCI Steering
12*	7	PS/2 Compatible Mouse Port
13	8	Numeric Data Processor
14*	9	Primary IDE Channel
15*	10	Secondary IDE Channel

\* These IRQs are usually available for ISA or PCI devices.

### IRQ assignments for this motherboard


	INTA#	INTB#	INTC#	INTD#	REQ#	GNT#
AIC-8130	PXIRQ2	—	—	—	X_REQ3	X_GNT3
ATI Rage XL	PIRQB#	—	—	—	REQ2#	GNT2#
BCM5705E	PIRQF#	—	—	—	REQ3#	GNT3#
PCI slot 1 (64-bit)	PXIRQ0	PXIRQ1	PXIRQ2	PXIRQ3	X_REQ0	X_GNT0



When using PCI cards on shared slots, ensure that the drivers support “Share IRQ” or that the cards do not need IRQ assignments. Otherwise, conflicts will arise between the two PCI groups, making the system unstable and the card inoperable.



## 2.6 Cable connections



### Pre-connected system cables

1. Parallel port cable (from motherboard to rear panel)
2. Rear fan connector (from power supply to motherboard)
3. 24-pin SSI power connector (from power supply to motherboard)
4. 8-pin SSI power connector (power supply to motherboard)
5. Secondary IDE connector (from motherboard to optical drive)
6. Device fan connector (from motherboard to SATA backplane board)
7. SATA connectors (from motherboard to SATA backplane board)
8. System fan connectors (from mid-fans to SATA backplane)
9. SATA backplane power connector (from power supply)
10. 4-pin power connector (from power supply to optical drive)



## 2.7 Removable components

You may need to remove previously installed system components when installing or removing system devices, or when you need to replace defective components. This section tells how to remove the following components:

1. System fans
2. Device fan
3. Power supply module
4. Optical drive
5. Motherboard

### 2.7.1 System fans

To uninstall the system fans:

1. Disconnect all the system fan cables from the connectors on the backplane board.
2. Remove the four screws that secure a fan.
3. Repeat step 2 to uninstall the other fans.




Fan screw

### 2.7.2 Device fan

To uninstall the device fan:

1. Disconnect the system fan cable from the connector on the motherboard.
2. Remove the four screws that secure the device fan.




Fan screw

## 2.7.3 Power supply module

To uninstall the power supply module:

1. Disconnect all the power cables connected to the motherboard and other system devices.



2. Use a Phillips (cross) screwdriver to remove the screw that secures the front end of the power supply.



3. Slide the power supply backward for about half an inch, then carefully lift it out from the chassis.

## 2.7.4 Optical drive


To uninstall the optical drive:

1. Please use a pin-ejector (paper clipper may be used) for tray-out.. (or you can open the tray by pushing the “open button”)



When changing ODD, the black ODD front plastic housing is already removed. User can uninstall/install ODD after remove the tray bezel.

2. Then remove the tray bezel demonstrated in the photo.



3. Disconnect the power and signal cabled connected to the rear of the ODD.




4. Use a Philips (cross) screwdriver to remove the two screws that secure the metal bracket on the side of the ODD.
5. Remove the bracket to release the drive.



To install an optical drive:



1. Please follow previous Step 1 instructions to tray-out and to remove the ODD bezel.



2. Then put the ODD inside the server and insert ODD into the ODD bay.



The purpose of the metal bracket is to secure the ODD us securely in place.



3. Secure the bracket with two screws and re-connect the power and signal cables in place. Put back the tray bezel to finish ODD installation.




## 2.7.5 Motherboard


To uninstall the motherboard:

1. Disconnect all the pre-connected cables from the motherboard. See section “2.6 Cable connections” for illustration.
2. Uninstall all the devices from the motherboard including the CPU and heatsink, riser card bracket, and DDR DIMMs. Refer to the corresponding sections for instructions on removing these components.
3. Remove the riser card standoff by twisting it counterclockwise.


Riser card standoff



3. Use a Phillips (cross) screwdriver to remove the screws that secure the motherboard to the base of the chassis.




4. Carefully lift the motherboard out of the chassis as shown.




To reinstall the motherboard:



1. Firmly hold the motherboard by the sides and insert it into the chassis as shown.



2. Carefully adjust the motherboard until the rear panel ports fit in place.




3. Use a Phillips (cross) screwdriver to secure the motherboard with seven (7) screws in the holes as shown.





Screw hole

4. Insert the riser card standoff into the motherboard hole beside the PCI-X slot, and twist it clockwise until secure.



5. Reconnect all the required cables to the motherboard. See section “2.6 Cable connections” for illustration.
6. Reinstall all the devices that you have previously removed.

## 2.8 SATA backplane cabling





# Chapter 3

This chapter describes how to install the optional components and devices into the barebone server.




ASUS AP1600R-E2 (BA2/B12)

# Installation options

### 3.1 Rackmount rail kit items


If you have the rackmount rail kit, it contains two pairs of rails (one pair for each side of the barebone system), and eight (8) pairs of nut-and-bolt type screws.



### 3.2 Rack rails assembly

To assemble the rack rails:


1. Determine the depth of the rack where you wish to install the system.
2. Match one long and one short rail to your desired length, and fix them together using four (4) pairs of nuts and bolts.
3. Repeat step 2 to assemble the other rail pair.



### 3.3 Attaching the rails to the rack

To attach the rails to the rack:

1. Select one unit of space (1U) on the rack where you wish to install the barebone server.
2. Remove the screws from the 1U space on the rack front.



1U space

3. Align the front end holes of a rack rail pair to the 1U space.
4. Drive in two screws on the outer holes to secure the front end.




5. Find the **rear 1U space** that corresponds to the **front 1U space** where you attached the rail.
6. Remove the screws from the rear 1U space, and align the rear end holes.
7. Drive in two screws on the outer holes to secure the rear end.
8. From the rack front, find the corresponding 1U space for the second rail pair.
9. Repeat steps 2 to 7 to attach the second rail pair. When properly installed, the rack rails appear as shown.



## 3.4 Rackmounting the server

To mount the server to the rack:

1. Firmly hold the server on both sides and insert the rear panel side to the front end of the rack rail, then carefully push the server all the way to the back until the front panel fits the front end of the rack, and the rack screws on the server match the middle hole on the rack..



2. Tighten the two rack screws to secure the server to the rack.



Rack screw

# Chapter 4


This chapter includes the motherboard layout, and brief descriptions of the jumpers and internal connectors.



ASUS AP1600R-E2 (BA2/B12)

# Motherboard info

# 4.1 Motherboard layout



The four grayed out card slots are present on the motherboard but are not used in this system. You may install one PCI-X card via the riser card bracket.

## Layout contents

Jumpers	Page
1. Clear RTC RAM (CLRRTC1)	4-4
2. VGA Graphics controller setting (3-pin VGA_EN1)	4-5
3. USB device wake-up (3-pin USBPW12, USBPW34)	4-5
4. Keyboard power (3-pin KBPWR1)	4-6
5. Gigabit LAN controller setting (3-pin LAN_EN1)	4-6
6. Gigabit LAN controller setting (3-pin LAN_EN2)	4-7
7. BIOS Recovery (3-pin RECOVERY1)	4-7

Connectors	Page
1. Floppy disk drive connector (34-1 pin FLOPPY)	4-8
2. IDE connectors (40-1 pin PRI_IDE1, SEC_IDE1)	4-8
3. Serial ATA connectors (7-pin SATA1, SATA2)	4-9
4. Hard disk activity LED connector (2-pin HDLED1)	4-10
5. System fan connectors (REAR_FAN1/2, FRNT_FAN1/2)	4-10
6. USB connector (10-1 pin USB34)	4-11
7. Serial port connector (10-1 pin COM2)	4-11
8. SSI power connectors (24-pin EATXPWR1, 8-pin SSI+12V1/+12V2)	4-12
9. Backplane SMBus connector (6-1 pin BPSMB1)	4-13
10. Power Supply SMBus connector (6-1 pin PSUSMB1)	4-13
11. Parallel port connector (26-1 pin LPT1)	4-14
12. BMC connector (16-pin BMCONN1)	4-14
13. System panel auxiliary connector (20-pin AUX_PANEL1) LAN1 Link activity LED (2-pin LAN1_LINKACTLED) LAN2 Link activity LED (2-pin LAN2_LINKACTLED) Locator LED 1 (2-pin LOCATORLED1) Locator LED 2 (2-pin LOCATORLED2) Locator Button/Switch (2-pin LOCATORBTN) Front Panel System Bus (6-1 pin)	4-15
14. System panel connector (20-pin PANEL1) System power LED (Green 3-pin PLED) Hard disk drive activity LED (Red 2-pin IDE_LED) System warning speaker (Orange 4-pin SPEAKER) ATX power button/soft-off button (Yellow 2-pin PWRSW) Reset button (Blue 2-pin RESET)	4-16

## 4.2 Jumpers

### 1. Clear RTC RAM (CLRTC1)

This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which include system setup information such as system passwords.

To erase the RTC RAM:


1. Turn OFF the computer and unplug the power cord.
2. Remove the onboard battery.
3. Move the jumper cap from pins 1-2 (default) to pins 2-3. Keep the cap on pins 2-3 for about 5~10 seconds, then move the cap back to pins 1-2.
4. Re-install the battery.
5. Plug the power cord and turn ON the computer.
6. Hold down the <Del> key during the boot process and enter BIOS setup to re-enter data.



---

Except when clearing the RTC RAM, never remove the cap on CLRTC1 jumper default position. Removing the cap will cause system boot failure!

---



---


You do not need to clear the RTC when the system hangs due to overclocking. For system failure due to overclocking, use the C.P.R. (CPU Parameter Recall) feature. Shut down and reboot the system so the BIOS can automatically reset parameter settings to default values.

---




## 2. VGA Graphics controller setting (3-pin VGA\_EN1)

These jumpers allow you to enable or disable the onboard ATI Rage XL video graphics controller. Set to pins 1-2 to enable the video graphics controller.



## 3. USB device wake-up (3-pin USBPW12, USBPW34)


Set these jumpers to +5V to wake up the computer from S1 sleep mode (CPU stopped, DRAM refreshed, system running in low power mode) using the connected USB devices. Set to +5VSB to wake up from S3 and S4 sleep modes (no power to CPU, DRAM in slow refresh, power supply in reduced power mode).



- The USB device wake-up feature requires a power supply that can provide 500mA on the +5VSB lead for each USB port; otherwise, the system would not power up.
- The total current consumed must NOT exceed the power supply capability (+5VSB) whether under normal condition or in sleep mode.

#### 4. Keyboard power (3-pin KBPWR1)


This jumper allows you to enable or disable the keyboard wake-up feature. Set this jumper to pins 2-3 (+5VSB) to wake up the computer when you press a key on the keyboard (the default is the Space Bar). This feature requires an ATX power supply that can supply at least 1A on the +5VSB lead, and a corresponding setting in the BIOS.



NCLV-D Keyboard power setting

#### 5. Gigabit LAN controller setting (3-pin LAN\_EN1)


These jumpers allow you to enable or disable the onboard Broadcom BCM5721 Gigabit LAN controller. Set to pins 1-2 to activate the Gigabit LAN feature.



NCLV-D LAN\_EN1 setting

## 6. Gigabit LAN controller setting (3-pin LAN\_EN2)

These jumpers allow you to enable or disable the onboard Broadcom BCM5705E Gigabit LAN controller. Set to pins 1-2 to activate the Gigabit LAN feature.




## 7. BIOS Recovery (3-pin RECOVERY1)

This jumper allows you to recover your original BIOS from a floppy disk in case the BIOS codes and data are corrupted.

To recover the BIOS:

1. Turn OFF your computer and unplug the power cord.
2. Move the jumper cap from pins 1-2 (default) to pins 2-3.
3. Insert a floppy disk with the original or updated BIOS file.
4. Plug the power cord and turn ON the computer.
5. The system searches for the BIOS file in the floppy then reflashes the BIOS.
6. When finished, shut down your computer.
7. Replace the jumper cap from pins 2-3 to pins 1-2.
8. Reboot your computer.
9. Hold down the **<Del>** key during the boot process and enter BIOS setup to re-enter data.




## 4.3 Connectors

### 1. Floppy disk drive connector (34-1 pin FLOPPY)

This connector is for the provided floppy disk drive (FDD) signal cable. Insert one end of the cable to this connector, then connect the other end to the signal connector at the back of the floppy disk drive.




Pin 5 on the connector is removed to prevent incorrect cable connection when using a FDD cable with a covered Pin 5.



**NCLV-D Floppy disk drive connector**

FLOPPY




**NOTE:** Orient the red markings on the floppy ribbon cable to PIN 1.

### 2. IDE connectors (40-1 pin PRI\_IDE1, SEC\_IDE1)

These connectors are for Ultra DMA 100/66 signal cables. The Ultra DMA 100/66 signal cable has two connectors: a blue connector for the primary IDE connector on the motherboard and a black connector for an Ultra DMA 100/66 IDE slave device (optical drive/hard disk drive). If you install two hard disk drives, you must configure the second drive as a slave device by setting its jumper accordingly. Refer to the hard disk documentation for the jumper settings.



- Pin 20 on the IDE connector is removed to match the covered hole on the Ultra DMA cable connector. This prevents incorrect insertion when you connect the IDE cable.
- Use the 80-conductor IDE cable for Ultra DMA 100/66 IDE devices.



**NCLV-D IDE connectors**

SEC\_IDE1



PRI\_IDE1



**NOTE:** Orient the red markings (usually zigzag) on the IDE ribbon cable to PIN 1.


### 3. Serial ATA connectors (7-pin SATA1, SATA2)

These connectors are for the Serial ATA signal cables for Serial ATA hard disk drives.

If you installed Serial ATA hard disk drives, you can create a RAID 0 or RAID 1 configuration with the Adaptec® HostRAID Technology through the onboard Intel® 6300ESB integrated RAID controller.



These connectors are set to **Standard IDE** mode by default. In **Standard IDE** mode, you can connect Serial ATA boot/data hard disk drives to these connectors. If you intend to create a Serial ATA RAID set using these connectors, set the **Configure SATA As** item in the BIOS to [RAID]. See section “4.3.6 IDE Configuration” on page 4-15 for details.



#### Important notes on Serial ATA


- You must install Windows® 2000 Service Pack 4 or the Windows® XP Service Pack 1 before using Serial ATA hard disk drives. The Serial ATA RAID feature (RAID 0/RAID 1) is available only if you are using Windows® 2000/XP.
- Use only two Serial ATA RAID connectors for each RAID 0 or RAID 1 set.
- When using the connectors in **Standard IDE** mode, connect the primary (boot) hard disk drive to the SATA1 or SATA2 connector. Refer to the table below for the recommended SATA hard disk drive connections.

#### Serial ATA hard disk drive connection

Connector	Setting	Use
SATA1	Master	Boot disk
SATA2	Slave	Data disk

#### 4. Hard disk activity LED connector (2-pin HDLED1)

This connector supplies power to the hard disk activity LED. The read or write activities of any device connected to the primary/secondary IDE connectors or the SATA connectors cause this LED to light up.




**NCLV-D**  
SCSI/SATA card activity LED connector

#### 5. System fan connectors (REAR\_FAN1/2, FRNT\_FAN1/2)

The fan connectors support cooling fans of 350 mA ~ 740 mA (8.88 W max.) or a total of 2.1 A ~ 4.44 A (53.28 W max.) at +12V. Connect the fan cables to the fan connectors on the motherboard, making sure that the black wire of each cable matches the ground pin of the connector.




Do not forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components. These are not jumpers! Do not place jumper caps on the fan connectors!



**NCLV-D** Fan connectors

## 6. USB connector (10-1 pin USB34)


This connector is for USB 2.0 ports. Connect the USB module cable to this connector, then install the module to a slot opening at the back of the system chassis. The USB connector complies with USB 2.0 specification that supports up to 480 Mbps connection speed.



**NCLV-D USB 2.0 connector**

## 7. Serial port connector (10-1 pin COM2)

This connector is for a serial (COM) port. Connect the serial port module cable to this connector, then install the module to a slot opening at the back of the system chassis.




**NCLV-D  
Serial port2 (COM2) connector**

## 8. SSI power connectors (24-pin EATXPWR1, 8-pin SSI+12V1/+12V2)

These connectors are for SSI power supply plugs. The power supply plugs are designed to fit these connectors in only one orientation. Find the proper orientation and push down firmly until the connectors completely fit.




- Use of an SSI 12 V Specification 2.0-compliant power supply unit (PSU) that provides a minimum power of 450 W is recommended for a fully-configured system.
- Do not forget to connect the 8-pin ATX +12 V power plug; otherwise, the system will not boot up.
- Use of a PSU with a higher power output is recommended when configuring a system with more power consuming devices. The system may become unstable or may not boot up if the power is inadequate.
- You must install a PSU with a higher power rating if you intend to install additional devices.






### 9. Backplane SMBus connector (6-1 pin BPSMB1)

This connector allows you to connect SMBus (System Management Bus) devices. Devices communicate with an SMBus host and/or other SMBus devices using the SMBus interface.




### 10. Power Supply SMBus connector (6-1 pin PSUSMB1)

This connector allows you to connect SMBus (System Management Bus) devices. Devices communicate with an SMBus host and/or other SMBus devices using the SMBus interface.




## 11. Parallel port connector (26-1 pin LPT1)

This connector is for a parallel port. Connect the parallel port module cable to this connector, then install the module to a slot opening at the back of the system chassis.




## 12. BMC connector (16-pin BMCCONN1)

This connector is for an ASUS server management card.



### 13. System panel auxiliary connector (20-pin AUX\_PANEL1)

This connector supports several server system functions.




**NCLV-D Auxiliary panel connector**

- **LAN1 link activity LED (2-pin LAN1\_LINKACTLED)**  
This 2-pin connector is for the LAN1 Activity LED. Connect the LAN1 Activity LED cable to this connector. This LED blinks during a network activity and is always lit when linked.
- **LAN2 link activity LED (2-pin LAN2\_LINKACTLED)**  
This 2-pin connector is for the LAN2 Activity LED. Connect the LAN2 Activity LED cable to this connector. This LED blinks during a network activity and lights up when linked.
- **Locator LED 1 (2-pin LOCATORLED1)**  
This 2-pin connector is for the Locator LED 1. Connect the Locator LED 1 cable to this connector. This LED lights up when the Locator button is pressed.
- **Locator LED 2 (2-pin LOCATORLED2)**  
This 2-pin connector is for the Locator LED 2. Connect the Locator LED 2 cable to this connector. This LED lights up when the Locator button is pressed.
- **Locator Button/Switch (2-pin LOCATORBTN)**  
This connector is for the locator button. This button queries the state of the system locator.
- **Front Panel SMBus (6-1 pin)**  
This connector allows you to connect SMBus (System Management Bus) devices. Devices communicate with an SMBus host and/or other SMBus devices using the SMBus interface.

## 14. System panel connector (20-pin PANEL1)

This connector supports several chassis-mounted functions.



The system panel connector is color-coded for easy connection. Refer to the connector descriptions on the next page for details.

- **System power LED (Green 3-pin PLED)**  
This 3-pin connector is for the system power LED. Connect the chassis power LED cable to this connector. The system power LED lights up when you turn on the system power, and blinks when the system is in sleep mode.
- **Hard disk drive activity LED (Red 2-pin IDE\_LED)**  
This 2-pin connector is for the HDD Activity LED. Connect the HDD Activity LED cable to this connector. The IDE LED lights up or flashes when data is read from or written to the HDD.
- **System warning speaker (Orange 4-pin SPEAKER)**  
This 4-pin connector is for the chassis-mounted system warning speaker. The speaker allows you to hear system beeps and warnings.
- **ATX power button/soft-off button (Yellow 2-pin PWRSW)**  
This connector is for the system power button. Pressing the power button turns the system on or puts the system in sleep or soft-off mode depending on the BIOS settings. Pressing the power switch for more than four seconds while the system is ON turns the system OFF.
- **Reset button (Blue 2-pin RESET)**  
This 2-pin connector is for the chassis-mounted reset button for system reboot without turning off the system power.

# Chapter 5

This chapter lists the hardware setup procedures that you have to perform when installing or removing system components.



ASUS AP1600R-E2 (BA2/B12)

# BIOS setup

## 5.1 Managing and updating your BIOS

The following utilities allow you to manage and update the motherboard Basic Input/Output System (BIOS) setup.

1. **ASUS AFUDOS** (Updates the BIOS in DOS mode using a bootable floppy disk.)
2. **ASUS CrashFree BIOS 2** (Updates the BIOS using a bootable floppy disk or the motherboard support CD when the BIOS file fails or gets corrupted.)
3. **ASUS Update** (Updates the BIOS in Windows® environment.)

Refer to the corresponding sections for details on these utilities.



---

Save a copy of the original motherboard BIOS file to a bootable floppy disk in case you need to restore the BIOS in the future. Copy the original motherboard BIOS using the ASUS Update or AFUDOS utilities.

---

### 5.1.1 Creating a bootable floppy disk



---

This barebone system does not include a floppy disk drive. Connect an external floppy disk drive (USB interface) to any of the USB 2.0 ports on the front or rear panel if you need to use a floppy disk.

---

To create a bootable floppy disk:

1. Do either one of the following to create a bootable floppy disk.
  - DOS environment
    - a. Insert a 1.44MB floppy disk into the drive.
    - b. At the DOS prompt, type **format A: /S** then press <Enter>.
  - Windows® XP environment
    - a. Insert a 1.44 MB floppy disk to the floppy disk drive.
    - b. Click **Start** from the Windows® desktop, then select **My Computer**.
    - c. Select the 3 1/2 Floppy Drive icon.
    - d. Click **File** from the menu, then select **Format. A Format 3 1/2 Floppy Disk** window appears.
    - e. **Windows® XP users:** Select **Create an MS-DOS startup disk** from the format options field, then click **Start**.

### Windows® 2000 environment

To create a set of boot disks for Windows® 2000:

- a. Insert a formatted, high density 1.44 MB floppy disk into the drive.
  - b. Insert the Windows® 2000 CD to the optical drive.
  - c. Click **Start**, then select **Run**.
  - d. In the **Open** field, type `D:\bootdisk\makeboot a:` assuming that D is your optical drive letter.
  - e. Press <Enter>, then follow screen instructions to continue.
2. Copy the original or the latest motherboard BIOS file to the bootable floppy disk.

## 5.1.2 AFUDOS utility

The AFUDOS utility allows you to update the BIOS file in DOS environment using a bootable floppy disk with the updated BIOS file. This utility also allows you to copy the current BIOS file that you can use as backup when the BIOS fails or gets corrupted during the updating process.

### Copying the current BIOS

To copy the current BIOS file using the AFUDOS utility:



- 
- Make sure that the floppy disk is not write-protected and has at least 600 KB free space to save the file.
  - The succeeding BIOS screens are for reference only. The actual BIOS screen displays may not be same as shown.
- 

1. Copy the AFUDOS utility (afudos.exe) from the motherboard support CD to the bootable floppy disk you created earlier.
2. Boot the system in DOS mode, then at the prompt type:

```
afudos /o[filename]
```

where the [filename] is any user-assigned filename not more than eight alphanumeric characters for the main filename and three alphanumeric characters for the extension name.

```
A:\>afudos /oOLDBIOS1.rom
```

Main filename      Extension name

3. Press <Enter>. The utility copies the current BIOS file to the floppy disk.

```
A:\>afudos /oOLDBIOS1.rom
AMI Firmware Update Utility - Version 1.19 (ASUS V2.07(03.11.24BB))
Copyright (C) 2002 American Megatrends, Inc. All rights reserved.
Reading flash ..... done
Write to file..... ok
A:\>
```

The utility returns to the DOS prompt after copying the current BIOS file.

## Updating the BIOS file

To update the BIOS file using the AFUDOS utility:

1. Visit the ASUS website ([www.asus.com](http://www.asus.com)) and download the latest BIOS file for the motherboard. Save the BIOS file to a bootable floppy disk.



---

Write the BIOS filename on a piece of paper. You need to type the exact BIOS filename at the DOS prompt.

---

2. Copy the AFUDOS utility (afudos.exe) from the motherboard support CD to the bootable floppy disk you created earlier.
3. Boot the system in DOS mode, then at the prompt type:

```
afudos /i[filename]
```

where [filename] is the latest or the original BIOS file on the bootable floppy disk.

```
A:\>afudos /iINCLVD.ROM
```



4. The utility verifies the file and starts updating the BIOS.

```
A:\>afudos /iNCLVD.ROM /pbnc
AMI Firmware Update Utility - Version 1.19(ASUS V2.07(03.11.24BB))
Copyright (C) 2002 American Megatrends, Inc. All rights reserved.

WARNING!! Do not turn off power during flash BIOS
Reading file ..... done
Reading flash ..... done

Advance Check .....
Erasing flash ..... done
Writing flash ..... 0x0008CC00 (9%)
```



---

Do not shut down or reset the system while updating the BIOS to prevent system boot failure!

---

5. The utility returns to the DOS prompt after the BIOS update process is completed. Reboot the system from the hard disk drive.

```
A:\>afudos /iNCLVD.ROM /pbnc
AMI Firmware Update Utility - Version 1.19(ASUS V2.07(03.11.24BB))
Copyright (C) 2002 American Megatrends, Inc. All rights reserved.

WARNING!! Do not turn off power during flash BIOS
Reading file ..... done
Reading flash ..... done

Advance Check .....
Erasing flash ..... done
Writing flash ..... done
Verifying flash .... done

Please restart your computer

A:\>
```

### 5.1.3 ASUS CrashFree BIOS 2 utility

The ASUS CrashFree BIOS 2 is an auto recovery tool that allows you to restore the BIOS file when it fails or gets corrupted during the updating process. You can update a corrupted BIOS file using the motherboard support CD or the floppy disk that contains the updated BIOS file.



- Prepare the motherboard support CD or the floppy disk containing the updated motherboard BIOS before using this utility.
- Make sure that you rename the original or updated BIOS file in the floppy disk to **NCLVD.ROM**.

### Recovering the BIOS from a floppy disk



This barebone system does not include a floppy disk drive. Connect an external floppy disk drive (USB interface) to any of the USB 2.0 ports on the front or rear panel if you need to use a floppy disk.

To recover the BIOS from a floppy disk:

1. Turn on the system.
2. Insert the floppy disk with the original or updated BIOS file to the floppy disk drive.
3. The utility displays the following message and automatically checks the floppy disk for the original or updated BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...  
Checking for floppy...
```

When found, the utility reads the BIOS file and starts flashing the corrupted BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...  
Checking for floppy...  
Floppy found!  
Reading file "NCLVD.ROM". Completed.  
Start flashing...
```



DO NOT shut down or reset the system while updating the BIOS! Doing so can cause system boot failure!

4. Restart the system after the utility completes the updating process.

## Recovering the BIOS from the support CD

To recover the BIOS from the support CD:

1. Remove any floppy disk from the floppy disk drive, then turn on the system.
2. Insert the support CD to the optical drive.
3. The utility displays the following message and automatically checks the floppy disk for the original or updated BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...  
Checking for floppy...
```

When no floppy disk is found, the utility automatically checks the optical drive for the original or updated BIOS file. The utility then updates the corrupted BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...  
Checking for floppy...  
Floppy not found!  
Checking for CD-ROM...  
CD-ROM found!  
Reading file "NCLVD.ROM". Completed.  
Start flashing...
```



---

DO NOT shut down or reset the system while updating the BIOS! Doing so can cause system boot failure!

---

4. Restart the system after the utility completes the updating process.



---

The recovered BIOS may not be the latest BIOS version for this motherboard. Visit the ASUS website ([www.asus.com](http://www.asus.com)) to download the latest BIOS file.

---

## 5.1.4 ASUS Update utility

The ASUS Update is a utility that allows you to manage, save, and update the motherboard BIOS in Windows® environment. The ASUS Update utility allows you to:

- Save the current BIOS file
- Download the latest BIOS file from the Internet
- Update the BIOS from an updated BIOS file
- Update the BIOS directly from the Internet, and
- View the BIOS version information.

This utility is available in the support CD that comes with the motherboard package.



---

ASUS Update requires an Internet connection either through a network or an Internet Service Provider (ISP).

---

### Installing ASUS Update

To install ASUS Update:

1. Place the support CD in the optical drive. The **Drivers** menu appears.
2. Click the **Utilities** tab, then click **Install ASUS Update VX.XX.XX**.
3. The ASUS Update utility is copied to your system.



---



Quit all Windows® applications before you update the BIOS using this utility.

---

## Updating the BIOS through the Internet

To update the BIOS through the Internet:

1. Launch the ASUS Update utility from the Windows® desktop by clicking **Start > Programs > ASUS > ASUSUpdate > ASUSUpdate**. The ASUS Update main window appears.



2. Select **Update BIOS from the Internet** option from the drop-down menu, then click **Next**.
3. Select the ASUS FTP site nearest you to avoid network traffic, or click **Auto Select**. Click **Next**.

- From the FTP site, select the BIOS version that you wish to download. Click Next.
- Follow the screen instructions to complete the update process.




The ASUS Update utility is capable of updating itself through the Internet. Always update the utility to avail all its features.



## Updating the BIOS through a BIOS file

To update the BIOS through a BIOS file:

- Launch the ASUS Update utility from the Windows® desktop by clicking **Start > Programs > ASUS > ASUSUpdate > ASUSUpdate**. The ASUS Update main window appears.
- Select **Update BIOS from a file** option from the drop-down menu, then click **Next**.



- Locate the BIOS file from the **Open** window, then click **Save**.
- Follow the screen instructions to complete the update process.

## 5.2 BIOS setup program

This motherboard supports a programmable firmware chip that you can update using the provided utility described in section “5.1 Managing and updating your BIOS.”

Use the BIOS Setup program when you are installing a motherboard, reconfiguring your system, or prompted to “Run Setup”. This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the firmware hub.

The firmware hub on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press <Del> during the Power-On-Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.


If you wish to enter Setup after POST, restart the system by pressing <Ctrl+Alt+Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.



- 
- The default BIOS settings for this motherboard apply for most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Select the **Load Setup Defaults** item under the Exit Menu. See section “5.7 Exit Menu.”
  - The BIOS setup screens shown in this section are for reference purposes only, and may not exactly match what you see on your screen.
  - Visit the ASUS website ([www.asus.com](http://www.asus.com)) to download the latest BIOS file for this motherboard.
-

## 5.2.1 BIOS menu screen



## 5.2.2 Menu bar

The menu bar on top of the screen has the following main items:

- Main** For changing the basic system configuration
- Advanced** For changing the advanced system settings
- Power** For changing the advanced power management (APM) configuration
- Boot** For changing the system boot configuration
- Exit** For selecting the exit options and loading default settings

To select an item on the menu bar, press the right or left arrow key on the keyboard until the desired item is highlighted.

## 5.2.3 Navigation keys

At the bottom right corner of a menu screen are the navigation keys for that particular menu. Use the navigation keys to select items in the menu and change the settings.



---

Some of the navigation keys differ from one screen to another.


---



## 5.2.4 Menu items

The highlighted item on the menu bar displays the specific items for that menu. For example, selecting **Main** shows the Main menu items.

The other items (Advanced, Power, Boot, and Exit) on the menu bar have their respective menu items.



Main menu items

## 5.2.5 Sub-menu items

A solid triangle before each item on any menu screen means that the item has a sub-menu. To display the sub-menu, select the item and press <Enter>.

## 5.2.6 Configuration fields

These fields show the values for the menu items. If an item is user-configurable, you can change the value of the field opposite the item. You cannot select an item that is not user-configurable.


A configurable field is enclosed in brackets, and is highlighted when selected. To change the value of a field, select it then press <Enter> to display a list of options. Refer to “5.2.7 Pop-up window.”

## 5.2.7 Pop-up window

Select a menu item then press <Enter> to display a pop-up window with the configuration options for that item.

## 5.2.8 Scroll bar

A scroll bar appears on the right side of a menu screen when there are items that do not fit on the screen. Press the Up/Down arrow keys or <Page Up> / <Page Down> keys to display the other items on the screen.



Pop-up window

Scroll bar

## 5.2.9 General help

At the top right corner of the menu screen is a brief description of the selected item.

## 5.3 Main menu

When you enter the BIOS Setup program, the **Main** menu screen appears, giving you an overview of the basic system information.



This is a NOTE. Refer to section “5.2.1 BIOS menu screen” for information on the menu screen items and how to navigate through them.

```
BIOS SETUP UTILITY
Main  Advanced  Power  Boot  Exit

System Time           [11:51:19]
System Date           [Thu 05/07/2004]
Legacy Diskette A    [1.44M, 3.5 in]

▶ Primary IDE Master   : [ST320413A]
▶ Primary IDE Slave   : [ASUS CD-S520/A]
▶ Third IDE Master    : [Not Detected]
▶ Third IDE Slave     : [Not Detected]
▶ Fourth IDE Master   : [Not Detected]
▶ Fourth IDE Slave    : [Not Detected]
▶ IDE Configuration

▶ System Information

Use [ENTER], [TAB]
or [SHIFT-TAB] to
select a field.

Use [+] or [-] to
configure system time.

← Select Screen
↑↓ Select Item
+- Change Field
Tab Select Field
F1 General Help
F10 Save and Exit
ESC Exit

<C>Copyright 1985-2002. American Megatrends, Inc.
```

### 5.3.1 System Time [xx:xx:xxxx]

Allows you to set the system time.

### 5.3.2 System Date [Day xx/xx/xxxx]


Allows you to set the system date.

### 5.3.3 Legacy Diskette A [1.44M, 3.5 in.]

Sets the type of floppy drive installed. Configuration options: [Disabled]  
[360K, 5.25 in.] [1.2M, 5.25 in.] [720K, 3.5 in.] [1.44M, 3.5 in.]  
[2.88M, 3.5 in.]

### 5.3.4 Primary, Third and Fourth IDE Master/Slave

The BIOS automatically detects the connected IDE devices. There is a separate sub-menu for each IDE device. Select a device item, then press <Enter> to display the IDE device information.



The BIOS automatically detects the values opposite the dimmed items (Device, Vendor, Size, LBA Mode, Block Mode, PIO Mode, Async DMA, Ultra DMA, and SMART monitoring). These values are not user-configurable. These items show N/A if no IDE device is installed in the system.

#### Type [Auto]

Selects the type of IDE drive. Setting to [Auto] allows automatic selection of the appropriate IDE device type. Select [CDROM] if you are specifically configuring a CD-ROM drive. Select [ARMD] (ATAPI Removable Media Device) if your device is either a ZIP, LS-120, or MO drive. Configuration options: [Not Installed] [Auto] [CDROM] [ARMD]

#### LBA/Large Mode [Auto]

Enables or disables the LBA mode. Setting to [Auto] enables the LBA mode if the device supports this mode, and if the device was not previously formatted with LBA mode disabled. Configuration options: [Disabled] [Auto]

#### Block (Multi-sector Transfer) [Auto]

Enables or disables data multi-sectors transfers. When set to [Auto], the data transfer from and to the device occurs multiple sectors at a time if the device supports multi-sector transfer feature. When set to [Disabled], the data transfer from and to the device occurs one sector at a time. Configuration options: [Disabled] [Auto]

## PIO Mode [Auto]

Selects the PIO mode.

Configuration options: [Auto] [0] [1] [2] [3] [4]

## SMART Monitoring [Auto]

Sets the Smart Monitoring, Analysis, and Reporting Technology.

Configuration options: [Auto] [Disabled] [Enabled]


## 32Bit Data Transfer [Disabled]

Enables or disables 32-bit data transfer.

Configuration options: [Disabled] [Enabled]

### 5.3.5 IDE Configuration

The items in this menu allow you to set or change the configurations for the IDE devices installed in the system. Select an item then press <Enter> if you wish to configure the item.



## Onboard IDE Operate Mode [Enhanced Mode]

Allows selection of the IDE operation mode depending on the installed operating system (OS). Set to [Enhanced Mode] if you are using native OS including Windows® 2000/XP. Configuration options: [Compatible Mode] [Enhanced Mode]

### Enhanced Mode Support On [S-ATA]

Allows you to use native OS on Serial ATA and Parallel ATA ports. It is recommended that you do not change the default setting for better OS compatibility. In this setting, you may use legacy OS on the Parallel ATA ports only if you do not install any Serial ATA device.

### Configure S-ATA as RAID [No]

Allows you to set the Serial ATA devices connected to the Serial ATA connectors as RAID sets. Configuration options: [No] [Yes]



The following item appears only when you set the **Onboard IDE Operate Mode** to [Compatible Mode]

#### Compatible Mode Option [Primary P-ATA+S-ATA]

Allows you to select the combined mode for the installed IDE and SATA devices.

The Secondary **P-ATA+S-ATA** and **P-ATA Ports Only** options are for advanced users only. If you set to any of these options and encountered problems, revert to the default setting **Primary P-ATA+S-ATA**. Configuration options: [Primary P-ATA+S-ATA] [Secondary P-ATA+S-ATA] [P-ATA Ports Only]


### IDE Detect Time Out [35]

Selects the time out value for detecting ATA/ATAPI devices.

Configuration options: [0] [5] [10] [15] [20] [25] [30] [35]

## 5.3.6 System Information

This menu gives you an overview of the general system specifications. The BIOS automatically detects the items in this menu.



### AMI BIOS

Displays the auto-detected BIOS information

### Processor

Displays the auto-detected CPU specification

### System Memory


Displays the auto-detected system memory

## 5.4 Advanced menu

The Advanced menu items allow you to change the settings for the CPU and other system devices.




Take caution when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction!



### 5.4.1 USB Configuration

The items in this menu allows you to change the USB-related features. Select an item then press <Enter> to display the configuration options.



The **Module Version** and **USB Devices Enabled** items show the auto-detected values. If no USB device is detected, the **USB Devices Enabled** item shows **None**.

#### USB Function [Enabled]

Allows you to enable or disable the USB function.  
Configuration options: [Disabled] [Enabled]

## Legacy USB Support [Auto]

Allows you to enable or disable support for legacy USB devices. Setting to [Auto] allows the system to detect the presence of USB devices at startup. If detected, the USB controller legacy mode is enabled. If no USB device is detected, the legacy USB support is disabled.  
Configuration options: [Disabled] [Enabled] [Auto]

## USB 2.0 Controller [Enabled]


Allows you to enable or disable the USB 2.0 controller.  
Configuration options: [Enabled] [Disabled]

## USB 2.0 Controller Mode [HiSpeed]

Allows you to set the USB 2.0 controller mode to HiSpeed (480 Mbps) or FullSpeed (12 Mbps). Configuration options: [HiSpeed ] [FullSpeed ]

## 5.4.2 MPS Configuration

The items in this menu allows you to configure the Multi-Processor Table. Select an item then press <Enter> to display the configuration options.




## MPS Revision [1.4]

Allows you to select the multi-processor system revision.  
Configuration options: [1.1] [1.4]

### 5.4.3 Remote Access Configuration

The items in this menu allows you to configure the Remote Access features. Select an item then press <Enter> to display the configuration options.



#### Remote Access [Enabled]

Enables or disables the remote access feature.  
Configuration options: [Disabled] [Enabled]

#### Serial port number [COM1]

Enables or disables the remote access feature.  
Configuration options: [Disabled] [Enabled]

#### Serial Port Mode [115200 8,n,1]

Sets the Serial port mode.  
Configuration options: [115200 8,n,1] [57600 8,n,1] [38400 8,n,1]  
[19200 8,n,1] [09600 8,n,1]



### **Flow Control [None]**

Allows you to select the flow control for console redirection.

Configuration options: [None] [Hardware] [Software]

### **Redirection After BIOS POST [Always]**

Sets the redirection mode after the BIOS Power-On Self-Test (POST). Some operating systems may not work when this item is set to Always.

Configuration options: [Disabled] [Boot Loader] [Always]

### **Terminal Type [ANSI]**

Allows you to select the target terminal type.

Configuration options: [ANSI] [VT100] [VT-UTF8]

### **VT-UTF8 Combo Key Support [Disabled]**

Enables or disables the VT-UTF8 combo key support for ANSI or VT100 terminals. Configuration options: [Disabled] [Enabled]

## 5.4.4 CPU Configuration

The items in this menu show the CPU-related information that the BIOS automatically detects.



### Ratio CMOS Setting [ 8]

Sets the ratio between the CPU core clock and the Front Side Bus frequency. The BIOS auto-detects the default value of this item. Use the



You can only adjust the **Ratio CMOS** settings if you installed an unlocked CPU. Refer to the CPU documentation for details.

### Hyper-Threading Technology [Enabled]


Allows you to enable or disable the processor Hyper-Threading Technology. Configuration options: [Disabled] [Enabled]

### Max CPUID Value Limit [Disabled]

Setting this item to [Enabled] allows legacy operating systems to boot even without support for CPUs with extended CPUID functions. Configuration options: [Disabled] [Enabled]

## 5.4.5 Chipset

The Chipset menu allows you to change the advanced chipset settings. Select an item then press <Enter> to display the sub-menu.



### Onboard LAN Boot ROM [Enabled]


Allows you to enable or disable the option ROM in the onboard LAN controller. Configuration options: [Disabled] [Enabled]

### Onboard PCI LAN Boot ROM [Enabled]

Allows you to enable or disable the option ROM in the onboard PCI LAN controller. Configuration options: [Disabled] [Enabled]

### NorthBridge Configuration

The NorthBridge Configuration menu allows you to change the Northbridge settings.



### DIMM Speed

Displays the installed DIMM type and speed. This item is auto-detected and is not configurable.

### Memory Remap Feature [Enabled]

Allows you to remap the overlap PCI memory over the total physical memory. Configuration options: [Disabled] [Enabled]

## 5.4.6 Onboard Devices Configuration

Advanced		BIOS SETUP UTILITY
Configure Win627EHF Super IO Chipset		Allows BIOS to Select Serial Port1 Base Addresses.
Serial Port1 Address	[3F8/IRQ4]	
Serial Port2 Address	[2F8/IRQ3]	
Parallel Port Address	[378]	
Parallel Port Mode	[Normal]	
Parallel Port IRQ	[IRQ7]	

### Serial Port1 Address [3F8/IRQ4]

Allows you to select the Serial Port1 base address.

Configuration options: [Disabled] [3F8/IRQ4] [3E8/IRQ4] [2E8/IRQ3]

### Serial Port1 Address [2F8/IRQ3]

Allows you to select the Serial Port2 base address.

Configuration options: [Disabled] [2F8/IRQ3] [3E8/IRQ4] [2E8/IRQ3]

### Parallel Port Address [378]

Allows you to select the Parallel Port base addresses.

Configuration options: [Disabled] [378] [278] [3BC]

### Parallel Port Mode [ECP]

Allows you to select the Parallel Port mode.

Configuration options: [Normal] [Bi-directional] [EPP] [ECP]

#### ECP Mode DMA Channel [DMA3]

Appears only when the Parallel Port Mode is set to [ECP]. This item allows you to set the Parallel Port ECP DMA.

Configuration options: [DMA0] [DMA1] [DMA3]

#### EPP Version [1.9]

Allows selection of the Parallel Port EPP version. This item appears only when the **Parallel Port Mode** is set to **EPP**.

Configuration options: [1.9] [1.7]

#### Parallel Port IRQ [IRQ7]


Sets the Parallel port IRQ. Configuration options: [IRQ5] [IRQ7]

## 5.4.7 PCI PnP

The PCI PnP menu items allow you to change the advanced settings for PCI/PnP devices. The menu includes setting IRQ and DMA channel resources for either PCI/PnP or legacy ISA devices, and setting the memory size block for legacy ISA devices.



Take caution when changing the settings of the PCI PnP menu items. Incorrect field values can cause the system to malfunction.



### Plug And Play O/S [No]

When set to [No], BIOS configures all the devices in the system. When set to [Yes] and if you install a Plug and Play operating system, the operating system configures the Plug and Play devices not required for boot. Configuration options: [No] [Yes]

### PCI Latency Timer [64]

Allows you to select the value in units of PCI clocks for the PCI device latency timer register. Configuration options: [32] [64] [96] [128] [160] [192] [224] [248]

### Allocate IRQ to PCI VGA [Yes]

When set to [Yes], BIOS assigns an IRQ to PCI VGA card if the card requests for an IRQ. When set to [No], BIOS does not assign an IRQ to the PCI VGA card even if requested. Configuration options: [No] [Yes]

### Palette Snooping [Disabled]

When set to [Enabled], the palette snooping feature informs the PCI devices that an ISA graphics device is installed in the system so that the latter can function correctly. Configuration options: [Disabled] [Enabled]

### PCI IDE BusMaster [Enabled]

Allows BIOS to use PCI bus mastering when reading/writing to IDE devices.  
Configuration options: [Disabled] [Enabled]


### Offboard PCI/ISA IDE Card [Auto]

Allows you to assign a PCI slot to a PCI IDE card, when required.  
Configuration options: [Auto] [PCI Slot1] [PCI Slot2] [PCI Slot3] [PCI Slot4]  
[PCI Slot5] [PCI Slot6]

### IRQ-xx assigned to [PCI Device]

When set to [PCI Device], the specific IRQ is free for use of PCI/PnP devices. When set to [Reserved], the IRQ is reserved for legacy ISA devices. Configuration options: [PCI Device] [Reserved]

Use the arrow down key to scroll down the menu.



### DMA Channel X assigned to [PCI Device]


When set to [PCI Device], the specific DMA channel is free for use of PCI/PnP devices. When set to [Reserved], the DMA channel is reserved for legacy ISA devices. Configuration options: [PCI Device] [Reserved]

### Reserved Memory Size [Disabled]

Allows you to set the reserved memory size.  
Configuration options: [Disabled] [16k] [32k] [64k]

## 5.5 Power menu

The Power menu items allow you to change the settings for the ACPI and Advanced Power Management (APM) features. Select an item then press <Enter> to display the configuration options.




### 5.5.1 ACPI APIC Support [Enabled]

Allows you to enable or disable the Advanced Configuration and Power Interface (ACPI) support in the Application-Specific Integrated Circuit (ASIC). When set to Enabled, the ACPI APIC table pointer is included in the RSDT pointer list. Configuration options: [Disabled] [Enabled]



Do not change the ACPI APIC support after you have installed the operating system (OS), otherwise, a boot failure may occur.

## 5.5.2 APM Configuration



### Power Management [Enabled]

Allows you to enable or disable the motherboard Advance Power Management (APM) feature. Configuration options: [Enabled] [Disabled]

### Video Power Down Mode [Suspend]

Allows you to select the video power down mode  
Configuration options: [Disabled] [Standby] [Suspend]

### Hard Disk Power Down Mode [Suspend]

Allows you to select the hard disk power down mode  
Configuration options: [Disabled] [Standby] [Suspend]

### Suspend Time Out [Disabled]

Allows you to select the specified time at which the system goes on suspend mode. Configuration options: [Disabled] [1 Min] [2 Min] [4 Min] [8 Min] [10 Min] [20 Min] [30 Min] [40 Min] [50 Min] [60 Min]

### Throttle Slow Clock Ratio [50%]

Allows you to select duty cycle in throttle mode.  
Configuration options: [87.5%] [75.0%] [62.5%] [50.0%] [37.5%] [25.0%] [12.5%]

### Power Button Mode [On/Off]

Allows the system to go into On/Off mode or suspend mode when the power button is pressed. Configuration options: [On/Off] [Suspend]



### **Restore on AC Power Loss [Power Off]**

When set to Power Off, the system goes into off state after an AC power loss. When set to Power On, the system goes on after an AC power loss.

When set to Last State, the system goes into either off or on state, whatever the system state was before the AC power loss.

Configuration options: [Power Off] [Power On] [Last State]

### **Power On By PS/2 Keyboard [Disabled]**

Allows you to use specific keys on the keyboard to turn on the system.

This feature requires an ATX power supply that provides at least 1A on the +5VSB lead. Configuration options: [Disabled] [Enabled]

### **Power On By PS/2 Mouse [Disabled]**

When set to [Enabled], this parameter allows you to use the PS/2 mouse to turn on the system. This feature requires an ATX power supply that

provides at least 1A on the +5VSB lead. Configuration options: [Disabled] [Enabled]

### **Power On Ring [Disabled]**

When set to [Enabled], the system enables the RI to generate a wake event while the computer is in Soft-off mode.

Configuration options: [Disabled] [Enabled]

### **Power On By PME# [Disabled]**

When set to [Enabled], the system enables the PME to generate a wake event while the computer is in Soft-off mode.


Configuration options: [Disabled] [Enabled]

### **Power On By RTC Alarm [Disabled]**

Allows you to enable or disable RTC to generate a wake event. When this item is set to [Enabled], the items RTC Alarm Date, RTC Alarm Hour, RTC Alarm Minute, and RTC Alarm Second appear with set values.

Configuration options: [Disabled] [Enabled]

## 5.5.3 Hardware Monitor



### CPU1/CPU2 Temperature [xxx°C/xxx°F] MB Temperature [xxx°C/xxx°F]

The onboard hardware monitor automatically detects and displays the motherboard and CPU temperatures. Select [Disabled] if you do not wish to display the detected temperatures.

### CPU1/CPU2 Fan Speed [0] Front1/Front2 Fan Speed [0] Rear1/Rear2 Fan Speed [xxxxRPM] or [N/A]

The onboard hardware monitor automatically detects and displays the CPU, front, and rear fan speed in rotations per minute (RPM). If the fan is not connected to the motherboard, the field shows N/A.



The CPU and Front fan speeds items normally show the value 0. To check the actual fan rotations per minute, use the ASUS Server Web-based Management (ASWM) software. Refer to the ASWM user guide for more information.

### Smart Fan Control [Disabled]

Allows you to enable or disable the ASUS Smart Fan feature that smartly adjusts the fan speeds for more efficient system operation. Configuration options: [Disabled] [Enabled]



The **CPU1 Temperature**, **CPU2 Temperature**, and **Front 1 Temperature** items appear when you enable the **Smart Fan Control** feature.

## CPU1/CPU2 Temperature [XXX] Front1 Temperature [XXX]

Allows you to set the CPU and system threshold temperature before the Smart Fan Control is disabled.

Use the arrow down key to display additional items.




## VCORE1 Voltage, VCORE1 Voltage, 3.3V Voltage, 5V Voltage, 5VSB Voltage, VBAT Voltage, 12V Voltage


The onboard hardware monitor automatically detects the voltage output through the onboard voltage regulators.

## 5.6 Boot menu

The Boot menu items allow you to change the system boot options. Select an item then press <Enter> to display the sub-menu.



### 5.6.1 Boot Device Priority



#### 1st ~ xxth Boot Device [1st Floppy Drive]

These items specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system.

Configuration options: [xxxxx Drive] [Disabled]

## 5.6.2 Boot Settings Configuration

BIOS SETUP UTILITY	
Boot	
Boot Settings Configuration	
Quick Boot	[Enabled]
Full Screen Logo	[Enabled]
AddOn ROM Display Mode	[Force BIOS]
Bootup Num-Lock	[On]
PS/2 Mouse Support	[Auto]
Wait For 'F1' If Error	[Enabled]
Hit 'DEL' Message Display	[Enabled]
Interrupt 19 Capture	[Enabled]
Quiet Boot Progress Bar	[Disabled]

Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.

### Quick Boot [Enabled]

Enabling this item allows the BIOS to skip some power on self tests (POST) while booting to decrease the time needed to boot the system. When set to [Disabled], BIOS performs all the POST items.

Configuration options: [Disabled] [Enabled]

### Full Screen Logo [Enabled]

Allows you to enable or disable the full screen logo display feature.

Configuration options: [Disabled] [Enabled]



Set this item to [Enabled] to use the ASUS MyLogo2™ feature.

### Add On ROM Display Mode [Force BIOS]

Sets the display mode for option ROM.

Configuration options: [Force BIOS] [Keep Current]

### Bootup Num-Lock [On]

Allows you to select the power-on state for the NumLock.

Configuration options: [Off] [On]

### PS/2 Mouse Support [Auto]

Allows you to enable or disable support for PS/2 mouse.

Configuration options: [Disabled] [Enabled] [Auto]

### Wait for 'F1' If Error [Enabled]

When set to Enabled, the system waits for the F1 key to be pressed when error occurs. Configuration options: [Disabled] [Enabled]

### Hit 'DEL' Message Display [Enabled]

When set to Enabled, the system displays the message "Press DEL to run Setup" during POST. Configuration options: [Disabled] [Enabled]

## Interrupt 19 Capture [Enabled]


When set to [Enabled], this function allows the option ROMs to trap Interrupt 19. Configuration options: [Disabled] [Enabled]

## Quiet Boot Progress Bar [Disabled]

Enables or disables the quiet boot progress bar during POST. Configuration options: [Disabled] [Enabled]

### 5.6.3 Security

The Security menu items allow you to change the system security settings. Select an item then press <Enter> to display the configuration options.



### Change Supervisor Password

Select this item to set or change the supervisor password. The Supervisor Password item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a Supervisor Password:

1. Select the **Change Supervisor Password** item, then press <Enter>.
2. From the password box, type a password composed of at least six letters and/or numbers, then press <Enter>.
3. Confirm the password when prompted.

The message "Password Installed" appears after you successfully set your password.


To change the supervisor password, follow the same steps as in setting a user password.

To clear the supervisor password, select the **Change Supervisor Password** then press <Enter>. The message “Password Uninstalled” appears.



If you forget your BIOS password, you can clear it by erasing the CMOS Real Time Clock (RTC) RAM. See section “2.6 Jumpers” for information on how to erase the RTC RAM.

After you have set a supervisor password, the other items appear to allow you to change other security settings.



## User Access Level [Full Access]

This item allows you to select the access restriction to the Setup items. Configuration options: [No Access] [View Only] [Limited] [Full Access]

**No Access** prevents user access to the Setup utility.

**View Only** allows access but does not allow change to any field.

**Limited** allows changes only to selected fields, such as Date and Time.

**Full Access** allows viewing and changing all the fields in the Setup utility.

## Change User Password

Select this item to set or change the user password. The **User Password** item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a User Password:

1. Select the Change User Password item and press <Enter>.
2. On the password box that appears, type a password composed of at least six letters and/or numbers, then press <Enter>.
3. Confirm the password when prompted.

The message “Password Installed” appears after you set your password successfully.

To change the user password, follow the same steps as in setting a user password.

### **Clear User Password**

Select this item to clear the user password.

### **Password Check [Setup]**

When set to [Setup], BIOS checks for user password when accessing the Setup utility. When set to [Always], BIOS checks for user password both when accessing Setup and booting the system.

Configuration options: [Setup] [Always]

### **Boot Sector Virus Protection [Disabled]**


Allows you to enable or disable the boot sector virus protection.

Configuration options: [Disabled] [Enabled]



## 5.7 Exit menu

The Exit menu items allow you to load the optimal or failsafe default values for the BIOS items, and save or discard your changes to the BIOS items.



Pressing <Esc> does not immediately exit this menu. Select one of the options from this menu or <F10> from the legend bar to exit.

### Exit & Save Changes

Once you are finished making your selections, choose this option from the Exit menu to ensure the values you selected are saved to the CMOS RAM. An onboard backup battery sustains the CMOS RAM so it stays on even when the computer is turned off. When you select this option, a confirmation window appears. Select **Yes** to save the changes and exit.



If you attempt to exit the Setup program without saving your changes, the program prompts you with a message asking if you want to save your changes before exiting. Press <Enter> to save the changes while exiting.

### Exit & Discard Changes

Select this option only if you do not want to save the changes that you made to the Setup program. If you made changes to fields other than System Date, System Time, and Password, the BIOS asks for a confirmation before exiting.

### Discard Changes

Allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select **Yes** to discard any changes and load the previously saved values.

## Load Setup Defaults

Allows you to load the default values for each of the parameters on the Setup menus. When you select this option or if you press <F5>, a confirmation window appears. Select **Yes** to load default values. Select **Exit & Save Changes** or make other changes before saving the values to the non-volatile RAM.

# Chapter 6

This chapter provides instructions for creating and configuring RAID, and installing the necessary drivers for different system components.



ASUS AP1600R-E2 (BA2/B12)

# Driver installation

## 6.1 RAID

The server system/motherboard comes with the **Adaptec® HostRAID™** technology embedded in the Intel® 6300ESB Southbridge to support up to two SATA hard disk drives and RAID 0, 1, and JBOD configurations.

Refer to the RAID definitions below.

### 6.1.1 RAID configurations

**RAID 0** (*Data striping*) optimizes two identical hard disk drives to read and write data in parallel, interleaved stacks. Two hard disks perform the same work as a single drive but at a sustained data transfer rate, double that of a single disk alone, thus improving data access and storage. Use of two new identical hard disk drives is required for this setup.

**RAID 1** (*Data mirroring*) copies and maintains an identical image of data from one drive to a second drive. If one drive fails, the disk array management software directs all applications to the surviving drive as it contains a complete copy of the data in the other drive. This RAID configuration provides data protection and increases fault tolerance to the entire system. Use two new drives or use an existing drive and a new drive for this setup. The new drive must be of the same size or larger than the existing drive.

**JBOD** (*Spanning*) stands for **Just a Bunch of Disks** and refers to hard disk drives that are not yet configured as a RAID set. This configuration stores the same data redundantly on multiple disks that appear as a single disk on the operating system. Spanning does not deliver any advantage over using separate disks independently and does not provide fault tolerance or other RAID performance benefits.



---

If you want to boot the system from a hard disk drive included in a created RAID set, copy first the RAID driver from the support CD to a floppy disk before you install an operating system to the selected hard disk drive. Refer to section “2. RAID driver installation” for details.

---

### 6.1.2 Installing hard disk drives

The motherboard supports Serial ATA hard disk drives for RAID set configuration. For optimal performance, install identical drives of the same model and capacity when creating a disk array.

To install the SATA hard disks for RAID configuration:

1. Install the SATA hard disks into the drive bays following the instructions in the system user guide.
2. Connect a SATA signal cable to the signal connector at the back of each drive and to the SATA connector on the motherboard.
3. Connect a SATA power cable to the power connector on each drive.

### 6.1.3 Setting the RAID item in BIOS

You must set the RAID item in the BIOS Setup before you can create a RAID set(s). To do this:

1. Enter the BIOS Setup during POST.
2. Go to the **Advanced Menu**, select **Onboard device**, then press <Enter>.
3. Select the item **SATA Configuration**, then press <Enter> to display the configuration options.
4. Select **RAID** from the **SATA Mode** options, then press <Enter>.
5. Save your changes, then exit the BIOS Setup.



---

Refer to the BIOS setup for details on configuring the BIOS.

---

### 6.1.4 RAID configuration utility

You can create a RAID set using the utility embedded in the RAID controller. For example, you can use the **Adaptec RAID Configuration Utility** if you installed SATA hard disk drives on the SATA connectors supported by the Intel® 6300ESB Southbridge.

The Adaptec RAID Configuration Utility allows you to create RAID 0 and RAID 1 set using the SATA hard disk drives connected to the SATA connectors supported by the motherboard Southbridge chip.

To enter the Adaptec RAID Configuration Utility:

1. Turn on the system after installing all the SATA hard disk drives.
2. During POST, the Adaptec HostRAID™ technology automatically detects the installed SATA hard disk drives and displays any existing RAID set(s). Press <Ctrl> <A> to enter the utility.

```
Adaptec Embedded SATA HostRAID BIOS V2.2-1 1237
(c) 1998-2004 Adaptec, Inc. All Rights Reserved.

*** Press <Ctrl><A> for Adaptec RAID Configuration Utility! ***

Controller #00: HostRAID-ICH8 at PCI Bus:00, Dev:1F, Func:02
Loading Configuration...Done.
Port#00 ST380023AS 3.01 74.53 GB Healthy
Port#01 ST380023AS 3.01 74.53 GB Healthy

SATA JBOD- PORT-0 ST380023AS 74.53 GB
SATA JBOD- PORT-1 ST380023AS 74.53 GB

2 JBOD Device(s) Found.
```

3. Use the arrow keys to highlight an option.




The **Array Configuration Utility** menu lets you create and manage RAID sets. The **Disk Utilities** allows you to check and verify SATA hard disk drives.

At the bottom of the screen is the legend box. The keys on the legend box allow you to navigate through the setup menu options or execute commands. The keys on the legend box vary according to the menu level.

### 6.1.4.1 Creating a RAID 0 set (Striped)


To create a RAID 0 set:

1. From the Adaptec RAID Configuration Utility initial menu, highlight **Array Configuration Utility**, then press <Enter>.
2. From the Main Menu, select **Create Array**, then press <Enter>.





5. A message appears on screen, warning users that initialization will erase all array information on the drives. Press <Y> to proceed or press <N> to abort creating the RAID 0 set.



6. After disk initialization, the utility displays the **Array Properties** menu. Select **Array Type > RAID 0 (Stripe)**, then press <Enter>.





7. Move the cursor to the **Array Label** option, then type a name for the RAID 0 set. Press <Enter> when done.

```
*****Array Properties*****
* Array Type       : RAID 0(Stripe)
* Array Label      : 6300ESB
* Array Size       : 149.031 GB
* Stripe Size      : 64KB
* Create RAID via  :
*
*                  [Done]
*****
<Tab> Next Field, <Shift+Tab> Previous Field
<Enter> Accept Value, <Esc> Cancel Dialog Box, <F1> Help
```

8. Move the cursor to the **Stripe Size** option, select **64KB** from the menu, then press <Enter> to select.

```
*****Array Properties*****
* Array Type       : RAID 0(Stripe)
* Array Label      : 6300ESB
* Array Size       : 149.031 GB
* Stripe Size      :
*                  * 16KB *
*                  * 32KB *
*                  * 64KB *
* Create RAID via  :
*
*                  [Done]
*****
<=> Moves Cursor, <Esc> Cancel Selection, <Enter> Accept Selection, <F1> Help
```



---

For server systems, we recommend that you use a lower array block size. For multimedia computer systems used mainly for audio and video editing, we recommend a higher array block size for optimum performance.

---

9. Move the cursor to the **Create RAID via** option, select **No Init** from the menu, then press <Enter> to select.

```
*****Array Properties*****
* Array Type       : RAID 0(Stripe)
* Array Label     : 6300ESB
* Array Size      : 149.031 GB
* Stripe Size     : 64KB
* Create RAID via : * No Init
                  * Migrate
                  [ ]*****
*
<=> Moves Cursor, <Esc> Cancel Selection, <Enter> Accept Selection, <F1> Help
```

10. When you have finished setting the array properties, move the cursor to **Done**, then press <Enter> to create the RAID 0 set.


```
*****Array Properties*****
* Array Type       : RAID 0(Stripe)
* Array Label     : 6300ESB
* Array Size      : 149.031 GB
* Stripe Size     : 64KB
* Create RAID via : No Init
                  [Done]*****
*
<Tab> Next Field, <Shift+Tab> Previous Field
<Enter> Accept Value, <Esc> Cancel Dialog Box, <F1> Help
```



### 6.1.4.2 Creating a RAID 1 set (Mirrored)

To create a RAID 1 set:

1. Follow instructions 1 to 5 of the section “Creating a RAID 0 set (Stripe).”
2. From the **Array Properties** menu, select **Array Type > RAID 1 (Mirror)**, then press <Enter>.



3. Move the cursor to the **Array Label** option, then type a name for the RAID 1 set. Press <Enter> when finished.



4. Move the cursor to the **Create RAID via** option, select **Quick Init** from the menu, then press <Enter> to select.

```
*****Array Properties*****
* Array Type       : RAID 1(Mirror)
* Array Label      : 6300ESB
* Array Size       : 74.500 GB
* Stripe Size      : N/A
* Create RAID via  : * Build
                  : * Clear
                  : [D] Quick Init
*****
<=> Moves Cursor, <Esc> Cancel Selection, <Enter> Accept Selection, <F1> Help
```

5. When you have finished setting the array properties, move the cursor to **Done**, then press <Enter> to create the RAID 1 set.

```
*****Array Properties*****
* Array Type       : RAID 1(Mirror)
* Array Label      : 6300ESB
* Array Size       : 74.500 GB
* Stripe Size      : N/A
* Create RAID via  : Quick Init
                  : [Done]
*****
```

6. A message appears on screen informing you that a RAID 1 array created with Quick Init requires you to run a Verify W/FIX on the drives for consistency. Press any key to continue.

```
*****
* Creating a RAID 1 using Quick Init may require you to run
* a VERIFY W/FIX using OS utility to make drives consistent.
*****
Press any key to continue....
```

- After you have created the RAID 1 set, the utility main menu appears. Select **Manage Array** to display the created set. Press <Enter> to view the array properties.

```

*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 6300ESB          RAID 1   74.5GB **
* Add/Delete Hotspare  *****
* Initialize Drives    *****
*****

Symbol (*) indicates this array is bootable, <Del> Delete Array
<Enter> Display Array properties and members, <Ctrl-S> Verify Array
<Ctrl-R> Rebuild Array, <Ctrl-B> Mark/Unmark Bootable Array <*> Moves Cursor _

```

- The screen displays the array properties. Press <Esc> to return to the previous menu.

```

*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 6300ESB          RAID 1   74.5GB **
* Add/Delete Hotspare  *****
* Initialize Drives    *****
*****

*****Array Properties*****
* Array #00           : 6300ESB          Type       : RAID 1
* Array Size         : 74.5GB
* Array Status       : OPTIMAL
*****

*****Array Members*****
* 00 ST380023AS      74.5GB
* 01 ST380023AS      74.5GB
*****

<Esc> Previous Menu

```

- To exit the utility, press <Esc>, highlight **Yes**, then press <Enter>.

```

*** Exit Utility? ***
  Yes
  No
*****

Arrow keys to move cursor, <Enter> to select option, <Esc> to exit (**=default)

```

### 6.1.4.3 Creating a bootable RAID set

To create a bootable RAID set:

1. From the main menu, select **Manage Arrays**, then select the RAID set you want to make as bootable.

```
*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 6300ESB          RAID 0 149GB *
* Add/Delete Hotspare *****
* Initialize Drives    *
*****

Symbol (*) indicates this array is bootable. <Del> Delete Array
<Enter> Display Array properties and members. <Ctrl-S> Verify Array
<Ctrl-R> Rebuild Array. <Ctrl-B> Mark/Unmark Bootable Array <=> Moves Cursor
```

2. Press <Ctrl> + <B>. A message appears on screen informing you that all other arrays (if available) will become non-bootable. Press <Y> to continue.

```
*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 6300ESB          RAID 0 149GB *
* Add/Delete Hotspare *****
* Initialize Drives    *
*****

*****
* This will make all other existing bootable array Non-bootable. *
* Do you want to make this array bootable? (Yes/No): *
*****

Y - Yes, N - No.
```

The RAID 0 array becomes bootable. An asterisk precedes a bootable array for easy identification.

```

*****Main Menu*****
* Manage Arrays
* Create Array
* Add/Delete Hotspare
* Initialize Drives
*****

*****List of Arrays*****
** * 00 6300ESB RAID 0 149GB *
*****

Symbol (*) indicates this array is bootable, <Del> Delete Array
<Enter> Display Array properties and members, <Ctrl+S> Varyify Array
<Ctrl+R> Rebuild Array, <Ctrl+B> Mark/Unmark Bootable Array <*> Moves Cursor

```

3. Press <Esc> to return to the previous menu.
4. Exit the utility, then reboot the system.
5. During POST, press <Esc> to select the boot device.

```

= Main Processor(s): Genuine Intel(R) CPU 3.20GHz
*****
* Math Processor : Built-In Base Memory Size : 640KB
* Floppy Drive A: : 1.44 MB 3 1/2" Extd Memory Size : 1023MB
* Floppy Drive B: : None Serial Port(s) : 3F8,2F8
* Display Type : VGA/EGA Parallel Port(s) : 378
* BIOS Build Date : 05/12/04 PS/2 Mouse : Present
* ACPI 1.0 Support : Enabled
*****
* ATA(PI) Device(s) Type Size LBA Block SMART 32Bit DMA PIO
* Mode Mode Info Mode Mode
* Secondary Master : ATAPI CDROM UDMA2 4
*****
* PCI Devices:
* PCI Onboard PCI Bridge PCI Onboard PCI Bridge
* PCI Onboard USB Controller, IRQ11 PCI Onboard System Device
* PCI Onboard System Device PCI Onboard USB Controller, IRQ10
* PCI Onboard USB Controller, IRQ9 PCI Onboard PCI Bridge
* PCI Onboard SerialBus Cntrl, IRQ9 PCI Onboard RAID, IRQ5
* PCI Onboard IDE PCI Bridge Ethernet, IRQ5
* PCI Bridge RAID, IRQ9 PCI Bridge VGA
*****
Press <ESC> to boot...2

```

6. Use the up or down arrow to highlight the bootable RAID set (HostRAID#0-#0 6300ESB), then press <Enter> to select. The system boots from the RAID set.

```

*****
* Please select boot device:
*****
* 1st FLOPPY DRIVE
* *SM-ASUS DVD-ROM E616
* *HostRAID#0-#0 6300ESB
*****

* and * to move selection
* ENTER to select boot device
* ESC to boot using defaults
*****

```



#### 6.1.4.4 Deleting a RAID 0 set

To delete a RAID 0 set:

1. From the array list, select the RAID set you want to delete, then press <Del>. The Array Properties dialog box appears.

```
*****Main Menu*****
* Manage Arrays
* Create Array
* Add/Delete Hotspare
* Initialize Drives
*****

*****List of Arrays*****
* * 00 6300ESB RAID 0 149GB *
*****

Symbol (*) indicates this array is bootable, <Del> Delete Array
<Enter> Display Array properties and members, <Ctrl-S> Verify Array
<Ctrl-R> Rebuild Array, <Ctrl-B> Mark/Unmark Bootable Array <=> Moves Cursor
```

2. Move the cursor to **Delete**, then press <Enter> to delete the selected RAID set; otherwise, move the cursor to **Cancel** to close the dialog box.

```
*****Main Menu*****
* Manage Arrays
* Create Array
* Add/Delete Hotspare
* Initialize Drives
*****

*****List of Arrays*****
* * 00 6300ESB RAID 0 149GB *
*****

*****Array Properties*****
* Array #00 : 6300ESB Type : RAID 0 *
* Array Size : 149GB Stripe Size: 64KB *
* * * * *
* [Delete] [Cancel] *
* * * * *

<Tab> Next Field, <Shift-Tab> Previous Field
<Enter> Accept Value, <Esc> Cancel Dialog Box
```

3. When prompted, press <Y> to delete the RAID set or press <N> to abort the operation.

```
*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** * 00 6300ESB          RAID 0    149GB *
* Add/Delete Hotspare  *****
* Initialize Drives    *****
*****

*****
* WARNING: Deleting the array will result in data loss!
* Do you want to delete the Array?(Yes/No):
*****

Y - Yes, N - No.
```

4. To verify if the array was deleted, select **Manage Arrays** from the main menu. A **No Arrays Present** message pops up on the screen if no array is detected.

```
*****Main Menu*****
* Manage Arrays          *
* Create Array          *
* Add/Delete Hotspare  *
* Initialize Drives    *
*****


*****
* No Arrays present. *
*****

Press any key to continue....
```


### 6.1.4.5 Deleting a RAID 1 set

To delete a RAID 1 set:

1. From the array list, select the RAID set you want to delete, then press <Del>. The Array Properties dialog box appears.



2. Move the cursor to **Delete**, then press <Enter> to delete the selected RAID set; otherwise, move the cursor to **Cancel** to close the dialog box.



- When prompted, press <Y> to delete the RAID set or press <N> to abort the operation.

```

*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 RAID 1          RAID 1    74.5GB **
* Add/Delete Hotspare  *****
* Initialize Drives    *****
*****

*****
* WARNING: Deleting the array will render array unusable. *
* Do you want to delete the Array? (Yes/No):               *
*****

Y - Yes, N - No.

```

- When prompted, use the arrow keys to select either **Member#0** or **Member#1** to delete a RAID 1 set member. Select **[None]** or **[Both]** if you want to delete the entire array.

```

*****Main Menu*****
* Manage Arrays          *****List of Arrays*****
* Create Array          ** 00 RAID 1          RAID 1    74.5GB **
* Add/Delete Hotspare  *****
* Initialize Drives    *****
*****

*****Deleting Information*****
* Member#0: port#00      Member#1: port#01      *
* To delete the partition table, choose which member: *
* [None ] [Member#0] [Member#1] [Both ] *
*****

<Tab> Next Field, <Shift+Tab> Previous Field
<Enter> Accept Value, <Esc> Cancel Dialog Box

```

- To verify if the array was deleted, select **Manage Arrays** from the main menu. A **No Arrays Present** message pops up on the screen if no array is detected.

```

*****Main Menu*****
* Manage Arrays          *
* Create Array          *
* Add/Delete Hotspare  *
* Initialize Drives    *
*****

*****
* No Arrays present. *
*****

Press any key to continue...

```

### 6.1.4.6 Rebuilding a RAID set


The utility displays the condition of the RAID set during the POST. When a RAID set is degraded, you can use the utility to rebuild it.




Check the physical connections of the SATA hard disk drives before you rebuild a degraded RAID set. Check the system and motherboard user guide for additional information.

To rebuild a RAID array:

1. Enter the Adaptec RAID Configuration Utility following the instructions in the section “Creating a RAID 0 (Stripe).”
2. Select **Array Configuration Utility** from the initial menu, then press <Enter>.



3. From the main menu, highlight Manage Arrays, then press <Enter> to display the installed RAID sets.
4. Highlight the degraded RAID set, then press <Enter> to display the array properties. The **Array Status** shows DEGRADED.





## 6.1.5 Creating a RAID driver disk



---

You may have to use another system to create the RAID driver disk from the system/motherboard support CD or from the Internet.

---

### 6.1.5.1 Windows® 2000/2003 Server

A floppy disk with the RAID driver is required when installing Windows® 2000/2003 Server operating system on a hard disk drive that is assigned to an array.

To create a RAID driver disk from Windows® environment:

1. Place the system or motherboard support CD in the optical drive.
2. When the **Drivers** menu appears, select the RAID driver disk you want to create.

#### **OR**

Browse the contents of the support CD to locate the driver disk utility. The **Intel® 6300ESB RAID Driver Disk** is located in:

**\Drivers\6300ESB\Windows**

3. Insert a formatted high-density floppy disk to the floppy disk drive.
4. Follow screen instructions to complete the process.
5. After creating a RAID driver disk, eject the floppy disk, then write-protect it to prevent computer virus infection.

### 6.1.5.2 Red Hat® Linux 9.0

To create an **Intel® 6300ESB Red Hat® Linux 9.0** driver disk:

1. Insert a blank formatted high-density floppy disk to the floppy disk drive.
2. Decompress the file **RH9.0+release+build+16.gz** into the floppy disk from the following path in the support CD:

**\Drivers\6300ESB\Linux**

3. Eject the floppy disk.

## 6.1.6 Installing the Intel® 6300ESB RAID controller driver

### 6.1.6.1 Windows® 2000/2003 Server OS

#### *During Windows® 2000/2003 Server OS installation*

To install the Intel® 6300ESB RAID controller driver when installing Windows® 2000/2003 Server OS:

1. Boot the computer using the Windows® 2000/2003 Server installation CD. The **Windows® 2000/2003 Setup** starts.




2. Press <F6> when the message “**Press F6 if you need to install a third party SCSI or RAID driver...**” appears at the bottom of the screen.
3. When prompted, press <S> to specify an additional device.






4. Insert the Intel® 6300ESB RAID driver disk you created earlier to the floppy disk drive, then press <Enter>.



5. Select the **Adaptec Embedded Serial ATA HostRAID Driver for Windows 2000/XP/2003**, then press <Enter> to select.




6. The Windows® 2000/2003 Setup loads the RAID controller drivers from the RAID driver disk. When prompted, press <Enter> to continue installation.
7. Setup then proceeds with the OS installation. Follow screen instructions to continue.


## To an existing Windows® 2000/2003 Server OS

To install the Intel® 6300ESB RAID controller driver on an existing Windows® 2000/2003 Server OS:

1. Restart the computer, then log in with **Administrator** privileges.
2. Windows® automatically detects the RAID controller and displays a **New Hardware Found** window. Click **Cancel**.
3. Right-click the **My Computer** icon on the Windows® desktop , then select **Properties** from the menu.
4. Click the **Hardware** tab, then click the **Device Manager** button to display the list of devices installed in the system.



5. Right-click the **RAID controller** item, then select **Properties**.
6. Click the **Driver** tab, then click the **Update Driver** button.
7. The **Upgrade Device Driver Wizard** window appears. Click **Next**.
8. Insert the RAID driver disk you created earlier to the floppy disk drive.
9. Select the option "**Search for a suitable driver for my device (recommended)**", then click **Next**.
10. The wizard searches the RAID controller drivers. When found, click **Next** to install the drivers.




11. Click **Finish** after the driver installation is done.




To verify the Intel® 6300ESB RAID controller driver installation:

1. Right-click the **My Computer** icon on the Windows® desktop , then select **Properties** from the menu.
2. Click the **Hardware** tab, then click the **Device Manager** button.
3. Click the “+” sign before the item **SCSI and RAID controllers**.  
The **Adaptec Embedded Serial ATA HostRAID** item should appear.




4. Right-click the **Adaptec Embedded Serial ATA HostRAID** item, then select **Properties** from the menu.
5. Click the **Driver** tab, then click the **Driver Details** button to display the RAID controller drivers.
6. Click **OK** when finished.




### 6.1.6.2 Red Hat® Linux 9.0

To install the Intel® 6300ESB RAID controller driver when installing Red Hat® Linux 9.0 OS:


1. Boot the system from the Red Hat® Installation CD.
2. At the `boot:`, type `linux dd`, then press <Enter>.




3. Select **Yes** using the <Tab> key when asked if you have the driver disk. Press <Enter>



4. Select **fd0** using the <Tab> key when asked to select the driver disk source. Press <Tab> to move the cursor to **OK**, then press <Enter>.




5. When prompted, insert the Intel® 6300ESB Red Hat® Linux 9.0 driver disk to the floppy disk drive, select **OK**, then press <Enter>.



The drivers for the Intel® 6300ESB RAID controller are installed to the system.

- When asked if you will load additional RAID controller drivers, select **No**, then press <Enter>; otherwise, select **Yes** if you need to install additional RAID controller drivers.



- Follow screen instructions to continue the OS installation.

## 6.2 LAN

This section provides instructions on how to install the Broadcom® Gigabit LAN controller drivers.

### 6.2.1 Windows® 2000/2003 Server


To install the Broadcom® Gigabit LAN controller driver on a Windows® 2000/2003 Server OS:

1. Restart the computer, then log on with **Administrator** privileges.
2. Insert the motherboard/system support CD to the optical drive. The CD automatically displays the **Drivers** menu if Autorun is enabled in your computer.




- Windows® automatically detects the LAN controllers and displays a **New Hardware Found** window. Click **Cancel** to close this window.
- If **Autorun** is NOT enabled in your computer, browse the contents of the support CD to locate the file **ASSETUP.EXE** from the **BIN** folder. Double-click the **ASSETUP.EXE** to run the CD.

3. Click the **Broadcom 5721 LAN Driver** option to begin installation.



4. Click **Next** when the InstallShield Wizard window appears. Follow screen instructions to continue installation.





## 6.2.3 Red Hat® Linux 9.0

Follow these instructions when installing the Broadcom® Gigabit LAN controller base driver for the Red Hat® Linux version 5.2.x operating system. The following procedures were tested for 2.4.x kernels through 2.4.20.

### 6.2.3.1 Installing the source RPM package

To install the source RPM package:

1. Install the source RPM package:  

```
rpm -ivh bcm5700-<version>.src.rpm
```
2. Change the directory to the RPM path and build the binary driver for your kernel:  

```
cd /usr/src/{redhat,OpenLinux,turbo,packages,rpm ..}  
rpm -bb SPECS/bcm5700.spec or rpmbuild -bb SPECS/  
bcm5700.spec
```



---

The RPM path is different for different Linux distributions.

---

3. Install the newly built package (driver and man page):  

```
rpm -ivh RPMS/i386/bcm5700-<version>.i386.rpm
```



---

You need the force option when installing the driver on some distributions that has an older version of the driver.

---

For **2.2.x kernels**, the driver is installed in:

```
/lib/modules/<kernel_version>/net/bcm5700.o
```

For **2.4.x kernels**, the driver is installed in:

```
/lib/modules/<kernel_version>/kernel/drivers/net/  
bcm5700.o
```

For **2.4.x kernels with bcm5700 driver patched in**, the driver is installed in:

```
/lib/modules/<kernel_version>/kernel/drivers/net/bcm/  
bcm5700.o
```

**or**

```
/lib/modules/<kernel_version>/kernel/drivers/addon/  
bcm5700/bcm5700.o
```

4. Load the driver:  

```
insmod bcm5700
```
5. Refer to Linux distribution documentation to configure the network protocol and address.

### 6.2.3.2 Building the driver from the TAR file

To build the driver from the TAR file:

1. Create a directory and extract the TAR files:  
`tar xvzf bcm5700-<version>.tar.gz`
2. Build the driver `bcm5700.o` as a loadable module for the running kernel:  
`cd bcm5700-<version>/src`  
`make`
3. Test the driver by loading it:  
`insmod bcm5700.o`
4. Install the driver and man page:  
`make install`



---

See the RPM instructions on the previous page for the location of the installed driver.

---

5. Refer to Linux distribution documentation to configure the network protocol and address.

## 6.2.4 Novell NetWare Server

### 6.2.4.1 Novell NetWare Server 4.2/5.x/6.0

Follow these instructions when installing the Broadcom® Gigabit LAN controller drivers on Novell NetWare Server 4.2, 5.x, or 6.0 system.



---

Make sure that you install the latest support pack before installing the LAN driver. The latest support packs may be downloaded from: <http://support.novell.com/misc/patlst.htm>.

---

#### Creating an archive disk

If you want to create an archive disk, copy all the files from

**CDROM\NetWare\Driver**

directory to a floppy disk.

If you want to use the SUPPORT CD to install the drivers, make sure that the **CDROM.NLM** is loaded and that you know the NetWare Volume name for the optical drive.

#### Installing the drivers

To install the Broadcom® Gigabit LAN controller driver on a Novell NetWare Server 4.2/5.x/6.0 OS:

1. From the NetWare Server console, type **LOAD NWCONFIG** or **NWCONFIG**, then press <Enter>.
2. From the **Configuration Options** screen, select the **Driver** options, then press <Enter>.
3. Select the **Configure network drivers** option, then press <Enter>.
4. Select the **Load an additional driver** option, then press <Enter>.
5. Place the support CD or archive disk to the optical drive, then select the **Install an unlisted driver** option by pressing <Insert>.
6. If you are using the archive disk, insert the floppy disk to the floppy disk drive, then press <Enter>.

If you are using the support CD mounted as a NetWare volume, press F3, then type **NetWare\Driver** from the <Volume Name>: prompt.



---

The <Volume Name> is the name of the NetWare Volume for the support CD and NetWare\Driver is the directory of the installation files on the support CD.

---

7. When the name of the driver appears, press <Enter> to select.
8. Select <Yes>, then press <Enter> when a **Copy the driver** prompt appears.
9. After copying the driver, select <Yes>, then press <Enter> to copy the .LDI file. This is the driver's installation script.
10. When finished, select **Save parameters** and **load driver** to continue.
11. Choose **Exit** to return to the server console prompt.

### Setting the minimum packet receive buffers

When you do an initial installation of NetWare 4.2/5.x/6.0 and have more than two network adapters installed, the installation program allows you to allocate the actual number of packet receive buffers needed by the adapter.

During installation, the RxBuffers value should be set to 32—the minimum number of buffers the driver requires for each adapter. Although this setting affects the network adapter performance, it allows installation of the operating system and up to eight network adapters.

After installation is completed, you need to increase the number of buffers allocated to the driver as described in **Verifying or Modifying Adapter Properties**.

To increase the number of buffers

1. After installing the NetWare 5.x/6.0, set the minimum packet receive buffers parameter in the **startup.ncf** file to **1500** per network adapter. Set the maximum packet receive buffers to three times the minimum packet receive buffers. Typically, 4 MB of RAM is required per 1000 receive buffers. Refer to the **Verifying or Modifying Adapter Properties** for more information.
2. In the **autoexec.ncf** file, delete the packet receive buffers parameter (RxBuffers=32) in the adapter load statement. Deleting the receive buffers parameter from the load statement reverts the receive buffers parameter to the default value (200).



---

You must restart the server for the changes to take effect.

---

## 6.2.4.2 Novell NetWare Server 6.5

Follow these instructions when installing the Broadcom® Gigabit LAN controller drivers on a Novell NetWare Server 6.5 system.



---

Make sure that you install the latest support pack before installing the LAN driver. The latest support packs may be downloaded from: <http://support.novell.com/misc/patlst.htm>.

---

### Creating an archive disk

Refer to the previous section for details on how create an archive disk.

### Installing the drivers

To install the Broadcom® Gigabit LAN controller driver on a Novell NetWare Server 6.5 OS:

1. From the NetWare Server console, type **HDETECT**, then press <Enter>.
2. From **Options**, press <Enter> to accept Platform Support Module and HotPlug Support Module. The system detects the installed devices.
3. From **Options**, scroll down to select **Modify**, then press <Enter> to focus on the detected devices.
4. Scroll down to **Network boards**, then press <Enter>.
5. From the **Additional Driver Options**, scroll down to select **Modify**, then press <Enter>.
6. Place the support CD or archive disk to the optical drive, then select the **Add** option by pressing <Insert>.
7. Select the **Install an unlisted driver** option by pressing <Insert>.
6. If you are using the archive disk, insert the floppy disk to the floppy disk drive, then press <Enter>.

If you are using the support CD mounted as a NetWare volume, press F3, then type **NetWare\Driver** from the <Volume Name>: prompt.



---

The <Volume Name> is the name of the NetWare Volume for the support CD and NetWare\Driver is the directory of the installation files on the support CD. Place the support CD or driver disk created using the Broadcom MakeDisk utility, and select the Add option, by pressing Insert.

---

9. When the name of the driver appears, press <Down Arrow> or <Tab> to return to the **Additional Driver Options**.
10. Select **Return to driver summary**, then press <Enter>.
11. Select **Continue** from **Options**.
12. Select **Continue** from the **Protocol Options**; otherwise configure and bind the protocols before continuing.

Installation is now complete.

## 6.2.5 Solaris

The network adapter driver for Solaris 8.0 system comes in three formats:

- Datastream format: **BRCMbcme.pkg**
- Compressed and TAR file system format: **BRCMbcme.tar.Z**
- Driver Update (DU) binary image\*: **bcmedu.img**

*\* Use to create DU diskette*

### Installing the drivers

Follow these instructions when installing the Broadcom® Gigabit LAN controller drivers on a Solaris 8.0 system.

1. Change the directory to where the **BRCMbcme.pkg** is located.

2. Use the command:

```
pkgadd -d BRCMbcme.pkg
```

or

Copy **BRCMbcme.tar.Z** to **/tmp** using these commands:

```
cd /tmp
```

```
uncompress BRCMbcme.tar.Z
```

```
tar xvf BRCMbcme.tar
```

```
pkgadd -d /tmp
```

3. Execute **prtconf** to determine instance number of the NIC.

4. Use the command:

```
ifconfig bcme[instance_number] plumb
```

5. Use the command:

```
ifconfig bcme[instance_number] ip_address netmask....
```

### Saving the changes

To make these changes permanent:

1. Use a text editor (e.g., vi) to create a file in the **/etc** directory, then name the file as **hostname.bcme[instance\_number]**. Add the IP address of the interface to this file, save, then exit.
2. Add a proper subnet mask to the file **/etc/netmasks**.

## Changing the NIC settings

In Solaris 7.0 (Intel platform), the operating system allocates only 36 pages of 4K physically contiguous memory. The driver needs about 130K of physically contiguous memory per NIC.

In order to use more than one NIC the OS has to allocate more memory. This can be done by setting an OS system variable **lomempages** in the file **/etc/system**. For example, when you install four NICs in a Solaris 7 system, the physically contiguous memory is calculated as follows:

4 NICs \* 130K = 520 K or 130 pages of 4K is required.

Since this memory can be used by other drivers in the system, 200 pages of 4K memory is allocated. Add the following line in file **/etc/system**:

```
set lomempages=200
```

## 6.2.6 UNIX

### 6.2.6.1 SCO OpenServer 5.0.7

Follow these instructions when installing the Broadcom® Gigabit LAN controller drivers on an SCO OpenServer system.

#### Creating an installation disk

This driver is released as a media image file containing the driver package. You can copy the media image file directly to the target machine to install, or copy from an installation diskette that you can create.

To create an installation disk

1. Copy the file **VOL.000.000** to an SCO system.
2. Create a diskette using:  

```
dd if=VOL.000.000 of=/dev/rfd0135ds18
```

#### Installing the Driver

To install the driver:

1. Use the **custom** or **scoadmin** software to install the SCO OpenServer driver from the media image or from the created installation disk.
2. After installing the package, use **netconfig** to add the new network adapter.
3. After adding the network adapter, modify the hardware configuration in **Advanced Options** to change the **Line Speed** and **Flow Control**, if desired. Listed below are the settings for these properties.

##### Line Speeds

- AutoNegotiate (default) (all speeds advertised)
- Fixed HalfDuplex10
- Auto HalfDuplex10 (only 10 Mbps half-duplex advertised)
- Fixed FullDuplex10
- Auto FullDuplex10 (only 10 Mbps full-duplex advertised)
- Fixed HalfDuplex100
- Auto HalfDuplex100 (only 100 Mbps half-duplex advertised)
- Fixed FullDuplex100
- Auto FullDuplex100 (only 100 Mbps full-duplex advertised)
- Auto HalfDuplex1000 (only 1000 Mbps half-duplex advertised)
- Fixed FullDuplex1000\*
- Auto FullDuplex1000 (only 1000 Mbps full-duplex advertised)



---

\*Fixed FullDuplex1000 (1 Gbps) speed valid only for fiber optic connections. For copper or twisted-pair connections, 1 Gbps can only be achieved through auto-negotiation with a 1 Gbps partner.

---



## Flow Control

- Off
- AutoNegotiate (Symmetric Pause advertised)\*
- RxPause
- TxPause
- RxPause/TxPause



- 
- Auto-negotiation of Flow Control is only valid when the Line Speed is set to AutoNegotiate (all speeds advertised or single speed advertised).

\* Default setting. When selected or configured, a kernel relink and restart is required before the new configuration takes effect.

---

## 6.2.6.2 UnixWare/OpenUnix 8

### Overview

Follow these instructions when installing the Broadcom® Gigabit LAN controller drivers on a UnixWare/OpenUnix 8 system.



---

The network adapter driver is released as an installable package in datastream format.

---

1. Use the following command to install the bcme package on the Unixware system:  

```
pkgadd -d <install-path>
```

Where <install-path> is the full path name of the installable package **bcme-<version>.pkg**.
2. After installing the package, use **netcfg** or **scoadmin network** to add the network adapter.
3. When prompted, select the **Line Speed**, then select **Advanced Option** for Flow Control, MAC Address, and Jumbo MTU Size settings. Change these settings, if desired.  
Listed on the next page are the settings for these properties.

## Line Speed

- Auto-Negotiate (default) (all speeds advertised)
- 10 Mbps Half-Duplex Fixed
- 10 Mbps Half-Duplex Auto (only 10 Mbps half-duplex advertised)
- 10 Mbps Full-Duplex Fixed
- 10 Mbps Full-Duplex Auto (only 10 Mbps full-duplex advertised)
- 100 Mbps Half-Duplex Fixed
- 100 Mbps Half-Duplex Auto (only 100 Mbps half-duplex advertised)
- 100 Mbps Full-Duplex Fixed
- 100 Mbps Full-Duplex Auto (only 100 Mbps full-duplex advertised)
- 1000 Mbps Half-Duplex Auto (only 1000 Mbps half-duplex advertised)
- 1000 Mbps Full-Duplex Fixed\*
- 1000 Mbps Full-Duplex Auto (only 1000 Mbps full-duplex advertised)



---

\*1000 Mbps (1 Gbps) full-duplex, fixed speed is only valid for fiber connections. For copper, twisted-pair connections, 1 Gbps can only be set through auto-negotiation with a 1 Gbps link partner.

---

## Flow Control

- Disabled
- Auto Negotiation (Symmetric Pause advertised)\*
- Receive Pause
- Transmit Pause
- Receive & Transmit Pause



---

- Auto-negotiation of Flow Control is only valid when the Line Speed is set to AutoNegotiate (all speeds advertised or single speed advertised).

\* Default setting. When selected or configured, a kernel relink and restart is required before the new configuration takes effect.

---

## 6.3 VGA

This section provides instructions on how to install the Intel® E7221 Super Video Graphics Adapter (SVGA) driver.

### 6.3.1 Windows® 2000 Server

You need to manually install the Intel® E7221 SVGA driver on a Windows® 2000 Server operating system.


To install the Intel® E7221 SVGA driver:

1. Restart the computer, then log on with **Administrator** privileges.
2. Insert the motherboard/system support CD to the optical drive. The support CD automatically displays the **Drivers** menu if Autorun is enabled in your computer.



Windows® automatically detects the VGA controller and displays a **New Hardware Found** window. Click **Cancel** to close this window.

3. Click the item **Intel(R) E7221 Chipset (SVGA)** item from the **Drivers** menu.



4. The **Intel(R) E7221 Graphics Driver Installer Software** window appears. Click **Next**. Follow screen instructions to complete installation.




### 6.3.2 Windows® 2003 Server

The Windows® 2003 Server operating system automatically recognizes the Intel® E7221 SVGA driver during system installation. There is no need to install an additional driver(s) to support the onboard VGA.


#### Verifying the VGA driver installation

To verify if the Intel® E7221 SVGA driver is properly installed in a Windows® 2000/2003 Server operating system:

1. Right-click the **My Computer** icon on the Windows® desktop, then select **Properties** from the menu.
2. Click the **Hardware** tab, then click the **Device Manager** button.
3. Click the “+” sign before the item **Display adapters**.  
The **Intel® E7221 SVGA XXXXXX** item should appear.



4. Right-click the **Intel® E7221 SVGA XXXXXX** item, then select **Properties** from the menu.
5. Click the **Driver** tab, then click the **Driver Details** button to display the VGA drivers.
6. Click **OK** when finished.



### 6.3.3 Red Hat® Linux 9.0

The Red Hat® Linux 9.0 (2.4.x kernels) operating system automatically recognizes the Intel® E7221 SVGA driver during system installation. There is no need to install an additional driver(s) to support the onboard VGA.