



# **CrossLink**

## **Quick Start Guide**

## ASUS Contact Information

### ASUSTeK COMPUTER INC.

Address	15 Li-Te Road, Peitou, Taipei, Taiwan 11259
Telephone	+886-2-2894-3447
Fax	+886-2-2890-7798
E-mail	info@asus.com.tw
Web site	www.asus.com.tw

#### *Technical Support*

Telephone	+86-21-38429911
Online support	support.asus.com

### ASUS COMPUTER INTERNATIONAL (America)

Address	800 Corporate Way, Fremont, CA 94539, USA
Telephone	+1-510-739-3777
Fax	+1-510-608-4555
Web site	usa.asus.com

#### *Technical Support*

Telephone	+1-812-282-2787
Support fax	+1-812-284-0883
Online support	support.asus.com

### ASUS COMPUTER GmbH (Germany and Austria)

Address	Harkort Str. 21-23, D-40880 Ratingen, Germany
Fax	+49-2102-959911
Web site	www.asus.de
Online contact	www.asus.de/sales

#### *Technical Support*

Component Telephone	+49-1805-010923
System/Notebook/Eee/ LCD Telephone	+49-1805-010920
Support Fax	+49-2102-9599-11
Online support	support.asus.com

## Table of contents

<b>ASUS Contact Information .....</b>	<b>2</b>
<b>Table of contents .....</b>	<b>3</b>
<b>System Requirements.....</b>	<b>4</b>
<b>Getting to know your CrossLink device.....</b>	<b>4</b>
<b>Launching the CrossLink panel.....</b>	<b>5</b>
<b>Using Flash Share .....</b>	<b>6</b>
Transferring files/folders into the USB flash drive .....	7
Marking a file/folder.....	7
Searching for specific files .....	7
<b>Using Data Link .....</b>	<b>8</b>
Windows® operating system .....	8
<b>Using Folder Link .....</b>	<b>10</b>
Synchronizing a folder .....	11
Synchronizing your favorite websites.....	12
Synchronizing multiple tasks.....	12
Removing a task .....	12
<b>Using Outlook Link.....</b>	<b>13</b>
Setting up the general e-mail sync settings .....	14
Synchronizing Outlook items .....	14
<b>Using Remote Share .....</b>	<b>15</b>

## System Requirements


Before using your CrossLink device, ensure that your system meets the following requirements:

- Microsoft Windows® XP / Vista / Windows® 7
- 1.0GHz CPU or higher
- 512MB RAM or higher
- At least 100 MB free space
- Built-in USB port 1.1 or 2.0

## Getting to know your CrossLink device

Your CrossLink device includes the USB flash drive and USB cable. It allows you to:

- Transfer and synchronize data with another computer;
- Share Internet connection with another computer; and
- Read data from optical drive of another computer.



## Launching the CrossLink panel

Before using your CrossLink device, you need to launch the CrossLink panel.




To launch the CrossLink panel:

- If you only want to use Flash Share, simply insert your CrossLink USB flash drive into your computer's USB port.
- If you want to use other CrossLink applications:
  1. Insert the USB cable into the USB flash drive.
  2. Connect the CrossLink device to both computers. Follow the instructions below to launch the CrossLink panel according to your computer's operating system:
    - **Windows® XP:** Once you insert the device, the CrossLink interface is launched automatically. If CrossLink is not automatically launched, double-click the CrossLink icon on **My Computer** to launch the CrossLink interface.
    - **Windows® Vista:** When you insert the device, click **Launch CrossLink** from the Auto-run window. If Auto-run is not launched, double-click the CrossLink icon on **My Computer** to launch the CrossLink interface. If the User Account Control window is displayed, click **Allow** to proceed with the launching of the CrossLink interface.

## Using Flash Share

Flash Share enables you to manage your files on the USB flash drive.



Item	Computer Icon
1	<b>Device</b> <ul style="list-style-type: none"> <li>Displays the available space on the USB flash drive.</li> <li>Double-click this icon to hide the Flash Share window and display only the icon. When in Icon mode, double-click the icon again to switch back to the Flash Share window mode.</li> </ul> <p>Note: The icon's size changes depending on the data that has been added or removed from the USB flash drive.</p>
2	<b>Settings button:</b> Click to view and edit the settings of your USB flash drive.
3	<b>Minimize button</b> Click to minimize the Flash Share window.
4	<b>Exit button</b> Click to close the Flash Share window.
5	<b>File list</b> Displays the files and their file information in your USB flash drive.
6	<b>Suit Symbol button</b> Use the suit symbols to mark and sort your files.
7	<b>File filter menu</b> Click to filter files based on the filter categories.
8	<b>Previous/Next button</b> Click to go to the back to <b>Previous</b> or go to the <b>Next</b> screen.

---

## Transferring files/folders into the USB flash drive

---

To transfer files/folders into the USB flash drive:

- Drag and drop the files into the Device icon or in File list.

---

## Marking a file/folder

---

To mark a file/folder:

- Click the Suit Symbol icon and select any of these suit symbols that you want to use: heart, club, diamond, and spade.

---

## Searching for specific files

---

The File Filter function enables you to search for specific files in the USB flash drive based on the category.


To search for specific files:

- From the File Filter menu, select the specific category that you want to search files from.

# Using Data Link

Data Link enables you to transfer and share data between two computers with Windows or Linux operating systems (Windows to Windows, Windows to Linux, or Linux to Linux).

## Windows® operating system



Item	Computer Icon
1	<b>Computer icon</b> <ul style="list-style-type: none"><li>Displays the computer's available space you connect with.</li><li>Double-click this icon to hide the Data Link window and display only the icon. When in Icon mode, double-click the icon again to switch back to the Flash Share window mode.</li></ul>
2	<b>Option button:</b> Click to view the Data Link options.
3	<b>Minimize button</b> Click to minimize the Data Link window.
4	<b>Exit button</b> Click to close the Data Link window.
5	<b>File list</b> Displays the files and their file information in the remote computer.
6	<b>Directory list</b> Click to browse the files/folders in the disk drives of the remote computer.



## Transferring a file/folder:

To transfer a file or folder:


- Drag and drop a file/folder into the Computer icon.

## Transferring multiple files/folders

The Dock screen allows you to transfer multiple files/folders between two computers.


To transfer multiple files/folders:

1. Click the Option icon and select **Open Dock** to launch the Dock screen.
2. Drag and drop the files/folders that you want to copy in the Dock screen. You may also right-click on a file/folder in the File list, and then select **Add to dock** to add the file/folder in the Dock screen.
3. From the Dock screen, select all the files/folders and drop these files/folders in the File list in the Data Link screen.






# Using Folder Link

Folder Link allows you to synchronize data between two computers.







Item	Computer Icon
1	<b>Add Task button</b> Click to create a new sync task. The new task appears in the Task list.
2	<b>Sync All button</b> Click to synchronize all tasks.
3	<b>Option button</b> Click to view the Folder Link settings.
4	<b>Minimize button</b> Click to minimize the Folder Link window.

Item	Computer Icon	
5	<b>Exit button</b> Click to close the Folder Link window.	
6	<b>Sync Info</b> Provide the necessary information for the synchronization process.	
7	<b>Sync direction buttons</b> Click any of these buttons to specify the sync direction.	
		Keep the contents consistent in both folders. If there are two files with the same name, synchronize the latest file with the old one.
		Copy all the files from the local folder to the remote folder. If there are two files with the same name, overwrite the remote file with the local one.
		Copy all the files from the remote folder to the local folder. If there are any two files with the same name, overwrite the local file with the remote one.
8	<b>Task list</b> Displays the sync tasks.	

## Synchronizing a folder

To synchronize a folder:

1. Click  to create a sync task.
2. In the **Task Name** field, key in a unique name for the sync task.
3. Select **Folder Link** as the task type.
4. In the **Sync Contents** field, select the destinations on both computers.
5. Select any of these buttons to specify the sync destination:

	Keep the contents consistent in both folders. If there are two files with the same name, synchronize the latest file with the old one.
	Copy all the files from the local folder to the remote folder. If there are two files with the same name, overwrite the remote file with the local one.
	Copy all the files from the remote folder to the local folder. If there are any two files with the same name, overwrite the local file with the remote one.

6. Click **Sync this Task** to synchronize the task. If you want to view the sync records, click **Yes** on the confirmation message.

## Synchronizing your favorite websites

---


To synchronize your favorite websites:

1. Follow steps 1-2 in **Synchronizing a task**.
2. Select **IE My Favorites Sync**.
3. Click **Sync this Task** to synchronize the task. If you want to view the sync records, click **Yes** on the confirmation message.

## Synchronizing multiple tasks

---

To synchronize multiple tasks:

- If you have several tasks that you want to synchronize at one time, click .

## Removing a task


---

To remove a task:

1. From the Task list, select the sync task that you want to remove.
2. Click **Remove this Task**.

# Using Outlook Link

Outlook Link allows you to synchronize Outlook items such as e-mail messages, contacts, calendar, and tasks between two computers.



Item	Computer Icon
1	<b>Sync directions</b> From this field, select the sync direction.
2	<b>Sync items</b> Select the Outlook items that you want to synchronize.
3	<b>Start Sync button</b> Click to start the synchronization process.
4	<b>Sync Setup button</b> Click to define the general settings of your e-mail server.

## Setting up the general e-mail sync settings

---

To set up the e-mail sync settings:

1. Click **Sync Setup**.
2. Select the sync rules.
3. Select the e-mail server for your computer.
4. Key in the necessary information for your e-mail server.
5. Click **OK**.

## Synchronizing Outlook items

---

To synchronize Outlook items:

1. Select the sync direction.
2. Select the items that you want to synchronize.

If you want to synchronize other Outlook item:

- a. Select **Sync other mail folder**.
  - b. Select the locations of the folder that you want to synchronize.
3. Click **Start sync**.
  4. Select the sync rules, and then click **Start** to start the synchronization process.

## Using Remote Share

Remote Share allows you to share Internet connection with and read data from the CD drive of another computer.

To use Remote Share:

1. Connect the CrossLink device to both computers.
2. Launch the CrossLink panel.
3. From the CrossLink panel, select **Remote Share** and wait for your computer to establish connection with the other computer.
4. On the Remote Share screen, select the action that you want to perform.

