


ASUS Xonar Essence One USB F/W Update


The steps for USB Firmware update of ASUS Xonar Essence One :

- (1) Execute “FWUpdate.exe” when Xonar Essence One is Power-on and connecting to PC/NB.




- (2) Choose “USB\VID_0b05&Pid_17a8&Rev_0107” in “Device Name”

ASUS Xonar Essence One USB F/W Update




- (3) Click “Update FW” and choose the “6631-0109-EssenceOne-ALL.hex” as the firmware update file. Click “ok” to start USB Firmware update.




ASUS Xonar Essence One USB F/W Update

- (4) The USB Firmware is now updating.



- (5) The following information “Firmware Update Finished. Device will be reset” will show up after firmware update is done.

ASUS Xonar Essence One USB F/W Update



- (6) Turn on Xonar Essence One again and check the USB Firmware information by touching Xonar icon in your system tray.

