

## ASUS Xonar Essence One USB F/W Update


### 【IMPORTANT】：

While updating firmware , please do not switch off power 。

And please plug in to USB 2.0 port.


ASUS Xonar Essence One USB Firware Update ：

- (1) After Xonar Essence One is powered on and connected to PC , execute FWUpdateEndUser.exe
- (2) Select “Device Name” as “USB\VID\_0b05&Pid\_17a8&Rev\_xxxx”




## ASUS Xonar Essence One USB F/W Update

- (3) Select “Update FW” and choose the latest Firmware document. Press ” OK” and it will automatically update USB Firmware




- (4) Here' s the loading process



## ASUS Xonar Essence One USB F/W Update

- (5) After firmware has been updated successfully, you will see the following message “Firmware Update Finished. Please replug the device.”



- (6) Restart Xonar Essence One and check if it is the latest version



## ASUS Xonar Essence One USB F/W Update

### ※ FAQ


#### 【QUESTION】

Under Windows 7 , if firmware updates unsuccessfully, it cannot update correctly. Can' t find the device under Device manager.

#### 【ANS】


Follow the steps in this order:

1. Enter control panel > Device manager, find Universal Serial Bus controllers' "USB Composite Device"




## ASUS Xonar Essence One USB F/W Update

2. Right click to select “Update Driver Software”




3. Select ” Browse my computer for driver software”




## ASUS Xonar Essence One USB F/W Update

4. Locate to "Xonar Essence One USB FW Update \Driver" and select "Install"




5. After the installation is complete, the following screen will appear ◦





## ASUS Xonar Essence One USB F/W Update

6. Execute “FWUpdateEndUser.exe” and select “Device Name” as “USB\Vid\_0D8C&Pid\_5200&Rev\_0100”



7. Reupdate firmware as step 2 .