


ASUS T-M3N8200 CPU Fan Note

Set the QFAN_MODE jumper before you install the CPU fan.



- Set the QFAN_MODE jumper to pins 1-2 if you are using a 3-pin CPU fan plug. Set this jumper to 2-3 if you are using a 4-pin CPU fan plug.
- Ensure that you set the QFAN_MODE jumper correctly. The ASUS Q-Fan feature may not function properly if you set this jumper wrong.