








Release Date: 17/8/2008	
Recommended System Requirement and Tools for Firmware Update	
Software	Firmware: ASUS.7FF2M.zip (韌體: ASUS.7FF2M.zip)
Hardware	Ufoto (UF735) that requires firmware update (需要更新韌體的數位相框 UF735)
	One Memory Card(一張記憶卡) Support memory Card(支援記憶卡種類) : Secure Digital (SD卡) Compact Flash (CF卡) Multimedia Card (MMC卡) Memory Stick (MS卡) eXtreme Digital(xD 卡)
How to update firmware for ASUS Ufoto (如何更新數位相框的韌體)?	
1.	<p>Extract "ASUS.7FF2M.zip" to Memory Card(將下載之韌體壓縮檔解壓縮至欲更新之記憶卡內).</p>  


2.	Insert the Memory card to Ufoto(將存有韌體之記憶卡插入 UF735 卡槽中).
3.	<p>Connect the bundled power adapter form your Ufoto to a power outlet(將 UF735 接上電源)</p>  <p>The diagram illustrates the power connection for the Ufoto device. A power adapter is shown with its AC plug inserted into a standard wall outlet. The adapter's DC cable is connected to the power input port on the back of the Ufoto device, which is indicated by a blue arrow. The Ufoto device is shown from a top-down perspective with its lid open.</p>
4.	<p>Press the power button to power on Ufoto(開機).</p>  <p>The diagram shows the front of the Ufoto device. A blue circle highlights the power button, which is located on the right side of the device's frame. A black line points from the text 'Power button' to this button. A grey curved arrow on the left indicates that the device's lid can be rotated.</p> <p>Power button</p>

5. After power on the Ufoto, you will get Message" Plug the AC power adapter and press any key to start the updating process", please press  to start to updating firmware(等畫面出現 "請接上變壓器,並按下任意鍵開始更新韌體" 訊息後, 按下確認按鍵開始更新).




6. Firmware updating is in processing; It contains 3 steps and takes about 2 minutes(韌體更新中，包含三個步驟，更新過程約兩分鐘).


First step(步驟 1): Format the device(格式化)




Second step(步驟 2): Update maincode(更新源碼)



Third step(步驟 3): Install MP3 GIF FILE(安裝 MP3 文档)



7. Once firmware is updated, you will get the message "Firmware update in completed. Remove all card for system reboot", please remove the memory card to reboot the Ufoto(待畫面出現 "韌體更新完成，請重新開啓 UFOTO" 之訊息時，拔出記憶卡重新啓動 Ufoto).



8. After reboot the device, please go to Setting->Information to check the firmware Version(在主畫面下選擇進入"設定值"，選擇"資訊"，檢查是否為最新版本之韌體以確保更新完成).

