

Realtek WHCI Driver Installation and User Guide

Document Information

	Information
Document ID	
Document Released by	Simon Chuang and Ken Huang
Release Date	06/17/2008
File Name	Realtek WHCI Driver Installation and User Guide v0.7

Document History

Version	Issue Date	Changes
0.5	12/19/2007	Initial release
0.6	04/17/2008	Update for WHCI Release 1.0
0.7	06/17/2008	Update for WHCI Release 1.03

Table of Contents

1	Introduction.....	2
2	Description of Hardware and its Application	2
3	Software Setup.....	3
4	Driver Installation	6
4.1	WHCI Driver	6
4.2	Cable Association Driver	7


1 Introduction

This document describes how to install the software package. The software package includes GUI, WHCI driver, and cable association driver of Realtek WHCI host solution.

2 Description of Hardware and its Application

The WHCI software release package is applicable to the following Realtek hardware.

2-1. PCIe HMC (Half-Mini Card) with its Express Card adaptor




2-2. PCIe Express Card




3 Software Setup

- 3-1. Make sure WHCI and DWA are disconnected from the PC/laptop platform.
- 3-2. Execute "Realtek WHCI [version] x86 [Date].exe" in zipped file.
- 3-3. Select "Allow" when the User Account Control Window pop-up.






Click "Install this driver software anyway" whenever it pops up.





3-4. The installed directory includes GUI application and drivers.



4 Driver Installation

4.1 WHCI Driver



- 4.1-1. Plug in WHCI Express card or HMC with its card adaptor.
- 4.1-2. System will be detecting the new hardware and perform automatic driver installation.



WHCI driver is installed successfully.

4.2 Cable Association Driver

- 4.2-1. Use Realtek RTU7105 one-port device as an example. Make sure your one-port device on hand is HW-configured properly. Connect the upstream port(mini-B) to PC/laptop with USB cable, and then, power on the RTU7105 one-port device.
- 4.2-2. System will be detecting the new hardware and perform automatic driver installation.



Cable Association Driver is installed successfully.

- 4.2-3. Launcher the UWB Manager from the Taskbar and check the device is appeared.

