


ASUS[®]

UFOTO

UF735

User Guide



E3371

First Edition V1
November 2007

Copyright © 2007 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Notices	v
Safety information	vi
Care & Cleaning	vii
Notes for This Manual	viii
Where to find more information.....	viii
Chapter 1: Hardware introduction	
Package contents.....	1-2
System requirements for sub-display function	1-3
Hardware introduction.....	1-4
Front view.....	1-4
Back view.....	1-4
Side view.....	1-5
To connect uFOTO:.....	1-6
Connecting your uFOTO.....	1-6
Chapter 2: Getting started	
Using your uFOTO for the first time.....	2-2
Setting language and time/date.....	2-2
Installing the Sub-Display utility	2-2
uFOTO placement	2-3
Screen menu.....	2-4
Setting your uFOTO.....	2-4
Viewing photos.....	2-9
Displaying images from different sources:.....	2-9
Previewing photos	2-10
Adjusting effects.....	2-11
Copying photos to your uFOTO	2-12
Deleting photos from your uFOTO.....	2-13
Listening to MP3s.....	2-14
Copying MP3 files to your uFOTO.....	2-15
Deleting MP3 files from your uFOTO.....	2-16
Calendar	2-17
Calendar SlideShow	2-17
Reminiscence	2-18

Software introduction	2-19
Data synchronization	2-19
Sub-Display	2-19
Specifications summary.....	2-24
Troubleshooting (FAQ)	2-25

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

As an Energy Star® Partner, our company has determined that this product meets the Energy Star® guidelines for energy efficiency.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

Safety information

- Before setting up uFOTO, carefully read all the documentation that came with the package.
- To prevent fire or shock hazard, never expose uFOTO to rain or moisture.
- Never try to open uFOTO cabinet. The dangerous high voltages inside uFOTO may result in serious physical injury.
- Before turning the device on, make sure that all cables are correctly connected and the power cable is not damaged. If you encounter any damage, contact your dealer immediately.
- Make sure to use uFOTO only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place uFOTO in any area where it may become wet.
- Place uFOTO on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period of time. This will protect the device from damage due to power surges.
- To ensure satisfactory operation, use uFOTO only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC.
- If you encounter technical problems with uFOTO, contact a qualified service technician or your retailer.



This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

Care & Cleaning

- Follow the correct lifting techniques when positioning uFOTO. Grasp the edges when lifting or carrying uFOTO.
- Turn your uFOTO off and unplug the power cord before cleaning. Clean the surface with a lint-free, non-abrasive cloth. Stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the LCD. Never spray cleaner directly on the screen, as it may drip inside device and cause an electric shock.

The following indications are normal with uFOTO:

- The screen may flicker during the initial use due to the nature of the fluorescent light. When this happens, turn off the power switch then turn the device back on.
- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching images. The screen will recover slowly or you can also reset the device.
- If you encounter a problem with your device, contact your retailer. Do not attempt to repair the device yourself.

Notes for This Manual

A few notes and warnings are used throughout this guide, allowing you to complete certain tasks safely and effectively. These notes have different degrees of importance as follows:



WARNING! Important information that must be followed for safe operation.



IMPORTANT! Vital information that must be followed to prevent damage to data, components, or persons.



TIP: Tips for completing tasks.



NOTE: Information for special situations.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. ASUS websites

The ASUS websites worldwide provide updated information on ASUS hardware and software products.
Refer to <http://www.asus.com>


2. Optional documentation

Your product package may include optional documentation that may have been added by your retailer. These documents are not part of the standard package.

Chapter 1


Hardware introduction

This chapter provides a general description of uFOTO UF735 including the installation requirements, hardware features, and basic installation procedures.




Package contents


Check your uFOTO UF735 Digital Photo Frame package for the following items:




uFOTO photo frame



Power adaptor



USB cable



Support CD



Quick Start Guide



Warranty card



If any of the above items is damaged or missing, contact your retailer immediately.

Optional accessories:



Digital Camera
(under mass storage mode)



USB flash disk



PC / Notebook



memory card

System requirements for sub-display function

Make sure your PC / Notebook system meets the minimum requirements:

Minimum requirements


- Windows XP
- 1GHz CPU
- 512MB RAM
- 150MB available HD space

Recommended specifications


- Windows XP
- 2GHz CPU
- 1GB RAM
- 150MB available HD space

Hardware introduction

Front view




Back view



(From the back panel)


Button	Function
	Single select, Volume control hotkey, Photo and calendar selection switch
	Exit
	Menu for advanced selection
	Right / Down
	Left / Up
	Confirm / Play or Pause / Quick Power On
	Power On/Off

Side view




Connecting your uFOTO


The illustrations below show devices that you can connect to your uFOTO.




To connect you uFOTO:




1. Plug the uFOTO power adaptor to a power outlet.



- 2.a. Connect your digital camera (under mass storage mode) or USB flash disk to the uFOTO.



- 2.b. Insert your memory card to the card slot.




- 2.c. Connect your uFOTO to your PC or notebook as a mass storage or a sub-screen.

Chapter 2

Getting started

This chapter guides you to use the functions of your uFOTO, including viewing photos, listening to MP3, displaying the calendar, and using the Sub-Display.




Using your uFOTO for the first time

Setting language and time/date


1. Press  or  to turn on the device.
2. Go to Setting menu.
3. Select Language to set preferred language.
4. Select Time and Date to set time and date.



 is for quick power on only; you cannot press  turn off the device. Press  to turn on or off your uFOTO normally.



Power button



Installing the ASUS uFOTO Utility


The ASUS uFOTO Utility contains two functions: data synchronization and sub-display. To normally use the functions, make sure to install the ASUS uFOTO Utility successfully.

To install the **ASUS uFOTO Utility**:

1. Insert the support CD into the optical drive.
2. Double-click the **ASUS uFOTO Utility** icon, then follow the on-screen instructions to finish the installation.
3. Restart your computer after the installation.


uFOTO placement

With a rotating support stand, you can conveniently position your uFOTO either vertically or horizontally on a stable and flat surface.




The display automatically rotates 90 degrees clockwise depending on your preferred orientation.

Adjust the support stand:



Rotate the support stand clockwise to adjust and support vertical or horizontal placement.




Back view



Front view

You can also rotate the support stand in an upward position to hand on a hook as shown:



Screen menu

uFOTO provides several visual and audio functions such as viewing photos, listening to mp3s, displaying digital calendar, and using the Sub-Display.




Setting your uFOTO

Configure several basic settings from the Setting function. From the main menu, use ◀ or ▶ to select the **Setting** icon , and press the confirm button  to enter.




Languages

From the Setting menu, use ◀ and ▶ to select the Language item, then press Ⓞ to enter. Highlight your desired language from the list of supported languages, then press Ⓞ to confirm the selection.



Time and Date

From **Setting** menu, use ◀ or ▶ to select the **Time and Date** item, then press Ⓞ to set the precise time and date for the Calendar display.



To set the time:


1. From the main menu, go to **Setting > Time and Date > Time** to display the following screen.



2. Use ◀ or ▶ to select the field (hh / mm / ss) and change the values. Press Ⓞ to confirm the setting.

To set the date:

1. From the main menu, go to **Setting > Time and Date > Date** to display the following screen.



2. Use ◀◀ or ▶▶ to select the field (mm / dd / yyyy) and change the values. Press Ⓜ to confirm the setting.

Brightness

Enter the Brightness item to adjust the desired brightness.

Setting the alarm

1. From the main menu, go to **Setting > Alarm** to display the following screen.



2. Use ◀◀ or ▶▶ to select alarm preset, then press Ⓜ.



- Set the snooze.



- Set the alarm time.




- Set the alarm type




Information

Enter this item to view detailed information about your uFOTO , the status of the inserted memory card, and the current software version.



Set Default

Select **Yes** to restore to the factory default setting or **No** to maintain the current settings.



Viewing photos

From uFOTO, you are able to easily display images stored in an SD/MMC card, DF card, Memory Stick, xD card, a Digital Camera, a USB device, or **My uFOTO Picture** folder in your computer.




Refer to the specification summary on page 2-24 for supported image file formats.

Displaying images from different sources:

@ To display images from your personal memory card:


1. Insert your memory card with pictures into the corresponding slot.




2. Select the image file(s) you want to display.

To display images from your USB device (Digital Camera / USB flash disk):

1. Connect the bundled USB cable from your digital camera to your uFOTO.




Insert your USB flash disk into the USB port on the uFOTO.



2. Select the music file(s) you want to display.

To display images from "My uFOTO Picture" folder in your computer (Sub-Display function):

1. Connect the bundled USB cable from your computer to your uFOTO.



2. Refer to section "**Data Synchronization**" on page 2-19 for details on how to synchronize photos in your computer on the uFOTO.

Previewing photos

1. From the main menu, use ◀ or ▶ to select , then press ⏹ to enter.
2. Select the photo source, then press ⏹ to view the browsing screen.
3. In the browsing screen, press ◀ and ▶ to select a photo, then press ⏹ to display the full view.

While viewing the selected photo, you can switch to the previous or next one pressing press ◀ and ▶.

Pressing ⏹ allows you to switch between the Slideshow mode or the Browse mode.


Changing photo sequence

To change the photo display sequence:

1. In the browsing screen, use ◀ or ▶ to highlight a photo, then press  to check the checkbox below the photo.
2. Press , then use ◀ or ▶ to highlight the item **Move Forward / Move Backward** as you want.
3. Press ⏹ to confirm the setting.

Adjusting effects

While viewing the selected photo, press  to configure the following settings:



1 Foto-in-motion

Displays your photos in five different modes.

- **Standard:** provides balanced user comforts and color enrichment.
- **Vivid mode:** enhances saturation and contrast for a more saturated color.
- **Nostalgic Mode:** displays photos in old picture style.
- **Spotlight Mode:** enhances color sharpness and strong contrast.
- **Black and White Mode:** displays photos in black and white.

2 Slideshow Mode

Auto-display your photos in order, saving you from clicking on each photo.

3 Transition Effect

Provides you several transition effects.

4 Frequency

Allows you to set the photo transition frequency .

5 Story Mode

A built-in photo demonstration combined with music background.

6 Play with MP3

Allows you to select the desired music from your storage device while viewing photos.

7 MP3 Menu

Allows you to adjust the volume and playback mode for the currently playing MP3 file.

Copying photos to your uFOTO

You can copy your favorite photos from your memory card, USB device, PC, or Notebook to the uFOTO.

Memory capacity table

Item	Space
Internal memory	128MB
usable memory	100MB



- When stored in the internal memory of the uFOTO, the photos are automatically resized into a 720 x 480 resolution.
- The operating system of your uFOTO takes around 28MB of the total internal memory.
- 100MB allows you to store over 700 photos.

Copying a single photo:

1. While browsing, highlight a photo, then press to check the checkbox below the photo and press .
2. Select **Copy to**, then press .
3. Select the storage source where you want to paste the copied photo, then press to confirm.

Copying all photos:

1. While browsing, press .
2. Select **Select All**, then press .
3. Press again, select **Copy to**, then press .
4. Select the storage source where you want to paste the copied photos, then press to confirm.

Deleting photos from your uFOTO

Deleting a single photo:

1. While browsing, highlight a photo, then press  to check the checkbox below the photo and press .
2. Select **Delete**, then press .
3. Select **Yes** to delete the file, or **No** to abort the selection.

Deleting all photos:

1. While browsing, press .
2. Select **Select All**, then press .
3. Press  again, then select **Delete** and press .
4. Select **Yes** to delete the file, or **No** to abort the selection.

Listening to MP3s

Enjoy with your uFOTO! uFOTO can play music files from your memory card, USB device, or **My uFOTO Music** folder in your computer.

From the main menu, use ◀◀ and ▶▶ to select , and press Ⓜ to enter.



The uFOTO only supports files of **.mp3** format.

To play music from your personal memory card:

1. Insert your memory card with MP3 files into the corresponding slot.
2. Select the music file(s) you want to play.

To play music from your USB device:

1. Connect your USB device with MP3 files to your uFOTO with the bundled USB cable.

Or:

Insert your USB device into the USB port on your uFOTO.

2. Select the music file(s) you want to play.

To play music from your "My uFOTO Music" folder in your computer:

1. Connect your computer to your uFOTO with the bundled USB cable.
2. Install the software in the bundled support CD.
3. Find "My uFOTO Music" folder in your computer.
4. Refer to section "**Data Synchronization**" on page 2-19 for details on how to synchronize music files in your computer on your uFOTO.

While playing MP3, the following screen displays:



Press  then you can adjust the volume and playback mode for the currently playing MP3 file.

Copying MP3 files to your uFOTO

You can copy your favorite MP3 files from your memory card, USB device, PC, or Notebook to your uFOTO.

Copying a single MP3 file:

1. While in the playlist screen, highlight an MP3 file, then press  to check the checkbox below the file and press .
2. Select **Copy to**, then press .
3. Select the storage source where you want to paste the copied MP3 file, then press .

Copying all MP3 files:

1. While in the playlist screen, press .
2. Select **Select All**, then press .
3. Press  again, then select **Copy to** and press .
4. Select the storage source where you want to paste the copied mp3 files, then press .

Deleting MP3 files from your uFOTO

Deleting a single MP3 file:

1. While in the playlist screen, highlight an MP3 file, then press  to check the checkbox below the file and press .
2. Select **Delete**, then press .
3. Select **Yes** to delete the file, or **No** to abort the selection.

Deleting all MP3 files:

1. While in the playlist screen, press .
2. Select **Select All**, then press .
3. Press  again, then select **Delete** and press .
4. Select **Yes** to delete the file, or **No** to abort the selection.

Calendar

From the main menu, use ◀◀ or ▶▶ to select , then press ⏻ to enter.



Calendar SlideShow

While displaying the calendar, you can also view the photos in slideshow mode at the same time.

From the Calendar screen, press , then follow the steps in **Viewing photos** to display photos.

Configuring Calendar settings

From the Calendar screen, press  to configure several settings for photo display and music playback.

- 1 Slideshow Mode**
Allows you to disable the slideshow mode or set to sequential / random mode.
- 2 Transition Effect**
Provides you several transition effects.
- 3 Frequency**
Allows you to set the photo transition frequency .
- 4 Play with MP3**
Allows you to select the desired music from your storage device while displaying the calendar and photos.
- 5 Photo Source**
Allows you to select a storage device where photos are located.

6 Reminiscence

A shortcut to the Reminiscence function. Refer to the next section **Reminiscence** for more details.

7 Sub/Full Screen Mode

Allows you to display the calendar in **Sub Screen** or **Full Screen**.

8 MP3 Menu

Allows you to adjust the volume and playback mode for the currently playing MP3 file.

Reminiscence

The Reminiscence function allows you to search for a photo according to the date when the photo was taken.

Use ◀◀ and ▶▶ to select the field (mm / dd / yyyy) and change the values. Press ⏹ to confirm the setting.



Software introduction

To install the **ASUS uFOTO Utility**:

1. Insert the support CD into the optical drive.
2. Double-click the **ASUS uFOTO Utility** icon, then follow the on-screen instructions to finish the installation.
3. Restart your computer after the installation.

Data synchronization

The synchronization function makes it a lot easier and faster to pass photos and MP3 files to your uFOTO.



Before using this function, make sure that you have installed the ASUS uFOTO Utility.

To synchronize data:

1. Connect your uFOTO with your computer using the bundled USB cable.
2. Select **Mass Storage**, then press **⏏** to enter.
3. Double-click the **ASUS uFOTO Utility** icon on the computer desktop to start the **ASUS uFOTO Folder Sync utility**.
4. Copy your favorite MP3 files to the **My uFOTO Music** folder and photos to the **My uFOTO Picture** folder.



Before synchronizing files, make sure to check if the files are already in **C:\My Documents\My uFOTO Picture** or **C:\My Documents\My uFOTO Music**.

5.
 - Click **Auto** to start the synchronization.
 - Click **To Sync My uFOTO Photo** to synchronize the **My uFOTO Picture** folder only.
 - Click **To Sync My uFOTO Music** to synchronize the **My uFOTO Music** folder only.

Sub-Display

uFOTO can be used as a second screen to your computer and display the instant information windows or message tools you want.



Before using this function, make sure that you have installed the ASUS uFOTO Utility.

To start the Sub-Display utility:

1. Connect your uFOTO with your computer using the bundled USB cable.
2. Select **Sub-Display**, then press  to enter.
3. Double-click **Sub-Display** on the computer desktop to start the **ASUS Sub-Display Utility**.

To use the Sub-Display functions:

When the utility is activated, the same display is shown both on your computer and on your uFOTO.



Adjusting the screen

Press the following buttons to adjust the viewing screen.

-  and  : to zoom in or zoom out.
-  : to fit the screen in proportion.
- **1:1** : to display the screen in original proportion.

Selecting your ideal Sub-Display mode

The Sub-Display utility offers three kinds of viewing modes. You can decide which mode to use under different circumstances.




The Sub-Display function supports only the Duplication mode and Selection mode under Windows® Vista operating system.

Duplication mode

Make uFOTO your second display by selecting this mode. You will see the same movements simultaneously while editing a word, deleting a file, writing a sentence, etc.

When you select the Duplication mode, the screen on your computer is duplicated to your uFOTO.




Hand-shaped cursor

Adjust the position of the screen by dragging the screen with the hand-shaped cursor.




Selection mode

Move the scroll bar in the preview screen to select the window you want to display on the uFOTO.




After selecting the window, check the checkbox on the down right side of the preview screen.




Extension mode

When enabling the extension mode, you can hide the current viewing window by dragging it outside of the computer desktop window. Adjust the position of the window on your uFOTO by dragging the same screen with the hand-shaped cursor in the control panel.



You can also extend part of the current viewing window to your uFOTO.



Advanced settings

Click Advanced to adjust the settings including Image Adjustment and Display Setting.






Image Adjustment (Brightness, Contrast, Quality, Speed)



Display Setting (Display resolution selection)



Specifications summary

Panel Type	TFT LCD
Panel size	7" screen
Resolution	720 x 480
Pixel pitch	0.1905 mm x 0.1905 mm
Brightness (Max.)	220 nits
Contrast Ratio (Typ.)	800:1
Response time	30 ms
Battery	Internal / non-removable, rechargeable Li-polymer battery
Battery life time	Lasting for 60 minutes system operation > 60% capacity after charging 500 times
Sound	1W x 2 stereo speakers
Power supply	AC/DC switching power adaptor
I/O	1x USB 2.0 High Speed Host (mini A/B) 1x Slave/OTG (female A type) 3.5 mm audio jack (stereo)
Data input	CF Type I SD, MMC, xD, MS and MS Pro
Internal memory	NAND Flash: 128MB
Supported file format	Picture: JPEG, BMP, GIF Music: MP3
OS compatibility	Mass Storage: Windows® 2000/ME/XP/Vista, Mac OS X Sub-Display: Windows® XP/Vista
Firmware update	Through external memory cards (SD, mini SD)
Languages supported	English, German, Italian, French, Spanish, Russian, Traditional Chinese, Simplified Chinese, Japanese, Turkish
Regulation approvals	UL/cUL, CB, CE, Gost-R, CCC, FCC, C-Tick, BSMI, VCCI, RoHS, PSB, Vista Compliance

*Specifications are subject to change without notice.

Troubleshooting (FAQ)

Problem	Possible Solution
uFOTO does not turn on	<ul style="list-style-type: none">• Check if the adaptor is properly plugged.• Check if your uFOTO is fully charged.
The battery remaining indicator is incorrect	<ul style="list-style-type: none">• The phenomenon occurs when you are using your uFOTO in an extremely hot or cold environment.• The displayed battery remaining differ from the current one. Fully discharge and then recharge the built-in battery to correct the display.• The built-in battery is discharged. Plug the adaptor into your uFOTO for charging.
I cannot launch the Sub-Display function	<ul style="list-style-type: none">• The USB cable is not well connected.• The ASUS uFOTO utility is not completely installed. Refer to page 2-19 and re-install the utility.• The Sub-Display function cannot work with the Mass Storage mode simultaneously. Make sure that you are not in the Mass Storage mode prior to launching the Sub-Display function.
I cannot import photos or MP3 files uFOTO	<ul style="list-style-type: none">• The internal memory is full. Remove some files from your uFOTO.
The LCD brightness is not stable	<ul style="list-style-type: none">• Check if the AI Light function is enabled. If you enable this function, the LCD backlight will auto-adjust according to the surrounding environments.

