

How to Update the Firmware. (for O!Play Gallery)

Step1. Firmware Version check.

1. Please check the version of your Media Player's current firmware before beginning this update. If your Media Player's firmware is the latest version. you will not need to update the firmware.
2. Connect the Media Player to your TV and then turn on the Media Player.
3. Press the **Setup** button on the Remote controller and the **setting** screen will be displayed.
4. Click the **System** item. Check the **System Information**→ **Firmware Version: 1.74.** (earlier version).
5. If you want to upgrade your O!Play Gallery. you can choose either an Online upgrade or USB upgrade.

Step2. Firmware Upgrade.

Online(Network) upgrade

- 1.Go to **Setup > System update> Online upgrade** to perform the firmware upgrade process via the Internet.



Note: Make sure that you have Internet connection before upgrading the firmware via the Internet.


USB upgrade

1. Visit to ASUS SUPPORT site(**Drivers and Download**)to Download the latest Firmware.


<http://support.asus.com/download/download.aspx?SLanguage=en-us>

2. In the(Drivers and Download)Homepage. Please Select the(**Option 3.Select Model Manually**)
Press **Start** → Select Product.(**Multimedia**) Series (**Digital Media Player**). Models(**O!Play Gallery**) and select your PC's **OS** .then click The "**Confirm** "
when you're sure you've selected the correct Model. Please see image below.





3. When the next page open, you can find the firmware folder. Please see image below.
Please click the **firmware** folder




4. Select an appropriate Firmware. then Click the Download from...that's nearest you, a 'File Download' window will probably pop up.
Click the save. if save it to your computer's Desktop. Please see image below.




5.The zipped firmware will be downloaded and saved to your Desktop.

Once the zipped firmware (gallery.bin) is downloaded and saved on your desktop,



6. Unzip the compressed firmware to (gallery.bin). Then using a blank/ formatted USB Flash Stick to copy or paste the (gallery.bin Only). The attached PDF (How to Update the Firmware) only for your reference.

The Unzipped firmware file (gallery.bin) as below:



Step4. To Update the Firmware.

1. Insert the USB Flash Stick(the **gallery.bin** Loaded) to USB port of your Media Player. The Media Player will recognize the firmware in the USB Flash drive automatically.
2. Press the **Setup** button on the Remote controller and the **setting** screen will be displayed.
3. Click on the **System** item and press OK. Then navigate to the **System update** and choose the USB Press **OK** to Verify the Firmware and start updating. (**USB upgrade**)
4. At this moment, Your TV screen will go dark temporarily and following screen will display again.



New firmware updates is in the process (take about few minute).when the update is successfully completed the Media Player will reboot automatically.

WARNING :

DO NOT UNPLUG (Power Cord and USB Flash drive)TURN OFF, OR USE ANY OTHER FEATURE OF YOUR MEDIA PLAYER DURING THE FIRMWARE UPDATE PROCESS. Doing so will cause the writing of the firmware update to the player to be halted and the player may no longer operate properly. If the player stops working, please contact ASUS Authorized Service Provider at 0800-093-456.

Emergency Recovery Instructions.

If the O!Play accidentally shut down during the firmware upgrade, the safe mode will enable the O!Play to be re-upgraded. you can to restart the Upgrade.

The Media Player will re-upgrade automatically. Repeat the same procedure as above Until the upgrade has been successfully finished.

If the firmware cannot be upgraded with the Safe Mode. it means that either incorrect firmware or problems with the USB Flash Stick. (Replace it & re-download)