

Type	Device Model	
USB 2.0	ASUS BS-F112 320G	FUJITSUWyvo E 500GB
	Imation SOHOT PRO 320GB	lomega eGo 500GB
	Seagate Free Agent Xtreme 1.5TB	TRANSCEND STOREJET 25F 500GB
	Vantec NST-D100	WD My Book Home 750GB
	HITACHI-LIFE STUDIO-1TB	WD ELEMENTS SE 1TB
USB 3.0	Agestar 3UB3A8 USB 3.0	Buffalo HD-PE640U3 640GB
	BuffaloSHD-PEHU3-BK SSD 64GB	CyberSlim S1-U3 Turbo
	CyberSlim S2-U3 Turbo	CYBERSLIM-S1-U3H USB3.0
	CYBERSLIM S2-U3 USB3.0	Sharkoon Rapid
	Sharkoon Quickport DUO	Sharkoon Rapid case 2.5
	iomegaeGo 2TB	Seagate-STAC2000300-2TB
	Seagate-STAC3000301-3TB	TRANSCEND TS640GSJ25D3
	WD-MY BOOK 3.0-1TB	CENDA C601U 5G 500GB
	WD My passport Essential SE 750GB	SILICON POWER10060946-640GA
	PQI H566	PQI S533-E
	Data-Tec U350SR-U3	Patriot Auntlet Enclosure SSD
	Ineo I-NA317+	UNITEK Y-1034
	UNITEK Y-1072	
SATA	HITACHI HDP725032GLA380 320GB	Samsung HD321KJ 320GB
	WD WD30EZRX 3TB	WD WD10EACS
	SAMSUNG HD103SJ 1TB	Seagate ST31000529AS
	WD 6400AAKS	WD 5000AAKS
	WD WD15EARS 1.5TB	SEAGATE ST3500320AS 500GB



- The Hard Disk Drive (HDD) Support list may change without prior notice.
- Turn off your O!Play TV PRO before removing the HDD. When the HDD is not properly removed, an error message appears. When this occurs, connect the HDD to a computer running on Windows® OS to rescan the HDD contents.