

O!PLAY TV PRO

Qualified Vendors List

Type	Device Model		
USB 2.0	• ASUS BS-F112 320G	• HITACHI-LIFE STUDIO-1TB	• WD My Book Home 750GB
	• Imation SOHOT PRO 320GB	• FUJITSUWyvo E 500GB	• WD ELEMENTS SE 1TB
	• Seagate Free Agent Xtreme 1.5TB	• Iomega eGo 500GB	
	• Vantec NST-D100	• TRANSCEND STOREJET 25F 500GB	
USB 3.0	• Agetstar 3UB3A8 USB 3.0	• PQI H566	• Seagate-STAC2000300-2TB
	• BuffaloSHD-PEHU3-BK SSD 64GB	• Data-Tec U350SR-U3	• TRANSCEND TS640GSJ25D3
	• CyberSlim S2-U3 Turbo	• Ineo I-NA317+	• CENDA C601U 5G 500GB
	• CYBERSLIM S2-U3 USB3.0	• UNITEK Y-1072	• SILICON POWER10060946-640GA
	• Sharkoon Quickport DUO	• Buffalo HD-PE640U3 640GB	• PQI S533-E
	• iomegaGo 2TB	• CyberSlim S1-U3 Turbo	• Patriot Auntlet Enclosure SSD
	• Seagate-STAC3000301-3TB	• CYBERSLIM-S1-U3H USB3.0	• Patriot Auntlet Enclosure SSD
	• WD-MY BOOK 3.0-1TB	• Sharkoon Rapid	• UNITEK Y-1034
	• WD My passport Essential SE 750GB	• Sharkoon Rapid case 2.5	
SATA	• HITACHI HDP725032GLA380 320GB	• WD WD15EARS 1.5TB	• WD 5000AAKS
	• WD WD30EZRX 3TB	• Samsung HD321KJ 320GB	• SEAGATE ST3500320AS 500GB
	• SAMSUNG HD103SJ 1TB	• WD WD10EACS	
	• WD 6400AAKS	• Seagate ST31000529AS	
Wireless Keyboard	• ASUS W3000	• Microsoft Wireless Laser Desktop 6000	• MSI Wireless Combo 630
	• Microsoft Wireless Laser Desktop 3000	• Logitech MX3200 Laser	
Wireless Mouse	• ASUS GX800	• ASUS WT460	• ASUS WT450
	• ASUS WT410	• ASUS WT400	• ASUS WX-Lamborghini



- The Qualified Vendors List may change without prior notice.
- Turn off your O!Play TV PRO before removing the HDD. When the HDD is not properly removed, an error message appears. When this occurs, connect the HDD to a computer running on Windows® OS to rescan the HDD contents.