

Optical Disc Drive Firmware Upgrade Guide

Follow the instructions below to identify the model of your optical disc drive and upgrade its firmware.

To Identify the ODD model

For Windows XP:

1. Double-click **System** in the **Control Panel**.
2. Click the **Hardware** tab, and then click the **Device Manager** button.
3. Click the "+" sign before the item **DVD/CD-ROM drives**, and note down the ODD model, for example: **MATSHITA DVD-RAM UJ862AS ATA Device**.

For Windows Vista / Windows 7:

1. Click **Start**, right-click **Computer**, and then click **Properties**.
2. Click **Device Manager** in the left pane.
3. Click the "+" sign before the item **DVD/CD-ROM drives**, and note down the ODD model, for example: **MATSHITA DVD-RAM UJ862AS ATA Device**.

To upgrade ODD firmware

1. Download the corresponding ODD firmware in the following address
<http://support.asus.com/download/download.aspx?product=20&model=ODD%20Firmware&SLanguage=en-us&os=8>
2. Double-click the downloaded executable file to upgrade ODD firmware.