

## Self-upgrade guide to Windows® 7 for your Eee PC™ with Windows® XP

**Prior to upgrading to Windows® 7, please download the following:**

- BIOS (v.2204)
- Chipset Intel 945 (v9.1.1.1016)
- VGA Intel (v8.15.10.1912)
- Touchpad (v7.0.5.7)
- KB Filter (v1.0.0.3\_32)
- Audio (v6.0.1.5924)
- LAN (v1.0.0.45)
- Wireless NE785 (v8.0.0.177)
- HotkeyService (v1.15)
- Super Hybrid Engine (SHE) (v2.09)
- ASUS Update (v1.03.02)
- Instant Key (v1.12)

### **Windows® 7 Self-Upgrade Steps**

\*Please note:

- (1) We recommend you follow the step-by-step upgrade instructions as shown in the SOP file. Failure to do so may result in errors during the upgrade process.
  - (2) For any assistance during the installation process, contact ASUS Support at <http://support.asus.com/contact/contact.aspx?SLanguage=en-us>
1. Under Windows® XP in your Eee PC™, upgrade BIOS via the ASUS Update (for Windows® XP).
  2. Install Windows® 7 operating system from the DVD.  
\*Please note: Ensure that it is in the same language as your current Windows® XP operating system.
  3. Install required drivers, utilities, and applications in the following order:
    - 1) Chipset Intel 945: Run "Setup.exe"
    - 2) VGA Intel: Run "Setup.exe"
    - 3) Hotkey Service: Run "HotkeyService\_1.11.01.exe"
    - 4) Touchpad: Run "Setup.exe"
    - 5) Bluetooth: Run "Setup.exe"
    - 6) KB Filter: Run "PNPINST.exe"
    - 7) Audio: Run "Setup.exe"
    - 8) LAN: Run "Setup.exe"
    - 9) Wireless NE785: Run "Setup.exe" in the "Install\_CD" folder
    - 10) Super Hybrid Engine: Run "SuperHybridEngine\_2.09.exe"
    - 11) ASUS Update: Run "AsusSetup.exe"