



Touchpad Lock (F3): Pressing Fn and F3 will lock your touchpad to prevent you from accidentally moving the cursor while typing. To enable the touchpad, simply press Fn and F3 again.