



Update ACPI to 4.0.0006


1. Download the files on your desktop.




2. Update BIOS. Click ASUSUpdate. (Start > Programs > ASUS >ASUSUpdate for Eee PC > ASUSUpdate)




3. Choose “Update BIOS from file” and click “Next”




4. Choose the BIOS file where you put and click “Open”.




5. Click “Yes” to reboot your computer.



6. After update BIOS, computer will reboot again and knock press F2.



7. Choose “Check BIOS Information” and click “Next”.




8. To check BIOS version is 0601.




9. Click “Control Panel”. (Start > Settings > Control Panel)



10. Choose “Add or Remove Programs”.



11. Remove “Asus ACPI Driver”.



12. Click “Yes” to remove “Asus ACPI Driver”.




13. Click “No” to remove TouchPad driver.



14. Remove “TouchPad driver”.



15. Click “OK” to remove the program.



16. Click “Yes” to restart computer.




17. This is normal messenger, click “Cancel” to close it.



18. Open the file of ACPI.




19. Click “Asus ACPI Driver” to install this program.



20. Click “Next”.



21. Click “Install”.




22. Click “Finish”.




23. Open the file to install TouchPad driver.




24. Click “setup”.



25. Click “Next”.




26. Click “Next”.



27. Click “Continue Anyway”.



28. Choose “Yes, I want to restart my computer now.” and click “Finish”



29. After restart computer, this SOP is finish.