

# FUU\_SOP

## 【Notices】

### ◎Summary :

Welcome to use ASUS P526 update updating Firmware. You would use this updating program to update the latest newly version of ASUS P526 internal firmware. So, this will enhance the ASUS P526 cellphone's stability and make its performance better. Read the following introduction carefully before updating.

### ◎Firmware Version :

ASUS P526-V6.1.X.XXX

### ◎Updating program supports following operation system :

Windows 2000 、 Windows XP 、 Windows Vista edition


### ◎Attention :

1. In order to maintain the computer's stability and avoid updating failures, don't operate many programs simultaneously.
2. The previous data couldn't be preserved after updating newly edition firmware. Please use the additional backing program to back up your data.
3. Don't update other languages' or regions' firmware edition to your PDA cellphone.
4. Don't remove USB cable before updating finished.
5. You should back up all the encrypted data on SD card before updating, because the file on encrypted SD card can't be opened after updating.


### ◎Procedure:

1. Firstly, check the power left if it is up 50%, and keep cellphone was turned on.
2. Synchronize device to PC with USB.
3. Check PC installing the [ActiveSync 4.5] (windows 2000, XP) or [WMDC] (windows vista) and make sure it's in connection status.
4. Click [update] button to upgrade.
5. If it failed to upgrade, please keep USB connect to PC and re-execute firmware, following expert mode to upgrade.

## I. Install ASUS P526 updating procedure \*exe application.




Installing.




Finish installation.

## II. Execute upgrade procedure.

1. Turn on device.
2. Synchronize device to PC with USB
3. Make sure synchronization is successful. Status: [Connected]




4. ASUS P526 updating procedure's main window looks like as below, click [update] button.





<Note1 : If appear the below information, make sure cellphone synchronize to PC successfully.>

<Note2 : Make sure power is above 50%, or update wouldn't go on.>



5. Confirm Boot Code firmware.






Cellphone firmware version is different according to different BootCode. The updating procedure will auto run. Before [update] button change into [Finish], please don't pull out USB in case of fail.

6. Updating procedure then will be shown on cellphone.



7. Please wait for 5-7 minutes.
8. Updating finish, Click [Finish]





### III. Saving update if failed with above method.

1. If it failed to update, please don't remove battery.
2. Re-turn on cellphone, Press power button or reset to restart cellphone, then press [OK] at once to show like as below.




3. Connect cellphone to PC with USB.

4. Execute ASUS P526 updating procedure, click [Expert Mode].







5. Start saving update.




6. Updating



7. Updating procedure then will be shown on cellphone.



8. Wait for 5-7 minutes until expert mode update finish.



9. Cellphone will restart automatically.