

## ***CONTENT***

---

F.C.C. statement  
Important safeguards

### ***Chapter 1 Introduction***

1.2 Features.....	1
1.3 Checking List.....	1

### ***Chapter 2 Installation***

2.1 Connect your monitor to a computer.....	2
---	---

### ***Chapter 3 Overview of your monitor***

3.1 Front Panel overview.....	3
-------------------------------	---

### ***Chapter 4 Operation***

4.1 Power ON/OFF switch.....	4
4.2 Power indicator.....	4
4.3 Volume.....	4
4.4 Menu features.....	4
4.5 OSD menu.....	5
4.6 Preset modes timing chart.....	7

### ***Chapter 5 Technical information***

5.1 Signal Connector Pin Assignment.....	8
5.2 Visual Inspection. ....	9
5.3 Troubleshooting.....	10



## **FEDERAL COMMUNICATIONS COMMISSION(F.C.C) STATEMENT**

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient/Relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer of an experienced radio/TV technician for help.

**CAUTION:** *Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.*

**NOTE:** *The use of a non-shielded interface cable with this equipment is prohibited.*



---

## IMPORTANT SAFEGUARDS

### Warnings:

1. Read all of these instructions. Save these instructions for later use, please.
  2. Unplug this monitor from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
  3. Do not use attachments not recommended by the monitor manufacturer as they may cause hazards.
  4. Do not use this monitor near water. For example near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc...
  5. Do not place this monitor on an unstable cart, stand, or table. The monitor may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart or stand recommended by the manufacturer or sold with monitor. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.
  6. Slots and openings in the cabinet and the back or bottom are provided for ventilation, and to insure reliable operation of the television receiver and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the monitor on a bed, sofa, rug, or other similar surface. This monitor should never be placed near or over a radiator or heat register. This monitor should not be placed in built-in installation such as a bookcase unless proper ventilation is provided.
  7. This monitor should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied in your home, consult your monitor dealer or local power company.
  8. This monitor is equipped with a three-wire grounding type plug, a plug having a third (grounding) pin. This plug will only fit into grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.
  9. Do not allow anything to rest on the power cord. Do not locate this monitor where the cord will be abused by persons working on it.
  10. Follow all warnings and instructions marked on the monitor.
  11. For added protection for this monitor, when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the monitor due to power-line surges.
  12. Do not overload wall outlets and extension cords as this can result into fire or electric shock.
  13. Never push objects of any kind into this monitor through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the monitor.
  14. Do not attempt to service this monitor yourself since opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
  15. Unplug this monitor from the wall outlet and refer servicing to qualified service personnel under the following conditions:
    - a. When the power cord or plug is damaged or frayed.
    - b. If liquid has been spilled into the monitor.
    - c. If the monitor has been exposed to rain or water.
    - d. If the monitor does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls, may result in damage and will often require extensive work by a qualified technician to restore the monitor to normal operation.
    - e. If the monitor has been dropped or the cabinet has been damaged.
    - f. When the monitor exhibits a distinct change in performance this indicated a need for service.
  16. When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer that have the same characteristics as the original parts. Unauthorized substitutions may result in fire, electric shock, or other hazards.
  17. Upon completion of any service or repairs to this monitor, ask the service technician to perform routine safety checks to determine that the monitor is in safe operating condition.
  18. The socket outlet shall be near the equipment and shall be easily accessible.
  19. The power supply cord is used as the main disconnect device.
-


**1.1 Features**

1. Horizontal frequencies: 31KHz to 80KHz.  
Vertical frequencies: 56Hz to 76Hz.
2. Microprocessor based with OSD (On Screen Display) control.
3. Compatible with standard IBM VGA ,extended VGA,super VGA, IBM XGA modes, as well as VESA resolution standards.
4. Universal power supply.
5. Microsoft windows 95/98/2000/ME/XP compatible & VESA Display Data channel (DDC)1/2B compatible.

**1.2 Checking List**

Please make sure the following items are included with your LCD monitor:

- **Your monitor**
- **AC power cord**
- **DC Adapter**
- **Signal cable**
- **User manual**




If any of these items are missing, please contact with your dealer for Technical support and customer service.


*Note:*  
Be sure to save original box and all packing material for transport in future if the Monitor need .

**2.1 Connect your monitor to computer**

- 2.1.1 Turn off your computer and unplug its power cable.
- 2.1.2 Connect the signal cable to the video port on the back of your computer.
- 2.1.3 Connect the power cable for your monitor to the DC adapter and connect the adapter the DC power jack on the back of your monitor. you must use the supplied adapter.
- 2.1.4 Speaker connect one end of the audio cable to the connector on the back of the monitor audio, and the other end to the sound card of the computer output.
- 2.1.5 Plug the computer and monitor power cables into a nearby outlet.
- 2.1.6 Turn your computer and monitor on, if your monitor display an image, you have successfully installed the monitor. If the monitor does not display an image, check all the connections.



3.1 Front Panel overview



**1. Menu Button**

To push menu button turns on the menu, and it activates the items you highlight .

**2. Volume Button**

To choose which function you need .you may choose + or -

**3. Select Button**

To choose which function you need .you may choose ▼counterclockwise or ▲ Clockwise.

**4. Auto Button**

Auto adjust the display mode to its utmost performance according to VGA setting.

**5. Power Button**

Use this button to turn the monitor on and off.

**6. Power indicator**

## Chapter 4

### OPERATION Direct - Access Features

#### 4.1 SWITCHING THE MONITOR ON/OFF

This ON/OFF button is used for switching the monitor on and off.

**Note:** The ON/OFF switch does not disconnect the device from the mains voltage. To completely disconnect the mains voltage, please remove the power plug from the socket.

#### 4.2 POWER INDICATOR

This indicator lights up green(PM17T/D)/blue(PM17TS) when the monitor operates normally.If the monitor is in power saving mode, this indicator change to orange. When monitor is turn off, this indicator change the color to dark.

#### 4.3 VOLUME

This feature adjust the DOWN button to decrease the volume and UP button to increase the volume.

##### Important information on audio playback

To achieve optimum sound quality from the monitor speakers, the audio cable should be connected to the Line-Out socket (headphone socket) of the computer. If you connect the audio cable to the Speaker-Out socket (soundcard) of the computer, Please set the volume under Windows to range between 20% - 40% of the maximum value to achieve optimum sound quality.

#### 4.4 MENU FEATURES

The following features can all be accessed by using your monitor's on screen menu system. Once are finished. Making adjustments to a feature, selecting the exit icon to turn off the menu.

Please follow the procedure of selection and adjust an item using the OSD system as below steps for main functions adjustment.

- Step 1: Press the MENU button to activate the OSD menu.  
The main menu appears on the screen with icons for the setting functions.
- Step 2: If necessary, use the ▲ or ▼ button to mark an other icon.
- Step 3: Press the MENU button to activate the highlighted icon.
- Step 4: Use the ▲ or ▼ button to make the desired setting.
- Step 5: Select the EXIT symbol to exit the OSD menu.
- Step 6: Repeat step 2 through 5 to make further adjustments.

All changes are stored immediately


## Chapter 4

### OPERATION Direct - Access Features

#### 4.5 OSD MENU

##### 1. Main menu

OSD main menu of controls gives you an overview of the selection of controls available. When you want to make adjustment of the screen image, press and release button Menu



##### 2. OSD Adjustment

You can choose where you would like OSD image to appear on your screen.

**H-Position :**  To move the OSD image horizontally left or right.

**V-Position :**  To move the OSD image vertically up or down.

**Exit :**  To exit the sub menu

##### 3. Language

You can choose one of the seven language you need.

##### 4. Reset

Reset the currently highlighted control to the factory setting. User must be using factory preset video mode to use this function.

##### 5. Auto / (SET UP)

 Auto adjust display mode to its utmost performance according to VGA setting. In the event of the display image needs further adjustment .

## Chapter 4

### OPERATION Direct - Access Features

 SET UP select menu. (Only for PM17T/PM17TS)

1. Input Select 


You can choose the signal input status which you need.

2. AUTO Select 

Auto adjust display mode to its utmost performance according to VGA setting. In the event of the display image needs further adjustment. In addition, press this key for more than three seconds, the input signal can be realized switching over automatically.

6. Color Select 

**Color Select Menu**



**Select user mode** 

User color you can adjust to individual color gum intensity by yourself. Increase or decrease red, green or blue depending upon which color is selected.

**COOL:** This control adjusts the color temperature of the screen image. This item are preset by factory, you can not adjust these setting. The performance is bluer and brighter.

**WARM:** The performance is redder and closer to paper white.

**NATURAL:** to give the white color a natural tint.

7. Phase 

To improve focus clarity an image stability.

8. H. Size 

To increase or decrease the horizontal size of image.

9. V. Position 

To move the picture image vertically up or down.

10. H. Position 

To move the picture image horizontally left or right.

11. Contrast 

Adjust the image brightness in relation to the background.

12. Brightness 

Adjust the overall image and background screen brightness.

## Chapter 4

### OPERATION Direct - Access Features


#### 4.6 Preset Modes Timing Chart

Item	Resolution (dots x lines)	Horizontal Freq.(kHz)	Vertical Freq.(Hz)
1	720 x 400	31.47	70
2	640 x 480	31.47	60
3	640 x 480	37.86	72.8
4	640 x 480	37.50	75
5	800 x 600	35.15	56.2
6	800 x 600	37.88	60.3
7	800 x 600	48.08	72.2
8	800 x 600	46.87	75
9	1024 x 768	48.36	60
10	1024 x 768	56.48	70.1
11	1024 x 768	60.02	75
12	1280 x 1024	63.98	60
13	1280 x 1024	80	75

5.1 Signal connector pin assignment

1. PM17D /PM17T /PM17TS

PIN	Signal (D-sub)	PIN	Signal (D-sub)
1	Red	9	NC or +5V Input
2	Green	10	Ground
3	Blue	11	Ground
4	Ground	12	SDA (FOR DDC)
5	Self Test	13	H. Sync
6	Red Ground	14	V. Sync
7	Green Ground	15	SCL (FOR DDC)
8	Blue Ground		




15-Pin mini D-Type male connector

## Chapter 5

### Technical Information

#### 2. PM17T/PM17TS

PIN	Signal (DVI)	PIN	Signal (DVI)
1	TMDS Data 2-	16	Hot Plug Detect
2	TMDS Data 2+	17	TMDS Data 0-
3	TMDS Data 2/4 shield	18	TMDS Data 0+
4	TMDS Data 4-	19	TMDS Data 0/5 shield
5	TMDS Data 4+	20	TMDS Data 5-
6	DDC Clock	21	TMDS Data 5+
7	DDC Data	22	Clock shield
8	Analog Vertical Synchronal	23	Clock +
9	TMDS Data 1-	24	Clock -
10	TMDS Data 1+		
11	TMDS Data 1/3 shield		
12	TMDS Data 3-		
13	TMDS Data 3+		
14	+5V Power		
15	Ground		



#### 5.2 Visual Inspection

*Even the normal pixels on the LCD screen reach 99.99% or higher, there may be 0.01% or less pixels showing dark or light while displaying.*

#### 5.3 Trouble shooting

Before calling for service , check the information in this section to see if you can remedy any problems by yourself. If you need assistance, please call the dealer where you purchased the LCD monitor.

**There is no SCREEN image**

Please check these items:

- The power cord is securely connected the monitor, the adaptor, and the wall outlet.
- Check the signal cable connection between the monitor and the computer.
- Adjust the brightness and contrast controls.
- Monitor in power saving mode.

**Display image is too large or small**

- Use the OSD controls to adjust Auto Setup.

**The colors are discord**

- Signal cable properly connected?
- Use OSD controls to adjust the color control setting.

**The image is too light or too dark**

- Use OSD controls to adjust the brightness and contrast.

**There is no sound or sound is low**

- Check the audio cable connector.
- Make sure the computer sound program is working.
- Change the volume on sound setting. Adjust your sound card or computer volume setting.

For applicable power supplies see user instructions!

Adapter Suppliers:

1. Li Shin: LSE9901B1250
2. Linearity: LAD6019AB4
3. Lien Chang: LCA01F
4. FSP Group Inc: FSP048-1AD101C
5. Medi Power: AD-1250B