



•• M530w

SMARTPHONE ••

USER MANUAL

ASUS contact information

ASUSTeK COMPUTER INC. (Asia-Pacific)

Address	15 Li-Te Road, Peitou, Taipei, Taiwan 112
Web site	www.asus.com.tw

Technical Support

Telephone	+886-2-2894-3447
Support Fax	+886-2-2890-7698
Software download	support.asus.com *

ASUS COMPUTER INTERNATIONAL (America)

Address	44370 Nobel Drive, Fremont, CA 94538, USA
Telephone	+1-502-955-0883
Fax	+1-502-933-8713
Web site	usa.asus.com
Software download	support.asus.com *

ASUS COMPUTER GmbH (Germany and Austria)

Address	Harkort Str. 25, D-40880 Ratingen, Germany
Telephone	+49-2102-95990
Fax	+49-2102-959911
Online contact	www.asuscom.de/sales

Technical Support

Telephone	+49-2102-95990
Fax	+49-2102-959911
Online support	www.asuscom.de/support
Web site	www.asuscom.de/news

* Available on this site is an online Technical Inquiry Form that you can fill out to contact technical support.

E3093

First edition

May 2007

Copyright © 2007 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Microsoft, Activesync, Outlook, Pocket Outlook, Windows, and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or in other countries. Microsoft products are licensed to OEMs by Microsoft Licensing, Inc., a wholly owned subsidiary of Microsoft Corporation.

Safety Information

Safety precautions for the power supply unit and battery

Use the correct external power source. The power adapter of this product can only be operated from the type of power source indicated on the electrical ratings label. If you are not sure of the type of power source required, consult your authorized service provider.



Battery pack care. This product contains a Li-Ion Polymer battery. There is a risk of fire and burns if the battery pack is handled improperly. Do not attempt to open or service the battery pack.



WARNING



DANGER OF EXPLOSION IF BATTERY PACK IS INCORRECTLY REPLACED. TO REDUCE RISK OF FIRE OR BURNS, DO NOT DISASSEMBLE, CRUSH, PUNCTURE, OR SHORT EXTERNAL CONTACTS OR CIRCUITS. DO NOT DISPOSE OF IN FIRE OR WATER, OR EXPOSE TO TEMPERATURES HIGHER THAN 60OC(140OF). REPLACE THE BATTERY PACK ONLY WITH MANUFACTURER SPECIFIED BATTERIES. RECYCLE OR DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATIONS.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff. If your device offers a “flight mode” or similar feature, consult airline staff as to its use in flight.

Driving

Full attention should be given to driving at all times. Local laws and regulations restricting the use of wireless devices while driving must be observed.

Hospitals

Mobile phones should be switched off whenever you are requested to do so in hospitals, clinics, or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Petrol Stations

Obey all posted signs with respect to the use of wireless devices or other radio equipment in locations with flammable material and chemicals. Switch off your wireless device whenever you are instructed by authorized staff.

Interference

Care must be taken when using the phone in close proximity to personal medical devices such as pacemakers and hearing aids.

For Pacemakers

Pacemaker manufacturers recommend that a minimum space of 15cm be maintained between a mobile phone and a pacemaker to avoid interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry the phone in a breast pocket.

For Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

For Other Medical Devices

Consult your physician and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

Specific Absorption Rate (SAR)

Your M530w has been designed, manufactured and tested not to exceed the limits for exposure to electromagnetic fields recommended by the Council of the European Union. These limits are part of comprehensive guidelines developed by independent scientific organisations.

European standards provide for the amount of radio frequency electromagnetic energy absorbed by the body when using a phone to be measured by reference to the Specific Absorption Rate (SAR). The SAR limit for the general public is currently 2 watts per kilogram averaged over 10 grams of body tissue.

Radio Frequency (RF) radiation exposure for body-worn operation: To ensure compliance with RF exposure guidelines, this device must be used to with a minimum of 1.5 cm (0.6 inch) separation from the body. Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

The maximum SAR value for M530w is GSM: 0.196W/kg@10g(CE); DCS: 0.413W/kg@10g(CE); and WCDMA: 0.323W/kg@10g(CE).

Table of Contents

Chapter 1	Getting Started.....	1
1-1	Introducing the ASUS M530w Smartphone.....	1
1-2	Getting to know your Smartphone.....	2
1-3	Installing the SIM card and battery.....	7
1-4	Installing and removing a microSD card.....	9
1-5	Charging your Smartphone.....	10
1-6	Turning your Smartphone ON/OFF	11
Chapter 2	Learning to Use Your Smartphone.....	12
2-1	Navigating	12
2-2	Home screen	14
2-3	Start menu.....	16
2-4	Quick List.....	17
Chapter 3	Using Call Features	18
3-1	Making a voice call	18
3-2	Responding to a voice call	22
3-3	Options during a call.....	23
3-4	Making a video call.....	24
3-5	Responding to a video call	25
Chapter 4	Synchronizing with ActiveSync.....	26
4-1	Microsoft ActiveSync	26
4-2	Installing ActiveSync on your PC.....	27
4-3	Connecting your Smartphone to a PC.....	28
4-4	Creating a partnership.....	28

4-5	Synchronizing with a PC	29
4-6	Synchronizing with an Exchange Server	31
4-7	Creating a synchronization schedule	32
4-8	Remote synchronization	34
Chapter 5	Managing Your Smartphone	35
5-1	Personalizing your Smartphone	35
5-2	Improving performance	42
5-3	Turning on/off wireless mode	43
5-4	Keeping your Smartphone secure	44
5-5	Restarting your Smartphone	47
5-6	Resetting your Smartphone	47
5-7	Adding and removing programs	48
5-8	Managing and backing up files	49
Chapter 6	Getting Connected	52
6-1	Connecting to the Internet	52
6-2	Internet Sharing	55
6-3	Using Internet Explorer Mobile	56
6-4	Using Bluetooth®	59
Chapter 7	Messaging	64
7-1	Entering text, numbers, and symbols	64
7-3	Managing accounts	68
7-4	Text and e-mail messages	68
7-5	MMS messaging	72
7-6	Windows® Live	75
Chapter 8	Organizing Your Life	79

8-1	Using Contacts	79
8-2	Using Calendar	82
8-3	Using Tasks	84
8-4	Using Voice Notes	85
Chapter 9	Multimedia	86
9-1	Using your camera	86
9-2	Working with pictures and videos	89
9-3	Listening to music and watching videos	92
9-4	Using Java (MIDlet Manager)	96
Chapter 10	Voice Commander	98
10-1	Using the Voice Commander	98
10-2	Using the Vocab Settings	110
10-3	Using the Digit Trainer	111
Chapter 11	Other Features	112
11-1	WorldCard Mobile	112
11-2	Task Manager	113
11-3	ClearVue Office Applications	113
11-4	Spb® Zip	115
11-5	Default Settings	115
11-6	Mode Switcher	116
11-7	Remote Presenter	117
Appendix	Notices	126
Index	130

ASUS M530w specifications

Processor	Marvell PXA270 416MHz tri-band GSM/GPRS
Operating system	Microsoft® Windows Mobile™ 6 (Standard version)
Network system	Tri-Band GSM/GPRS (900/1800/1900) + WCDMA(UMTS) (2100MHz) GPRS class 10
Memory	256MB Flash ROM 64MB SDRAM
Display	2.4-inch 65K color TFT-LCD (240 x 320 pixels)
Camera	Dual CMOS camera Main: 2.0 megapixel CMOS main camera with built-in LED flash, macro mode, and 4x digital zoom Sub: VGA resolution CMOS sub camera
Expansion slot	One slot - Micro SD card slot
Connectivity	Bluetooth® v2.0 / USB 1.1 (client +host) /WLAN 802.11b/g
Audio	2.5 mm stereo earphone jack / built-in microphone / built-in speakerphone
Size	117 mm x 65 mm x 13.8 mm
Weight	135 grams (with battery)
Battery	1200mAh removable/rechargeable Li-ion
Battery life	150 hours standby time / 4 hours talk time with GSM and 2 hours talk time with WCDMA *

* The actual performance is dependent on multiple factors, including network and usage environment.

Package contents

Your package includes several accessories for the Smartphone. After unpacking, check the items against the list below and make sure that they are in good condition. If any item is missing or damaged, contact your dealer or retailer immediately.

Standard items

- ASUS M530w Smartphone
- USB sync cable
- AC adapter
- Microsoft Getting Started CD: includes Microsoft® ActiveSync® 4.5
- Removable/ rechargeable 1200mAh Li-ion battery (SBP-10 battery manufactured by Welldone)
- Headset
- Manual
- Quick Start Guide
- Warranty card
- Protection case

IMPORTANT

Operate this unit (including the protection case) within a temperature range of 20 ~ 30 °C (68 ~ 86 °F) and 50% humidity to avoid damaging your Smartphone and accessories,

Chapter 1 Getting Started

1-1 Introducing the ASUS M530w Smartphone


The ASUS® M530w 3G Smartphone comes with the latest mobile technology that fits your world into your hands. The M530w is a tri-band mobile phone with high resolution LCD, built-in dual CMOS camera with camcorder, video calling and messaging capability, organizer, GPRS, and a micro SD card slot.

In addition to 256 MB phone memory, the microSD card extends storage space, allowing you to save photos, messages, texts, graphics, and audio files like no other mobile phone can, making it a perfect partner whether you are on or off the road.

With these features and many more, the ASUS M530w is sure to give you a satisfying mobile phone experience.


1-2 Getting to know your Smartphone

Layout




Components:


- 1 Power/Quick List button
- 2 Power LED
- 3 Sub camera lens
- 4 Call key
- 5 Left soft key
- 6 Home Button
- 7 Navigation buttons
- 8 Action button
- 9 Right soft key
- 10 Back button
- 11 End key
- 12 The QWERTY keypad
- 13 Select button
- 14 Volume controller



Bottom features



Rear features



Right side feature

Components:

- 15 Earphone slot
- 16 Mini-USB connector
- 17 Camera lens
- 18 Camera flash light
- 19 Speaker
- 20 Battery compartment
- 21 Camera button / Function Side key

Device components description

No.	Item	Description
1	Power/Quick List button	<p>Press and hold to turn the phone ON/OFF.</p> <p>Press and quickly release to open the Quick List, which gives you quick access to Wireless Manager (for enabling and disabling wireless capabilities), Key lock, and preset profiles.</p>
2	Notification LED	<p>This multi-color LED notifies the following:</p> <ul style="list-style-type: none">• Green - Phone fully charged.• Flashing green - Network detected.• Red - Phone is charging.• Flashing red - Event notification.• Flashing blue - Bluetooth® or WLAN(IEEE 802.11b/g) ON.
3	Sub Camera Lens	<p>This sub camera is for the video conference.</p>
4	Call key	<p>Press to answer a call or dial a number.</p> <p>Press twice to redial last number.</p> <p>Press and hold during an active call to switch to speakerphone mode.</p> <p>Press once to place an active call on hold and answer another incoming call.</p>
5	Left Soft key	<p>Use to select the command right above it on the main display.</p> <p>When the keypad is locked, press this key followed quickly by the Asterisk key to unlock.</p>
6	Home Button	<p>Press to return to the Home screen.</p>
7	Navigation buttons	<p>Use this to move up, down, right, and left through selections on the display.</p> <p>The primary use of the Up and Down navigation keys is for movement within menus and navigation through contacts.</p> <p>The primary use of the Left and Right keys is change settings and edit text.</p>

No.	Item	Description
8	Action button	The Action key acts much like the Enter key on a keyboard. In general, press to confirm an action. When you scroll to a check box, pressing the Action key selects or clears the check box.
9	Right Soft key	Performs the task indicated above the button.
10	Back button	Press to go back to the previous screen. Press to delete in a text field.
11	End key	Press to end a call.
12	QWERTY keypad	Press to enter text, numbers, and symbols. For more information see 7-2 Entering text, numbers, and symbols .
13	Select button	The Select button acts much like the Action key. Press this button to confirm an action. When you scroll to a check box, press this button to select or clear the check box.
14	Volume controller	Press the arrow buttons to adjust the volume . Press the upper volume key to activate the voice command.
15	Earphone port	Plug headset accessory to this port .
16	Mini-USB connector	Use this connector to synchronize your data or to charge the battery .
17	Camera lens	This 2-megapixel camera comes with Auto-Macro (AM) lens and flash light features.
18	Camera flashlight	Allows you to capture images in a dim environment.
19	Speaker	Allows you to listen audio media and phone calls.

No.	Item	Description
20	Battery compartment	Contains the battery that supplies power to the device.
21	Camera button / Function Side key	<p>By default, this button is used to activate the Camera application:</p> <p>Press to launch the camera viewfinder.</p> <p>Press to take a picture if already in camera mode.</p> <p>To change the key assignment and activate other applications using this button, press Start > More > Settings > More > Key Assignment. From the dropdown list, select the application you want to activate using this button.</p>


1-3 Installing the SIM card and battery

The phone operator provides you with a Subscriber Identity Module (SIM) card that stores your mobile phone number, phone book entries, and SMS/MMS messages. Install the SIM card before you install the battery.

NOTE The SIM card usually comes embedded on a plastic card. Read the SIM card documentation before removing the SIM card. Remove any rough edges on the SIM card before you install it to the Smartphone.



To install a SIM card:

1. Remove the battery compartment cover.
2. Insert the SIM card into the slot with its nicked corner and its contacts face down.
3. Replace the battery compartment cover.



To insert the battery:

1. Align the gold metal contacts on the battery with the contacts on the phone.
2. Slide the back cover into your phone.




CAUTION Use only the battery that comes with your Smartphone package. Use of an incorrect battery type may result in injury or explosion.

1-4 Installing and removing a microSD card

To install a microSD card

1. Remove the battery compartment cover.
2. With the label side (usually the side with the card manufacturer's name) face up, and the barcode/serial number side face down, insert the card into the microSD card slot located on the right side of the phone.
3. Push the card all the way into the slot until it fits completely.



To remove the microSD card

1. Press the card slightly until it ejects. You may then safely remove the card.
2. Replace battery compartment cover.

CAUTION A microSD card fits only in one orientation, and slides smoothly into the slot if inserted correctly. DO NOT force the card into the slot.

1-5 Charging your Smartphone

WARNING Use only the charger that came with your Smartphone.


Make sure that the battery is fully charged before using the Smartphone for the first time. Initial battery charging may take about eight (8) hours. You can charge the battery when the phone is either on or off.

A battery icon on the screen indicates the battery power level. Refer to “Status indicator icons” in **2-2 Home screen** for battery icon indications.

To charge the battery



1. Connect the AC adapter to a power source.
2. Connect the power cable plug to the mini USB sync and power connector.

NOTE The power LED lights up amber to indicate that the battery is charging and lights up green when the battery is fully-charged.





1-6 Turning your Smartphone ON/OFF

To turn ON your phone

1. Press and hold **Power**  for approximately three seconds until the display turns on.
2. If you are asked for a Personal Identification Number (PIN) code, key in the code using the keypad, then press **Action** . The main display shows the idle screen.
3. Enter your PIN and press **Done**. Wait for your operator and Microsoft screens to load.

To turn OFF the phone

Do one of the following:

- Press and hold **Power**  for approximately three seconds until the Microsoft Mobile power off screen shows and wait for the display to turn off.
- Press and quickly release **Power**  and select **Power off** from the Quick List screen.

Chapter 2 Learning to Use Your Smartphone


2-1 Navigating

Your Smartphone has several keys to help you navigate through your Smartphone's screens and make selections.

Navigation pad

The navigation pad consists of four keys and provides an easy way to move or scroll through selections on the screen.

The primary use of the Up and Down navigation keys is for movement within menus and navigation through contacts. The primary use of the Left and Right keys is to change the settings and edit text.



Action key

The Action key acts much like the Enter key on a keyboard. In general, pressing the Action key on a highlighted item confirms that you want to carry out the function.

Home key

The Home key takes you to the Home screen.

Back key

The Back key takes you to the previous screen. In a text field, the Back key deletes characters to the left of the cursor.

Soft keys

The two soft keys on your Smartphone are located directly below the display screen. Each soft key performs the action displayed right above it on the soft key bar. These two soft keys are context-sensitive; that is, the function of these two keys vary depending on what you are doing.


QWERTY keypad

You can use the alphanumeric keypad to quickly select programs and settings on your Smartphone. Press the number on the keypad that corresponds to the number shown next to the program or setting that you want to select.




2-2 Home screen

The Home screen automatically displays when you turn on your Smartphone or leave it idle.

The top of the Home screen displays the six most recently-used programs. The center of the display shows the service provider, the time, your next appointment, your current profile, and the number of new text messages. Scrolling to any of these items and pressing **Action**  opens the associated program.






























NOTE Press **Home**  at any time takes you back to this screen.

To customize the Home screen (layout, color scheme, background image), press **Start > Settings > Home Screen**.



Status indicator icons


Status indicators appear at the top of the screen and on the Home screen. The following table lists common status indicators and their meanings.

	New e-mail or text message (SMS)		Signal strength		Roaming
	New instant message		No signal		3G Roaming
	Voice call		No service		3G network available
	Voice call in progress		Multipress input mode, lowercase		GPRS available
	Data call in progress		Numeric input mode		GPRS in use
	Calls are forwarded		Synchronization error		WiFi available
	Call on hold		Sound ON.		Bluetooth on
	Missed call		Ringer off		
	Battery level		Pending alarm		
	Low battery		Missing SIM card		
	Battery charging		Faulty SIM		

2-3 Start menu

Your Smartphone comes with many preinstalled programs that you can start using right away. These programs can be accessed from the Start menu.


To use the Start menu

1. On the Home screen, press **Start**.
2. Scroll to a program using the navigation keypad and press **Action** .

You can add programs to the Start menu by downloading them from the internet on your PC and using ActiveSync to copy it to your phone.

To remove programs

- Press **Start > More > Settings > More > More > Remove Programs**. Scroll to the program to remove, then press **Menu > Remove**.





NOTE


You may change the viewing layout of the Start Menu. To do this, press **Start > More > Settings > Start Menu**, and select either **Grid View** or **List View**.


2-4 Quick List

The Quick List provides quick and convenient access to a list of common commands, such as turning off the phone, locking the phone, turning off wireless capabilities, and changing the profile type.

To use the Quick List

1. Press and quickly release **Power**  to display the Quick List.
NOTE: If you press and hold too long, the phone will power off.
2. Select the command you want by scrolling to it and pressing **Action** , **Select**, or by pressing the corresponding number on the alphanumeric keypad.
3. To return to the Home screen, press **Cancel**.



QUICK LIST COMMAND	DESCRIPTION
Power off	Turns off the phone
Wireless Manager	Turns on/off the phone and/or all wireless capability.
Lock	Locks the keypad so that you cannot make accidental keypresses. To unlock the keypad, press Unlock , and then press the * key ( .
Normal / Silent / Vibrate / Outdoor / Automatic	Select to make one of these preset profiles the active one. A check indicates the current profile. To change profile settings, select a profile and press Menu > Edit .

Chapter 3 Using Call Features



3-1 Making a voice call

Calling from the Home screen

To call from the Home screen

1. On the Home screen, start entering the phone number you want to call using the QWERTY keypad.

If you entered the wrong number, press **Back**  to delete the last digit; press and hold to delete all digits.

2. Once you have entered the number, press **Call**  to make the call.
3. Press **End**  to end the call.

NOTE

As you enter a phone number, the Smartphone searches Contacts, Call History, and the Speed Dial lists to find a matching name or number. When you see the name or number of the person you want to call listed, select it using the Up/Down navigation keys.

To redial the last number called, press **Send** twice from the Home screen.

Calling a Contacts entry

To call a Contacts entry

1. On the Home screen, press **Contacts**.
2. Select the contact name to call using the Up/Down navigation keys.

NOTE To quickly find a contact in a long list of contacts, you can enter the first few letters of the contact's name to narrow the search.

3. Press **Call**  to dial the default number assigned to the selected contact.



NOTE By default, the mobile telephone number (m) of a contact is dialed when you make a call from Contacts unless you specify otherwise.

To change the default number for a Contact

1. On the Home screen, press **Contacts**.
2. Select the contact whose default phone number you want to change.
3. Use the Left/Right navigation keys to change the default number. The letter to the right of the contact's name indicates the default number — m (mobile), w (work), or h (home).

Calling a number from the Call History list

To make a call from the Call History list



1. On the Home screen, press **Call**  or press **Start > Call History**.
2. Select the number or name you want to call, and press **Call** .

Calling using speed dial

You can create speed dials for frequently-called phone numbers or frequently-accessed items by simply pressing and holding one or two keys. You may choose Speed Dial entries from 2-99. You can create a Speed Dial for a phone number, a program on the Start menu, an E-mail address, or a Web page address (URL) that is stored in Contacts and in the SIM card.

NOTE You must assign a speed dial key to a phone number before you can use the speed dial feature.

To create a speed dial for a phone number, e-mail address, or URL address

1. On the Home screen, press **Start > Contacts**.
2. Select a contact and press **Action**  to view the contact details.
3. Select the phone number, e-mail address, or URL address, for which you want to assign a speed dial and press **Menu > Add to Speed Dial**.
4. Enter appropriate details in Name, Value, and Keypad assignment. In **Keypad assignment**, use the Left/Right navigation keys to select, or press **Action**  to view the full list of choices.

NOTE To quit creating a speed dial, press **Menu > Cancel** from the Speed dial screen.

5. Press **Done**.

To make a call using speed dial

On the Home screen, press and hold the number on the keypad that you have assigned as a speed dial for a number. If the keypad assignment consists of two digits, press the first digit then press and hold the second digit.

To create a speed dial for an item on the Start menu

1. On the Home screen, press **Start**.
2. Select an item and press **Menu > Add Speed Dial**.
4. Enter appropriate details in Name, Value, and Keypad assignment . In **Keypad assignment**, use the Left/Right navigationkeys to select, or press **Action** to view the full list of choices.
5. Press **Done** .

Making emergency calls

Calls to emergency service numbers can be made under any circumstances, even if you have locked the SIM card or your phone.

To place an emergency call

Enter the emergency number appropriate for your location, and press **Call** .

Making international calls

To make international calls, you must first enter the international prefix (+), followed by the country code, area code, and phone number.


To place an international call

1. Press and hold **+** on the keypad to enter a plus sign.
2. Enter the full phone number with the country code, area code, and phone number, and then press **Call**.

3-2 Responding to a voice call

Depending on your settings, the phone rings, vibrates, or rings and vibrates when it receives an incoming call. When you receive a call, the screen displays the caller's name and phone number. If the caller is not in your Contacts list, the screen displays the number only. When you receive a phone call, you have the option to answer it or ignore it.

To answer a voice call

Press **Answer** or **Call** .

To ignore a voice call

Press **Ignore** or **End** .

NOTE

Selecting **Ignore** or **End** will send the caller to your voice mailbox if it is enabled. If it is not, the caller will hear a busy tone.


3-3 Options during a call

Listed in the table below are the possible menu options for when a call is in progress. Some of these options are available only when multiple calls are in progress or during a conference call.


IN-CALL MENU OPTION	DESCRIPTION
Hold	Places the active call on hold.
Unhold	Activates the call that is on hold. You can also press Send to activate the call that is on hold.
Mute	Switches off the microphone for the active call (you can hear the caller but the caller can't hear you).
Unmute	Turns the microphone for the active call back on.
Speakerphone On/Off	Activates/deactivates the speakerphone. NOTE: You can also press and hold Send during an active call.
Conference	Joins together all existing calls if you have subscribed to this service.
Turn Hands-free On/Off	Turn on the hands-free function.
Contacts	Opens the Contacts list.
Save to Contacts	Save the caller to the contacts.
View Calendar	Opens the Calendar program
Call History	Opens the Call History list.

Managing multiple calls

To answer another call

1. Press **Answer** to place the first call on hold and answer the second call.
2. To end the second call and return to the first call, press **End** .

To hold a call to make a second call

1. Press **Menu > hold** to place the first call on hold and call a second number. When you have finished the second call, press **End**  to take you back to the first call.

To switch between calls

To switch between two calls, press **Swap**.

To set up a conference call

With multiple calls in progress, press **Menu > Conference**.

3-4 Making a video call

During a video call, you see a live video stream of the person you are talking to in the main display and the other person can see you on as well. To be able to make a video call, you must be in the coverage of a UMTS network. For availability of and subscription to video call services, contact your network operator or service provider.

To make a video call

1. On the Home screen, start entering the phone number you want to call using the QWERTY keypad or select a contact entry from your Contacts list.
2. Once you have entered the number, press **Menu > Video call** to make the call.

When the line is connected, you can see two video images and hear the sound through the loudspeaker.

3. Press **End**  to end the call.

3-5 Responding to a video call

To answer a video call

Press **Answer**  or **Call** .

To ignore a video call

Press **Ignore**  or **End** .

NOTE To configure the settings for your video call, press **Start > More > Video Phone > General**, and make the desired video call settings.

Chapter 4 Synchronizing with ActiveSync

4-1 Microsoft ActiveSync

With ActiveSync, you can synchronize the information on your PC with the information on your Smartphone. Synchronization compares the data on your phone with your PC and updates both with the most recent information. You can also use synchronization to add new programs to your phone.

Before you can synchronize your phone with your PC, you need to complete the following steps:

1. Install ActiveSync on your PC.
2. Connect your phone to the PC.
3. Create a partnership between the two devices.

NOTE For more information about synchronization, see the ActiveSync Help on the PC.

4-2 Installing ActiveSync on your PC

The ActiveSync program is already installed on your Smartphone. To synchronize information on your phone with your PC, you must also install ActiveSync on your PC. Install ActiveSync from the Getting Started CD that comes with your product package.

NOTE Before starting the ActiveSync installation, make sure that you have Microsoft® Outlook® installed on your PC.

IMPORTANT Do not connect your phone to your PC until you have finished installing ActiveSync.


To install ActiveSync on your PC

1. Place the Getting Started CD into the optical drive of your PC and follow the on-screen instructions to install ActiveSync.
2. Click **Start Here** to display the Overview screen.
3. Click **Install ActiveSync**, then follow the on-screen instructions to complete installation.

4-3 Connecting your Smartphone to a PC

To connect your Smartphone to a PC

1. When prompted, connect the appropriate end of the USB sync cable to the mini USB and power connector at the bottom of your phone and the other end to a USB port on your PC.
2. ActiveSync will autostart when it detects your phone, and the Smartphone Sync Setup Wizard will open.



4-4 Creating a partnership

The wizard guides you through the steps to create a partnership. In the Sync Setup Wizard, you can do the following:

- Create a synchronization relationship between your PC and your phone.
- Configure an Exchange Server connection to synchronize directly with Exchange Server. To synchronize your phone with Exchange Server, obtain the name of the Exchange Server, your user name, password, and domain name from your administrator before completing the wizard.
- Choose information types (Calendar, Contacts, Tasks, Outlook E-mail, Favorites) to synchronize.

When you finish the wizard, ActiveSync synchronizes your phone automatically. Once synchronization completes, you can disconnect your phone from your PC. After the first synchronization, you will notice that the information from your PC that you selected now appears on your Smartphone.

4-5 Synchronizing with a PC

Changing information to synchronize

By default, ActiveSync does not automatically synchronize all Outlook information. You can use ActiveSync options to turn synchronization for specific information types on and off:

1. On the Home screen, press **Start > ActiveSync**.
2. Press **Menu > Options**.
3. Do one or more of the following:
 - Select the check box for the items you want to synchronize.
 - Clear the check box for any items you do not want to synchronize.
 - To customize synchronization of a PC, select the PC name then press **Menu > Settings**.
 - To customize synchronization of a particular type of information, select the information type then press **Settings**.
 - To stop synchronizing with a PC completely, select the PC name and press **Menu > Delete**.

NOTE	E-mail can be synchronized with only one PC.
-------------	--

Using USB sync cable

1. Connect your phone to a PC using the USB sync cable.
2. **ActiveSync** should detect it automatically and start synchronizing. If not, on the Home screen, press **Start > ActiveSync**.
3. Press **Sync** to start synchronizing.
4. Press **Stop** to stop synchronization before it completes.

Using Bluetooth

You can synchronize your phone with a PC using the Bluetooth wireless technology.

1. Follow the instructions in ActiveSync Help on the PC for configuring Bluetooth on your PC to support ActiveSync.
2. On the Home screen, press **Start > ActiveSync**.
3. Press **Menu > Connect via Bluetooth**. Ensure that the phone and PC are within close range.

NOTE

If this is the first time you have connected to this PC using Bluetooth, you must complete the Bluetooth wizard on the phone and set up a Bluetooth partnership with the PC before synchronizing. For more information about setting up a Bluetooth partnership, see “Creating a Bluetooth partnership” in 6-4 Using Bluetooth.

4. Press **Sync**.
5. When finished, press **Menu > Disconnect Bluetooth**. To preserve battery power, turn off Bluetooth.

4-6 Synchronizing with an Exchange Server

To set up an Exchange Server connection, you will need to get the name of the server and the server domain name from your service provider or system administrator. You must also know your Exchange user name and password.

NOTE Before you change synchronization settings on the phone, disconnect it from your PC.

1. On the Home screen, press **Start > ActiveSync > Menu > Configure Server**. If you have not yet set up sync with Exchange Server, the system displays the message **Add Server Source**.
2. In **Server address**, enter the name of the server running Exchange Server, and press **Next**.
3. Enter your user name, password, and domain name, and press **Next**.
If you want the phone to save your password so that you will not need to enter it again when connecting, select the **Save password** check box.
4. Select the check boxes for the types of information items that you want to synchronize with the Exchange Server.
5. To change available synchronization settings, select the type of information, and press **Menu > Settings**.
6. To change the rules for resolving synchronization conflicts, **Menu > Advanced**.
7. Press **Finish**.

4-7 Creating a synchronization schedule

You can create a schedule for automatically synchronizing information on your Smartphone with your PC or with Microsoft Exchange Server.

To set up a synchronization schedule with your PC, you must use ActiveSync on the PC. For more information on synchronization, see ActiveSync Help on the PC.

To set up a synchronization schedule with an Exchange server, you must use ActiveSync on your phone. See the next section for details.

Scheduling synchronization

Before changing synchronization settings on the phone, disconnect the phone from your PC.

To schedule synchronization

1. On the Home screen, press **Start > ActiveSync > Menu > Schedule**.
2. Do one or more of the following:

TO SYNC	DO THIS
Automatically as items arrive.	Under Peak times , select As items arrive . It is more cost-efficient to synchronize on at regular intervals when mail volume is high. Under Off-peak times , select As items arrive . This can be more cost-efficient than synchronizing on a regular schedule when mail volume is low.
When you are working, or e-mail volume is high.	Select an appropriately frequent interval in the Peak times list.
When e-mail volume is low.	Select a longer interval or As items arrive in the Off-peak times list.
While roaming	Select the Use above settings while roaming check box. To minimize roaming charges, clear the check box, and synchronize manually while roaming.
When you press Send in Messaging on the phone	Select the Send/receive when I click send check box.

NOTE To change peak time settings to more accurately adjust to periods of e-mail volume for you, press **Menu > Peak Times**.

4-8 Remote synchronization

Remote synchronization is when your phone is synchronized over a wireless connection instead of using a direct local connection to a PC. Synchronizing remotely with your PC may depend on your network configuration. For example, you may need to set up a virtual private network (VPN) connection to your network.

To synchronize remotely, you need to set up a connection first and then configure your phone. For more information on remote synchronization, see the ActiveSync Help on the PC.



Chapter 5 Managing Your Smartphone



5-1 Personalizing your Smartphone

Settings screens

You can view and change settings on your Smartphone to make it look and behave the way you like it. This includes changing the Home screen layout, adding your own ring tone, and set options for calls you receive, such as Call Forwarding and Call Waiting.

On the Home screen, press **Start > More > Settings** to display the Settings screen.





NOTE Select **More** from the Settings screen to display next page of Settings options, or press Left or Right on the navigation pad to display next or previous page of the Settings options.

Personalizing your Home screen

To personalize your Home screen

1. On the Home screen, press **Start > Settings > Home Screen**.
2. Make your desired changes and press **Done**.

To personalize the Home screen with your own image

1. On the Home screen, press **Start > Multimedia > Pictures & Videos**.
2. Select an image to use as the background image and press **Action**.
3. Press **Menu > Use as Home Screen**.
4. Use the **Left/Right** navigation keys to adjust the transparency and press **Finish**.

Setting the date, time, and alarm

To set the date and time

1. On the Home screen, press **Start > More > Settings > Clock and Alarm > Date and Time**.
2. Enter the Time zone, Date, and Time. To change the time from AM to PM, highlight **AM** and press the **P** key.

To set the alarm

1. On the Home screen, press **Start > More > Settings > Clock and Alarm > Alarm**.
2. Enter the correct information and press **Done**.

Changing regional settings

To change regional settings

1. On the Home screen, press **Start > More > Settings > More > More > Regional Settings**.
2. In **Language**, select your preferred language for the phone interface and menus.
3. In **Locale**, select your current location. The Locale option automatically changes the format of the remaining options, such as date, time, and currency, to reflect those used in that locale.
4. Press **Done** after you have finished making changes.

NOTE To activate the new language settings, you will need to turn the phone off and back on.

Changing profile settings

A profile determines how you get notified of events such as incoming calls, upcoming appointments, and new messages. Your current profile is displayed on the Home screen.

To quickly change the current profile

To quickly switch to a different profile, press and quickly release Power and scroll to the desired profile in the Quick List screen and press **Select**. To open the second page of the Quick List screen for more profile options, select **More**.

NOTE When profile is set to **Automatic**, your phone will automatically switch to Silent mode whenever you have a meeting set up in Calendar.

1. On the Home screen, press **Start > More > Settings > Profiles**.
2. Scroll to the profile you want to change, press **Menu > Edit**.


3. Change the settings and press **Done**.

NOTE To restore the default settings of a profile, press **Menu** and select **Reset to default**.

Setting up advanced sounds

Use the Advanced Sounds settings to customize the sounds for ring tones, notifications, reminders, alarm clock, alert, warnings, email, text message, and key tones. The phone comes with 13 preinstalled polyphonic ring tones from which you can choose.

To change the sound


1. On the Home screen, press **Start > More > Settings > Advanced Sounds**.
2. Highlight the item for which you want to change the sound.
3. Do one of the following:
 - Scroll left/right to select a different sound.
 - Press **Action**  to open the **Select an Item** screen, which allows you to select from a full list of sounds available for that event.

To use your own sound

1. Locate the sound file on your PC and copy the file.

NOTE The file must be in .wav, mid, .wma, or .mp3, .aac, .amr, or .qcp format.

2. Connect your Smartphone to your PC.
3. Open ActiveSync on your PC and click **Explore**.

4. Paste the file to any location you want on your Smartphone.
5. On the Home screen of your Smartphone, press **Start > More> Settings > Advanced Sounds**.
6. Highlight the item for which you want to use your own sound.
7. Do one of the following:
 - Press **Menu > Add Sounds** to open the **Add Sounds** screen.
 - Press **Action**  to open the **Select an Item** screen. Select **<Add Sounds>** to open the **Add Sounds** screen.
8. Locate and select the sound file on your Smartphone.
9. Press **Done** to save the changes and exit the **Advanced Sounds** screen.

Entering your contact information

The Owner Information screen is for entering and displaying personal information, such as your name, phone number, and e-mail address. Entering this information is strongly recommended as it allows the person who finds the phone to be able to contact you in case it is lost.

To enter owner information

1. On the Home screen, press **Start > More > Settings > More > More > More> Owner Information**.
2. Enter your details and press **Done**.

Assigning keypad functions

Your Smartphone comes with preinstalled programs which may have default keypad functions assigned to them. Use the Keypad Assignment settings to customize the keypad functions to open the programs you often use, or to perform shortcuts such as going back to the Home screen or launching the Quick List.

To assign keypad functions

1. On the Home screen, press **Start > More > Settings > More > Key Assignment**.
2. Select the keypad function that you want to assign to a program, then press **Done**.

Changing the Start Menu view

Use the Start Menu settings to change the viewing layout of the Start menu. You can view the Start menu either in **Grid View** or **List View**.

To change the Start Menu view

1. On the Home screen, press **Start > More > Settings > More > Start Menu**.
2. Select either **Grid View** or **List View**, then press **Done**.

Setting up the video call

Use the Video Phone settings to set up the video call settings on your Smartphone.

To set up the video call

1. On the Home screen, press **Start > More > Settings > More > Video Phone > General**.
2. In the **General** screen, you may choose to set up the following:
 - Select the **Accept without camera** option to accept a video call even when the other party does not have a camera feature on his phone.
 - In **Media in video call**, you may choose to present a picture, use the default medium, or not to use any medium.
 - In **Default audio out to**, you may choose the audio sound to be transmitted from your Smartphone. You may choose **Loudspeaker**, or **Receiver**.

Adjusting the headset volume level

Use the Headset Volume Limiter settings to adjust the volume level for your headset.

To adjust the headset volume level

1. On the Home screen, press **Start > More > Settings > More > Headset Volume Limiter**.
2. Use the left and right soft keys to decrease or increase the volume level.
3. Press **Done**.

5-2 Improving performance

Changing accessibility settings

To change accessibility settings

1. On the Home screen, press **Start > More > Settings > More > More > Accessibility**.
2. Set your preference for the following:
 - In **System font size**, set the font size to be displayed on your phone.
 - In **Multipress time out**, set the length of time to wait between keypresses when entering text in Multipress mode.
 - In **Confirmation time out**, set the delay before an unconfirmed action times out.
 - In **In-call alert volume**, set the volume for incoming call or receiving new message alerts while you are on the phone.
3. Press **Done**.

Changing power settings



Use Power Management to check the battery level and to configure power-saving settings, such as backlight and display time-outs.

1. On the Home screen, press **Start > More > Settings > More > More > Power Management**.
2. Adjust the following options:
 - In **Backlight time out on battery**, set the amount of time for the phone to be idle before the backlight turns off.
 - In **Backlight time out on AC**, set the amount of time for the phone to be idle before the backlight turns off when using AC power.
 - In **Display time out**, set the time limit for the phone to be idle before the screen turns off.
3. Press **Done**.

5-3 Turning on/off wireless mode

To turn on/off Bluetooth

Do one of the following:

- Press and quickly release **Power**  to display the Quick List screen and select **Wireless Manager**. Select **Bluetooth** and press **Action** .
- On the Home screen, press **Start > More > Settings > Connections > Bluetooth**. You may select: **Menu > Turn off Bluetooth**, **Menu > Turn on Bluetooth**, **Menu > Turn On Visibility**, or **Turn Off Visibility**.

To turn on/off radio mode

Press and quickly release **Power**  to display the Quick List screen and select **Wireless Manager**. Select **All Off** and press **Action** .

NOTE Turn off all radio interfaces of your phone when you are on an aircraft or in a hospital. You will not be able to make calls or send messages/emails but will still be able to use the organizer functions of your phone.



5-4 Keeping your Smartphone secure

Customize the level of security you want your phone to have by locking the keypad, the SIM card, or the entire phone.


Locking the keypad and multimedia player controls

To lock the keypad and multimedia player controls

You can do either of the following:

- Press and quickly release **Power**  to display the Quick List screen and select **Lock**.
- Press and hold the End key .

To unlock the keypad and multimedia player controls

Press **Unlock** followed quickly by the * key .

Locking the SIM card

Locking the SIM card prevents you and others from using the Smartphone until the correct password is entered, but you will still be able to make emergency calls. When you turn on the phone, you will be asked to enter your PIN1 password.

To lock the SIM card and set the PIN

1. On the Home screen, press **Start > More > Settings > More > Security > Enable SIM PIN**.
2. Enter the password (SIM card's PIN1), and press **Done**.

Once the PIN is enabled, your Smartphone will ask you to enter the PIN whenever you turn it on.

To unlock the SIM card

1. On the Home screen, press **Start > More > Settings > More > Security > Disable SIM PIN**.
2. Enter the password (SIM card's PIN1), and press **Done**.

To change the PIN


1. On the Home screen, press **Start > More > Settings > More > Security > Change SIM PIN**.
2. Enter the original PIN1 code.
3. Enter and confirm the new PIN, and then press **Done**.

To change PIN2

1. On the Home screen, press **Start > More > Settings > Security > Change PIN2**.
2. Enter the original PIN2 code (SIM card's PIN2).
3. Enter and confirm the new PIN2, and then press **Done**.


Locking the phone

To lock the phone

1. On the Home screen, press **Start > More > Settings > More > Security > Device Lock**.
2. Select the **Prompt if device unused for** check box by pressing **Action** .
3. Scroll down to the field below and select the amount of time for the phone to be inactive before it locks automatically.
4. In **Password type**, select the type of password you want to use.
5. Enter and confirm your password, and then press **Done**.

Controlling outgoing calls

Fixed dialing allows you to restrict your outgoing calls to selected phone numbers, if supported by your SIM card. You need the PIN2 code for this function. When this function is active, you can only call those phone numbers that are included in the fixed dialing list. Call barring, on the other hand, blocks certain types of call. Before you can use it, you must set up a Fixed dialling list.

1. On the Home screen, press **Start > More > Settings > Phone > More > Fixed Dialing**.
2. Select **Enable fixed dialing** by pressing **Action**  and then press **Done**.
3. Enter your SIM PIN 2, and press **Done**. Once fixed dialing has been turned on, you can begin to store fixed dialing numbers.
4. Press **Menu > Edit Numbers**.
5. Press **Menu > Add** and enter the phone number to add to your fixed dialing list.
6. Press **Done**.
7. Repeat steps 2 to 6 to add more numbers.

Blocking incoming/outgoing calls

Emergency calls can still be made with Call Barring on.

1. On the Home screen, press **Start > More > Settings > Phone > Call Barring**.
2. In **Block incoming calls**, select **Off**, **When roaming**, or **All calls**.
3. In **Block outgoing calls**, select **Off**, **Int'l except to home**, **Int'l calls**, or **All calls**.
4. Press **Done**.

5-5 Restarting your Smartphone

Occasionally, you may need to restart your phone; for example, when a program is not performing properly or the phone does not respond to key presses.

To restart the phone

1. Remove the battery.
2. Reinsert the battery and turn on your phone.

5-6 Resetting your Smartphone

Resetting your phone will remove all data from memory and restore the phone back to the factory default settings.

NOTE

When you reset your phone, all data you have entered in RAM, including all files, system settings, and additional programs you have installed, will be erased.

To reset your phone

1. On the Home screen, press **Start > Tools > Default Settings**.
2. Enter **1234** to confirm you want to restore default settings and press **OK**.

The phone will restart automatically after it has been reset.

5-7 Adding and removing programs

You can use ActiveSync to add programs to your phone or add a program directly from the Internet.

To add programs

1. Download the program to your PC.
2. Read any installation instructions or documentation that comes with the program. Many programs provide special installation instructions.
3. Connect your Smartphone to the PC using a USB cable.
4. Double-click the *.exe file.
 - If the executable file is an installation wizard, follow the instructions on the screen. Once the program has been installed on your PC, the wizard will automatically transfer the program to your phone.
 - If an installation wizard does not start, you will see an error message stating that the program is valid but that it is designed for a different type of PC. You will need to copy this program to your phone. If you cannot find any installation instructions for the program, use ActiveSync to copy the program file to the Program Files folder on your phone.

To remove a program

NOTE	Programs that come with the phone cannot be removed.
-------------	--

1. On the Home screen, press **Start > More > Settings > More > More > Remove Programs**.
2. Scroll to the program to remove.
3. Press **Menu > Remove**.

5-8 Managing and backing up files

There are a couple of ways to manage your files. You can use the File Explorer on your Smartphone or use ActiveSync on your PC.

You can back up files to your PC using ActiveSync or copy files to a storage card on your phone. You can also efficiently manage your files and folders using the File Explorer program on your phone. Changes you make to the information on your phone will not affect the information on your PC. If you want to automatically update information on both your phone and PC, synchronize the information instead. For more information about copying and synchronizing files, see ActiveSync Help on your PC.

To copy a file using ActiveSync

Copying a file results in separate versions of a file on your phone and PC. Because the files are not synchronized, changes made to one file will not affect the other.

1. Connect your phone to your PC using a USB cable.
2. In ActiveSync, click **Explore**.
3. Go to the file that you want to copy on your phone or PC.

4. Do one of the following:
- To copy the file to your phone, right-click the file, and click **Copy**. Right-click the desired folder on your phone, and click **Paste**.

NOTE To copy files to a storage card, insert a microSD card (see **1-4 Installing and removing a microSD card**). You can play MP3 and other media files directly from a microSD card inserted into your phone.

- To copy the file to your PC, right-click the file and click **Copy**. Right-click the desired folder on your PC, and click **Paste**.



Using File Explorer

File Explorer allows you to manage the files and folders on your phone just like you do on your PC.

To start File Explorer

- On the Home screen, press **Start > More > File Explorer**.

You can do the following on the File Explorer:

TO	DO THIS
Create a new folder	Go to where you want to create the new folder. Press Menu > Edit > New Folder . Enter a name for the new folder and press Action  .
Rename a file or folder	Select the file or folder that you want to rename, and press Menu > Edit > Rename . Enter a new name and press Action  .

TO	DO THIS
Delete a file or folder	Select the file or folder that you want to delete, and press Menu > Edit > Delete .
Beam a file	Select the file that you want to send. Press Menu > Beam . Select the device to which you want to send and press Beam .
Send a file by e-mail	Select the file to send, press Menu > Send . Select the e-mail account you want to send the file to and press Select . A new e-mail message is created with the file already attached.
Display information about a file or folder	Select the file or folder, and press Menu > Properties .
Sort files and folders	Press Menu > Sort By , and select a sort option.
Move a file or folder from one location to another	Select the file or folder that you want to move. Press Menu > Edit > Cut . Navigate to the new location and press Menu > Edit > Paste .
Duplicate a file or folder	Select the file or folder that you want to duplicate. Press Menu > Edit > Copy . Navigate to the new location and press Menu > Edit > Paste .

Chapter 6 Getting Connected

You can set up connections to the Internet and corporate network at work to do such activities as browse the Internet or intranet, send and receive emails and instant messages, and synchronize information using ActiveSync.

With an active connection, you can browse the web, download e-mails, chat using MSN Messenger, or synchronize wirelessly with the server. Check with your Internet Service Provider to see if a connection has already been set up for you, and if over-the-air configuration is supported.

6-1 Connecting to the Internet

On the Home screen, press **Start > Settings > Connections** to open the Connections screen. Connections settings allow you to set up Dial-up, Virtual Private Network (VPN), Bluetooth, Proxy, and General Packet Radio Service (GPRS) connections, so you can connect to the Internet or your corporate network.

Dial-up connection

To create a Dial-up connection

Every network connection is different. You should gather all of the relevant information or network settings you need before starting this process.

1. On the Home screen, press **Start > More > Settings > Connections > Dial-up**.
2. Press **Menu > Add**.
3. Enter the appropriate information.

NOTE In **Connects to**, select **The Internet** to connect directly to the Internet, **Work** to connect to your corporate network, **WAP Network** to connect to a Wireless Application Protocol network, or **Secure WAP Network** to connect to secure WAP sites, such as a bank.

4. Press **Done** .

GPRS, Proxy, and VPN connections

You can create GPRS, Proxy, and VPN connections using the same procedure as that for a Dial-up connection.

GPRS connection

GPRS is a high-speed transmission through the mobile phone network, which provides permanent online connection. To use GPRS to connect to the network, you need to apply for GPRS service with your Internet Service Provider.

Proxy connection

If you are connected to your ISP or private network during synchronization, your Smartphone should download the proper proxy settings from your PC. If these settings are not on your PC or need to be changed, ask your Internet Service Provider or network administrator for the proxy server name, server type, port, type of Socks protocol used, and your user name and password. A proxy connection is used to access the Internet using an existing connection to your corporate network.

VPN connection

A VPN connection helps you to securely connect to servers, such as a corporate network, using an existing Internet connection. Ask your network administrator for your user name, password, domain name, TCP/IP settings, and host name or IP address of the VPN server.

Changing option settings

The Options screen enables you to specify the number of redial attempts, time to wait before disconnecting, and how your PC connects to the network.

To access the Options screen

1. On the Home screen, press **Start > More > Settings > Connections**.
2. Press **Menu > Advanced > Menu > Options**.

Adding a URL exception

Some companies use periods in their intranet URLs (for example, intranet.companyname.com). A Work URL exception tells Internet Explorer Mobile to look on the Work network to find the URL instead of searching the Internet.

To add a URL exception

1. On the Home screen, press **Start > More > Settings > Connections**.
2. Press **Menu > Advanced > Menu > Work URL Exceptions**.
3. Press **Menu > Add**.
4. In **URL Pattern**, enter the URL, and press **Done**.

NOTE

Separate multiple URLs with a semicolon (;).

You should not create URL exceptions for URLs on the Internet.

6-2 Internet Sharing

The Internet Sharing feature enables you to use your Smartphone as an external modem for your computer to connect to the Internet. To connect your Smartphone to your PC for Internet connectivity, you can use either a USB or a Bluetooth device.

Setting up a USB connection

To set up a USB connection

1. On the Home screen, press **Start > Internet > Internet Sharing**.
2. In **PC Connection**, select **USB**.
3. In **Network Connection**, select the type of connection that your Smartphone will use to connect to the Internet.

NOTE	You must first create a network connection. Refer to 6-1 Connecting to the Internet .
-------------	--

4. Press **Connect**.
5. Connect your Smartphone to your PC using the USB sync cable. The status will change to **Connected**, and your PC is now connected to the Internet.

Setting up a Bluetooth® connection

To set up a Bluetooth® connection

1. Create a Bluetooth® partnership between your Smartphone and your computer.

NOTE	Refer to the section “Creating a Bluetooth partnership” under 6-4 Using Bluetooth® .
-------------	---

2. On the Home screen, press **Start > Internet > Internet Sharing**.
3. In **PC Connection**, select **Bluetooth PAN**.
4. In **Network Connection**, select the type of connection that your Smartphone will use to connect to the Internet.

NOTE You must first create a network connection. Refer to 6-1 Connecting to the Internet.

5. Press **Connect**.

6-3 Using Internet Explorer Mobile

You can use Internet Explorer Mobile to browse mobile favorites and channels that have been downloaded to your device without connecting to the Internet. You can also connect to the Internet through an ISP or a network connection to browse the Web.

NOTE Make sure that you have set up your Smartphone's connection. Refer to **6-1 Connecting to the Internet**.

Opening Internet Explorer Mobile

To open Internet Explorer

On the Home screen, press **Start > Internet > Internet Explorer**.

With Internet Explorer Mobile, the Favorites and History lists are displayed as the main screen instead of a home page, so you can easily go to your favorite Web sites. You can add Web sites that you visit frequently to the Favorites list.

TO	DO THIS
Change connection options	<ol style="list-style-type: none"> 1. Press Menu > Tools > Options > Connections. 2. Do one of the following: <ul style="list-style-type: none"> • To allow Internet Explorer to select network settings, select Automatically detect settings. • To manually choose network settings, in Select network, select the network to which Internet Explorer should connect.
View your Favorites list	From any Web page, press Favorites .
Go to a Web page	In Internet Explorer, press Menu > Address Bar . Enter the Web page address and press Go .
Go to a Web page in the History list	Press Menu > History . Select a Web page, and click Go .
Clear history, cookies, or temporary files	Press Menu > Tools > Options > Memory .
Add a Web page to the Favorites list	From the Web page that you want to add, press Menu > Add to Favorites .
Change the size of text on Web pages	Press Menu > View > Text Size and select the size you want.
Show or hide pictures on Web pages	Press Menu > View > Show Pictures . A check mark next to Show Pictures indicates that pictures will be displayed on Web pages.
View a page in full screen mode	Press Menu > View > Full Screen .
Exit full screen mode	Press one of the soft keys, and then press Menu > View > Full Screen to cancel the selection.
Change Web page display options	Press Menu > View . Select one of the display options.
Create a new folder in Favorites	Press Favorites > Menu > Add Folder .

Chapter 6

TO	DO THIS
Move a favorite to a folder	Press Favorites . Select the favorite to move. Press Menu > Edit . Under Folder , scroll to the folder to which you want to move the favorite and press Done .
Send a link via e-mail	Go to the Web page you want to send and press Menu > Tools > Send Link... > Outlook E-mail .

6-4 Using Bluetooth®

Bluetooth® is a short-range wireless communications technology that allows you to communicate with other devices, such as headsets, printers, PCs, GPS receivers, and other users' mobile devices. Devices with Bluetooth capabilities can exchange information without requiring a physical connection. Unlike infrared, you do not need to line up devices to exchange information through Bluetooth. The devices only need to be within a range of about 10 meters (30 feet) in an open space environment. You can even beam information to a device in a different room, as long as it is within the specified range.


Setting Bluetooth mode

By default Bluetooth is turned off. If you turn it on, and then turn off your phone, Bluetooth also turns off. When you turn on your phone again, Bluetooth turns on automatically.

To set Bluetooth mode

1. On the Home screen, press **Start > Settings > Connections > Bluetooth > Menu**.
2. Select **Turn On/Off Bluetooth, Turn On/Off Visibility** and press **Done**.

NOTE

You can also turn Bluetooth on and off by pressing and quickly releasing **Power** to access the Quick List and selecting **Wireless Manager**. Select **Settings > Bluetooth Settings** to set Bluetooth mode or select **Bluetooth** and press **Action**  to quickly toggle Bluetooth on and off.

BLUETOOTH MODE	DESCRIPTION
Turn On Bluetooth	The Bluetooth radio is turned on and you can use Bluetooth features.
Turn Off Bluetooth	The Bluetooth radio is turned off. You might want to turn the radio off at times to conserve battery power, or in situations where radio use is prohibited, like on airplanes and in hospitals.
Turn On Visibility	The Bluetooth radio is turned on, and other Bluetooth devices within range (about 10 meters) can detect your phone.
Turn Off Visibility	The Bluetooth radio is turned on, but other Bluetooth devices cannot detect your phone.

Creating a Bluetooth partnership

Before your phone can communicate with another device, you need to create a partnership between your phone and the other Bluetooth-enabled device. Your phone can create partnerships with up to 10 other Bluetooth devices.

To create a Bluetooth partnership

1. Ensure that the two devices are within close range and that both Bluetooth-enabled devices are discoverable.
2. On the Home screen, press **Start > Settings > Connections > Bluetooth**.
3. Select **Add new Device....** Your phone searches for other Bluetooth-enabled devices and displays them in the list.
4. Select the device with which you want to create a Bluetooth partnership, and press **Next**.
5. Enter a personal identification number (PIN) between 1 and 16 characters, and press **Next**.
6. Enter the same PIN on the other device.

NOTE Once you create a partnership, you don't need to **Turn on Visibility** to beam information between them. Bluetooth needs only to be turned on.

Pairing with a Bluetooth headset

1. On the Home screen, press **Start > More > Settings > Connections > Bluetooth > Menu** and select **Turn On Bluetooth** and **Turn On Visibility**.
2. Turn on your Bluetooth headset and bring it to within 10 meters of your Smartphone.
3. Put your Bluetooth headset into pairing mode. Refer to your Bluetooth headset's user manual for instructions.
4. On your phone, press **Add new device....**
5. Select the Bluetooth headset on the Add Devices list and press **Next**.
6. Enter the passkey provided in the headset user manual. The phone will now pair with the headset.
7. Set the Bluetooth mode on your phone to **On** and you are ready to talk hands free.

Listening to streaming audio with a Bluetooth headset

1. Make sure that your phone is paired with a Bluetooth headset by following the instructions in "Pairing with a Bluetooth headset."
2. On the Home screen, press **Start > More > Settings > Connections > Bluetooth** and select a Bluetooth headset in **Bluetooth Devices**.
3. Open Windows Media Players and start playing music.

TO	DO THIS
Beam information using Bluetooth	Make sure that Bluetooth is turned on and that the device that you want to beam to is discoverable. Select the item that you want to beam and press Menu > Beam [item] . Select the Bluetooth device to which you want to beam the item and press Beam .
Accept a Bluetooth partnership	Make sure that Bluetooth is turned on and that your phone is discoverable. When prompted to accept a Bluetooth partnership with the other device, press Yes . In PIN , enter a personal identification number (PIN) between 1 and 16 characters, and press Done . You must enter the same PIN that was entered on the device requesting the Bluetooth partnership.
Receive beamed information	On the Home screen, press Start > More > Settings > Connections > Beam . Select Receive incoming beams . Press Yes . To receive beams by using Bluetooth, ensure Bluetooth is turned on and that your phone is discoverable and within close range.
Rename a Bluetooth device	On the Home screen, press Start > More > Settings > Connections > Bluetooth . Select the Bluetooth device to rename and press Menu > Edit . In Name , enter a new name for the Bluetooth device, press Next , and then press Done .
Synchronize using Bluetooth	On the Home screen, press Start > More > ActiveSync > Menu > Connect via Bluetooth . See "Using Bluetooth" in 4-5 Synchronizing with a PC for more information.
End a Bluetooth partnership	On the Home screen, press Start > More > Settings > Connections > Bluetooth . Select the Bluetooth device with which you want to end the partnership and press Menu > Delete .
Specify a folder for received images from the Image server	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Images . In Default image directory , enter the desired directory for storing received images.


TO	DO THIS
Open received images from the Image server in the image viewer	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Images . Select the Open received images check box.
Save a thumbnail version of received images in the same folder as the received images	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Images . Select the Request thumbnail check box.
Configure security for Bluetooth use	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Security .
Specify a folder on your phone to share with another Bluetooth-enabled device	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > File Transfer . In Root directory , enter the path to the folder. Select the Use server authorization check box if authorization is required each time a remote client wants to connect.
Configure a Bluetooth printer	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Printer .
View the status of individual printing jobs	On the Home screen, press Start > More > Settings > Connections > Bluetooth Profiles > Printer . Press Menu > Status...

Chapter 7 Messaging

Your Smartphone is capable of composing, sending, and receiving Outlook e-mail, Internet e-mail, Multimedia Messaging Service (MMS) messages, and text messages.

7-1 Entering text, numbers, and symbols


Use the QWERTY keypad to enter text, numbers, and symbols.



Your Smartphone supports two input modes for entering text and numbers: **Multipress**, and **Numeric**. Multipress is used for entering text, and Numeric mode is used for entering numbers. When you select a field that requires text or numbers, the phone automatically selects the appropriate input mode. The status indicator on the top right side of the display screen shows the input mode that is currently active.

You may enter symbols from the QWERTY keypad or from the list of available symbols.

To change the input mode

1. Press  key on the keypad to change the input mode.


The status indicator for the selected input mode appears at the top right corner of the screen.

INDICATOR	INPUT MODE
a_bc	Multipress text input mode, lowercase
1₂3	Numeric input mode

Using Multipress mode

Multipress mode allows you to key in text by pressing keys on the keypad.

To enter uppercase texts



To enter uppercase texts, make sure that the input mode is in Multipress mode (**a_bc**), then press the  key.

To change the Multipress time out

On the Home screen, press **Start > More > Settings > More > More > Accessibility**. In **Multipress time out**, select the length of the pause between key presses.

Using Numeric mode

To enter numbers, use Numeric mode. If you need to enter a number within a line of text, change to Numeric mode to enter the number, and then change back to Multipress mode to finish entering the text.

1. If necessary, change to Numeric mode by pressing .
2. Enter the number or numbers you want using the keypad.
3. Change back to Multipress input mode by pressing  once.



NOTE

If a field permits a numeric entry only, such as a phone number, the input mode automatically defaults to Numeric mode.

Entering symbols

You may enter symbols from the QWERTY keypad or from the list of available symbols.

To enter symbols

- To enter symbols from the QWERTY keypad, short-press the  key, and press the symbol that you want to enter.
- If the symbol you want is not on the QWERTY keypad, press the  key to display the list of available symbols, then select the symbol you want to enter.

7-2 Setting up accounts

Before you can send and receive e-mails, you need to set up an e-mail account that you have with an Internet service provider (ISP) or an account that you access using a VPN server connection (typically a work account). You can send e-mail messages by synchronizing or by connecting directly to an E-mail server through your Internet service provider or a corporate network.

NOTE Before you set up an e-mail address on your Smartphone, you must have an Internet or an e-mail account.

To set up an e-mail account

1. On the Home screen, press **Start > Messaging > New E-mail Account....**
3. In **E-mail address**, enter the e-mail address for this account.
4. Select **Try to get e-mail settings automatically from the Internet**. Automatic setup attempts to download necessary e-mail server settings so that you do not need to enter them manually.
5. Follow the instructions to complete the setup.

NOTE If Automatic setup is successful, your user name is already entered and you can press **Next**, and then **Finish** to complete setting up your account, or press **Options** to access additional settings.



If Automatic setup is unsuccessful or you have an account you access using a VPN server connection, you will have to contact your ISP (Internet Service Provider) or network administrator to obtain information for entering settings manually.

7-3 Managing accounts

TO	DO THIS
View a list of accounts	On the Home screen, press Start > Messaging . A list of accounts is displayed with the number of unread messages in the Inbox of each account shown in parenthesis.
Send/receive Internet e-mail messages	On the Home screen, press Start > Messaging . Select the Internet e-mail account for which you want to send and receive messages and press Menu > Send/Receive . To stop this process, press Menu > Stop Send/Receive .
Delete an account	On the Home screen, press Start > Messaging . Select an account and press Menu > Delete .
Switch between accounts	With an account open, press Menu > Tools > Switch Accounts or use the Left/Right navigation keys to quickly switch to another account.
Changing account options	On the Home screen, press Start > Messaging . Select an account and press Select . Press Menu > Tools > Options and then select the type of option you want to change. Select Done to confirm.

7-4 Text and e-mail messages

To compose and send a text or e-mail message

1. On the Home screen, press **Start > Messaging**.
2. Select **Text Messages** or an e-mail account and press **Action**  or **Select**.
3. Press **Menu > New**.
4. In **To**, enter the mobile phone number or e-mail address of the person to which you want to send the message or press **Action**  to select the person from your contacts.

NOTE If you are sending a message to more than one recipient, separate them with a semicolon (;).

You can only send text messages to contacts with a mobile phone number.

5. Press the Down navigation key, and enter your message.
 6. When finished, press **Send** .
-

NOTE If you are working offline, e-mail messages are saved to the Outbox folder and sent the next time you connect.

TO	DO THIS
Insert a picture into an e-mail message	While composing your message, press Menu > Insert > Picture .
Insert a voice recording into an e-mail message	While composing your message, press Menu > Insert > Voice Note .
Set the priority, security, and language of an e-mail message	While composing your message, press Menu > Message Options .
Cancel a message	While composing your message, press Menu > Cancel Message .
Save a message	While composing your message, press Menu > Save to Drafts .
Delete a message	With the message you want to delete selected, press Delete .
Move a message to another folder	With the message you want to move selected, press Menu > Move . Scroll to the new folder and press Select .
Sort messages	On any account screen, press Menu > Tools > Options > Display . In Sort Messages by , select your desired sort method.
Insert a signature	On any account screen, press Menu > Tools > Options > Signatures .
Change message options	On any account screen, press Menu > Tools > Options .

Downloading e-mail messages

Use Messaging to send and receive e-mail messages in one of two ways:

- Synchronize e-mail messages with Microsoft Exchange or Microsoft Outlook on your PC
- Send and receive e-mail messages by connecting directly to an e-mail server through an Internet Service Provider (ISP) or a network

Synchronizing e-mail messages

You can e-mail messages as part of the general synchronization process. You will need to enable mail synchronization in ActiveSync. For more information on enabling mail synchronization, see the ActiveSync online help on your PC.

NOTE To connect directly to an e-mail server, see **4-6 Synchronizing with an Exchange Server**.

Managing folders

Each Messaging account has a set of five folders: Deleted Items, Drafts, Inbox, Outbox, and Sent Items. These folders store messages that you send and receive through the account. You can move a message to a different folder within the same account.

TO	DO THIS
View message folder contents	On the Home screen, press Start > Messaging . Select the account that you want to view. Press Menu > Folders and select the folder that you want to view.
Moving a message to a different folder	On the Home screen, press Start > Messaging . Select the account with the message that you want to move. Scroll to the message you want to move and press Menu > Move . Select the folder into which to move the message.

7-5 MMS messaging

MMS (Multimedia Messaging System) allows you to send text messages with multiple slides. Included on each slide can be a picture, video or audio, or text. MMS messages are sent by GPRS (General Packet Radio Service) to e-mail accounts or other MMS-enabled mobile devices.

NOTE You need to subscribe to the GPRS and MMS services with your service provider before you can send and receive MMS messages. Ask your phone operator on how to activate the MMS feature. Only mobile phones with MMS feature can send/receive MMS messages.

Depending on the service that you subscribe to, you may not be able to send and receive MMS messages to users using a different mobile phone network.

Accessing MMS

Do one of the following:

- On the Home screen, press **Start > Messaging > MMS**.
- After capturing a picture or video clip, press **Menu > Send > MMS**.





Editing MMS settings

On the MMS main screen, press **Menu > Tools > Options** to open the Preferences screen and edit MMS settings. Select or clear check boxes according to your needs.

On the MMS main screen, press **Menu > MMS Settings > MMSC Settings**, and select your Internet Service Provider from the list. Press **Menu > Edit** to access Multimedia Messaging Service Center (MMSC) settings. You should contact your mobile service operator for detail settings.

Composing and sending an MMS message

To compose and send an MMS message

1. On the Home screen, press **Start > Messaging > MMS > Menu > New**.
2. In the To: field, enter the mobile phone number or e-mail of your recipient. You can enter it using the keypad or press **Menu > Add Recipient** to select from your Contacts. If you have more than one recipient, separate them with semicommas.
3. In the Subject field, enter a subject for the message.
4. Select the Insert Picture/Video box and press **Action** . All of your pictures and video clips will be displayed in thumbnail view.
5. Select a picture or video clip and press **Action**  or **Select**.
6. Select the Insert Audio box and press **Action** . All of your available audio clips will be displayed in thumbnail view.
7. Select the audio clip you want to attach, then press **Action**  or **Select**.

NOTE You will not be able to attach an audio file to a slide with a video clip.

8. Press the Down navigation key to scroll down to the text field and enter your message.
9. Press **Send** to send the message.

Chapter 7

The following assumes that you are on the MMS message screen.

TO	DO THIS
Copy the message to other recipients	Use the Up/Down navigation keys to scroll up to display the Cc field. Enter the recipient's phone number or e-mail address or press Action to select a recipient from your Contacts list.
Hide a recipient's contact information from other message recipients	Use the Up/Down navigation keys to scroll up to display the Bcc field. Enter the recipient's phone number or e-mail address or press Action to select a recipient from your Contacts list.
Hide sender information	Press Menu > Options > Send Options . Select the Hide Sender check box.
Go to the next slide	Press the Right navigation key.
Go to the previous slide	Press the Left navigation key.
Create an MMS message from a template	Press Menu > Template > New from Templates to compose a message using a predefined template.
Create an MMS message template	Create a message or open an existing message, and press Menu > Template > Save as Templates .
Add preset or frequently used text strings to a message	In a text field, press Menu > Insert > My Text . Select the text string that you want to add and press Action or Insert .
Create or edit a preset message before adding it to the message body	In a text field, press Menu > Insert > My Text to open the My Text screen. Press Menu > Add My Text or Menu > Edit My Text .
Request message delivery notification	Press Menu > Options > Send Options . Select the Delivery Report check box.

7-6 Windows® Live

Windows® Live is an instant messaging software that is preinstalled in your Smartphone. It allows you to:

- Send and receive instant messages to your contacts who are online; and
- Access your Hotmail® account to send and receive e-mails.

To use Windows® Live, you must have a Passport account. If you have a Hotmail® or an MSN® account, you already have a Passport. Once you have obtained either a Microsoft® Passport or Microsoft® Exchange Server account, you are ready to set up your account.

NOTE You need a Microsoft® Passport account to use Windows Live® application. If you do not have a passport account, go to www.passport.com to obtain one.

Using Hotmail®

Use the Windows® Live application to access your Hotmail® mailbox and access your e-mails on your Smartphone.

To sign in Hotmail®

1. From the Home screen, press **Start > More > Windows Live**.
2. On the Windows Live - Sign In screen, press Sign in to Windows Live to enter Windows Live Setup session.
3. Press **Accept**. Then enter the e-mail address and password for your Hotmail® account.
4. Select **Save password** if you do not want to enter your password again in the future and press **Next**.

5. Select the check boxes if you want the Windows Live to show on the the Home screen.
6. Select what you want to sync on your device by checking the check boxes.
7. Sync e-mail for Hotmail account.

Using Windows® Live Messenger

To sign in and out of Windows® Live Messenger

1. Set e-mail address and password in Windows® Live.
2. When the setting is finished, from the Home screen, press **Start > More > Messenger**.
3. On the Windows® Live Messenger main screen, press **Sign In**.
4. To sign out, press **Menu > Sign Out**.

NOTE If you do not sign out of the Windows® Live Messenger application, you will remain connected. This may result in additional charges from your service provider.

Common Windows® Live Messenger features

TO	DO THIS
Add a contact	Press Menu > Add new contact , and follow the instructions on the screen.
Delete a contact	Select the contact to delete and press Menu > Contact options > Remove Contact .
Send an instant message	Select the recipient for the instant message from the displayed window at the bottom of the screen. Enter your message and press Send .

TO	DO THIS
Add other people to a conversation	From a chat session, press Menu > Options > Add participant , then select a contact.
Switch to another chat session	In the list of ongoing chats displayed at the bottom of screen, select the name of a contact with whom to chat.
Return to the contacts list	The contact list is on the left of the screen.
End a chat session	From a chat session, press Menu > End Conversation .
See all who are chatting	From a chat session, press Menu > Options > View participants .
Block someone on your Messenger contacts list from seeing and contacting you	In the Messenger contacts list, select the contact's name. Press Menu > Contact options > Block contact . The contact will no longer be able to see your status or send you messages.
Unblock a contact	In the Messenger contacts list, select the contact's name. Press Menu > Contact options > Unblock contact .
Change your status	In the Messenger contacts list, select your name. Select a status description and press Menu > Change status .
Send a voice clip	Press Voice clip to record then press Send .

NOTES for MSN Messenger service:

If your Internet service provider (ISP) only allows one connection at a time, you will meet some problems when using MSN Messenger concurrently with other applications. Such problems as described below may occur:

1. You cannot use MSN Messenger and Blackberry services on the device at the same time. If you have already activated your Blackberry service connection, and then activate MSN Messenger, MSN Messenger will always occupy the service connection.
2. If MMS uses different network setting with MSN Messenger and you use MSN Messenger first, you cannot send/receive MMS and use MSN Messenger at the same time. Hence, we recommend that you close MSN Messenger before activating any applications that require an Internet connection such as Internet Explorer, MMS, or Blackberry.

To close MSN

1. Log out from your MSN account.
2. Click the power key and choose **B** to enter **Wireless Device Manager**.
3. Close **Data Connection**.
4. To activate an application, launch **Data Connection** again. Then open your desired connection service (Internet Explorer, MMS, or Blackberry).

Chapter 8 Organizing Your Life

8-1 Using Contacts

Contacts maintains a list of your friends and colleagues so that you can easily find the information you look for, whether you are at home or on the road. Using Bluetooth on the device, you can quickly share Contacts information with other device users. If you use Outlook on your PC, you can synchronize Contacts between your phone and PC.

Viewing Contacts

To view the Contacts list, do one of the following:

- On the Home screen, press **Start > Contacts**.
- On the Home screen, press **Contacts**.

The contact list displays the names of your contacts alphabetically. Beside each name in the contact list is an abbreviation for the default communication method, such as the person's work phone number (w) or home phone number (h). If the contact information includes a work phone number, your Smartphone automatically sets it as the default number.

If there are phone numbers stored in your SIM card, the entries will be displayed at the end of the list, with a SIM card icon following the name.


TO	DO THIS
Create a new contact	On the Home screen, press Contacts > New > Outlook Contact . Enter information for the new contact and press Done .
Create a new contact on the SIM card	On the Home screen, press Contacts > New > SIM Contact . NOTE: You can only store one phone number for a SIM contact.
Edit a contact's information	On the Home screen, press Contacts . Select the contact whose information you want to edit and press Action . Press Menu > Edit . When finished making changes, press Done .
Call a contact from the contact list	On the Home screen, press Contacts . Select the contact to call and press Call . To call a phone number other than the default, select the contact, use the Up/Down navigation keys to scroll to the number you want to call, and press Call .
Send a text message to a contact	On the Home screen, press Contacts . Select the contact to which you want to send a text message and press Action . Scroll to Send Text Message .
Send an MMS message to a contact	On the Home screen, press Contacts . Select the contact to which you want to send an MMS message and press Menu > Send MMS .
Beam a contact's information to another device	On the Home screen, press Contacts . Select the contact to beam and press Menu > Send Contact > Beam . Select the device and press Beam .
Find a contact by name	On the Home screen, press Contacts . If you are not in Name view, press Menu > View By > Name . Enter the first few letters of the contact's name or the first few digits of the phone number until the contact is displayed.
Find a contact by company	On the Home screen, press Contacts . Press Menu > View By > Company . Select the company that your contact works at and press Action to see all the contacts who work there.

TO	DO THIS
Find a contact using filter	From the Contact list, press Menu > Filter . Select the category that you have assigned to the contact. To show all contacts again, select All Contacts .
Assign a ring tone to a contact	On the Home screen, press Contacts . Select the contact to which you want to assign a custom ring tone and press Action . Press Menu > Edit and scroll to Custom ring tone. Use the Left/Right navigation keys to select a ring tone and press Done . NOTE: You can only assign a ring tone to contacts who are in your Outlook Contact list.
Add a picture to a contact	On the Home screen, press Contacts . Select the contact to which you want to add a picture and press Action . Press Menu > Edit and scroll to Picture and press Action . Select an already existing picture and press Select or select Camera and take a picture to use. NOTE: You can only add a picture to contacts who are in your Outlook Contact list.

8-2 Using Calendar

Use Calendar to schedule appointments, including meetings and other events. Your appointments for the day can be displayed on the Home screen. You can also set Calendar to remind you of appointments. If you use Outlook on your PC, you can synchronize appointments between your phone and PC.

To open the Calendar program, do one of the following:

- On the Home screen, press **Start > Organizer > Calendar**.
- On the Home screen, scroll to the upcoming appointment and press **Action** .

Scheduling an appointment


To schedule an appointment

1. On the Home screen, press **Start > Organizer > Calendar**.
2. Press **Menu > New Appointment**.
3. Enter information about the appointment.
To schedule an all-day event, in **End time**, select **All day event**.
4. Press **Done**.

TO	DO THIS
Make an appointment recurring	Select the appointment and press Action . Press Menu > Edit . Scroll to Occurs and select one of the recurrence options.
Delete an appointment	Select the appointment to delete and press Menu > Delete Appointment .
Beam an appointment	Select the appointment to beam and press Action . Press Menu > Beam Appointment .

Viewing an appointment

To view an appointment

1. On the Home screen, press **Start > Organizer > Calendar**.
2. Select the appointment and press **Action** .

Viewing your schedule

You can view your schedule in your calendar in three different views: Week View, Month View, and Agenda View.

To view your schedule

1. On the Home screen, press **Start > Organizer > Calendar**.
2. Press **Menu** and then select your desired view.
 - **Week View**
 - **Month View**
 - **Agenda View**

TO	DO THIS
View today's agenda	From any Calendar view, press Menu > Go to Today .
View your agenda for a specific date	From any Calendar view, press Menu > Go to Date . Enter the date to view and press Done .
Show week numbers	From any Calendar view, press Menu > Tools > Options . Scroll to Month view and select Show week numbers .
Change the display of the work week	In any Calendar view, press Menu > Tools > Options and do the following: <ul style="list-style-type: none"> • To specify the first day of the week, in First day of week, select Sunday or Monday. • To specify the number of days you want to appear in a week, in Week view, select 5-day week, 6-day week, or 7-day week.

8-3 Using Tasks

Use Tasks to keep track of what you have to do.

The Tasks list

The task list is your “things to do” list. When you create or edit tasks with Outlook on your PC and then synchronize it with your phone, additional information, such as due date, priority, and category, may show. A task that has been marked as high priority is preceded by an exclamation mark, and one marked as low priority by a downward-pointing arrow. Overdue tasks are displayed in bold red.

NOTE You can synchronize information on your phone with your PC to keep your task list up to date in both locations.

TO	DO THIS
Create a task	On the Home screen, press Start > Organizer > Tasks . Scroll to the Enter new task here box at the top of the screen, enter the task name, and press Action .
Mark a task as completed	On the Home screen, press Start > Organizer > Tasks . Scroll to the task to mark complete, then press Complete .
Delete a task	On the Home screen, press Start > Organizer > Tasks . Scroll to the task to delete, then press Menu > Delete Task . Press Yes to confirm.
Change a completed task to incomplete	On the Home screen, press Start > Organizer > Tasks . Scroll to the completed task, then press Activate to change status to incomplete.
Find a task	On the Home screen, press Start > Organizer > Tasks . Press Menu > Sort by and select a sort option or Menu > Filter and select a category.

8-4 Using Voice Notes

You can use Voice Notes to create and play back short voice recordings and verbal reminders. Recordings are included in the All Notes list and are named consecutively Recording 1, Recording 2, and so on.

TO	DO THIS
Create a voice note	On the Home screen, pres Start > Organizer > Voice Notes . The All Notes screen is displayed. Hold the phone's microphone near your mouth. Press Record to start recording your voice note. A counter displays the number of seconds elapsed during recording. Press Stop to stop recording.
Play, rename, or delete a voice note	From the All Notes screen, select the voice note and then press Menu > Play , Menu > Rename , or Menu > Delete .
Set a voice note as a ring tone	From the All Notes screen, select the voice note to use as your current ring tone and then press Menu > Set As Ringtone . Press OK to confirm.

Chapter 9 Multimedia

9-1 Using your camera

Your Smartphone features a 2.0 megapixel built-in dual CMOS camera with flash, making it easy to take photos and record video clips with audio and sharing them with your family and friends.

Taking a picture

To take a picture

1. Do one of the following:
 - On the Home screen, press **Start > Multimedia > Camera**.
 - Press the **Camera** button on the right side of your phone.



NOTE If the camera is currently in Video mode, press the left navigation key to switch to Camera mode.

2. Press **Action** button or **Camera** button to take your picture. The picture is automatically saved in JPEG format to the location specified.

TO	DO THIS
Change the zoom factor	In Camera mode, press Menu > Zoom and select a zoom factor or press the Up/Down navigation keys.
Change the brightness	In Camera mode, press Menu > Advanced > Color Adjustment > Brightness . Press the left or right navigation keys to adjust the level of brightness. The default brightness level is 3.
Turn on the flash	In Camera mode, press Menu > Flash Mode > On .
Specify the file extension, filename prefix to use, date and time stamp, shutter sound, and burst interval	In Camera mode, press Menu > Advanced > Camera . To view the options from an item's dropdown list, select the item and press Action .
Take a series of (4 and 9 continuous) pictures	In Camera mode, press Menu > Burst .
Set the timer (5-10 seconds time lag)	In Camera mode, press Menu > Self Timer .
Take a close up picture (switch to macro mode)	In Camera mode, press Menu > Macro Mode > On to switch to macro mode.
Set a picture size to use when taking pictures for emailing	In Camera mode, press Menu > Picture Size . Select the desired size.
Change filename prefix for captured images	In Camera mode, press Menu > Advanced > Camera . In File Name Prefix , enter the desired prefix.
Save the pictures	In Camera mode, press Menu > Save to . You may save the pictures to the phone or to the storage card. Make sure that you have inserted a microSD card before choosing to save to the storage card.

Recording a video clip

To record a video clip

1. Do one of the following:
 - On the Home screen, press **Start > Multimedia > Camera**.
 - Press **Camera** button on the right side of your phone.
2. Press **Menu > Change Mode > Video Mode** and press **Done > Exit**. You can also press the right navigation key to switch the mode.
3. Press **Action**  or **Camera** button to start recording. The record indicator turns from green to red when the device starts recording.
4. Press **Action** , **Camera** button, or **Stop** to stop recording.

TO	DO THIS
Include audio clips when recording video clips	In Video mode, press Menu > Advanced > Video .
Set a video size to use when recording video clips	In Video mode, press Menu > Video Size . Select the desired size.
Change the zoom factor	In Video mode, press Menu > Zoom . Press the up/down keys to select a zoom factor.
Set video effects	In Video mode, press Menu > Effect . Select the desired effect.
Turn on the flash	In Video mode, press Menu > Flash Mode > On .
Take a close up video	In Video mode, press Menu > Macro Mode > On to switch to macro mode.
Save video clips	In Video mode, press Menu > Save to . Select if you want to save the video clips to the phone or to the storage card. Make sure that you have inserted a microSD card before choosing to save to the storage card.

9-2 Working with pictures and videos

Using Pictures & Videos


The Pictures & Videos program allows you to work with pictures or video clips on your Smartphone. After you have taken the pictures and videos, you can organize, edit, beam, as well as send them by using a messaging program.

To open the Pictures & Videos program, do one of the following:

- Press **Start > Multimedia > Pictures & Videos**.
- Press **Camera** button, then press **Thumbnails**.

TO	DO THIS
View a picture	Select the picture you want to see and press View .
Play a video clip	Select the video clip, shown as a Windows Media Player icon, you want to see and press Play .
Delete a picture or video clip	Select the picture or video clip you want to delete and press Menu > Delete .
View your pictures as a slide show	Press Menu > Play Slide Show .
Set a picture as the Home screen	Select the picture you want to use as the Home screen and press View > Menu > Use as Home Screen . Adjust the transparency and press Finish .

Chapter 9

TO	DO THIS
Edit a picture	<p>Select the picture you want to edit and press View. Press Menu > Edit, and do the following:</p> <ul style="list-style-type: none">• To rotate the picture 90 degrees, press Menu > Rotate.• To crop the picture, press Menu > Crop. Use the navigation pad to position the first corner of the cropping area and press Next. Position the second corner and press Finish. To start over, press Previous.• To automatically readjust the brightness and contrast levels of the picture, press Menu > Auto Correct. <p>Press Menu > Save As, to save the edited picture with a different name.</p>
E-mail a picture or video clip (You must already be set up to send and receive messages - see 7-2 Setting up accounts)	<p>Select the picture or video clip you want to send and press Menu > Send. Select the e-mail account you want to send the picture/video file to and press Select. A new e-mail message is created with the file attached. Enter the recipient's e-mail address, the subject, and your message, and press Send.</p>
Send a picture or video clip using MMS	<p>Select the picture or video clip you want to send and press Menu > Send. Select MMS and press Select. A new MMS message is created with the file attached. Enter the recipient's mobile phone number and the subject. Scroll down to Insert Audio (available only for pictures), press Action , and select an audio clip to attach. Scroll down to Insert Text, enter your message; and press Send.</p>
Print a picture to a Bluetooth-enabled printer	<p>Select the picture you want to print and press Menu > Print via Bluetooth.</p>
Beam a picture or video clip	<p>Select the picture or video clip you want to beam and press Menu > Beam picture... Select the device to which you want to send and press Beam.</p>

TO	DO THIS
Save to a different location	Copy and paste the file in the desired folder/location.
Set whether pictures are rotated clockwise or counter-clockwise.	Press Menu > Options > General . Select the second scroll box and use the Left/Right navigation keys to select Right (clockwise) or Left (counter-clockwise).
Set the screensaver to play when the phone is connected to a PC for more than two minutes	Press Menu > Options > Slideshow . Select the second scroll box and use the Left/Right navigation keys to select Portrait Pictures or Landscape Pictures .

9-3 Listening to music and watching videos

Use Microsoft® Windows Media™ Player Mobile for Smartphone to play digital audio and video files that are stored on your phone or on the Web. You can listen to media files through the speaker on the back of your Smartphone or through a stereo headset.

Windows Media Player Mobile can play the following types of files:

- Windows Media Audio (WMA)
- Windows Media Video (WMV)
- Motion Picture Experts Group-2 Audio Layer-3 (MP3)
- Third generation video standard H.263 baseline (3GP)

Use Microsoft Windows Media Player on your PC to copy digital audio and video to your phone.

Windows Media Player screens

Playback screen

The default screen that displays the playback controls (such as Play, Pause, Next, Previous, and Volume) and the video window. You can change the appearance of this screen by choosing a different skin.

Now Playing screen


The screen that displays the Now Playing playlist. This special playlist indicates the currently playing file and any files that are queued up to play next.

Library screen

The screen that lets you quickly find your audio files, video files, and playlists. It contains categories such as My Music, My Videos, My TV, and My Playlists.

Playing media files

To play a media file

1. On the Home screen, press **Start > Multimedia > Windows Media**.
2. Press **Menu > Library**.
3. Do one of the following:
 - To play a file from a library, select the library you want to use in the Library list and press **Action** .
 - To play a file that is not in a library, press **Menu > Open File**.
 - To play a file from the web, press **Menu > Open URL**. In **URL**, enter the Web address, or select a site you have visited before in **History**.
4. Select the file you want to play, and then press **Play**.

Playback screen options

When playback of an audio or video clip is in progress, the menu contains the following options.

OPTION	DESCRIPTION
Library	Displays the Library screen so you can choose a file to play.
Play/Pause	Play or pause playback of current file.
Stop	Stops playback. If playback is started again, it will start from the beginning of the current file.
Shuffle/Repeat	Select Shuffle to play the items in the Now Playing playlist in random order and Repeat to play the items in the Now Playing playlist repeatedly.
Full Screen	When a video is playing, it is displayed using the entire screen.
Options	Lets you adjust various Media Player options related to playback, video, network, library, skins, and hardware button assignment
Properties	Displays information about the file that is currently playing.
About	Displays information about Windows Media Player.

Playback controls

Keypad controls




Now Playing
Press to access information about the playing file

Menu
Press to access playback options

Navigation controls

Play/Pause
Press to play/pause the current file

Volume
Press up/down keys to adjust volume



Previous/Next
Press the left soft key to go back to previous file. Press the right soft key to go to the next file

9-4 Using Java (MIDlet Manager)

Your phone supports Java 2 Edition, J2ME. The Java MIDlet Manager allows you to download Java applications, such as games and utilities, that are specifically designed for mobile phones and then easily install and manage them.

To install, run, and manage MIDlet programs (MIDlets) on your phone, you have to first download the MIDlets to your device directly

Installing Java MIDlets directly from the Internet

To install Java MIDlets directly from the Internet

1. On the Home screen, press **Start > Tools > Java**. The Java screen appears.
2. Press **Menu > Install > Internet** to open Internet Explorer.
3. Locate the MIDlet/MIDlet suite while connected to the Internet.
4. Select the MIDlet/MIDlet suite to download.
5. Press **Yes** to start installing the MIDlet/MIDlet suite.
6. Press **Done** to confirm.

Installing Java MIDlets from a PC

You can install the MIDlets/MIDlet suites on your phone from a PC using the USB sync cable, or Bluetooth. MIDlets copied to your phone using infrared, Bluetooth, or e-mail attachments are automatically saved in the My Documents folder.

To install Java MIDlets from your PC

1. Download the games and utilities that you want to install on your Smartphone from your PC.
2. Open ActiveSync on your PC and click **Explore**.
3. Go to the **My Device\My Documents** or the **My Device\Storage Card** folder on your Smartphone and paste the files.
4. On the Home screen of your phone, press **Start > Tools > Java**. The esmertec Java screen appears.
5. Press **Menu > Install > Local**. A list of all MIDlets/MIDlet suites available displays.
6. Select the MIDlet/MIDlet suite to install and press **Install**.
7. Press **Yes** to install.
8. Press **Done** to confirm.

Running Java MIDlets

To run Java MIDlets

1. On the Home screen, press **Start > Tools > Java**. The phone displays a list of MIDlets.
2. Select a MIDlet, and then press **Action** .

TO	DO THIS
Uninstall a MIDlet	From the Java main screen, select the MIDlet to uninstall and press Menu > Uninstall .
Update a MIDlet	From the Java main screen, select the MIDlet to update and press Menu > Update .
Change the display name of a MIDlet	From the Java main screen, select the MIDlet to rename and press Menu > Edit .

Chapter 10 Voice Commander

10-1 Using the Voice Commander

The Voice Commander enables you to use voice commands to make phone calls and to launch applications in your Smartphone. It enables you to customize commands and personalize the digit model by adaptation.

To launch the Voice Commander, do one of the following:

- Press **Start > Tools > Voice Commander**.
- Long press the volume up button.

NOTE	For effective voice command recognition, create a voice tag for contact entries, or for applications in your Smartphone. Refer to 10-2 Using the Vocab Settings for instructions on creating voice tags.
-------------	---

Functions

The Voice Commander has several functions such as **voice name dialing**, **voice show contact**, **voice digit dial/redial/callback**, and other functions.

Voice Name Dialing

Use this function to call a contact person's home, work, or mobile number.

Usage: Call <Contact> at <Home/Work/Mobile>

Example 1: Call a person at his home.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: "Say your command"

User: "Call John Doe at home"

System: "Call John Doe at home, is this correct?"

User: "Yes"

System: "Dialing", dial to John Doe's home phone.

Example 2: Call a person with only one contact number in the system, such as his office phone number.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: "Say your command"

User: "Call John Doe"

System: "Call John Doe at work, is this correct?" <System had detected that John Doe only has an office phone number>

User: "Yes"

System: "Dialing", dial to John Doe's office number

Example 3: Call a person with multiple contact numbers.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Call John Doe”

NOTE System will display all John Doe’s contact numbers.

System: “Call John Doe, home, work, mobile, or cancel?”

User: “Home”

System: “Dialing”, dial to John Doe’s home number.

Example 4: Call a person whose name sounds exactly the same as another contact person. For example: Bryan Lee and Brian Li

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Call Bryan Lee”

System: “More than one Bryan Lee, please select”

NOTE System will show all contact persons whose names sound the same as that of the person you want to call. You can double-click on the contact person you want to call. If this contact person has more than one phone number, the system will display all of them and ask which phone number you want to call.

System: “Home, work, mobile, or cancel?”

User: Select Mobile number from the list.

System: “Dialing”, dial Bryan Lee’s mobile number

NOTES	<p>If the contact person only has one contact number, the system will automatically dial that number.</p> <p>When the system shows all the contact person’s phone numbers, you can select and double-click the selected contact number. The system will dial this number automatically.</p>
-------	---

Voice Show Contact

Use this function to ask for a contact person’s information.

Usage: Show <Contact> [at Home/at Work/at Mobile]

Example 1: Show a person’s contact information.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Show John Doe”

System: “John Doe”!

NOTE	System will show John Doe’s contact information.
------	--

Example 2: Asking for a specific information.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Show John Doe at work”

System: “John Doe, work, 0229109088”

NOTE System will show John Doe’s contact information.

Example 3: The person has no contact number.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Show John Doe at home”

System: “John Doe has no home number”

NOTE System will also show John Doe’s personal information.

Example 4: The person’s name sounds the same with that of another contact person or persons. For example: Bryan Lee and Brian Li

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Show Bryan Lee at work”

System: “More than one Bryan Lee, please select”

NOTES The system will show all the contact persons whose names sounds the same as that of the person you are inquiring about. Double-click on the contact person you want.

 If the contact person does not have the contact number you want such as his home number, the system will prompt: “<Contact> has no home number”; but the system will still show that person’s other contact information.

Voice Digit Dial/Redial/Callback

Use this function to directly voice a phone number to dial.

Usage: Digit Dial

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Digit Dial”

System: “What number?”

User: “0229109088”

System: “0229109088. Confirm, Cancel, Redial?”

NOTES If you say “**Confirm**”, the system will dial the number automatically. If you say “**Cancel**”, the system will return to the Voice Commander’s main screen and will prompt you for a command again. If you say “**Redial**”, the system will prompt for another number.

 To improve the accuracy of the digit dialer, train a personal digit adaptation model. Refer to **10-3 Using the Digit Trainer** for more details.

Usage: Redial

Use this command to dial the last outgoing call in the call history.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Redial”

System: “Call John Doe at home, is this correct?”

User: “Yes”

System: “Dialing”

Usage: Callback

Use this command to dial the last incoming number in the call history.

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Callback”

System: “Call Bryan Lee at home, is this correct?”

User: “Yes”

System: “Dialing”

Voice Start Application

Use this function to quickly launch applications in your Smartphone.

Usage:Start <Application>

1. Launch the Voice Commander and give the command.
2. The following exchange will take place:

System: “Say your command”

User: “Start Calendar”

System: “Calendar”

NOTE	The system will launch the Calendar application.
-------------	--

Today's/Tomorrow's/This week's appointments

Use this function to display your appointments in your Calendar.

Usage:Today's/Tomorrow/This week's appointments

Example: There are three appointments for today.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Today's appointments”

System: “There are 3 appointments” (The system will play every appointment's contents)

NOTE	Long press the volume up button to stop the current playback and go back to the Voice Commander's main screen.
-------------	--

Email/SMS/What time is it

Use this function to display your unread emails and SMS, and tell you the time.

Usage: Read Email / SMS

Use this command to read your e-mails and SMS.

Example: There are three unread e-mails.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Read E-mail”

System: “You have 3 e-mail” (The system will play every e-mail’s contents)

NOTE	Long press the volume up button to stop the current playback and go back to the Voice Commander’s main screen.
-------------	--

Usage: What time is it

Use this command to ask about the current time

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “What time is it?” (The system will tell you the time).

Meeting mode

Use this function to turn off your phone's ringer.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: "Say your command"

User: "Meeting mode"

NOTE The system will mute your phone's ringer.

Call History

Use this function to display your call history.

Usage: Call History

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: "Say your command"

User: "Call History"

NOTE The system will display your call history.

Voice Play Music

Use this function to play songs in your music list.

NOTE The system supports .mp3 and .wma file formats.

Usage: Play <song's file name>

Example 1: You want to assign a song playback.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Play The Moment”

System: “The Moment”

NOTE	The screen switches to play mode and plays the song.
-------------	--

Example 2: You want to assign all songs for playback.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Play music”

System: “Play music”

NOTE	The screen switches to play mode and plays all songs.
-------------	---

Example 3: You want to skip a song during playback.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: You can say “**Previous**” to play the previous song or say “**Next**” to play the next song

Example 4: You want to pause or resume playing the song.

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: You can say “**Pause**” to pause playing songs or say “**Resume**” to resume playing songs.

What can I say

Use this function if you have trouble using the Voice Commander. You can use this function to look for available voice commands

Usage: What can I say

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “What can I say”

NOTES

The system will display all the available voice commands.

You may also look for available voice commands from **Menu > Help** in the Voice Commander’s main screen.

Goodbye

Use this function to quit the Voice Commander.

Usage: Goodbye

1. Launch the Voice Commander and give the command. The following exchange will take place:

System: “Say your command”

User: “Goodbye”

System: “Goodbye”

10-2 Using the Vocab Settings

The Vocab Settings enables you to create voice tags for entries in your Contacts list, or for applications in your Smartphone. Creating voice tags makes it easier for your device to recognize voice commands.

To use the Vocab Settings

1. Press **Voice Command > Menu > Vocab Settings**.
2. Press **Menu**, then select which menu item you want to create a voice tag for. A list of available data for your chosen item is displayed. For example, if you press **Menu > Contacts**, your list of contact entries is displayed.
3. From the list, select the data you want to create a voice tag for.
4. Press **Menu > Voice Tag**, then start to record your voice. For example, when you are creating a voice tag for a contact entry, speak the name of the contact clearly.
5. Press **OK** when you are satisfied with your recording. Otherwise, press **Cancel**.

Voice Sensitivity

Your Smartphone allows you to set the level of voice sensitivity. When you speak a command to your device, your Smartphone compares your spoken command to the voice tags based on these levels of sensitivity: **Normal**, **Accurate**, and **Sensitive**.

- When set to **Normal**, your Smartphone will record voice tags without any of the background noise.
- When set to **Accurate**, your Smartphone will record voice tags exactly as you recorded them.
- When set to **Sensitive**, your Smartphone will record all sounds including background noise.

To set the level of voice sensitivity

1. Press **Voice Command > Menu > Vocab Settings**.
2. Press **Menu**, then select which menu item you want to create a voice tag for. A list of available data for your chosen item is displayed.
3. Press **Menu > Advanced Settings**. Choose the sensitivity level.
4. Press **OK** when finished.

10-3 Using the Digit Trainer

The Digit Trainer enables you to record a digit adaptation model for easy speech recognition.

To use the Digit Trainer

1. Press **Voice Command > Menu > Digit Trainer**.
2. Press **Record**, then say the digits displayed on the screen.
3. After the recording, the message “Is this utterance correct?”, appear. Press **Yes** to confirm.


Chapter 11 Other Features

11-1 WorldCard Mobile

The WorldCard Mobile is a character recognition tool that scans and identifies the printed text on a business card then automatically categorizes the information and sends it to your Contact list. Using a picture file of a business card, WorldCard Mobile analyzes the appearance of the details in the business card and converts them to editable text in your Contact list.

Using the WorldCard Mobile

To capture a business card picture file

1. Press **Start > Organizer > WorldCard Mobile**. The WorldCard Mobile screen displays.
2. Press **Capture** to take a photo of the business card you want to process.
3. Press  to save.
4. From the BCRView screen, press **Recognize**.

11-2 Task Manager





The Task Manager displays the available applications in your Smartphone, and enables you to view, close, activate, or close all applications; as well as give the resource information about an application.

To launch the Task Manager

1. From the Home screen, press **Start > Tools > Task Manager**.
2. Select the application, and press **Menu**. From the Menu selection, choose what you want to do with the application.

11-3 ClearVue Office Applications

Your Smartphone comes with preinstalled ClearVue Office applications that enables you to view documents, spreadsheets, presentations, and pdf files.

ICON	DESCRIPTION
	The Word Viewer opens a word file.
	The PDF Viewer opens a pdf file.
	The PPT Viewer opens a Powerpoint presentation file.
	The Excel Viewer opens an Excel spreadsheet file.

Word Viewer

This viewer shows documents created in Microsoft Word 97, 2000, 2002 (XP), and 2003. It can also display documents saved in Rich Text Format (.rtf).

To start this application, press **Start > Office > Word Viewer**.

PDF Viewer

This viewer displays Portable Document Format (.pdf) files.

To start this application, press **Start > Office > PDF Viewer**.

PPT Viewer

This viewer shows presentations created in Microsoft PowerPoint 97, 2000, 2002 (XP), and 2003.

To start this application, press **Start > Office > PPT Viewer**.

Excel Viewer

This viewer displays spreadsheets created in Microsoft Excel 97, 2000, 2002 (XP), and 2003..

To start this application, press **Start > Office > Excel Viewer**.

11-4 Spb® Zip

The Spb® Zip is a compression utility which enables you to zip your files to reduce your files to conserve storage space in your Smartphone.

To launch the Spb Zip

1. From the Home screen, press **Start > Tools > Spb Zip**. All your file folders will be displayed.
2. Select the files/folders to compress.
3. Press **Add to ZIP**. The compression process starts.

11-5 Default Settings

This option allows you to restore the default factory settings.


To restore default settings:

1. Press **Start > Tools > Default Settings**.
2. Enter '1234' in the Password field to confirm that you want to restore to default settings.
3. Press **Ok**.

WARNING This option will delete all files stored in this device.

11-6 Mode Switcher

Mode switcher allows you to easily switch between applications and tasks. To use the mode switcher, press the mode switcher button on your device keypad. Press again to shift between applications.



You can configure the mode switcher and define the switcher type or select items to appear in the mode switcher pop-up menu.

To define the switcher type

1. Press **Start > More > Settings > More > Mode Switcher**.
2. Press the left and right navigation keys to select the Switcher type.
3. Press the left and right navigation keys to set the switch Waiting Time.

To select items to appear in the switcher pop-up menu

1. Press **Start > Settings > More > Mode Switcher**.
2. Press **Menu > Item Settings**.
3. Use the right soft key to scroll through the items and check the boxes to select up to four applications to display on the Mode Switcher Bar.

11-7 Remote Presenter

From your Smartphone, Remote Presenter allows you to remotely control PowerPoint™ presentations running on your desktop or notebook. Operating over a Bluetooth wireless connection, it promotes convenience and freedom of movement during your presentation. It also enables you to review slide notes without affecting the audience's view of the slide show.

Using the Remote Presenter


IMPORTANT Before you start, make sure to install the Remote Presenter utility on your computer. You can find the installation files in the bundled support CD.

Remote Presenter works with Bluetooth-enabled computers only.


To use the Remote Presenter

1. Press **Start > Tools > Remote Presenter**.
2. Do the following before searching for Bluetooth devices:
 - Activate Bluetooth in your computer.
 - Launch the Remote Presenter program in your computer.


When done, press **Next**.



The following describes the Remote Presenter menu on your computer screen.



- From the list of Bluetooth devices found, select the name of computer containing your PowerPoint presentation then press **Next**.





- When requested, input the authentication passkey on your computer and your Smartphone.


NOTE

The Bluetooth authentication passkey is only required if a paired relationship is not yet established with the other device.


- From the Remote Controller menu on your computer, click **Start** to establish a connection. Press **OK** to exit reminder.




- When the connection is established, press **OK**.



- Tap the name of PowerPoint (.ppt) file to show then press **Next**.




Upon selection, Microsoft® PowerPoint is automatically launched on your computer with the selected file open.




8. You can now remotely control the PowerPoint presentation on your computer using your device. The following describes the control menu on your device.



- Click the **COM Ports** tab, then click **Add**. The **Add COM Port** screen appears.



- Select **Incoming (devices initiates the connection)**, and click **OK** when done. The newly created COM port is displayed on the list of available COM ports.



NOTE

For more information on COM ports, refer to the following websites:
<http://support.microsoft.com/kb/885365/>
<http://support.microsoft.com/kb/883258/>

Appendix Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

UL Safety Notices

Required for UL 1459 covering telecommunications (telephone) equipment intended to be electrically connected to a telecommunication network that has an operating voltage to ground that does not exceed 200V peak, 300V peak-to-peak, and 105V rms, and installed or used in accordance with the National Electrical Code (NFPA 70).

When using the Smartphone, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- **Do not use** the Smartphone near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- **Do not use** the Smartphone during an electrical storm. There may be a remote risk of electric shock from lightning.
- **Do not use** the Smartphone in the vicinity of a gas leak.

Required for UL 1642 covering primary (non-rechargeable) and secondary (rechargeable) lithium batteries for use as power sources in products. These batteries contain metallic lithium, or a lithium alloy, or a lithium ion, and may consist of a single electrochemical cell or two or more cells connected in series, parallel, or both, that convert chemical energy into electrical energy by an irreversible or reversible chemical reaction.

- **Do not** dispose the Smartphone battery pack in a fire, as they may explode. Check with local codes for possible special disposal instructions to reduce the risk of injury to persons due to fire or explosion.
- **Do not** use power adapters or batteries from other devices to reduce the risk of injury to persons due to fire or explosion. Use only UL certified power adapters or batteries supplied by the manufacturer or authorized retailers.

Checklist of Regulatory Statement

15.21

You are cautioned that any changes or modifications not expressly approved in this manual could void your authorization to use the device.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Prohibition of co-location

This device must not be co-located or operating in conjunction with any other antenna or transmitter

15.105 Federal Communications Commission (FCC) Requirements, Part 15

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Regulatory information / Disclaimers

Installation and use of this Wireless LAN device must be in strict accordance with the instructions included in the user documentation provided with the product. Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. The manufacturer is not responsible for any radio or television interference caused by unauthorized modification of this device, or the substitution of the connecting cables and equipment other than manufacturer specified. It is the responsibility of the user to correct any interference caused by such unauthorized modification, substitution or attachment. Manufacturer and its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failing to comply with these guidelines.

CAUTION: To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance 20cm between the radiator and your body. Use on the supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.

Safety Information

In order to maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance 20cm between the radiator and your body. Use only with supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.

Caution Statement of the FCC Radio Frequency Exposure

This Wireless LAN radio device has been evaluated under FCC Bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 Sections 2.1091, 2.1093, and 15.247(b)(4) addressing RF Exposure from radio frequency devices. The radiation output power of this Wireless LAN device is far below the FCC radio frequency exposure limits. Nevertheless, this device shall be used in such a manner that the potential for human contact during normal operation—as a mobile or portable device but use in a body-worn way is strictly prohibit. When using this device, a certain separation distance between antenna and nearby persons has to be kept to ensure RF exposure compliance. In order to comply with the RF exposure limits established in the ANSI C95.1 standards, the distance between the antennas and the user should not be less than 20cm.

Replaceable batteries

If an equipment is provided with a replaceable battery and if replacement by an incorrect type could result in an explosion (e.g. with some lithium batteries), the following applies:

- if the battery is placed in an OPERATOR ACCESS AREA, there shall be a marking close to the battery or a statement in both the operating and the servicing instructions;
- if the battery is placed elsewhere in the equipment, there shall be a marking close to the battery or a statement in the servicing instructions.

The marking or statement shall include the following or similar text:

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Index

A

- ActiveSync
 - Copying files 49
 - Installing 27
- Adding programs 48
- Answering calls 22

B

- Battery
 - Charging 10
- Beam
 - Bluetooth 62
 - Picture 90
 - Video clip 90
- Bluetooth
 - Beaming 62
 - Creating a partnership 60
 - Headset 61
 - Partnership 62
 - Printer 63
 - Receiving information 62
 - Renaming device 62
 - Security 63
 - Setting to Discoverable 59
 - Synchronizing 31, 62
 - Turning on/off 43, 59

C

- Calendar
 - Scheduling an appointment 82
- Call barring 47
- Calls
 - Answering 22, 25
 - Emergency 21
 - From Call History 19
 - From Contacts 19
 - From the Home screen 18
 - International 21
 - Rejecting 22, 25
 - Using speed dial 20
- Camera
 - Recording a video clip 88
 - Save to a different location 91
 - Taking a picture 86
 - Turning on the flash 87
- Charging
 - Battery 10
- Connecting
 - Internet 52
 - Phone to PC 28
- Connections
 - Dial-up 52
 - GPRS 53
 - Proxy 53
 - USB 55
 - VPN 53
- Contacts
 - Viewing 79

D

- Date
 - Setting 37
- Delete
 - Pictures 89
 - Video clips 89
- Dial-up connection 52

E

- E-mail accounts
 - Setting up 67
- E-mail messages
 - Composing 68
 - Downloading 70
 - Sending 68
 - Synchronizing 71
- Emergency calls 21
- Exchange Server
 - Synchronizing 31

F

- File Explorer
 - Beaming files 51
 - Creating folders 50
 - Deleting files 51
 - Deleting folders 51
 - Moving files 51
 - Moving folders 51

- Renaming files 50
- Renaming folders 50
- Sending a file by e-mail 51
- Starting 50
- Using 50

Files

- Copying 49
- Fixed dialing 46

H

- Home screen 14
 - Personalizing 37
 - Setting 89
 - Status indicator icons 15
- Hotmail 75

I

- Indicators
 - Status 15
- Input modes
 - Changing 65
 - Multipress mode 65
 - Numeric mode 66
- Installing
 - ActiveSync 27
 - Java MIDlets
 - From a PC 96
 - From the Internet 96
 - MicroSD card 9
 - Storage card 9
- International calls 21
- Internet
 - Connecting 52
- Internet Explorer Mobile 56
 - Changing options 57

- Internet Sharing 55
- USB connection 55

J

- Java MIDlets
 - Installing 96
 - Running 97

K

- Keypad
 - Locking 44
 - Unlocking 44

L

- Locking
 - Phone 46
 - SIM card 45

M

- Messaging
 - Changing options 68
 - Deleting accounts 68
 - E-mail 68
 - Inserting a signature 70
 - Managing accounts 68
 - Managing folders 71
 - MMS 72
 - Switching accounts 68
 - Text 68
- MicroSD card
 - Installing 9
 - Removing 9
- MIDlets
 - Running 97

- MMS messaging
 - Accessing 72
 - Editing settings 72
 - Hiding recipient 74
 - Hiding sender 74
 - My Text 74
 - Preset text 74
 - Requesting delivery notice 74
 - Sending
 - Pictures 90
 - Video clips 90
 - Using templates 74
- Multimedia player controls
 - Locking 44
 - Unlocking 44
- Multipress mode 65

N

- Numeric mode 66

P

- Partnership
 - Creating 28
- Personalizing
 - Home screen 37
- Phone
 - Locking 46
 - Resetting 47
 - Turning off 11
 - Turning on 11
- Phone settings
 - Call barring 47
 - Fixed dialing 46
- Pictures
 - Auto Correct 90

- Beaming 90
- Cropping 90
- Deleting 89
- E-mailing 90
- Rotating 91
- Saving 91
- Sending by MMS 90
- Viewing 89
- Pictures and Videos
 - Editing a picture 90
 - Viewing a picture 89
- PIN
 - Changing 45
- PIN2
 - Changing 45
- Printer
 - Configuring 63
- Profiles 17
 - Changing settings 38
- Programs
 - Adding 48
 - Calendar 82
 - Contacts 79
 - File Explorer 50
 - Creating folders 50
 - Internet Explorer Mobile 56
 - Java 96
 - Modem Link 55
 - Pictures & Videos 89
 - Pocket MSN 75
 - Removing 48
 - Tasks 84
 - Voice Notes 85
 - Windows Media Player 92
 - Controls 95

Q

- Quick List 17
- QWERTY keypad 64

R

- Rejecting calls 22, 25
- Remote synchronization 34
- Resetting
 - Phone 47

S

- Scheduling
 - Synchronization 32
- Screen
 - Settings 35
- Security
 - Bluetooth 63
- Settings
 - Date 37
 - Headset Volume Limiter 42
 - Phone
 - Call barring 47
 - Fixed dialing 46
 - Profile 38
 - Start Menu 41
 - Time 37
 - Video Phone 41
- Settings screens 35
- Setting up
 - E-mail accounts 67
- SIM card
 - Locking 45
 - Unlocking 45
- Speed dial 20
- Start menu 16

- Status indicator icons 15
- Storage card
 - Installing 9
 - Removing 9
- Symbols
 - Entering 66
- Synchronizing
 - Creating a schedule 32
 - E-mail messages 71
 - Remotely 34
 - Using Bluetooth 30
 - Using USB sync cable 30
 - With an Exchange Server 31
 - With a PC 29

T

- Tasks 84
- Text messages
 - Composing 68
 - Sending 68
- Time
 - Setting 37

U

- UL Safety Notices 127
- Unlocking
 - keypad 44
 - Multimedia player controls 44
 - SIM card 45
- URL exception 54
- USB connection 55

V

Video clips

Beaming 90

E-mailing 90

Playing 89

Sending by MMS 90

Voice Notes 85

W

Windows Live 75

Hotmail 75

Windows Live Messenger 76

Windows Media Player 92

Controls 95

Wireless Manager 4, 17

