



1.13 Remote controller

Remote controller features



- 1 Pairing key:** Press to pair the remote controller with the USB wireless adapter.
- 2 Function 1 key:** Use this key with another key to enter the specific lower right numbers, characters or actions (in orange).
- 3 Function 2 key:** Use this key with another key to enter the specific upper right numbers or characters (in white).
- 4 Caps Lock key:** Toggles the Caps Lock function on/off.
- 5 Maximize/Restore key:** maximizes / restores the computer screen.
- 6 Mode Switch key:** Switches between the mouse and scrolling functions.
- 7 Window switch key:** Mimics the standard keyboard's <Alt>+<Tab> function, which allows you to switch between windows or screens.
- 8 Navigation keys:** These keys mimic the mouse-click and scrolling functions of the standard keyboard and mouse.

To switch between mouse mode and scrolling mode, press .



Under the scrolling mode, the navigation keys can scroll up or down, left or right in documents or in webpages.



Under the scrolling mode, the up and down keys can adjust the volume of the media file that is currently playing.



Under the scrolling mode, the left and right keys can rewind/forward the media file that is currently playing.











Under the scrolling mode, the play / pause key plays or pauses the media file that is currently playing. Before using this function, set the <Enter> key as the hotkey for the Play / Pause function in your media player application.



The media function keys in the remote controller do not support Windows Media Player or Windows Media Center.

Function keys

	Increases the system volume.
	Decreases the system volume.
	Mimics the right-click function of the traditional mouse.
	Turns the power off.
	Switches to full screen or restores to original size.
	Returns to the desktop.
	Disables the system audio output.
	Closes the current window.

Using the remote controller

From a distance of up to ten meters, browse through menus, navigate the functions of your computer's media player or other functions that you normally do using the standard keyboard and mouse.


Using for the first time:

To use for the first time:

1. Insert the USB wireless adapter to your computer's USB port. The driver is installed automatically.
2. Wait for the driver installation to complete.
3. After the driver installation is completed, remove and then reinsert the USB wireless adapter to your computer's USB port.
4. Pair the remote controller and the USB wireless adapter.

Pairing the remote controller and the USB wireless adapter

To pair the remote controller and the USB wireless adapter:

1. After installing the driver, insert the USB wireless adapter to your computer's USB port.
2. Long press the pairing key  until the red LED flashes quickly, which indicates that the pairing process is completed.



- The remote controller does not work under BIOS.
- For details on using the remote controller's keys, refer to the previous section **Remote controller features**.



1 5 0 6 0 - 0 1 3 1 0 0 0 0