

ASUS Ai Gear

ASUS Ai Gear provides four system performance options that allows you to select the best performance setting for your computing needs. This easy-to-use utility adjusts the processor frequency and vCore voltage to minimize system noise and power consumption.

After installing Ai Suite from the bundled support CD, you can launch Ai Gear by double-clicking the Ai Suite icon on your Windows OS taskbar and then click the Ai Gear button on the Ai Suite main window.

Shift the gear to the performance setting that you like.

