

Motherboard user guide update

This is an information update for the user guide that came with your motherboard package.

Audio

Realtek® ALC1200, 8-channel High Definition Audio CODEC

- Supports Jack-Detecting, Multi-streaming, and Front Panel Jack-Retasking
- DTS Surround Sensation UltraPC
- Coaxial S/PDIF out ports at back I/O
- ASUS Noise-Filtering

DTS Surround Sensation UltraPC



DTS Surround Sensation UltraPC delivers exceptional 5.1 surround experience through the most common PC audio setups - your existing stereo speakers or headphones. In addition to virtual surround, “Bass Enhancement” provides stronger low frequency bass sound, and “Dialogue Clarity” provides clear human dialogue even with loud background sound. With these technologies, you may experience a better home-theatre audio with ease.

To set the DTS Surround Sensation UltraPC feature

1. Click the **Speakers** tab.
2. Click the **DTS UltraPC** sub-tab to turn on the DTS UltraPC feature.
3. Select the type of the audio source.
4. Click Advanced to display advanced surround settings.
5. Select and adjust each surround setting as needed.
6. Click Back to finish the setting.

