


## 3.2.2 Drivers menu

The drivers menu shows the available device drivers if the system detects installed devices. Install the necessary drivers to activate the devices.



### SiS IDE Driver

Installs the SiS IDE driver.

### SiS741/SiS741GX Graphic Driver

Installs the SiS741/SiS741GX graphic driver.

### AD1888 SoundMAX Driver

Installs the AD1888 SoundMAX® application and driver.

### SiS Ethernet Device Driver

Installs the SiS Ethernet device driver.

### USB 2.0 Driver

Installs the USB 2.0 driver.

### SiS 964 RAID Driver

Installs the SiS 964 RAID driver.



- This item does not automatically appear when you run the support CD. To install, browse the contents of the support CD to locate the file.
- The SiS 964 RAID driver is a **pseudo-RAID driver**. When installed, this driver does not enable RAID function. This driver is used only to enable S1/S3 wake-up when installing Windows® 98 SE/Me using a Serial ATA hard disk drive. See pages 2-23 and 2-25 for the required BIOS settings.