

OnChip SATA [Enabled]

Allows you to enable or disable the onchip SATA.
Configuration options: [Enabled] [Disabled]

SATA Mode [IDE]

Allows you to select the Serial ATA mode.
Configuration options: [IDE] [Pseudo-RAID]



When installing Windows® 98 SE/Me using a Serial ATA hard disk drive:

1. Set this item to [Pseudo-RAID] to enable S1/S3 wake-up.
 2. Install the SiS 964 RAID driver. Refer to section “3.2.2 Drivers menu” for details.
-

Serial Port1 Address [3F8/IRQ4]

Allows you to set the addresses for the onboard serial port connector.
Configuration options: [Disabled] [3F8/IRQ4] [2F8/IRQ3] [3E8/IRQ4] [2E8/IRQ3] [Auto]

Parallel Port Address [378/IRQ7]

Allows you to set the base address of the onboard parallel port connector. If you disable this field, the Parallel Port Mode and ECP DMA Select configurations are not available. Configuration options: [Disabled] [378/IRQ7] [278/IRQ5] [3BC/IRQ7]

Parallel Port Mode [ECP+EPP]

Allows you to set the operation mode of the parallel port.
Configuration options: [SPP] [EPP] [ECP] [ECP+EPP]

EPP Mode Select [EPP1.7]

Allows you to select the EPP mode. This item becomes configurable only if the **Parallel Port Mode** is set to [EPP] or [ECP+EPP].
Configuration options: [EPP1.9] [EPP1.7]

ECP Mode Use DMA [3]

Allows you to select the ECP Mode. This item becomes configurable only if the **Parallel Port Mode** is set to [EPP] or [ECP+EPP].
Configuration options: [1] [3]

Game Port Address [201]

Sets the I/O address for the game port.
Configuration options: [Disabled] [201] [209]