


ASUS Z8NR-D12 Technical Updates

This is an information update for the user guide that comes with your server system package.


2.5.10 Connect Thermal sensor cable

Follow the steps below to connect the thermal sensor cable to the connector on your motherboard.

1. Locate the TR1 or TR2 connector on the motherboard.



2. Connector the thermal sensor cable to the connector.



3. Place the other end of the thermal sensor cable to the device you would like to monitor temperature.

15G065254200