



B57UDIAG

Diagnostic Users Guide

Version 10.02 • Date 09/18/06

Prepared by: Tak Tomita
Edited by: Sean Vu, Austin Hui, Vanessa Jia

Copyright © 2000-2004 Broadcom Corporation
All Rights Reserved

No part of this document may be reproduced, in any form or by any means, without permission in writing from Broadcom Corporation.

Broadcom Corporation reserves the right to make changes to the products or information contained in this document without notice. No liability is assumed as a result of their use or application. No rights under any patent accompany the sale of any such products or information.

Epigram, InsideLine, and iLine10 are trademarks of Broadcom Corporation.

Broadcom Corporation
16125 Alton Parkway
Irvine, CA 92619-7013
www.broadcom.com

1.	INTRODUCTION	1
2.	PREREQUISITES	2
3.	FUNCTIONS LIST	3
4.	FUNCTIONS DESCRIPTION	6
4.1	c	6
4.2	cmd	6
4.3	w	6
4.4	asf	7
4.5	mba	7
4.6	mbap	7
4.7	mbas	8
4.8	firm	8
4.9	firmall	8
4.10	ver	10
4.11	pxe	10
4.12	elog	11
4.13	pipmi	11
4.14	ipmi	11
4.15	help	12
4.16	uipmi	12
4.17	dir	12
4.18	pump1	12
4.19	uump	13
4.20	u	13

4.21	pisci	13
4.22	piscicfg	13
4.23	pisciprg	14

1. Introduction

This document provides information on how to use the b57udiag DOS program on the Broadcom BCM57xx family of Gigabit Ethernet adapters.

The b57udiag program can be controlled by commands entered from the DOS prompt or a user command mode. When the b57udiag program is started without parameters, a number of diagnostic tests are executed. To enter the user command mode, use the -cmd parameter. DOS commands, described in the following sections, are entered at the DOS command line and executed without entering the user command mode.

When the user command mode is entered information for all devices in the system is displayed. The following excerpt provides an example of three devices in the system:

```

C Brd:Rv  Bus/Dev PCI  Spd  Base  IRQ  EEP      MAC          Fmw      Configuration
- - - - -
0 5703:A3  03:09:0  32  33   D580   11  128K  00101801026C  5703-c2.33  Mr,auto
1 5703:A3  03:0A:0  32  33   D990   5   128K  00101801026C  5703-c2.33  Mp,auto
2 5703:A3  05:05:0  32  33   E400   10  128K  00101801026C  5703-c2.33  Mb,auto

0:>setwol -e all

0:>device
C Brd:Rv  Bus/Dev PCI  Spd  Base  IRQ  EEP      MAC          Fmw      Configuration
- - - - -
0 5703:A3  03:09:0  32  33   D580   11  128K  00101801026C  5703-c2.33  WMp,auto
1 5703:A3  03:0A:0  32  33   D990   5   128K  00101801026C  5703-c2.33  WMp,auto
2 5703:A3  05:05:0  32  33   E400   10  128K  00101801026C  5703-c2.33  WMp,auto

```

In the example above, the Configuration column indicates the protocol used as the boot agent. The following protocols are supported.

- PXE: indicated by 'p'
- RPL: indicated by 'r'
- BOOTP: indicated by 'b'

2. Prerequisites

OS: DOS 6.22

Software: b57udiag.exe.

Input File List: The following files should be found in the same location of the b57diag.

ee57xyyy.yy (TX & RX CPUs Firmware file, xx chip type, yy version number)

eprom.bin (Serial EEPROM/FLASH config input file)

cpu.bin, cpu05.bin, cpu14a.bin, cpu14b.bin or cpusj.bin (CPU Instruction test)

cpudiag.bin or cpudg05.bin (CPU Accessing test)

flshdiag.bin, flashdg05.bin flashdg 14a.bin, flashdg 14b.bin, flashdgsj.bin,
flahdg5x.bin

ump14a.bin or ump14b.bin

config.sys (not required for EFI)

himem.sys (not required for EFI)

3. Functions List

Functions: cmd:

User Command Mode commands

upgfrm	Upgrade PXE or Boot Code from a file
dir	Display file directory in NVRAM
setwol	Enable/Disable WOL
setpxe	Enable/Disable PXE
setasf	Enable/Disable ASF
setmba	Enable Multiple Boot Agent
setipmi	Enable/Disable IPMI
nictest	Run a set of Ethernet Adapter Tests
exit	Exit from command mode
device	Show or switch device
version	Display program version
help	Display available commands
dos	Transfer to DOS prompt
reset	Reset chip
cls	Clear screen
asfprg	Program ASF firmware into NVRAM (3 bin files format)
pasf	Program ASF firmware into NVRAM (1 bin files format)
iscsiprg	Upgrade iSCSI Code from a file

Dos Prompt commands

-c <num>	Specify adapter to be test and/or modify
-cmd	Enter user command mode
-w <value>	Enable/Disable (value = 1/0) WOL in manufacture mode
-asf <value>	Enable/Disable (value = 1/0) ASF in manufacture mode
-mba <value>	Option to enable/disable MBA protocol 0. Disable 1. Enable
-mbap <value>	Option to select MBA protocol 0. PXE 1. RPL 2. BOOTP
-mbas <value>	Option to select MBA speed 0. auto 1. 10HD 2. 10FD 3. 100HD 4. 100FD 6. 1000FD (fiber)
-firm <file>	The feature is used to execute a field upgrade of bootcode firmware. The bootcode firmware is programmed into a/the device/s of a system if there is a match of the PCI DID, VID, SDID & SVID of firmware and device.
-firmall <file>	Update devices NVRAM based on <file> image match to HW The feature is used to execute a field upgrade of entire NVRAM image. The new NVRAM image is programmed into a/the device/s of a system if there is a match of the PCI DID, VID, SDID & SVID

- of firmware and device. Media Manufact Region and Media VPD Block in NVRAM will be preserved. If the Advance Firmware, such as ASF and IPMI, is present, the Configuration Block of the firmware will also be preserved. Three addition command line parameters, “-updateasfcfg”, “-updatesecfg”, “-updateiscsicfg” and “-sil”, can be used along with “-firmall” command.
- updateasfcfg Update the advance firmware configuration block of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updateasfcfg” command line parameter is entered before “-firmall” command, the Advance Firmware Configuration Block of the NVRAM will not be preserved. It will get updated by the input file of “-firmall” command. The “-firmall” command is described above.
 - updatesecfg Update the Media Manufact Region and Media VPD Block, of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updatesecfg” command line parameter is entered before “-firmall” command, the Meida Manufact Region and Media VPD Block of the NVRAM will not be preserved. They will get updated by the input file of “-firmall” command. The “-firmall” command is described above.
 - updateiscsicfg Update the ISCSI firmware configuration block of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updateiscsicfg” command line parameter is entered before “-firmall” command, the ISCSI Firmware Configuration Block of the NVRAM will not be preserved. It will get updated by the input file of “-firmall” command. The “-firmall” command is described above.
 - ver Version of the current software/eeprom.bin
 - pxe <file> Programming PXE firmware from file
 - elog <file> Produces a log file with only error information
 - pipmi <file> Programming IPMI firmware from <file>
 - ipmi <value> Enable/Disable (value=0/1) IPMI in manufacture mode
 - uipmi <file> Upgrading IPMI firmware from file if IPMI firmware is originally loaded.
 - dir Display file directory in NVRAM
 - pump1 <file> Programming UMP firmware from file
 - uump <file> Upgrading IPMI firmware from file if UMP firmware is originally loaded.
 - u <value> Enable/Disable (value = 1/0) UMP in manufacture mode.
 - piscsi Option to program iSCSI code into the NVRAM
 - piscsicfg Option to force program iSCSI CFG code into NVRAM
It should be used along with -piscsi.
 - piscsiprg Option to force program iSCSI PRG code into NVRAM
It should be used along with -piscsi.
 - disableeswitch Disable the E-Switch on the device that support eswitch, such as 5756. Without this option, PHY loopback test, external loopback test (pkttest -e), and carrier test are performed on both laptop mode

and docking mode. With this option, above tests are performed on the default port.

-help Display commands help

4. Functions Description

4.1 c

cmd: -c

Description: Specify adapter to be tested and/or modified.

Syntax: [-]c devnum

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The syntax for devnum is as followed:

<d [,d]... | all>

Where d is the device number 0 to number of devices – 1. For example, if you have three devices in the system, the valid device number is 0, 1, or 2.

Example:

From DOS prompt:

```
C:\>b57udiag -c 0 ; test device 0
C:\>b57udiag all ; test all devices found in the system
```

4.2 cmd

cmd: -cmd

Description: Enter command mode

Syntax: [-]cmd

Example:

From DOS prompt:

```
C:\>b57udiag -cmd
```

4.3 w

cmd: -w <value>

Description: enable/disable WOL (value = 1/0)

Syntax: [-]w <value> -c <devnum>

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

Example:

From DOS prompt:

```
C:\>b57udiag -w 1 -c 0
```

4.4 asf

cmd: -asf <value>

Description: enable/disable ASF (value = 1/0)

Syntax: [-]w <value> -c <devnum>

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

Example:

From DOS prompt:

```
C:\>b57udiag -asf 1 -c 0
```

4.5 mba

cmd: -mba <value> (value = 0 for Disable, 1 for Enable)

Description: enable/disable Multiple Boot Agent

Syntax: [-]mba <value> -c <devnum>

Example:

From DOS prompt:

```
C:\>b57udiag -mba 1 -c 0
```

4.6 mbap

cmd: -mbap <value> (value = 0 for PXE, 1 for RPL, 2 for BOOTP)

Description: Set MBA Protocol

Syntax: [-]mbap <value> -c <devnum>

Example:

```
C:\>b57udiag -mbap 0 -c 0
```

Set PXE for device 0

4.7 mbas

cmd: -mbas <value> (value = 0 for auto, 1 for 10HD, 2 for 10FD, 3 for 100HD, 4 for 100FD, 6 for 1000FD – fiber only)

Description: Set PXE speed.

Syntax: [-]mbas -c <devnum>

Example:

```
C:\>b57udiag -mbas 0 -c 0
```

Set PXE speed to auto for device 0

4.8 firm

cmd: -firm <file name>

Description: The feature is used to execute a field upgrade of bootcode firmware. The bootcode firmware is programmed into a/the device/s of a system if there is a match of the PCI DID, VID, SDID & SVID of firmware and device.

Syntax: [-]firm -c <devnum>

Example:

```
C:\>b57udiag -firm ee5704c2.24 -c 0
```

Upgrade eeprom.bin on device 0

4.9 firmall

cmd: -firmall <file>

Description: Update devices eeprom based on <file> image match. Only MAC addr will be preserved

Syntax: [-]firmall <file>

Example:

```
C:\>b57udiag -c 0 -firmall eeprom.bin
```

Upgrade eeprom on device 0, if device ID embedded in eeprom.bin matches with device 0

4.10 updateasfcfg

cmd: - updateasfcfg

Description: Update the advance firmware configuration block of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updateasfcfg” command line parameter is entered before “-firmall” command, the Advance Firmware Configuration Block of the NVRAM will not be preserved. It will get updated by the input file of “-firmall” command. The “-firmall” command is described above.

Syntax: [-]updateasfcfg

Example:

```
C:\>b57udiag -c 0 -firmall eeprom.bin -updateasfcfg
```

Upgrade eeprom on device 0, if device ID embedded in eeprom.bin matches with device 0. ASF Configuration block will be update according to the eeprom.bin.

4.11 updatesecfg

cmd: - updatesecfg

Description: Update the Media Manufact Region and Media VPD Block, of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updatesecfg” command line parameter is entered before “-firmall” command, the Meida Manufact Region and Media VPD Block of the NVRAM will not be preserved. They will get updated by the input file of “-firmall” command. The “-firmall” command is described above.

Syntax: [-]updatesecfg

Example:

```
C:\>b57udiag -c 0 -firmall eeprom.bin -updatesecfg
```

Upgrade eeprom on device 0, if device ID embedded in eeprom.bin matches with device 0. The Media Manufact Region block will be update according to the eeprom.bin.

4.12 updateiscsicfg

cmd: - updateiscsicfg

Description: Update the ISCSI firmware configuration block of NVRAM with that of the NVRAM image provided by “-firmall” command. When “-updateiscsicfg” command line parameter is entered before “-firmall” command, the ISCSI Firmware Configuration Block of the NVRAM will not be preserved. It will get updated by the input file of “-firmall” command. The “-firmall” command is described above.

Syntax: [-]updateiscsicfg

Example:

```
C:\>b57udiag -c 0 -firmall eeprom.bin -updateiscsicfg
```

Upgrade eeprom on device 0, if device ID embedded in eeprom.bin matches with device 0. The ISCSI Configuration block will be update according to the eeprom.bin.

4.13 ver

cmd: -ver

Description: Display B57UDIAG version and all devices installed.

Syntax: [-]-ver

Example:

```
C:\>b57udiag -vev
```

4.14 pxe

cmd: pxe <file name>

Description: Program PXE firmware with <file name> specified.

Syntax: [-]pxe <file name>

Example:

```
C:\>b57udiag -pxe b57pxe.bin -c 0
```

Program PXE code on device 0

4.15 elog

cmd: -elog <file name>

Description: Pipe error message to file.

Syntax: [-]elog <file name>

Example:

```
C:\>b57udiag -elog error.txt
```

```
All error message is pipe to error.txt file.
```

4.16 pipmi

cmd: -pipmi <file>

Description: Program IPMI firmware from <file>.

Syntax: [-]pipmi

Example:

```
C:\>b57udiag -c 0 -pipmi pt5721c6.09
```

```
Program IPMI code for 5721 device 0
```

4.17 ipmi

cmd: -c 0 -ipmi <value>

Description: Enable/Disable IPMI

Syntax: [-]ipmi

Example:

```
C:\>b57udiag -ipmi 1
```

```
Enable IPMI on device 0
```

4.18 help

cmd: -help

Description: Display commands help.

Syntax: [-]help

Example:

```
C:\>b57udiag -help
```

Commands help is displayed.

4.19 uipmi

cmd: -c 0 -uipmi <file>

Description: Upgrading IPMI firmware from file if IPMI firmware is originally loaded

Syntax: [-]uipmi

Example:

```
C:\>b57udiag -uipmi impi.bin
```

4.20 dir

cmd: -c 0 dir

Description: Display file directory in NVRAM

Syntax: [-]dir

Example:

```
C:\>b57udiag -dir
```

4.21 pump1

cmd: -pump1 <file>

Description: Program UMP firmware from file

Syntax: [-]pump1

Example:

```
C:\>b57udiag -pump1 ump.bin
```

4.22 uump

cmd: -pump1 <file>

Description: Upgrading UMP firmware from file if UMP firmware is originally loaded

Syntax: [-]uump

Example:

```
C:\>b57udiag -uump ump.bin
```

4.23 u

cmd: -u <file>

Description: Enable/Disable (value = 1/0) UMP in manufacture mode

Syntax: [-]u

Example:

```
C:\>b57udiag -u
```

4.24 piscsi

cmd: -piscsi <file>

Description: Program iSCSI firmware from file

Syntax: [-]piscsi

Example:

```
C:\>b57udiag -c 0 -piscsi iscsi.bin
```

4.25 piscsicfg

cmd: -piscsicfg

Description: Force program iSCSI CFG firmware from file. It should be used along with -piscsi

Syntax: [-]piscsicfg

Example:

```
C:\>b57udiag -c 0 -piscsi iscsi.bin -piscsicfg
```

4.26 piscsiprg

cmd: -piscsiprg

Description: Force program iSCSI PRG firmware from file. It should be used along with -piscsi

Syntax: [-]piscsiprg

Example:

```
C:\>b57udiag -c 0 -piscsi iscsi.bin -piscsiprg
```

4.27 disableeswitch

cmd: -disableeswitch

Description: Disable the E-Switch on the device that support eswitch, such as 5756. Without this option, PHY loopback test, external loopback test (pkttest -e), and carrier test are performed on both laptop mode and docking mode. With this option, above tests are performed on the default port..

Syntax: [-]disableeswitch

Example:

```
C:\>b57udiag -c 0 -disableeswitch
```