

M4A78-EM/1394



Motherboard

E4623

First Edition V1

April 2009

Copyright © 2009 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK Computer Inc. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

| | |
|---|------|
| Notices..... | vi |
| Safety information | vii |
| About this guide | vii |
| M4A78-EM/1394 specifications summary..... | ix |
| Chapter 1: Product introduction | |
| 1.1 Welcome! | 1-1 |
| 1.2 Package contents..... | 1-1 |
| 1.3 Special features..... | 1-1 |
| 1.3.1 Product highlights | 1-1 |
| 1.3.2 Innovative ASUS features..... | 1-3 |
| 1.4 Before you proceed | 1-5 |
| 1.5 Motherboard overview | 1-6 |
| 1.5.1 Placement direction | 1-6 |
| 1.5.2 Screw holes | 1-6 |
| 1.5.3 Motherboard layout | 1-7 |
| 1.5.4 Layout contents..... | 1-7 |
| 1.6 Central Processing Unit (CPU) | 1-8 |
| 1.6.1 Installing the CPU | 1-8 |
| 1.6.2 Installing the heatsink and fan | 1-10 |
| 1.7 System memory | 1-11 |
| 1.7.1 Overview | 1-11 |
| 1.7.2 Memory configurations..... | 1-12 |
| 1.7.3 Installing a DIMM | 1-16 |
| 1.7.4 Removing a DIMM | 1-16 |
| 1.8 Expansion slots..... | 1-17 |
| 1.8.1 Installing an expansion card | 1-17 |
| 1.8.2 Configuring an expansion card | 1-17 |
| 1.8.3 PCI slots..... | 1-17 |
| 1.8.4 PCI Express x1 slot..... | 1-17 |
| 1.8.5 PCI Express x16 slot..... | 1-17 |
| 1.9 Jumpers | 1-18 |
| 1.10 Connectors | 1-19 |
| 1.10.1 Rear panel ports | 1-19 |
| 1.10.2 Internal connectors | 1-22 |

Contents

| | | |
|-------------------|---|-------------|
| 1.11 | Software support..... | 1-29 |
| 1.11.1 | Installing an operating system | 1-29 |
| 1.11.2 | Support DVD information | 1-29 |
| Chapter 2: | BIOS information | |
| 2.1 | Managing and updating your BIOS | 2-1 |
| 2.1.1 | ASUS Update utility | 2-1 |
| 2.1.2 | ASUS EZ Flash 2 utility..... | 2-2 |
| 2.1.3 | ASUS CrashFree BIOS 3 utility | 2-3 |
| 2.2 | BIOS setup program | 2-4 |
| 2.2.1 | BIOS menu screen..... | 2-5 |
| 2.2.2 | Menu bar..... | 2-5 |
| 2.2.3 | Navigation keys..... | 2-5 |
| 2.2.4 | Menu items | 2-6 |
| 2.2.5 | Submenu items | 2-6 |
| 2.2.6 | Configuration fields | 2-6 |
| 2.2.7 | Pop-up window | 2-6 |
| 2.2.8 | Scroll bar..... | 2-6 |
| 2.2.9 | General help | 2-6 |
| 2.3 | Main menu | 2-7 |
| 2.3.1 | System Time | 2-7 |
| 2.3.2 | System Date | 2-7 |
| 2.3.3 | Primary IDE Master/Slave, SATA 1/2/3/5/6, E-SATA..... | 2-7 |
| 2.3.4 | SATA Configuration | 2-8 |
| 2.3.5 | System Information | 2-8 |
| 2.4 | Advanced menu | 2-9 |
| 2.4.1 | JumperFree Configuration | 2-9 |
| 2.4.2 | CPU Configuration | 2-11 |
| 2.4.3 | Chipset..... | 2-11 |
| 2.4.4 | Onboard Devices Configuration | 2-13 |
| 2.4.5 | PCI PnP | 2-13 |
| 2.4.6 | USB Configuration | 2-14 |
| 2.5 | Power menu..... | 2-14 |
| 2.5.1 | Suspend Mode..... | 2-15 |
| 2.5.2 | ACPI 2.0 Support | 2-15 |

Contents

| | | |
|------------|-----------------------------------|-------------|
| 2.5.3 | ACPI APIC Support | 2-15 |
| 2.5.4 | APM Configuration | 2-15 |
| 2.5.5 | HW Monitor Configuration | 2-16 |
| 2.6 | Boot menu | 2-16 |
| 2.6.1 | Boot Device Priority | 2-17 |
| 2.6.2 | Boot Settings Configuration | 2-17 |
| 2.6.3 | Security | 2-17 |
| 2.7 | Tools menu | 2-19 |
| 2.7.1 | ASUS EZ Flash 2 | 2-19 |
| 2.7.2 | Express Gate | 2-19 |
| 2.7.3 | AI NET 2 | 2-19 |
| 2.8 | Exit menu | 2-20 |

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://green.asus.com/english/REACH.htm>.



DO NOT throw the motherboard in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.



DO NOT throw the mercury-containing button cell battery in municipal waste. This symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.

Safety information

Electrical safety

- To prevent electric shock hazard, disconnect the power cable from the electric outlet before relocating the system.
- When adding or removing devices to or from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the motherboard, ensure that all power cables are unplugged.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operation safety

- Before installing the motherboard and adding devices on it, carefully read all the manuals that came with the package.
- Before using the product, ensure that all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Do not place the product in any area where it may become wet.
- Place the product on a stable surface.
- If you encounter technical problems with the product, contact a qualified service technician or your retailer.

About this guide

This user guide contains the information you need when installing and configuring the motherboard.

How this guide is organized

This guide contains the following parts:

- **Chapter 1: Product introduction**
This chapter describes the features of the motherboard and the new technology it supports.
- **Chapter 2: BIOS information**
This chapter tells how to change system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

Conventions used in this guide

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Instructions that you **MUST** follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. ASUS websites

The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS contact information.

2. Optional documentation

Your product package may include optional documentation, such as warranty flyers, that may have been added by your dealer. These documents are not part of the standard package.

Typography

Bold text

Italics

<Key>

<Key1>+<Key2>+<Key3>

Indicates a menu or an item to select.

Used to emphasize a word or a phrase.

Keys enclosed in the less-than and greater-than sign means that you must press the enclosed key.

Example: <Enter> means that you must press the Enter or Return key.

If you must press two or more keys simultaneously, the key names are linked with a plus sign (+).

Example: <Ctrl>+<Alt>+<D>

M4A78-EM/1394 specifications summary

| | |
|-----------------------|---|
| CPU | <p>AMD® Phenom™ X4 / Phenom™ X3 / Athlon™ X2 / Athlon™ / Sempron™ processors (socket AM2+/AM2) Compatible with Phenom™ II / Athlon™ X4 / Athlon™ X3 / Athlon™ X2 processors (AM3 CPU) Supports 45nm CPU AMD Cool 'n' Quiet™ 2.0 Technology (depends on CPU type) Supports CPU up to 125W * Refer to www.asus.com for the AMD CPU support list</p> |
| Chipset | AMD® 780G / SB710 |
| Front side bus | <p>Up to 5200MT/s HyperTransport™ 3.0 interface for AM3 / AM2+ CPU 2000 / 1600MT/s for AM2 CPU</p> |
| Memory | <p>Dual channel memory architecture</p> <ul style="list-style-type: none"> - 4 x 240-pin DIMM sockets support unbuffered ECC and non-ECC 1200(O.C.)/1066/800/667 MHz DDR2 memory modules - Supports up to 16GB system memory <p>* DDR2 1200(O.C.)/1066 is supported by AM2+ / AM3 CPU only. ** We recommend that you install the DDR2 1200 memory modules on the yellow slots for better performance. *** Refer to www.asus.com or this user manual for the Memory QVL (Qualified Vendors List). **** When you install a total memory of 4GB capacity or more, Windows® 32-bit operating system may only recognize less than 3GB. We recommend a maximum of 3GB system memory if you are using a Windows® 32-bit operating system.</p> |
| Graphics | <p>Integrated ATI Radeon™ HD 3200 GPU Supports HDMI™ with max. resolution up to 1920x1200 (1080P) Supports DVI-D (HDCP compliant) with max. resolution up to 2560x1600@60Hz dual-link Supports RGB with max. resolution up to 2048x1536@85Hz Supports Hybrid CrossFireX™ (for Windows® Vista only) Dual VGA output supports: RGB & DVI RGB & HDMI Maximum shared memory up to 256MB * Refer to www.amd.com for the discrete GPUs which support Hybrid CrossFireX™. ** The minimum system requirements of playing HD-DVD and Blu-ray disc: Graphics shared memory of 256MB / Dual-Core CPU / 1GB dual-channel DDR2 667 or single-channel DDR2 800</p> |

(continued on the next page)

M4A78-EM/1394 specifications summary

| | |
|-----------------------------------|--|
| Expansion slots | 1 x PCIe x16 slot 1 x PCIe x1 slot 2 x PCI slots |
| Storage / RAID | AMD® SB710 southbridge: <ul style="list-style-type: none"> - 1 x UltraDMA 133/100/66 connector - 5 x Serial ATA 3Gb/s connectors support RAID 0, RAID 1, and RAID 0+1 configurations (for Windows® Vista only) - 1 x eSATA 3Gb/s port supports JBOD |
| Audio | Realtek® ALC887 High Definition Audio 8-channel CODEC Supports Jack-detect and Multi-streaming technologies Supports S/PDIF_OUT interface |
| USB | Supports up to 12 USB 2.0/1.1 ports (6 ports at mid-board, 6 ports at the back panel) |
| LAN | PCIe Gigabit LAN |
| ASUS special features | ASUS Q-Fan ASUS CrashFree BIOS3 ASUS EZ Flash2 ASUS MyLogo2 ASUS Express Gate ASUS AI NET2 ASUS EPU-4 Engine ASUS Turbo Key |
| ASUS overclocking features | SFS (Stepless Frequency Selection) from 200MHz to 550MHz at 1MHz increment ASUS C.P.R. (CPU Parameter Recall) |
| Back panel I/O ports | 1 x PS/2 Keyboard / Mouse Combo port 1 x Optical S/PDIF_OUT port 1 x IEEE 1394a port 1 x VGA port 1 x HDMI port 1 x DVI port 1 x eSATA port 1 x LAN (RJ-45) port 6 x USB 2.0/1.1 ports 8-channel audio ports |

(continued on the next page)

M4A78-EM/1394 specifications summary

| | |
|-------------------------|--|
| Internal I/O connectors | 3 x USB 2.0 connectors support additional 6 USB 2.0 ports 1 x IDE connector 1 x COM connector 1 x LPT connector 1 x IEEE 1394a connector 5 x SATA connectors 1 x High definition front panel audio connector 1 x CD audio-in connector 1 x S/PDIF out connector 1 x CPU fan connector 1 x Power fan connector 1 x Chassis fan connector 1 x System panel connector 1 x 24-pin EATX power connector 1 x 4-pin ATX 12V power connector |
| BIOS | 8Mb Flash ROM, AMI BIOS, PnP, DMI v2.0, WfM2.0, ACPI v2.0a, SM BIOS 2.5 |
| Accessories | 1 x Serial ATA cable 1 x UltraDMA 133/100/66 cable 1 x I/O shield 1 x User Manual |
| Support DVD | Drivers ASUS PC Probe II ASUS LiveUpdate Utility Anti-Virus software (OEM version) |
| Form factor | MicroATX form factor: 9.6 in x 9.6 in (24.4 cm x 24.4 cm) |

**Specifications are subject to change without notice.*

[illegible]

Chapter 1

Product introduction

1.1 Welcome!

Thank you for buying an ASUS® M4A78-EM/1394 motherboard!

The motherboard delivers a host of new features and latest technologies, making it another standout in the long line of ASUS quality motherboards!

Before you start installing the motherboard, and hardware devices on it, check the items in your package with the list below.

1.2 Package contents

Check your motherboard package for the following items.

| | |
|-----------------|---|
| Motherboard | ASUS M4A78-EM/1394 motherboard |
| Cables | 1 x Serial ATA cable 1 x UltraDMA 133/100/66 cable |
| Accessories | 1 x I/O shield |
| Application DVD | ASUS motherboard Support DVD |
| Documentations | User Manual |



If any of the above items is damaged or missing, contact your retailer.

1.3 Special features

1.3.1 Product highlights



AMD® Phenom™ II / Athlon™ x4 / Athlon™ x3 / Athlon™ x2 AM3 CPU support

This motherboard supports AMD® AM3 multi-core processors with unique L3 cache and delivers better overclocking capabilities with less power consumption. It features dual-channel DDR2 1066 memory support and accelerates data transfer rate up to 5200MT/s via HyperTransport™ 3.0-based system bus. This motherboard also supports AMD® CPUs in the new 45nm manufacturing process.



AMD® Phenom™ x4 / Phenom™ x3 / Athlon™ x2 / Athlon™ / Sempron™ processors (socket AM2+/AM2)

This motherboard supports AMD® Socket AM2+ multi-core processors. It features dual-channel DDR2 1066 memory support and accelerates data transfer rate up to 5200MT/s via HyperTransport™ 3.0-based system bus. It also supports AMD® Cool 'n' Quiet Technology.



AMD® 780G chipset

The AMD 780G Northbridge is an AMD chipset designed for both HT1.0 and HT 3.0 interface speed. It features the future mainstream Hybrid CrossFire technology that significantly optimizes your 3D performance.



HyperTransport™ 3.0 support

HyperTransport™ 3.0 technology provides 2.6 times more bandwidth than HT1.0 that radically improves system efficiency for a smoother and faster computing environment.



AMD Cool 'n' Quiet Technology

This motherboard supports the AMD Cool 'n' Quiet technology which monitors system operation and automatically adjusts CPU voltage and frequency for a cool and quiet operating environment.



Dual channel DDR2 1200(O.C.) support

To attain top performance, ASUS engineers have successfully unleashed DDR2 1200(O.C.) MHz to meet the higher bandwidth requirements of the latest operating system, 3D graphics, multimedia, and Internet applications.



- Due to AM3/AM2+ CPU limitation, only one DDR2 1200/1066 DIMM is supported per channel. When four DDR2 1200/1066 DIMMs are installed, all DIMMs run at 800MHz frequency by default for system stability.
- We recommend that you install the DDR2 1200 memory modules on the yellow slots for better performance.
- Ensure that you download the latest BIOS version at www.asus.com and purchase the memory modules on the ASUS official Memory Qualified Vendors Lists (QVL).



Hybrid CrossFireX support

ATI Hybrid CrossFireX™ technology greatly boosts graphics performance with an onboard GPU and a discrete graphics card.



- Hybrid CrossFireX is supported by Windows® Vista OS only.
- Refer to www.amd.com for the discrete GPUs which support Hybrid CrossFireX™.



IEEE 1394a support

IEEE 1394a interface provides high speed digital interface for audio / video appliances such as digital television, digital video camcorders, storage peripherals and other portable devices.



64-bit CPU support

64-bit computing, the next generation technology that replaces the current 32-bit architecture, delivers advanced system performance, faster memory access, and increased productivity. This motherboard provides excellent compatibility and flexibility by supporting both 64-bit and 32-bit architecture.



Gigabit LAN solution

The onboard LAN controller is a highly integrated Gb LAN controller. It is enhanced with an ACPI management function to provide efficient power management for advanced operating systems.



Serial ATA 3Gb/s technology and SATA-On-The-Go

This motherboard supports hard drives based on the Serial ATA (SATA) 3Gb/s storage specification, delivering enhanced scalability and doubling the bus bandwidth for high-speed data retrieval and save. The external SATA port provides smart setup and hot-plug functions for easy data backup to external devices.



8-channel high definition audio

The onboard 8-channel HD audio (High Definition Audio, previously codenamed Azalia) CODEC enables high-quality 192KHz/24-bit audio output and jack-detect feature that automatically detects and identifies what types of peripherals are plugged into the audio I/O jacks and notifies users of inappropriate connection, which means there will be no more confusion of Line-in, Line-out, and Mic jacks.

1.3.2 Innovative ASUS features



ASUS Express Gate

Express Gate is a unique OS built into the motherboard. Five seconds after bootup, you can instantly surf the Internet without entering the Windows® OS.



- The actual boot time depends on the system configuration.
- ASUS Express Gate supports file uploading from SATA HDDs, ODDs and USB drives and downloading to USB drives only.
- Express Gate complies with the OpenGL standard. Refer to <http://support.asus.com> for Express Gate source codes.



ASUS MyLogo2™

This feature allows you to convert your favorite photo into a 256-color boot logo for a more colorful and vivid image on your screen.



ASUS CrashFree BIOS 3

ASUS CrashFree BIOS 3 is an auto-recovery tool that allows you to restore a corrupted BIOS file using the bundled support DVD or a USB flash disk that contains the BIOS file.



ASUS EZ Flash 2

ASUS EZ Flash 2 is a utility that allows you to update the BIOS without using an OS-based utility.



ASUS Q-Fan

ASUS Q-Fan technology intelligently adjusts CPU fan speeds according to system loading to ensure a quiet, cool, and efficient operation.



ASUS EPU

ASUS EPU is a unique power saving technology that detects the current system loadings and adjusts the power consumption in real time.



Turbo Key

ASUS Turbo Key allows you to turn the PC power button into a physical overclocking button. After the easy setup, Turbo Key can boost performances without interrupting ongoing work or games—with just one touch!



ASUS AI NET2

ASUS AI NET2 remotely detects the cable connection immediately after turning on the system, and any faulty cable connections are reported back up to 100 meters at 1 meter accuracy.



Green ASUS

This motherboard and its packaging comply with the European Union's Restriction on the use of Hazardous Substances (RoHS). This is in line with the ASUS vision of creating environment-friendly and recyclable products/packaging to safeguard consumers' health while minimizing the impact on the environment.



C.P.R. (CPU Parameter Recall)

The BIOS C.P.R. feature automatically restores the CPU default settings when the system hangs due to overclocking failure. C.P.R. eliminates the need to open the system chassis and clear the RTC data. Simply shut down and reboot the system, and the BIOS automatically restores the CPU parameters to their default settings.

1.4 Before you proceed


Take note of the following precautions before you install motherboard components or change any motherboard settings.



- Unplug the power cord from the wall socket before touching any component.
- Before handling components, use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, to avoid damaging them due to static electricity.
- Hold components by the edges to avoid touching the ICs on them.
- Whenever you uninstall any component, place it on a grounded antistatic pad or in the bag that came with the component.
- Before you install or remove any component, switch off the ATX power supply and detach its power cord. Failure to do so may cause severe damage to the motherboard, peripherals, or components.

Onboard LED

The motherboard comes with a standby power LED that lights up to indicate that the system is ON, in sleep mode, or in soft-off mode. This is a reminder that you should shut down the system and unplug the power cable before removing or plugging in any motherboard component. The illustration below shows the location of the onboard LED.



M4A78-EM/1394 Onboard LED

1.5 Motherboard overview

1.5.1 Placement direction

When installing the motherboard, ensure that you place it into the chassis in the correct orientation. The edge with external ports goes to the rear part of the chassis as indicated in the image below.


1.5.2 Screw holes

Place eight screws into the holes indicated by circles to secure the motherboard to the chassis.




DO NOT overtighten the screws! Doing so can damage the motherboard.

Place this side towards
the rear of the chassis.



1.5.3 Motherboard layout



1.5.4 Layout contents

| Connectors/Jumpers/Slots/LED | Page | Connectors/Jumpers/Slots/LED | Page |
|---|------|---|------|
| 1. IEEE 1394a port connector (10-1 pin IE1394_1) | 1-25 | 10. Clear RTC RAM (3-pin CLRTC) | 1-18 |
| 2. ATX power connectors (24-pin EATXPWR, 4-pin ATX12V) | 1-23 | 11. Onboard LED (SB_PWR) | 1-5 |
| 3. CPU Socket AM2+ | 1-8 | 12. SATA connectors (7-pin SATA1, SATA2, SATA3, SATA5, SATA6) | 1-25 |
| 4. DDR2 DIMM slots | 1-11 | 13. USB connectors (10-1 pin USB78, USB910, USB1112) | 1-26 |
| 5. CPU, power, and chassis fan connectors (4-pin CPU_FAN, 3-pin PWR_FAN, and 3-pin CHA_FAN) | 1-22 | 14. Digital audio connector (4-1 pin SPDIF_OUT) | 1-27 |
| 6. LPT connector (26-1 pin LPT) | 1-23 | 15. Front panel audio connector (10-1 pin AAFP) | 1-27 |
| 7. Serial port connector (10-1 pin COM1) | 1-22 | 16. Optical drive audio connector (4-pin CD) | 1-26 |
| 8. IDE connector (40-1 pin PRL_IDE) | 1-24 | 17. PCI / PCIe x 1 / PCIe x 16 slots | 1-17 |
| 9. System panel connector (20-8 pin PANEL) | 1-28 | | |

1.6 Central Processing Unit (CPU)

This motherboard comes with an AM2+ / AM2 socket designed for AMD® Phenom™ x4 / Phenom™ x3 / Athlon™ x2 / Athlon™ / Sempron™ processors. It also supports AM3 CPUs including Phenom™ II / Athlon™ x4 / Athlon™ x3 / Athlon™ x2 processors.




The AM2+ / AM2 socket has a different pinout from the 940-pin socket designed for the AMD Opteron™ processor. Use a CPU that is designed for the AM2+ / AM2 socket.

1.6.1 Installing the CPU

To install a CPU:


1. Locate the CPU socket on the motherboard.



M4A78-EM/1394 CPU socket AM2+

2. Press the lever sideways to unlock the socket, then lift it up to a 90°-100° angle.

Socket lever



Ensure that the socket lever is lifted up to a 90°-100° angle; otherwise, the CPU will not fit in completely.


3. Position the CPU above the socket such that the CPU corner with the gold triangle matches the socket corner with a small triangle.
4. Carefully insert the CPU into the socket until it fits in place.




The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to prevent bending the pins and damaging the CPU!

Small triangle


Gold triangle



5. When the CPU is in place, push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked.
6. Install a CPU heatsink and fan following the instructions that comes with the heatsink package. You can also refer to section **1.6.2 Installing heatsink and fan** for instructions.



7. Connect the CPU fan cable to the CPU_FAN connector on the motherboard.



M4A78-EM/1394 CPU fan connector



DO NOT forget to connect the CPU fan connector! Hardware monitoring errors can occur if you fail to plug this connector.

1.6.2 Installing the heatsink and fan




Ensure that you use only AMD®-certified heatsink and fan assembly.

To install the CPU heatsink and fan:

1. Place the heatsink on top of the installed CPU, ensuring that the heatsink fits properly on the retention module base.




- The retention module base is already installed on the motherboard upon purchase.
- You do not have to remove the retention module base when installing the CPU or installing other motherboard components.
- If you purchased a separate CPU heatsink and fan assembly, ensure that a Thermal Interface Material is properly applied to the CPU heatsink or CPU before you install the heatsink and fan assembly.



Your boxed CPU heatsink and fan assembly should come with installation instructions for the CPU, heatsink, and the retention mechanism. If the instructions in this section do not match the CPU documentation, follow the latter.

2. Attach one end of the retention bracket to the retention module base.



3. Align the other end of the retention bracket to the retention module base. A clicking sound denotes that the retention bracket is in place.



Ensure that the fan and heatsink assembly perfectly fits the retention mechanism module base, otherwise you cannot snap the retention bracket in place.

4. Push down the retention bracket lock on the retention mechanism to secure the heatsink and fan to the module base.
5. When the fan and heatsink assembly is in place, connect the CPU fan cable to the connector on the motherboard labeled CPU_FAN.




DO NOT forget to connect the CPU fan connector! Hardware monitoring errors can occur if you fail to plug this connector.

1.7 System memory

1.7.1 Overview

The motherboard comes with four Double Data Rate 2 (DDR2) Dual Inline Memory Modules (DIMM) sockets. The figure illustrates the location of the DDR2 DIMM sockets:



| Channel | Sockets |
|-----------|---------------------|
| Channel A | DIMM_A1 and DIMM_A2 |
| Channel B | DIMM_B1 and DIMM_B2 |

M4A78-EM/1394 240-pin DDR2 DIMM sockets

1.7.2 Memory configurations

You may install 512MB, 1GB, 2GB and 4GB unbuffered ECC and non-ECC DDR2 DIMMs into the DIMM sockets.



- You may install varying memory sizes in Channel A and Channel B. The system maps the total size of the lower-sized channel for the dual-channel configuration. Any excess memory from the higher-sized channel is then mapped for single-channel operation.
- Always install DIMMs with the same CAS latency. For optimum compatibility, we recommend that you obtain memory modules from the same vendor.
- Due to the memory address limitation on 32-bit Windows® OS, when you install 4GB or more memory on the motherboard, the actual usable memory for the OS can be about 3GB or less. For effective use of memory, we recommend that you do any of the following:
 - Install a maximum of 3GB system memory if you are using a 32-bit Windows® OS.
 - Use a 64-bit Windows® OS if you want to install 4GB or more memory on the motherboard.
- This motherboard does not support DIMMs made up of 256 megabits (Mb) chips or less.



The motherboard supports up to 16GB memory modules on Windows® XP Professional x64 and Vista x64 editions. You may install a maximum of 4GB DIMMs on each slot.

M4A78-EM/1394 Motherboard Qualified Vendors Lists (QVL)

DDR2-1200MHz capability

| Size | Vendor | Part No. | SS/DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|----------|------------------|-------|----------|-------------------|-------------------|--------------------------------|----|----|
| | | | | | | | A* | B* | C* |
| 2048MB(Kit of 2) | Kingston | KHX96002K2/2G | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | OCZ | OCZ2FX12002GK | DS | 5-5-5-18 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | Team | TXDD1024M1300HC6 | DS | 6-6-6-18 | Heat-Sink Package | Heat-Sink Package | - | - | - |



We recommend that you install the DDR2 1200 memory modules on the yellow slots for better performance.

DDR2-1066MHz capability

| Size | Vendor | Part No. | SS/DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|---------|---------------------|-------|----------|----------------------------------|------------|--------------------------------|----|----|
| | | | | | | | A* | B* | C* |
| 4096MB(Kit of 2) | A-Data | AD21066E002GU | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | Apacer | 78.0AG9S.9K4 | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(Kit of 2) | Apacer | 78.AA.GAL.9KZ | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | Corsair | CM2X1024-8500C5 | DS | N/A | Heat-Sink Package | Corsair | - | - | - |
| 2048MB(Kit of 2) | Corsair | CM2X1024-8500C5D | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | Corsair | CM2X2048-8500C5D | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | Crucial | BL12864AA1065.8FE5 | SS | N/A | Heat-Sink Package | N/A | - | - | - |
| 2048MB | Crucial | CT25664AA1067.16FE1 | DS | 7-7-7-13 | 9DJKH D9JKH | Micron | - | - | - |
| 2048MB(Kit of 2) | G.SKILL | F2-8500CL5D-2GBPI | SS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | G.SKILL | F2-8500CL5S-1GBPK | DS | 5-5-5-15 | Heat-Sink PackageSN:815130037562 | N/A | - | - | - |
| 2048MB(Kit of 2) | G.SKILL | F2-8500CL5D-2GBPK | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(Kit of 2) | G.SKILL | F2-8500CL5D-4GBPI-B | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(Kit of 2) | G.SKILL | F2-8500CL5D-4GBPI | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |

(continued on the next page)

DDR2-1066MHz capability

| Size | Vendor | Part No. | SS/DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|-----------|-----------------------|-------|----------|--|------------|--------------------------------|----|----|
| | | | | | | | A* | B* | C* |
| 4096MB(kit of 2) | G.SKILL | F2-8500CL5D-4GBPK | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | GEIL | GE22GB1066C5DC | SS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GE24GB1066C5QC | SS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GB24GB8500C5DC | DS | 5 | GL2L128M88BA25AB | GEIL | - | - | - |
| 2048MB | GEIL | GE24GB1066C5DC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 4096MB(kit of 2) | GEIL | GX24GB8500C5UDC | DS | 5 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | kingmax | KLED48F-B8KU6-NGES | SS | 6-6-6-24 | KKB8FNUXF-DXX-18A | kingmax | - | - | - |
| 2048MB | kingmax | KLEE88F-B8KU6-NNAS | DS | 6-6-6-24 | KKB8FNUXF-DXX-18A | kingmax | - | - | - |
| 1024MB(Kit of 2) | Kingston | KHX8500D2K2/1G | SS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 1024MB(Kit of 2) | Kingston | KHX8500D2K2/1GN(EPP) | SS | 5-5-5-18 | Heat-Sink Package | Kingston | - | - | - |
| 1024MB | Kingston | KHX8500D2K2/2GN(EPP) | DS | 5-5-5-18 | Heat-Sink Package | Kingston | - | - | - |
| 1024MB | Kingston | KVR1066D2N7/1G | DS | 7 | E5108AJBG-1J-E | Elpida | - | - | - |
| 2048MB(Kit of 2) | Kingston | KHX8500D2K2/2G | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | Kingston | KHX8500D2K2/4G | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | OCZ | OC2ZN10662GK(Epp) | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(Kit of 2) | OCZ | OC2ZN1066SR2DK(Epp) | DS | 5-5-5-15 | Heat-Sink Package 004820806001601-2 | OCZ | - | - | - |
| 4096MB(kit of 2) | OCZ | OC2ZF10664GK | DS | 6-7-7-20 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(kit of 2) | OCZ | OC2ZP10664GK(EPP) | DS | 5-5-5-18 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(kit of 2) | OCZ | OC2ZRP10664GK | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB | PSC | ALBE8G73F-AE1 | DS | 5-5-5-12 | A3R1GE3FG907MATOFTAIWAN-G8E | PSC | - | - | - |
| 1024MB | Qimonda | HY564T128000EU-1.9-C2 | DS | N/A | HYB18T1G800C2F-1.9FSS25253 | Qimonda | - | - | - |
| 2048MB(Kit of 2) | Transcend | TX1066QLU-2GK | SS | 5 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(kit of 2) | Transcend | TX1066QLU-4GK | DS | 5 | Heat-Sink Package | Transcend | - | - | - |



- Due to AM2+/AM3 CPU limitation, only one DDR2 1200/1066 DIMM is supported per channel. When four DDR2 1066/1200 DIMMs are installed, all DIMMs run at 800Mhz frequency by default for system stability.
- The default DIMM frequency depends on its Serial Presence Detect (SPD), which is the standard way of accessing information from a memory module. Under the default state, some memory modules for overclocking may operate at a lower frequency than the vendor-marked value.

DDR2-800MHz capability

| Size | Vendor | Part No. | SS/DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|---------|-------------------------|-------|----------|---------------------------------------|------------|--------------------------------|----|----|
| | | | | | | | A* | B* | C* |
| 512MB | A-Data | M2GVD6G3H3160Q1E52 | SS | N/A | VD29608A8A-25EG820813 | ADATA | - | - | - |
| 512MB | A-Data | M20AD6G3H3160Q1E58 | SS | N/A | AD29608A8A-25EG80812 | ADATA | - | - | - |
| 2048MB(Kit of 2) | A-Data | AD2800E001GOU | SS | 4-4-4-12 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | A-Data | M2GVD6G314170Q1E58 | DS | N/A | VD29608A8A-25EG80813 | ADATA | - | - | - |
| 4096MB(Kit of 2) | A-Data | AD2800E002GOU | DS | 4-4-4-12 | Heat-Sink Package | N/A | - | - | - |
| 512MB | Apacer | 78.91G91.9K5 | SS | 5 | AM4B570BJQS8E0751C | Apacer | - | - | - |
| 1024MB | Apacer | 78.01GA0.9K5 | SS | 5 | AM4B5808CQJS8E0749D | Apacer | - | - | - |
| 2048MB | Apacer | 78.A1GA0.9K4 | DS | 5 | AM4B5808CQJS8E0740E | Apacer | - | - | - |
| 2048MB | Apacer | 78.A1GA0.9K4 | DS | 5 | AM4B5808CQJS8E0747D | Apacer | - | - | - |
| 1024MB | Corsair | CM2X1024-6400 | DS | N/A | Heat-Sink Package | Corsair | - | - | - |
| 1024MB | Corsair | XMS2-6400 | DS | 4 | Heat-Sink Package | Corsair | - | - | - |
| 1024MB | Corsair | XMS2-6400 | DS | 5 | Heat-Sink Package | Corsair | - | - | - |
| 4096MB(Kit of 2) | Corsair | CM2X2048-6400CSDHX | DS | 5 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(Kit of 2) | Corsair | CM2X2048-6400C5 | DS | 5 | Heat-Sink Package | N/A | - | - | - |
| 2048MB(kit of 2) | Crucial | BL12864AL80A.8FE5(EPP) | SS | 4-4-4-12 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(kit of 2) | Crucial | BL25664AL80A.16FE5(EPP) | DS | 4-4-4-12 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(kit of 2) | Crucial | BL25664AR80A.16FE5(EPP) | DS | 4-4-4-12 | Heat-Sink Package | N/A | - | - | - |
| 512MB | G.SKILL | F2-6400CL5D-1GBNQ | SS | 5-5-5-15 | Heat-Sink Package SN:8151030036642 | G.SKILL | - | - | - |
| 1024MB | G.SKILL | F2-6400CL4D-2GBPK | DS | 4 | Heat-Sink Package | G.SKILL | - | - | - |
| 1024MB | G.SKILL | F2-6400CL5D-2GBNQ | DS | 5 | Heat-Sink Package | G.SKILL | - | - | - |
| 2048MB | G.SKILL | F2-6400CL4D-4GBPK | DS | 4 | Heat-Sink Package | G.SKILL | - | - | - |
| 2048MB | G.SKILL | F2-6400CL5D-4GBPQ | DS | 5 | Heat-Sink Package | G.SKILL | - | - | - |
| 4096MB | G.SKILL | F2-6400CL6Q-16GMQ | DS | 5 | Heat-Sink Package | N/A | - | - | - |

(continued on the next page)

DDR2-800MHz capability

| Size | Vendor | Part No. | SS/DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|--------------|-----------------------|-------|----------|------------------------------|--------------|--------------------------------|----|----|
| | | | | | | | A' | B' | C' |
| 1024MB | GEIL | GB22GB6400C4DC | DS | 5 | GL2L64M088BA30EB | GEIL | - | - | - |
| 1024MB | GEIL | GB22GB6400C5DC | DS | 5 | GL2L64M088BA30EB | GEIL | - | - | - |
| 1024MB | GEIL | GB24GB6400C4QC | DS | 4 | GL2L64M088BA30EB | GEIL | - | - | - |
| 1024MB | GEIL | GB24GB6400C5QC | DS | 5 | GL2L64M088BA30EB | GEIL | - | - | - |
| 1024MB | GEIL | GE22GB800C4DC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GE22GB800C5DC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GE24GB800C4QC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GE24GB800C5QC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GX22GB6400DC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 1024MB | GEIL | GX22GB6400UDC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GB24GB6400C4DC | DS | 4 | GL2L128M88BA25AB | GEIL | - | - | - |
| 2048MB | GEIL | GB24GB6400C5DC | DS | 5 | GL2L128M88BA25AB | GEIL | - | - | - |
| 2048MB | GEIL | GB28GB6400C4QC | DS | 4 | GL2L128M88BA25AB | GEIL | - | - | - |
| 2048MB | GEIL | GB28GB6400C5QC | DS | 5 | GL2L128M88BA25AB | GEIL | - | - | - |
| 2048MB | GEIL | GE24GB800C4DC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GE24GB800C5DC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GE28GB800C4QC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GE28GB800C5QC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GX22GB6400CJSC | DS | 4 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GX22GB6400LX | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GX24GB6400DC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 512MB | Kingmax | KLD2C8F-A8K15 | SS | N/A | KK48FF1XF-JFS-25A | Kingmax | - | - | - |
| 1024MB | Kingmax | KKB8FFBXF-CFA-25U | SS | N/A | KLD48F-B8KB5 | Kingmax | - | - | - |
| 2048MB | kingmax | KLDE88F-B8KB5 | DS | N/A | KKB8FFBXF-CFA-25U | kingmax | - | - | - |
| 512MB | Kingston | KVR800D2N6/ 512 | SS | 6 | E5108AJBG-8E-E | Elpida | - | - | - |
| 1024M(Kit of 2) | Kingston | KHX6400D2LK2/1GN | SS | 4-4-4-12 | Heat-Sink Package | Kingston | - | - | - |
| 1024MB | Kingston | KHX6400D2L1/G | DS | 4-4-4-12 | Heat-Sink Package | Kingston | - | - | - |
| 1024MB | Kingston | KVR800D2N5/1G | DS | 5 | D6408TR4CGL25USL36240 6PECCA | Kingston | - | - | - |
| 1024MB | Kingston | KVR800D2N6/1G | DS | N/A | E5108AJBG-8E-E | Elpida | - | - | - |
| 2048MB(Kit of 2) | Kingston | KHX6400D2K2/2G | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB | Kingston | 461625.010819 PTGC | DS | 6 | KVR800D2N6/2G | Kingston | - | - | - |
| 2048MB | Kingston | KHX6400D2/2G | DS | 5 | Heat-Sink Package | Kingston | - | - | - |
| 2048MB | Kingston | KVR800D2N5/2G | DS | 5 | E1108ACBG-8E-E | Elpida | - | - | - |
| 4096MB | Kingston | KVR800D2N6/4G | DS | 6 | E2108ABSE-8G-E | Elpida | - | - | - |
| 512MB | Micron | MT9HTF6472AY-80ED4 | SS | N/A | 6ED22D9GKX(ECC) | Micron | - | - | - |
| 1024MB | Micron | MT9HTF12872AY-800E1 | SS | N/A | D9HNP 7YE22(ECC) | Micron | - | - | - |
| 1024MB | Micron | MT118HTF12872AY-80ED4 | DS | N/A | 6TD22D9GKX(ECC) | Micron | - | - | - |
| 1024MB | OCZ | OC22G800R22GK | DS | 5 | Heat-Sink Package | OCZ | - | - | - |
| 1024MB | OCZ | OC22P800R22GK | DS | 4 | Heat-Sink Package | OCZ | - | - | - |
| 1024MB | OCZ | OC22RPPR8002GK | DS | 4 | Heat-Sink Package | OCZ | - | - | - |
| 1024MB | OCZ | OC22VU8004GK | DS | 6 | Heat-Sink Package | OCZ | - | - | - |
| 2048MB(Kit of 2) | OCZ | OC22SE8002GK | DS | 5-5-5-15 | Heat-Sink Package | N/A | - | - | - |
| 2048MB | OCZ | OC22F8004GK | DS | 5 | Heat-Sink Package | N/A | - | - | - |
| 4096MB(Kit of 2) | OCZ | OC22P8004GK | DS | 5 | Heat-Sink Package | N/A | - | - | - |
| 1024MB | PSC | AL7E8F73C-8E1 | SS | 5 | A3R1GE3CFF734MAA0E | PSC | - | - | - |
| 2048MB | PSC | AL7E8E63H-10E1K | DS | N/A | A3R1GE3CFF750RABBP(ECC) | PSC | - | - | - |
| 2048MB | PSC | AL8E8F73C-8E1 | DS | 5 | A3R1GE3CFF734MAA0E | PSC | - | - | - |
| 2048MB | PSC | SHG772-AA3G | DS | N/A | PL8E8F73C-8E1 | PSC | - | - | - |
| 2048MB | PSC | XCP271A3G-A | DS | N/A | PL8E8G73E-8E1 | PSC | - | - | - |
| 2048MB | Qimonda | HY564T256020EU-2.5-C2 | DS | 5 | HY818T1G800C2F-2.5 | Qimonda | - | - | - |
| 512MB | Samsung | K4T51083QG-HCF7 | SS | 6 | M378T6553QZ3-CF7 | Qimonda | - | - | - |
| 1024MB | Samsung | K4T1G084QQ-HCF7 | SS | 6 | M378T2863QZ3-CF7 | Qimonda | - | - | - |
| 1024MB | Samsung | M391T2863QZ3-CF7 | SS | N/A | K4T1G084QQ-HCF7(ECC) | Samsung | - | - | - |
| 1024MB | Samsung | K4T51083QG-HCF7 | DS | 6 | M378T2953QZ3-CF7 | Samsung | - | - | - |
| 2048MB | Samsung | K4T1G084QQ-HCF7 | DS | 6 | M378T5663QZ3-CF7 | Samsung | - | - | - |
| 2048MB | Samsung | M391T5663QZ3-CF7 | DS | N/A | K4T1G084QQ-HCF7(ECC) | Samsung | - | - | - |
| 4096MB | Samsung | M378T5263AZ3-CF7 | DS | N/A | K4T2G084QA-HCF7 | Samsung | - | - | - |
| 1024MB | Super Talent | T800UB1G4C | DS | 4 | Heat-Sink Package | Super Talent | - | - | - |
| 512MB | Transcend | TS64MLQ64V8J | SS | 5 | 7HD22 D9GMH | Micron | - | - | - |
| 1024MB | Transcend | JM800QLU-1G | SS | 5 | TQ1243PCF8 | Transcend | - | - | - |
| 1024MB | Transcend | TS128MLQ64V8U | SS | 5 | E1108ACBG-8E-E | ELPIDA | - | - | - |
| 1024MB | Transcend | JM800QLJ-1G | DS | 5 | TQ123PJF8F0801 | Transcend | - | - | - |
| 1024MB | Transcend | JM800QLJ-1G | DS | 5 | TQ123YBF8 T0747 | Transcend | - | - | - |
| 1024MB | Transcend | TS128MLQ64V8J | DS | 5 | 7HD22D9GMH | Micron | - | - | - |
| 2048MB | Transcend | JM800QLU-2G | DS | 5 | TQ243PCF8 | Transcend | - | - | - |
| 2048MB | Transcend | TS256MLQ64V8U | DS | 5 | E1108ACBG-8E-E | Elpida | - | - | - |
| 2048MB | Transcend | TS256MLQ72V8U | DS | N/A | E1108ACBG-8E-E(ECC) | Elpida | - | - | - |

DDR2-667MHz capability

| Size | Vendor | Part No. | SS/ DS | CL | Chip NO. | Chip Brand | DIMM socket support (Optional) | | |
|------------------|--------------|---------------------|-----------|----------|--|--------------|--------------------------------------|----|----|
| | | | | | | | A* | B* | C* |
| 2048MB | A-Data | M2OAD5H3J41701C53 | DS | N/A | AD20908A8A-3EG 30724 | ADATA | - | - | - |
| 512MB | Apacer | 78.91G92.9K5 | SS | 5 | AM4B5708JQJUS7E0751C | Apacer | - | - | - |
| 512MB | Apacer | AU 512E667C5KBGC | SS | 5 | AM4B5708GQJS7E06332F | Apacer | - | - | - |
| 512MB | Apacer | AU 512E667C5KBGC | SS | 5 | AM4B5708MJUS7E0627B | Apacer | - | - | - |
| 1024MB | Apacer | 78.01G90.9K5 | SS | 5 | AM4B5808CQJS7E0751C | Apacer | - | - | - |
| 1024MB | Apacer | AU01GE667C5KBGC | DS | N/A | AM4B5708GQJS7E0636B | Apacer | - | - | - |
| 1024MB | Apacer | AU01GE667C5KBGC | DS | 5 | AM4B5708MJUS7E0627B | Apacer | - | - | - |
| 2048MB | Apacer | AM4B5808CQJS7E0749B | DS | 5 | 78.A1G90.9K4 | Apacer | - | - | - |
| 512MB | Corsair | VS 512MB667D2 | DS | N/A | M1110052532M8CEC | Corsair | - | - | - |
| 1024MB | Corsair | VS1GB667D2 | DS | N/A | M1D095D62864M8CEC | Corsair | - | - | - |
| 1024MB | Corsair | XMS2-5400 | DS | 4 | Heat-Sink Package | Corsair | - | - | - |
| 2048MB(Kit of 2) | G.SKILL | F2-5400PHU2-2GBNT | DS | 5-5-5-15 | D2 64M8CCF 0815 C7173S | G.SKILL | - | - | - |
| 4096MB(Kit of 2) | G.SKILL | F2-5300CL5D-4GBMQ | DS | 5-5-5-15 | Heat-Sink Package SN:8151030036559 | G.SKILL | - | - | - |
| 1024MB | GEIL | GX21GB5300SX | DS | 3 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GX22GB5300LX | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 2048MB | GEIL | GX24GB5300LDC | DS | 5 | Heat-Sink Package | GEIL | - | - | - |
| 512MB | Kingmax | KLCC28F-A8KB5 | SS | N/A | KKEA88B4LAUG-29DX | Kingmax | - | - | - |
| 1024MB | Kingmax | KLCD48F-A8KB5 | DS | N/A | KKEA88B4LAUG-29DX | Kingmax | - | - | - |
| 512MB | Kingston | KVR667D2N5/ 512 | SS | 5 | SO1237650821 SBP D6408TR4CGL25 USL074905PECNB | Kingston | - | - | - |
| 1024MB | Kingston | KVR667D2E5/1G | DS | 5 | E5108AJBG-8E-E(ECC) | Elpida | - | - | - |
| 1024MB | Kingston | KVR667D2N5/1G | DS | 5 | SO1280420822 SOP D6408TR4CGL25 USL156304PECXA | Kingston | - | - | - |
| 2048MB | Kingston | KVR667D2E5/2G | DS | 5 | NT5TU128M8DE-3C(ECC) | Elpida | - | - | - |
| 2048MB | Kingston | KVR667D2N5/2G | DS | 5-5-5-15 | 7RE22 D9HNL | Micron | - | - | - |
| 2048MB | Kingston | KVR667D2N5/2G | DS | 5 | E1108ACBG-8E-E 0813A90CC | ELPIDA | - | - | - |
| 1024MB | Micron | MT8HTF12864AY-667E1 | SS | 5 | D9HNL 7ZE17 | Micron | - | - | - |
| 512MB | PSC | AL6E8E63J-6E1 | SS | 5 | A3R12E3JFF717B9A00 | PSC | - | - | - |
| 1024MB | PSC | AL7E8F73C-6E1 | SS | 5 | A3R1GE3CFF734MAA0J | PSC | - | - | - |
| 1024MB | PSC | AL6E8E63J-6E1 | DS | 5 | A3R12E3JFF717B9A01 | PSC | - | - | - |
| 2048MB | PSC | AL8E8F73C-6E1 | DS | 5 | A3R1GE3CFF733MAA00 | PSC | - | - | - |
| 4096MB | Samsung | M37875263AZ3-CE6 | DS | N/A | K4T2G084QA-HCE6 | Samsung | - | - | - |
| 1024MB | Super Talent | T667UB1GV | DS | 5 | PG 64M8-800 0750 | Super Talent | - | - | - |
| 1024MB | Transcend | JM667QLU-1G | SS | 5 | TQ243PCF8T10838 | Transcend | - | - | - |
| 1024MB | Transcend | JM667QLU-1G | DS | 5 | E5108AJBG-8E-E | Elpida | - | - | - |
| 2048MB | Transcend | JM667QLU-2G | DS | 5 | TQ243PCF8T10834 | Transcend | - | - | - |
| 512MB | Twinmos | 8D-A3JK5MPETP | SS | 5 | A3R12E3GEFF633ACAQY | PSC | - | - | - |



SS: Single-sided / DS: Double-sided

DIMM support:

- **A*:** Supports one module inserted into any slot as single-channel memory configuration.
- **B*:** Supports one pair of modules inserted into either the yellow slots or the black slots as one pair of dual-channel memory configuration.
- **C*:** Supports two pairs of modules inserted into both the yellow slots and the black slots as two pairs of dual-channel memory configuration.




Visit the ASUS website at www.asus.com for the latest QVL.

1.7.3 Installing a DIMM




Unplug the power supply before adding or removing DIMMs or other system components. Failure to do so can cause severe damage to both the motherboard and the components.

1. Press the retaining clips outward to unlock a DDR2 DIMM socket.
2. Align a DIMM on the socket such that the notch on the DIMM matches the break on the socket.



A DDR2 DIMM is keyed with a notch so that it fits in only one direction. DO NOT force a DIMM into a socket to avoid damaging the DIMM.

3. Firmly insert the DIMM into the socket until the retaining clips snap back in place and the DIMM is properly seated.



1.7.4 Removing a DIMM


To remove a DIMM:

1. Simultaneously press the retaining clips outward to unlock the DIMM.



Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged when it flips out with extra force.

2. Remove the DIMM from the socket.



1.8 Expansion slots

In the future, you may need to install expansion cards. The following sub-sections describe the slots and the expansion cards that they support.



Unplug the power cord before adding or removing expansion cards. Failure to do so may cause you physical injury and damage motherboard components.

1.8.1 Installing an expansion card

To install an expansion card:

1. Before installing the expansion card, read the documentation that came with it and make the necessary hardware settings for the card.
2. Remove the system unit cover (if your motherboard is already installed in a chassis).
3. Remove the bracket opposite the slot that you intend to use. Keep the screw for later use.
4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
5. Secure the card to the chassis with the screw you removed earlier.
6. Replace the system cover.

1.8.2 Configuring an expansion card

After installing the expansion card, configure it by adjusting the software settings.

1. Turn on the system and change the necessary BIOS settings, if any. See Chapter 2 for information on BIOS setup.
2. Assign an IRQ to the card.
3. Install the software drivers for the expansion card.



When using PCI cards on shared slots, ensure that the drivers support "Share IRQ" or that the cards do not need IRQ assignments. Otherwise, conflicts will arise between the two PCI groups, making the system unstable and the card inoperable.

1.8.3 PCI slots

The PCI slots support cards such as a LAN card, SCSI card, USB card, and other cards that comply with PCI specifications.

1.8.4 PCI Express x1 slot

This motherboard supports PCI Express x1 network cards, SCSI cards, and other cards that comply with the PCI Express specifications.


1.8.5 PCI Express x16 slot

This motherboard supports a PCI Express x16 graphics card that complies with the PCI Express specifications.

1.9 Jumpers

1. Clear RTC RAM (CLRRTC)

This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which include system setup information such as system passwords.



To erase the RTC RAM:

1. Turn OFF the computer and unplug the power cord.
2. Move the jumper cap from pins 1-2 (default) to pins 2-3. Keep the cap on pins 2-3 for about 5~10 seconds, then move the cap back to pins 1-2.
3. Plug the power cord and turn ON the computer.
4. Hold down the key during the boot process and enter BIOS setup to reenter data.




Except when clearing the RTC RAM, never remove the cap on CLRRTC jumper default position. Removing the cap will cause system boot failure!



- If the steps above do not help, remove the onboard battery and move the jumper again to clear the CMOS RTC RAM data. After clearing the CMOS, reinstall the battery.
 - You do not need to clear the RTC when the system hangs due to overclocking. For system failure due to overclocking, use the CPU Parameter Recall (C.P.R) feature. Shut down and reboot the system so the BIOS can automatically reset parameter settings to default values.
-

1.10 Connectors

1.10.1 Rear panel ports



1. **PS/2 Keyboard/Mouse Combo port (purple).** This port is for a PS/2 keyboard or mouse.
2. **Optical S/PDIF_OUT port.** This port connects to an external audio output device via an optical S/PDIF cable.
3. **Video Graphics Adapter (VGA) port.** This 15-pin port is for a VGA monitor or other VGA-compatible devices.
4. **USB 2.0 ports 3 and 4.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.
5. **LAN (RJ-45) port.** This port allows Gigabit connection to a Local Area Network (LAN) through a network hub.

LAN port LED indications

| Activity/Link LED | | Speed LED | |
|-------------------|---------------|-----------|--------------------|
| Status | Description | Status | Description |
| OFF | No link | OFF | 10Mbps connection |
| ORANGE | Linked | ORANGE | 100Mbps connection |
| BLINKING | Data activity | GREEN | 1Gbps connection |

ACT/LINK SPEED LED LED



LAN port

6. **Center/Subwoofer port (orange).** This port connects to the center/subwoofer speakers.
7. **Rear Speaker Out port (black).** This port connects to the rear speakers in the 4, 6, and 8-channel audio configurations.
8. **Line In port (light blue).** This port connects to the tape, CD, DVD player, or other audio sources.
9. **Line Out port (lime).** This port connects to a headphone or a speaker. In the 4, 6 and 8-channel configurations, the function of this port becomes Front Speaker Out.
10. **Microphone port (pink).** This port connects to a microphone.
11. **Side Speaker Out port (gray).** This port connects to the side speakers in the 8-channel audio configuration.



Refer to the audio configuration table below for the function of the audio ports in the 2, 4, 6, or 8-channel configuration.

Audio 2, 4, 6, or 8-channel configuration

| Port | Headset 2-channel | 4-channel | 6-channel | 8-channel |
|------------|-------------------|-------------------|-------------------|-------------------|
| Light Blue | Line In | Line In | Line In | Line In |
| Lime | Line Out | Front Speaker Out | Front Speaker Out | Front Speaker Out |
| Pink | Mic In | Mic In | Mic In | Mic In |
| Orange | – | – | Center/Subwoofer | Center/Subwoofer |
| Black | – | Rear Speaker Out | Rear Speaker Out | Rear Speaker Out |
| Gray | – | – | – | Side Speaker Out |



Ensure the audio device of sound playback is **Realtek High Definition Audio** (the name may be different based on the OS). Go to **Start > Control Panel > Sounds and Audio Devices > Sound Playback** to configure the settings.

- 12. USB 2.0 ports 1 and 2.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.
- 13. IEEE 1394a port.** This 6-pin IEEE 1394a port provides high-speed connectivity for audio/video devices, storage peripherals, PCs, or portable devices.
- 14. eSATA port.** This port connects to an external Serial ATA hard disk drive.



To use hot-plug, set the **OnChip SATA Type** item in the BIOS to **[AHCI]**. See section 2.3.4 **SATA Configuration** for details.

- 15. DVI-D Out port.** This port is for any DVI-D compatible device and is HDCP compliant allowing playback of HD DVD, Blu-Ray, and other protected content.
- 16. HDMI port.** This port is for a High-Definition Multimedia Interface (HDMI) connector, and is HDCP compliant allowing playback of HD DVD, Blu-Ray, and other protected content.



Dual display output support

- This table indicates that whether the following dual display outputs are supported on your motherboard:

| Dual display outputs | Supported | Not supported |
|----------------------|-----------|---------------|
| DVI + D-Sub | • | |
| DVI + HDMI | | • |
| HDMI + D-Sub | • | |

- During POST, only the monitor connected to the D-Sub port has display. The dual display function works only under Windows.



Playback of HD DVD and Blu-Ray discs

- For better playback quality, we recommend that you follow the system requirements listed below.

| Suggested list | |
|----------------|------------------------------------|
| CPU | AMD® Athlon 4400+ |
| DIMM | DDR2 800 (1GB or higher) |
| BIOS setup | Frame Buffer Size--256MB or higher |

| File format | Best resolution | |
|---------------------|-----------------|----------------|
| | Windows® XP | Windows® Vista |
| Non-protected clips | 1920 x 1080p | 1920 x 1080p |
| HD-DVD | 1920 x 1080p | 1280 x 1080p |
| Blu-Ray | 1280 x 1080p | 1280 x 1080p |

- To play HD DVD or Blu-Ray disc, ensure to use HDCP compliant devices and software.

- 17. USB 2.0 ports 5 and 6.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.


1.10.2 Internal connectors

1. Serial port connector (10-1 pin COM1)

The connector is for a serial (COM) port. Connect the serial port module cable to the connector, then install the module to a slot opening at the back of the system chassis.



The serial port bracket (COM1) is purchased separately.




M4A78-EM/1394 Serial port (COM1) connector

2. Power, CPU, and chassis fan connectors (3-pin PWR_FAN, 4-pin CPU_FAN, 3-pin CHA_FAN)

The fan connectors support cooling fans of 350mA~740mA (8.88W max.) or a total of 1A~2.22A (26.64W max.) at +12V. Connect the fan cables to the fan connectors on the motherboard, ensuring that the black wire of each cable matches the ground pin of the connector.



DO NOT forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components. These are not jumpers! DO NOT place jumper caps on the fan connectors.




M4A78-EM/1394 fan connectors



Only the CPU fan supports the ASUS Q-Fan feature.

3. ATX power connectors (24-pin EATXPWR, 4-pin ATX12V)

These connectors are for an ATX power supply. The plugs from the power supply are designed to fit these connectors in only one orientation. Find the proper orientation and push down firmly until the connectors completely fit.




M4A78-EM/1394 ATX power connectors



- For a fully configured system, we recommend that you use a power supply unit (PSU) that complies with ATX 12 V Specification 2.0 (or later version) and provides a minimum power of 400 W.
- Do not forget to connect the 4-pin ATX12V power plug. Otherwise, the system will not boot.
- We recommend that you use a PSU with a higher power output when configuring a system with more power-consuming devices or when you intend to install additional devices. The system may become unstable or may not boot up if the power is inadequate.

4. LPT connector (26-pin LPT)

The LPT (Line Printing Terminal) connector supports devices such as a printer. LPT is standardized as IEEE 1284, which is the parallel port interface on IBM PC-compatible computers.



M4A78-EM/1394 Parallel Port Connector

5. IDE connector (40-1 pin PRI_IDE)

The onboard IDE connector is for Ultra DMA 133/100/66 signal cable. There are three connectors on each Ultra DMA 133/100/66 signal cable: blue, black, and gray. Connect the blue connector to the motherboard's IDE connector, then select one of the following modes to configure your devices:


| | Drive jumper setting | Mode of device(s) | Cable connector |
|---------------|------------------------|-------------------|-----------------|
| Single device | Cable-Select or Master | - | Black |
| Two devices | Cable-Select | Master | Black |
| | | Slave | Gray |
| | Master | Master | Black or gray |
| | Slave | Slave | |



- Pin 20 on the IDE connector is removed to match the covered hole on the Ultra DMA cable connector. This prevents incorrect insertion when you connect the IDE cable.
- Use the 80-conductor IDE cable for Ultra DMA 133/100/66 IDE devices.




If any device jumper is set as "Cable-Select", ensure that all other device jumpers have the same setting.



6. Serial ATA connectors (7-pin SATA1, SATA2, SATA3, SATA5 and SATA6)

These connectors are for the Serial ATA signal cables for Serial ATA 3Gb/s hard disk and optical disk drives. The Serial ATA 3Gb/s is backward compatible with Serial ATA 1.5Gb/s specification. The data transfer rate of the Serial ATA 3Gb/s is faster than the standard parallel ATA with 133 MB/s (Ultra DMA133). If you install Serial ATA hard disk drives, you can create a RAID 0, RAID 1, and RAID 0+1 configurations through the onboard SB710 chipset.



M4A78-EM/1394 SATA connectors




Install the Windows® XP Service Pack 1 before using Serial ATA.



- For detailed instructions on RAID configurations, refer to the RAID manual in the Support DVD.
- If you intend to create a Serial ATA RAID set using these connectors, set the **OnChip SATA Type** item in the BIOS to **[RAID]**. See **2.3.4 SATA Configuration** for details.

7. IEEE 1394a port connector (10-1 pin IE1394_1)

This connector is for an IEEE 1394a port. Connect the IEEE 1394a module cable to this connector, then install the module to a slot opening at the back of the system chassis.




M4A78-EM/1394 IEEE 1394a Connector



Never connect a USB cable to the IEEE 1394a connector. Doing so will damage the motherboard!

8. USB connectors (10-1 pin USB78, USB910, USB1112)

These connectors are for USB 2.0 ports. Connect the USB module cable to any of these connectors, then install the module to a slot opening at the back of the system chassis. These USB connectors comply with USB 2.0 specification that supports up to 480Mbps connection speed.




Never connect a 1394 cable to the USB connectors. Doing so will damage the motherboard!



The USB 2.0 module is purchased separately.


9. Optical drive audio connector (4-pin CD)

This connector allows you to receive stereo audio input from sound sources such as a CD-ROM, TV tuner, or MPEG card.



10. Digital audio connector (4-1 pin SPDIF_OUT)

This connector is for an additional Sony/Philips Digital Interface (S/PDIF) port.




Ensure that the audio device of Sound playback is **Realtek High Definition Audio** (the name may be different based on the OS). Go to **Start > Control Panel > Sounds and Audio Devices > Sound Playback** to configure the setting.



The S/PDIF module is purchased separately.

11. Front panel audio connector (10-1 pin AAFP)


This connector is for a chassis-mounted front panel audio I/O module that supports either High Definition Audio or AC'97 audio standard. Connect one end of the front panel audio I/O module cable to this connector.



- We recommend that you connect a high-definition front panel audio module to this connector to avail of the motherboard high-definition audio capability.
- If you want to connect a high-definition front panel audio module to this connector, set the **Front Panel Select** item in the BIOS setup to **[HD Audio]**. If you want to connect an AC'97 front panel audio module to this connector, set the item to **[AC97]**. By default, this connector is set to **[HD Audio]**. See section 2.4.4 **Onboard Devices Configuration** for details.

12. System panel connector (20-8 pin PANEL)

This connector supports several chassis-mounted functions.



M4A78-EM/1394 System panel connector

- **System power LED (2-pin PLED)**

This 2-pin connector is for the system power LED. Connect the chassis power LED cable to this connector. The system power LED lights up when you turn on the system power, and blinks when the system is in sleep mode.

- **Hard disk drive activity LED (2-pin +IDE_LED)**

This 2-pin connector is for the HDD Activity LED. Connect the HDD Activity LED cable to this connector. The IDE LED lights up or flashes when data is read from or written to the HDD.

- **System warning speaker (4-pin SPEAKER)**

This 4-pin connector is for the chassis-mounted system warning speaker. The speaker allows you to hear system beeps and warnings.

- **Power/Soft-off button (2-pin PWRSW)**

This 2-pin connector is for the system power button. Pressing the power button turns the system ON or puts the system in SLEEP or SOFT-OFF mode depending on the BIOS settings. Pressing the power switch for more than four seconds while the system is ON turns the system OFF.

- **Reset button (2-pin RESET)**

This 2-pin connector is for the chassis-mounted reset button for system reboot without turning off the system power.

1.11 Software support

1.11.1 Installing an operating system

This motherboard supports Windows® XP/Vista Operating Systems (OS). Always install the latest OS version and corresponding updates to maximize the features of your hardware.



- Motherboard settings and hardware options vary. Refer to your OS documentation for detailed information.
- Ensure that you install Windows® XP Service Pack 3 or later versions / Windows® Vista Service Pack 1 or later versions before installing the drivers for better compatibility and system stability.

1.11.2 Support DVD information

The Support DVD that comes with the motherboard package contains the drivers, software applications, and utilities that you can install to avail all motherboard features.




The contents of the Support DVD are subject to change at any time without notice. Visit the ASUS website at www.asus.com for updates.

To run the Support DVD

Place the Support DVD into the optical drive. The DVD automatically displays the Drivers menu if Autorun is enabled on your computer.



The following screen is for reference only.



Click an icon to display Support DVD/ motherboard information

Click an item to install



If Autorun is NOT enabled on your computer, browse the contents of the Support DVD to locate the file ASSETUP.EXE from the BIN folder. Double-click the ASSETUP.EXE to run the DVD.

[illegible]

Chapter 2

BIOS information

2.1 Managing and updating your BIOS



Save a copy of the original motherboard BIOS file to a USB flash disk in case you need to restore the BIOS in the future. Copy the original motherboard BIOS using the ASUS Update utility.

2.1.1 ASUS Update utility

The ASUS Update is a utility that allows you to manage, save, and update the motherboard BIOS in Windows® environment.



-
- ASUS Update requires an Internet connection either through a network or an Internet Service Provider (ISP).
 - This utility is available in the support DVD that comes with the motherboard package.
-

Installing ASUS Update

To install ASUS Update:

1. Place the support DVD into the optical drive. The **Drivers** menu appears.
2. Click the **Utilities** tab, then click **ASUS Update**.
3. Follow the onscreen instructions to complete the installation.



Quit all Windows® applications before you update the BIOS using this utility.

Updating the BIOS

To update the BIOS:

1. From the Windows® desktop, click **Start > Programs > ASUS > ASUS Update > ASUS Update** to launch the ASUS Update utility.
2. From the dropdown list, select either of the following methods:

Updating from the Internet

- a. Select **Update BIOS from the Internet**, then click **Next**.
- b. Select the ASUS FTP site nearest you to avoid network traffic, or click **Auto Select** then click **Next**.
- c. From the FTP site, select the BIOS version that you want to download then click **Next**.



The ASUS Update utility is capable of updating itself through the Internet. Always update the utility to avail all its features.

Updating from a BIOS file

- a. Select **Update BIOS from a file**, then click **Next**.
 - b. Locate the BIOS file from the **Open** window, then click **Open**.
3. Follow the onscreen instructions to complete the updating process.

2.1.2 ASUS EZ Flash 2 utility


The ASUS EZ Flash 2 feature allows you to update the BIOS without using an OS-based utility.



Before you start using this utility, download the latest BIOS file from the ASUS website at www.asus.com.

To update the BIOS using EZ Flash 2:

1. Insert the USB flash disk that contains the latest BIOS file to the USB port, then launch EZ Flash 2 in either of these two ways:
 - Press **<Alt> + <F2>** during POST to display the following:



- Enter the BIOS setup program. Go to the **Tools** menu to select **EZ Flash 2** and press **<Enter>** to enable it.
2. Press **<Tab>** to switch between drives until the correct BIOS file is found, then press **<Enter>**. EZ Flash 2 performs the BIOS updating process and automatically reboots the system when done.



- This function supports USB flash disks with **FAT 32/16** format and single partition only.
- DO NOT shut down or reset the system while updating the BIOS to prevent system boot failure!

2.1.3 ASUS CrashFree BIOS 3 utility

The ASUS CrashFree BIOS 3 is an auto recovery tool that allows you to restore the BIOS file when it fails or gets corrupted during the updating process. You can update a corrupted BIOS file using the motherboard Support DVD or a USB flash disk that contains the updated BIOS file.



- Prepare the motherboard Support DVD or a USB flash disk containing the updated motherboard BIOS before using this utility.
- Always connect the SATA cable to the SATA1/2/3/5/6 connector; otherwise, the utility will not function.

Recovering the BIOS

To recover the BIOS:

1. Turn on the system.
2. Insert the Support DVD or USB flash disk containing the BIOS file to the optical disk drive or a USB port.

The utility displays the following message and automatically checks the Support DVD or the USB flash disk for the BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...
Checking for CD-ROM...
```

When the BIOS file is found, the utility reads it and starts erasing the corrupted BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...
Checking for CD-ROM...
CD-ROM found!
Reading file "M4A78EMF.ROM". Completed.
Start Erasing...
Start Programming...
```

3. Restart the system after the utility completes the updating process.



- Only a USB flash disk with FAT 32/16 format and single partition supports ASUS CrashFree BIOS 3. The device size should be smaller than 8GB.
- DO NOT shut down or reset the system while updating the BIOS! Doing so can cause system boot failure!



The recovered BIOS may not be the latest BIOS version for this motherboard. Download the latest BIOS file from the ASUS website at www.asus.com.

2.2 BIOS setup program

This motherboard supports a programmable Serial Peripheral Interface (SPI) chip that you can update using the provided utility described in section 2.1 **Managing and updating your BIOS**.

Use the BIOS Setup program when you are installing a motherboard, reconfiguring your system, or prompted to “Run Setup.” This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the SPI chip.

The SPI chip on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press **** during the Power-On Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.

If you want to enter Setup after POST, reboot the system by doing any of the following procedures:

- Restart using the OS standard shut-down procedure.
- Press **<Ctrl>+<Alt>+** simultaneously.
- Press the reset button on the system chassis.
- Press the power button to turn the system off then back on.




Using the **power button**, **reset button**, or the **<Ctrl>+<Alt>+** keys to force reset from a running operating system can cause damage to your data or system. We recommend that you always shut down the system properly from the operating system.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.



-
- The default BIOS settings for this motherboard apply to most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Select the **Load Setup Defaults** item under the **Exit** menu. See section 2.8 **Exit Menu**.
 - The BIOS setup screens in this chapter are for reference only. They may not exactly match what you see on your screen.
 - Visit the ASUS website at www.asus.com to download the latest BIOS file for this motherboard.
-

2.2.1 BIOS menu screen



2.2.2 Menu bar

The menu bar on top of the screen has the following main items:

| | |
|-----------------|--|
| Main | For changing the basic system configuration |
| Advanced | For changing the advanced system settings |
| Power | For changing the advanced power management (APM) configuration |
| Boot | For changing the system boot configuration |
| Tools | For configuring options for special functions |
| Exit | For selecting the exit options and loading default settings. |

To select an item on the menu bar, press the right or left arrow key on the keyboard until the desired item is highlighted.

2.2.3 Navigation keys

At the bottom right corner of a menu screen are the navigation keys for that particular menu. Use the navigation keys to select items in the menu and change the settings.



Some of the navigation keys differ from one screen to another.

2.2.4 Menu items

The highlighted item on the menu bar displays the specific items for that menu. For example, selecting Main shows the Main menu items.

The other items (Advanced, Power, Boot, Tools, and Exit) on the menu bar have their respective menu items.

2.2.5 Submenu items

A solid triangle before each item on a menu screen means that the item has a submenu. To display the submenu, select the item and press **<Enter>**.

2.2.6 Configuration fields

These fields show the values for the menu items. If an item is user-configurable, you can change the value of the field opposite the item. You cannot select an item that is not user-configurable.

A configurable field is enclosed in brackets, and is highlighted when selected. To change the value of a field, select it then press **<Enter>** to display a list of options. Refer to **2.2.7 Pop-up window**.

2.2.7 Pop-up window


Select a menu item then press **<Enter>** to display a pop-up window with the configuration options for that item.

2.2.8 Scroll bar

A scroll bar appears on the right side of a menu screen when there are items that do not fit on the screen. Press the **<Up>** / **<Down>** arrow keys or **<Page Up>** / **<Page Down>** keys to display the other items on the screen.

2.2.9 General help

At the top right corner of the menu screen is a brief description of the selected item.




2.3 Main menu

When you enter the BIOS Setup program, the Main menu screen appears, giving you an overview of the basic system information.



Refer to section 2.2.1 **BIOS menu screen** for information on the menu screen items and how to navigate through them.



2.3.1 System Time [xx:xx:xx]

Allows you to set the system time.

2.3.2 System Date [Day xx/xx/xxxx]

Allows you to set the system date.

2.3.3 Primary IDE Master/Slave, SATA 1/2/3/5/6, E-SATA

While entering Setup, the BIOS automatically detects the presence of IDE/SATA devices. There is a separate submenu for each IDE/SATA device. Select a device item then press **<Enter>** to display the IDE/SATA device information.

The BIOS automatically detects the values opposite the dimmed items (Device, Vendor, Size, LBA Mode, Block Mode, PIO Mode, Async DMA, Ultra DMA, and SMART monitoring). These values are not user-configurable. These items show Not Detected if no IDE/SATA device is installed in the system.

Type [Auto]

Selects the type of IDE drive. Setting this item to **[Auto]** allows automatic selection of the appropriate IDE device type. Select **[CDROM]** if you are specifically configuring a CD-ROM drive. Select **[ARMD]** (ATAPI Removable Media Device) if your device is either a ZIP, LS-120, or MO drive. Configuration options: [Not Installed] [Auto] [CDROM] [ARMD]



This item only appears in the Primary IDE Master/Slave menus.

LBA/Large Mode [Auto]

Enables or disables the LBA mode. Setting this item to **[Auto]** enables the LBA mode if the device supports this mode, and if the device was not previously formatted with LBA mode disabled. Configuration options: [Disabled] [Auto]

Block (Multi-Sector Transfer) M [Auto]

Enables or disables data multi-sectors transfers. When this item is set to **[Auto]**, the data transfer from and to the device occurs multiple sectors at a time if the device supports multi-sector transfer feature. When this item is set to **[Disabled]**, the data transfer from and to the device occurs one sector at a time. Configuration options: [Disabled] [Auto]

PIO Mode [Auto]

Selects the PIO mode. Configuration options: [Auto] [0] [1] [2] [3] [4]

DMA Mode [Auto]

Selects the DMA mode. Configuration options: [Auto]

SMART Monitoring [Auto]

Sets the Smart Monitoring, Analysis, and Reporting Technology. Configuration options: [Auto] [Disabled] [Enabled]

32Bit Data Transfer [Enabled]

Enables or disables 32-bit data transfer. Configuration options: [Disabled] [Enabled]

2.3.4 SATA Configuration

The **SATA Configuration** menu allows you to configure your storage devices. Select an item then press **<Enter>** to display the submenu.

OnChip SATA Channel [Enabled]

Enables or disables OnChip SATA Channel. Configuration options: [Disabled] [Enabled]

OnChip SATA Type [SATA]

This item appears only when you set the OnChip SATA Channel item to [Enabled]. Allows you to set the OnChip SATA Type. Configuration options: [SATA] [RAID] [AHCI]



If you want to boot the system from a hard disk drive included in a created RAID set, copy the RAID driver from the Support DVD to a USB flash disk before you install an operating system to the selected hard disk drive.

2.3.5 System Information

This menu gives you an overview of the general system specifications. The BIOS automatically detects the items in this menu.

BIOS Information

Displays the auto-detected BIOS information.

Processor

Displays the auto-detected CPU specification.

System Memory


Displays the auto-detected system memory.

2.4 Advanced menu

The **Advanced** menu items allow you to change the settings for the CPU and other system devices.



Take caution when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction.



2.4.1 JumperFree Configuration



Depending on your AMD® CPU type (AM2, AM2+ or AM3), the items on this section may not exactly match what you see on your screen.

CPU Overclocking [Auto]

Allows selection of CPU overclocking options to achieve desired CPU internal frequency. Select either one of the preset overclocking. Configuration options: [Auto] [Manual] [Overclock Profile] [Test Mode]



The following item appears only when the **CPU Overclocking** item is set to [Manual].

CPU/HT Reference Clock (MHz) [200]

Allows you to set the CPU/HT Reference Clock. The valid value is between 200 MHz and 550 MHz.



The following item appears only when the **CPU Overclocking** item is set to [Overclock Profile].

Overclock Options [Auto]

Allows you to set the overclocking options. Configuration options: [Auto] [Overclock 2%] [Overclock 5%] [Overclock 8%] [Overclock 10%]

GPU Overclocking [Auto]

Allows you to select the GPU Overclocking. Configuration options: [Auto] [Manual]



The following item appears only when the **GPU Overclocking** item is set to [Manual].

GPU Engine Clock [500]

Allows you to set the GPU engine clock. The valid value is between 150 and 999.

PCIe Overclocking [Auto]

Allows you to select the PCIe Overclocking. Configuration options: [Auto] [Manual]



The following item appears only when the **PCIe Overclocking** item is set to [Manual].

PCIe Clock [100]

Allows you to set the PCIe clock. The valid value is between 100 and 150.

Processor Frequency Multiplier [Auto]

Allows you to select the processor frequency. Configuration options: [Auto] [x8.0 1600 MHz] [x8.5 1700 MHz] [x9.0 1800 MHz] [x9.5 1900 MHz] [x10.0 2000 MHz] [x10.5 2100 MHz] [x11 2200 MHz] [x11.5 2300 MHz]

CPU Over Voltage [Auto]

Allows you to set the CPU over voltage. Configuration options: [Auto] [+50mv] [+100mv] [+150mv]

VDDNB Over Voltage [Auto]

Allows you to set the VDDNB over voltage. Configuration options: [Auto] [+33mv] [+66mv] [+100mv]

Hyper Transport Speed [Auto]

The Hyper Transport link will run at this speed if it is slower than or equal to the system clock and the board is capable. Configuration options: [200 Mhz] [400 Mhz] [600 Mhz] [800 Mhz] [1 GHz] [1.2 GHz] [1.4 GHz] [1.6 GHz] [1.8 GHz] [2.0 GHz] [Auto]

Hyper Transport Width [Auto]

The Hyper Transport link will run at this width. Configuration options: [Auto] [8 Bit] [16 Bit]

Memory Clock Mode [Auto]

Allows you to set the memory clock mode. Configuration options: [Auto] [Manual]



The following item appears only when the **Memory Clock Mode** item is set to [Manual].

Memclock Value [200 MHz]

Allows you to set the Memclock value. Configuration options: [200 MHz] [266 MHz] [333 MHz] [400 MHz] [533 MHz]

DRAM Timing Mode [Auto]

Allows you to set the DRAM timing mode. Configuration options: [Auto] [Both]

Memory Over Voltage [Auto]

Allows you to set the memory over voltage. The value ranges from 1.85000V to 2.24375V with a 0.00625V interval. Configuration options: [Auto]

Chipset Over Voltage [Auto]

Allows you to set the chipset over voltage. Configuration options: [Auto] [+50mv] [+100mv] [+150mv]

2.4.2 CPU Configuration

The items in this menu show the CPU-related information that the BIOS automatically detects.

GART Error Reporting [Disabled]

This option should remain disabled for the normal operation. The driver developer may enable it for testing purpose. Configuration options: [Disabled] [Enabled]

Microcode Updation [Enabled]

Allows you to enable or disable the microcode updation. Configuration options: [Disabled] [Enabled]

Secure Virtual Machine Mode [Disabled]

Allows you to enable or disable the AMD Secure Virtual Machine mode. Configuration options: [Disabled] [Enabled]

Cool 'n' Quiet [Enabled]

Allows you to enable or disable the generation of ACPI_PPC, _PSS, and _PCT objects. Configuration options: [Disabled] [Enabled]

CPU Prefetching [Enabled]

Allows you to enable or disable the CPU prefetching. Configuration options: [Enabled] [Disabled]

C1E Configuration [Disabled]

Allows you to enable or disable C1E Dual-Core related CPU power State. Configuration options: [Disabled] [Enabled]

Advanced Clock Calibration [Disabled]

Adjusting this item helps enhance the processor's overclocking capability.

[Disabled] Disables this function.

[Auto] The BIOS automatically adjusts this function.

[All Cores] Enables the processor to have the best overclocking performance.

[Per Core] Enhances the processor's overclocking capability.

2.4.3 Chipset

The **Chipset** menu allows you to change the advanced chipset settings. Select an item then press **<Enter>** to display the submenu.

NorthBridge Configuration

Memory Configuration

Bank Interleaving [Auto]

Allows you to enable the bank memory interleaving.

Configuration options: [Disabled] [Auto]

Channel Interleaving [Disabled]

Allows you to enable the channel memory interleaving.

Configuration options: [Disabled] [Address bits 6] [Address bits 12]

[XOR of Address bits [20:16,6]] [XOR of Address bits [20:16,9]]

Enable Clock to All DIMMs [Disabled]

Enables or disables clock to all DIMMs. Configuration options: [Disabled] [Enabled]

MemClk Tristate C3/ATLVID [Disabled]

Enables or disables the MemClk Tristate C3/ALTVID.

Configuration options: [Disabled] [Enabled]

Memory Hole Remapping [Enabled]

Enables or disables the memory remapping around memory hole. Configuration options: [Disabled] [Enabled]

DCT Unganged Mode [Auto]

Allows you to enable or disable unganged DRAM mode.

Configuration options: [Auto] [Always]

Power Down Enable [Enabled]

Enables or disables the DDR power down mode.

Configuration options: [Disabled] [Enabled]

ECC Configuration

ECC Mode [Disabled]

Enables or disables the DRAM ECC that allows the hardware to report and correct memory errors automatically. Configuration options: [Disabled] [Basic] [Good] [Super] [Max] [User]

Alternate VID [Auto]

Allows you to specify the alternate VID while in low power states. Configuration options:

[Auto] [0.800 V] [0.825V] [0.850V] [0.875V] [0.900V] ... [1.500V] [1.525V] [1.550V]

Internal Graphics

Primary Video Controller [GFX0-GPP-IGFX-PCI]

Allows you to set the primary video controller. Configuration options: [GFX0-GPP-IGFX-PCI] [GPP-GFX0-IGFX-PCI] [PCI-GFX0-GPP-IGFX] [IGFX-GFX0-GPP-PCI]

UMA Frame Buffer Size [Auto]

Configuration options: [Auto] [32MB] [64MB] [128MB] [256MB]

Surround View [Auto]

Allows you to disable or enable the Surround View function. Configuration options: [Auto] [Disabled] [Enabled]



This item becomes user-configurable when you install an ATI graphics card into the PCIe x16 slot.

Frame Buffer Location [Above 4G]

Configuration options: [Below 4G] [Above 4G]

AMD 780 HD Audio [Enabled]

Allows you to enable or disable AMD 780 HD audio. Configuration options: [Enabled] [Disabled]

2.4.4 Onboard Devices Configuration

Serial Port1 Address [3F8/IRQ4]

Allows you to select the Serial Port1 base address.

Configuration options: [Disabled] [3F8/IRQ4] [2F8/IRQ3] [3E8/IRQ4] [2E8/IRQ3]

Parallel Port Address [378]

Allows you to select the Parallel Port base addresses.

Configuration options: [Disabled] [378] [278] [3BC]

Parallel Port Mode [Normal]

Allows you to select the Parallel Port mode. Configuration options: [Normal] [EPP] [ECP] [EPP+ECP]

Parallel Port IRQ [IRQ7]

Allows you to set the Parallel Port IRQ. Configuration options: [IRQ5] [IRQ7]

HD Audio Controller [Enabled]

Allows you to enable or disable the HD Audio Controller. Configuration options: [Disabled] [Enabled]

Front Panel Select [HD Audio]

Allows you to set the HD audio mode. Configuration options: [AC97] [HD Audio]

SPDIF_OUT Mode Setting [SPDIF Output]

Allows you to set the SPDIF_OUT mode. Configuration options: [HDMI Output] [SPDIF Output]

Onboard LAN Controller [Enabled]

Allows you to enable or disable the Onboard LAN. Configuration options: [Enabled] [Disabled]

Onboard LAN Boot ROM [Disabled]

Allows you to enable or disable the Onboard LAN Boot ROM. Configuration options: [Enabled] [Disabled]

1394 Controller [Enabled]

Allows you to enable or disable the onboard 1394 device support. Configuration options: [Enabled] [Disabled]

2.4.5 PCI PnP

The **PCI PnP** menu items allow you to change the advanced settings for PCI/PnP devices.

The menu includes setting IRQ and DMA channel resources for either PCI/PnP or legacy ISA devices, and setting the memory size block for legacy ISA devices.



Be cautious when changing the settings of the PCI PnP menu items. Incorrect field values can cause the system to malfunction.

Plug and Play O/S [No]

When set to **[No]**, BIOS configures all the devices in the system. When set to **[Yes]** and if you install a Plug and Play operating system, the operating system configures the Plug and Play devices not required for boot. Configuration options: [No] [Yes]

2.4.6 USB Configuration

The items in this menu allows you to change the USB-related features. Select an item then press **<Enter>** to display the configuration options.



The Module Version and USB Devices Enabled items show the auto-detected values. If no USB device is detected, the item shows **None**.

USB Functions [Enabled]

Allows you to enable or disable the USB Functions.

Configuration options: [Enabled] [Disabled]

USB 2.0 Controller [Enabled]

Allows you to enable or disable the USB 2.0 Controller.

Configuration options: [Enabled] [Disabled]

Legacy USB Support [Enabled]


Allows you to enable or disable support for USB devices on legacy operating systems (OS). Setting to Auto allows the system to detect the presence of USB devices at startup. If detected, the USB controller legacy mode is enabled. If no USB device is detected, the legacy USB support is disabled. Configuration options: [Disabled] [Enabled] [Auto]

USB 2.0 Controller Mode [HiSpeed]

Allows you to configure the USB 2.0 controller in HiSpeed (480 Mbps) or Full Speed (12 Mbps). Configuration options: [FullSpeed] [HiSpeed]

2.5 Power menu

The Power menu items allow you to change the settings for the Advanced Configuration and Power Interface (ACPI) and the Advanced Power Management (APM). Select an item then press **<Enter>** to display the configuration options.



2.5.1 Suspend Mode [Auto]

Allows you to select the Advanced Configuration and Power Interface (ACPI) state to be used for system suspend. Configuration options: [S1 (POS) Only] [S3 Only] [Auto]

[S1(POS) Only] - Enables the system to enter the ACPI S1 (Power on Suspend) sleep state. In S1 sleep state, the system appears suspended and stays in a low power mode. The system can be resumed at any time.

[S3 Only] - Enables the system to enter the ACPI S3 (Suspend to RAM) sleep state (default). In S3 sleep state, the system appears to be off and consumes less power than in the S1 state. When signaled by a wake-up device or event, the system resumes to its working state exactly where it was left off.

[Auto] - Detected by OS.

2.5.2 ACPI 2.0 Support [Disabled]

Allows you to add more tables for Advanced Configuration and Power Interface (ACPI) 2.0 specifications. Configuration options: [Disabled] [Enabled]

2.5.3 ACPI APIC Support [Enabled]

Allows you to enable or disable the Advanced Configuration and Power Interface (ACPI) support in the Application-Specific Integrated Circuit (ASIC). When set to **Enabled**, the ACPI APIC table pointer is included in the RSDT pointer list. Configuration options: [Disabled] [Enabled]

2.5.4 APM Configuration

Restore on AC Power Loss [Power Off]

When set to **Power Off**, the system goes into off state after an AC power loss. When set to **Power On**, the system goes on after an AC power loss.
Configuration options: [Power On] [Power Off] [Last State]

Power On From S5 By PME# [Disabled]

Allows you to enable or disable PME wake from sleep state. Configuration options: [Disabled] [Enabled]

Power On From S5 By Ring [Disabled]

Enable or disable RI to generate a wake event. Configuration options: [Disabled] [Enabled]

Power On From S5 By PS/2 KB/MS [Disabled]

Enable or disable PS/2 Keyboard/Mouse to generate a wake event.
Configuration options: [Disabled] [Enabled]

Power On From S5 By RTC Alarm [Disabled]

Allows you to enable or disable RTC to generate a wake event. When this item is set to **Enabled**, the items RTC Alarm Date, RTC Alarm Hour, RTC Alarm Minute, and RTC Alarm Second appear with set values. Configuration options: [Disabled] [Enabled]

2.5.5 HW Monitor Configuration

CPU Temperature [xxx°C/xxx°F] or [Ignored]

MB Temperature [xxx°C/xxx°F] or [Ignored]

The onboard hardware monitor automatically detects and displays the motherboard and CPU temperatures. Select **Ignored** if you do not wish to display the detected temperatures.

CPU/Chassis/Power Fan Speed [xxxxRPM] or [Ignored]

The onboard hardware monitor automatically detects and displays the CPU, chassis, and power fan speed in rotations per minute (RPM). If the fan is not connected to the motherboard, the field shows **N/A**. Select **Ignored** if you do not wish to display the detected speed.

VCORE Voltage, 3.3V Voltage, 5V Voltage, 12V Voltage

The onboard hardware monitor automatically detects the voltage output through the onboard voltage regulators. Select **Ignored** if you do not wish to display the detected voltage output.

Smart Q-Fan Function [Enabled]

Allows you to enable or disable the ASUS Q-Fan feature that smartly adjusts the fan speeds for more efficient system operation. Configuration options: [Disabled] [Enabled]

Fan Auto Mode Start Voltage [5.0V]

Allows you to select the fan auto mode start voltage. Configuration options: [4.0V] [4.5V] [5.0V] [5.5V] [6.0V]

Fan Auto Mode Start Speed Temp [25°C]


Allows you to select the fan auto mode start speed temperature. Configuration options: [25°C] [26°C] [27°C] [28°C] ... [48°C]

Fan Auto Mode Full Speed Temp [55°C]

Allows you to select the fan auto mode full speed temperature. Configuration options: [51°C] [52°C] [53°C] [54°C] ... [75°C]

2.6 Boot menu

The **Boot** menu items allow you to change the system boot options. Select an item then press **<Enter>** to display the sub-menu.



2.6.1 Boot Device Priority

1st ~ xxth Boot Device

These items specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system. Configuration options: [Removable Dev.] [Hard Drive] [ATAPI CD-ROM] [Disabled]

2.6.2 Boot Settings Configuration

Quick Boot [Enabled]

Enabling this item allows the BIOS to skip some power on self tests (POST) while booting to decrease the time needed to boot the system. When set to **[Disabled]**, BIOS performs all the POST items. Configuration options: [Disabled] [Enabled]

Full Screen Logo [Enabled]

This allows you to enable or disable the full screen logo display feature. Configuration options: [Disabled] [Enabled]



Set this item to **[Enabled]** to use the ASUS MyLogo 2™ feature.

AddOn ROM Display Mode [Force BIOS]

Sets the display mode for option ROM. Configuration options: [Force BIOS] [Keep Current]

Bootup Num-Lock [On]

Allows you to select the power-on state for the NumLock. Configuration options: [Off] [On]

Wait for 'F1' If Error [Enabled]

When set to **Enabled**, the system waits for the F1 key to be pressed when error occurs.

Configuration options: [Disabled] [Enabled]

Hit 'DEL' Message Display [Enabled]

When set to **Enabled**, the system displays the message **Press DEL to run Setup** during POST. Configuration options: [Disabled] [Enabled]

2.6.3 Security

The Security menu items allow you to change the system security settings. Select an item then press **<Enter>** to display the configuration options.

Change Supervisor Password

Select this item to set or change the supervisor password. The Supervisor Password item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a Supervisor Password:

1. Select the **Change Supervisor Password** item and press **<Enter>**.
2. From the password box, type a password composed of up to six letters and/or numbers, then press **<Enter>**.
3. Confirm the password when prompted.

The message “Password Installed” appears after you successfully set your password.

To change the supervisor password, follow the same steps as in setting a supervisor password.

To clear the supervisor password, select the **Change Supervisor Password** then press **<Enter>** twice. The message “Password Uninstalled” appears.



If you forget your BIOS password, you can clear it by erasing the CMOS Real Time Clock (RTC) RAM. See section **1.9 Jumpers** for information on how to erase the RTC RAM.

After you have set a supervisor password, the other items appear to allow you to change other security settings.

User Access Level [Full Access]

This item allows you to select the access restriction to the Setup items. Configuration options: [No Access] [View Only] [Limited] [Full Access]

No Access prevents user access to the Setup utility.

View Only allows access but does not allow change to any field.

Limited allows changes only to selected fields, such as Date and Time.

Full Access allows viewing and changing all the fields in the Setup utility.

Change User Password

Select this item to set or change the user password. The **User Password** item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a User Password:

1. Select the **Change User Password** item and press **<Enter>**.
2. On the password box that appears, type a password composed of up to six letters and/or numbers, then press **<Enter>**.
3. Confirm the password when prompted.

The message “**Password Installed**” appears after you set your password successfully.

To change the user password, follow the same steps as in setting a user password.

Clear User Password


Select this item to clear the user password.

Password Check [Setup]

When set to **[Setup]**, BIOS checks for user password when accessing the Setup utility. When set to **[Always]**, BIOS checks for user password both when accessing Setup and booting the system. Configuration options: [Setup] [Always]

2.7 Tools menu

The **Tools** menu items allow you to configure options for special functions. Select an item then press **<Enter>** to display the sub-menu.



2.7.1 ASUS EZ Flash 2

Allows you to run ASUS EZ Flash 2. When you press **<Enter>**, a confirmation message appears. Use the left/right arrow key to select between **[Yes]** or **[No]**, then press **<Enter>** to confirm your choice.

2.7.2 Express Gate [Auto]

Allows you to enable or disable the ASUS Express Gate feature. ASUS Express Gate is a unique instant-on environment that provides quick access to the Internet and Skype. Configuration options: **[Enabled]** **[Disabled]** **[Auto]**

Enter OS Timer [10 Seconds]

Sets countdown duration that the system waits at the Express Gate's first screen before starting Windows or other installed OS. Choose **[Prompt User]** to stay at the first screen of Express Gate for user action. Configuration options: **[Prompt User]** **[1 second]** **[3 seconds]** **[5 seconds]** **[10 seconds]** **[15 seconds]** **[20 seconds]** **[30 seconds]**

Reset User Data [No]

Allows you to clear Express Gate's user data. Configuration options: **[No]** **[Reset]**

When setting this item to **[Reset]**, ensure to save the setting to the BIOS so that the user data will be cleared the next time you enter the Express Gate. User data includes the Express Gate's settings as well as any personal information stored by the web browser (bookmarks, cookies, browsing history, etc.). This is useful in the rare case where corrupt settings prevent the Express Gate environment from launching properly.



The first time wizard will run again when you enter the Express Gate environment after clearing its settings.


2.7.3 AI NET 2

Check Realtek LAN cable [Disabled]

Enables or disables checking of the Realtek LAN cable during the Power-On Self-Test (POST). Configuration options: **[Disabled]** **[Enabled]**

2.8 Exit menu

The **Exit** menu items allow you to load the optimal or failsafe default values for the BIOS items, and save or discard your changes to the BIOS items.



Pressing **<Esc>** does not immediately exit this menu. Select one of the options from this menu or **<F10>** from the legend bar to exit.

Exit & Save Changes

Once you are finished making your selections, choose this option from the Exit menu to ensure the values you selected are saved to the CMOS RAM. An onboard backup battery sustains the CMOS RAM so it stays on even when the PC is turned off. When you select this option, a confirmation window appears. Select **OK** to save changes and exit.

Exit & Discard Changes

Select this option only if you do not want to save the changes that you made to the Setup program. If you made changes to fields other than System Date, System Time, and Password, the BIOS asks for a confirmation before exiting.

Discard Changes

This option allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select **OK** to discard any changes and load the previously saved values.

Load Setup Defaults

This option allows you to load the default values for each of the parameters on the Setup menus. When you select this option or if you press **<F5>**, a confirmation window appears. Select **OK** to load default values. Select **Exit & Save Changes** or make other changes before saving the values to the non-volatile RAM.