

M4N78-VM

ASUS[®]

Motherboard

E4704

First Edition V1

May 2009

Copyright © 2009 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK Computer Inc. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Notices.....	vi
Safety information	vii
About this guide	vii
M4N78-VM specifications summary.....	ix
Chapter 1: Product introduction	
1.1 Welcome!	1-1
1.2 Package contents	1-1
1.3 Special features	1-1
1.3.1 Product highlights	1-1
1.3.2 Innovative ASUS features	1-3
1.4 Before you proceed	1-5
1.5 Motherboard overview	1-6
1.5.1 Placement direction	1-6
1.5.2 Screw holes	1-6
1.5.3 Motherboard layout	1-7
1.5.4 Layout contents.....	1-7
1.6 Central Processing Unit (CPU)	1-8
1.6.1 Installing the CPU	1-8
1.6.2 Installing the heatsink and fan	1-10
1.7 System memory	1-11
1.7.1 Overview	1-11
1.7.2 Memory configurations.....	1-12
1.7.3 Installing a DIMM	1-16
1.7.4 Removing a DIMM	1-16
1.8 Expansion slots	1-17
1.8.1 Installing an expansion card	1-17
1.8.2 Configuring an expansion card	1-17
1.8.3 PCI slots.....	1-17
1.8.4 PCI Express x1 slot.....	1-17
1.8.5 PCI Express x16 slot.....	1-17
1.9 Jumpers	1-18
1.10 Connectors	1-20
1.10.1 Rear panel ports	1-20
1.10.2 Internal connectors	1-22

Contents

1.11	Software support	1-30
1.11.1	Installing an operating system	1-30
1.11.2	Support DVD information	1-30

Chapter 2: BIOS information

2.1	Managing and updating your BIOS	2-1
2.1.1	ASUS Update utility	2-1
2.1.2	ASUS EZ Flash 2 utility.....	2-2
2.1.3	ASUS CrashFree BIOS 3 utility	2-3
2.2	BIOS setup program	2-4
2.2.1	BIOS menu screen.....	2-5
2.2.2	Menu bar.....	2-5
2.2.3	Navigation keys.....	2-5
2.2.4	Menu items	2-6
2.2.5	Submenu items	2-6
2.2.6	Configuration fields	2-6
2.2.7	Pop-up window	2-6
2.2.8	Scroll bar.....	2-6
2.2.9	General help	2-6
2.3	Main menu	2-7
2.3.1	System Time	2-7
2.3.2	System Date	2-7
2.3.3	Primary IDE Master/Slave, SATA 1-4.....	2-7
2.3.4	Storage Configuration	2-8
2.3.5	System Information	2-8
2.4	Advanced menu	2-9
2.4.1	JumperFree Configuration	2-9
2.4.2	CPU Configuration	2-12
2.4.3	Chipset.....	2-12
2.4.4	Onboard Devices Configuration.....	2-14
2.4.5	PCI PnP	2-14
2.4.6	USB Configuration	2-14
2.5	Power menu	2-15
2.5.1	Suspend Mode.....	2-16
2.5.2	ACPI 2.0 Support	2-16

Contents

2.5.3	ACPI APIC Support.....	2-16
2.5.4	APM Configuration.....	2-16
2.5.5	Hardware Monitor	2-17
2.6	Boot menu	2-17
2.6.1	Boot Device Priority	2-18
2.6.2	Boot Settings Configuration	2-18
2.6.3	Security	2-18
2.7	Tools menu	2-20
2.7.1	ASUS EZ Flash 2.....	2-20
2.7.2	Express Gate	2-20
2.7.3	AI NET 2.....	2-20
2.8	Exit menu	2-21

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://green.asus.com/english/REACH.htm>.



DO NOT throw the motherboard in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.



DO NOT throw the mercury-containing button cell battery in municipal waste. This symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.

Safety information

Electrical safety

- To prevent electric shock hazard, disconnect the power cable from the electric outlet before relocating the system.
- When adding or removing devices to or from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the motherboard, ensure that all power cables are unplugged.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operation safety

- Before installing the motherboard and adding devices on it, carefully read all the manuals that came with the package.
- Before using the product, ensure that all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Do not place the product in any area where it may become wet.
- Place the product on a stable surface.
- If you encounter technical problems with the product, contact a qualified service technician or your retailer.

About this guide

This user guide contains the information you need when installing and configuring the motherboard.

How this guide is organized

This guide contains the following parts:

- **Chapter 1: Product introduction**
This chapter describes the features of the motherboard and the new technology it supports.
- **Chapter 2: BIOS information**
This chapter tells how to change system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

Conventions used in this guide

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Instructions that you **MUST** follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. ASUS websites

The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS contact information.

2. Optional documentation

Your product package may include optional documentation, such as warranty flyers, that may have been added by your dealer. These documents are not part of the standard package.

Typography

Bold text

Indicates a menu or an item to select.

Italics

Used to emphasize a word or a phrase.

<Key>

Keys enclosed in the less-than and greater-than sign means that you must press the enclosed key.

Example: <Enter> means that you must press the Enter or Return key.

<Key1>+<Key2>+<Key3>

If you must press two or more keys simultaneously, the key names are linked with a plus sign (+).

Example: <Ctrl>+<Alt>+<D>

M4N78-VM specifications summary

CPU	<p>AMD® Phenom™ X4 / Phenom™ X3 / Athlon™ X2 / Athlon™ / Sempron™ processors (socket AM2+/AM2) Compatible with Phenom™ II / Athlon™ X4 / Athlon™ X3 / Athlon™ X2 processors (AM3 CPU) Supports AMD® Cool 'n' Quiet™ Technology Supports CPU up to 125W * Refer to www.asus.com for the AMD® CPU support list.</p>
Chipset	NVIDIA® GeForce 8200 (MCP78S)
System bus	<p>Up to 5200 MT/s HyperTransport™ 3.0 interface for AM2+/AM3 CPU 2000 / 1600 MT/s for AM2 CPU</p>
Memory	<p>Dual channel memory architecture</p> <ul style="list-style-type: none"> - 2 x 240-pin DIMM sockets support unbuffered ECC and non-ECC 1200(O.C.)/1066/800/667 MHz DDR2 memory modules - Supports up to 8GB system memory <p>* DDR2 1200(O.C.)/1066 is supported by AM2+/AM3 CPU only. ** Refer to www.asus.com or this user manual for the Memory QVL (Qualified Vendors List). *** When you install a total memory of 4GB capacity or more, Windows® 32-bit operating system may only recognize less than 3GB. We recommend a maximum of 3GB system memory if you are using a Windows® 32-bit operating system.</p>
Graphics	<p>Integrated NVIDIA® GeForce 8 Series GPU Maximum shared memory of 512MB Supports Hybrid SLI™ technology (for Windows® Vista only) Supports HDMI™ technology with max. resolution up to 1920 x 1200 Supports DVI with max. resolution up to 1920 x 1200 Supports D-Sub with max. resolution up to 1920 x 1440 Supports Microsoft® DirectX 10 Supports PCI Express™ 2.0/1.0 architecture</p>
Expansion slots	<p>1 x PCI Express™ x16 slot 1 x PCI Express™ x1 slot 2 x PCI 2.2 slots</p>
Storage	<p>1 x UltraDMA 133/100/66 connector 6 x Serial ATA 3Gb/s connectors support RAID 0, RAID 1, RAID 0+1, RAID 5, and JBOD configurations (for Windows® Vista only)</p>
LAN	RTL8211CL PHY Gigabit LAN

(continued on the next page)

M4N78-VM specifications summary

Audio	<p>ALC887 High Definition Audio 8-channel CODEC</p> <ul style="list-style-type: none"> - Supports optical S/PDIF out interface at back I/O - Supports Jack-detect and Multi-streaming technologies
USB	<p>Supports up to 12 USB 2.0/1.1 ports (6 ports at mid-board, 6 ports at the back panel)</p>
ASUS special features	<p>ASUS Express Gate ASUS EPU-4 Engine ASUS Q-Fan ASUS CrashFree BIOS 3 ASUS EZ Flash 2 ASUS AI NET 2 ASUS MyLogo 2 ASUS Turbo Key</p>
ASUS overclocking features	<p>SFS (Stepless Frequency Selection):</p> <ul style="list-style-type: none"> - FSB tuning from 200MHz up to 550MHz at 1MHz increment - Memory tuning from 667MHz up to 1066MHz - PCIe frequency tuning from 100MHz up to 150MHz at 1MHz increment <p>Overclocking protection:</p> <ul style="list-style-type: none"> - ASUS C.P.R. (CPU Parameter Recall)
Back panel I/O ports	<p>1 x PS/2 Keyboard / Mouse Combo port 1 x Optical S/PDIF out port 1 x HDMI port 1 x DVI port 1 x D-Sub port 1 x LAN (RJ-45) port 6 x USB 2.0/1.1 ports 8-channel audio I/O ports</p>
Internal I/O connectors	<p>3 x USB 2.0/1.1 connectors support additional 6 USB 2.0/1.1 ports 1 x IDE connector 1 x COM connector 6 x SATA connectors 1 x CPU/Chassis/Power fan connectors 1 x LPT connector 1 x Front panel audio connector 1 x System panel connector 1 x CD audio-in connector 1 x S/PDIF out connector 1 x 24-pin EATX power connector 1 x 4-pin ATX 12V power connector</p>

(continued on the next page)

M4N78-VM specifications summary

BIOS	8Mb Flash ROM, AMI BIOS, PnP, DMI2.0, WfM2.0, ACPI 2.0, SM BIOS 2.5
Accessories	1 x UltraDMA 133/100/66 cable 1 x Serial ATA cable 1 x I/O shield 1 x User Manual
Support DVD	Drivers ASUS Express Gate ASUS Update ASUS PC Probe II Anti-Virus software (OEM version)
Form Factor	MicroATX form factor: 9.6 in x 8.8 in (24.4cm x 22.4cm)

**Specifications are subject to change without notice.*

Chapter 1

Product introduction

1.1 Welcome!

Thank you for buying an ASUS® M4N78-VM motherboard!

The motherboard delivers a host of new features and latest technologies, making it another standout in the long line of ASUS quality motherboards!

Before you start installing the motherboard, and hardware devices on it, check the items in your package with the list below.

1.2 Package contents

Check your motherboard package for the following items.

Motherboard	ASUS M4N78-VM motherboard
Cables	1 x Serial ATA cable 1 x UltraDMA 133/100/66 cable
Accessories	1 x I/O shield
Application DVD	ASUS motherboard Support DVD
Documentations	User Manual



If any of the above items is damaged or missing, contact your retailer.

1.3 Special features

1.3.1 Product highlights



AMD® Phenom™ II / Athlon™ x4 / Athlon™ x3 / Athlon™ x2 AM3 CPU support

This motherboard supports AMD® AM3 multi-core processors with unique L3 cache and delivers better overclocking capabilities with less power consumption. It features dual-channel DDR2 1066 memory support and accelerates data transfer rate up to 5200MT/s via HyperTransport™ 3.0-based system bus. This motherboard also supports AMD® CPUs in the new 45nm manufacturing process.



AMD® Phenom™ x4 / Phenom™ x3 / Athlon™ x2 / Athlon™ / Sempron™ processors (socket AM2+/AM2)

This motherboard supports AMD® Socket AM2+ multi-core processors. It features dual-channel DDR2 1066 memory support and accelerates data transfer rate up to 5200MT/s via HyperTransport™ 3.0-based system bus. It also supports AMD® Cool 'n' Quiet Technology.



NVIDIA® GeForce 8200

The NVIDIA® GeForce 8200 offers the support of Hybrid SLI technology, DirectX10 graphics features, HD video playback with HDMI / DVI output. It also supports HyperTransport™ 3.0 interface, PCI Express™ 2.0 bus architecture, Serial ATA 3 GB/s devices, and is optimized with AMD's AM2+/AM3 and multi-core CPUs to provide excellent system performance.



HyperTransport™ 3.0 support

HyperTransport™ 3.0 technology provides 2.6 times more bandwidth than HT1.0 that radically improves system efficiency for a smoother and faster computing environment.



AMD Cool 'n' Quiet Technology

This motherboard supports the AMD Cool 'n' Quiet technology which monitors system operation and automatically adjusts CPU voltage and frequency for a cool and quiet operating environment.



Dual channel DDR2 1200(O.C.) support

To attain top performance, ASUS engineers have successfully unleashed DDR2 1200(O.C.) MHz to meet the higher bandwidth requirements of the latest operating system, 3D graphics, multimedia, and Internet applications.



- DDR2 1200(O.C.)/1066 is supported by AM2+/AM3 CPU only.
- Ensure that you download the latest BIOS version at www.asus.com and purchase the memory modules on the ASUS official Memory Qualified Vendors Lists (QVL).



Gigabit LAN solution

The onboard LAN controller is a highly integrated Gb LAN controller. It is enhanced with an ACPI management function to provide efficient power management for advanced operating systems.



NVIDIA® Hybrid SLI™ support

Hybrid SLI™ technology is a unique hybrid multi-GPU technology built upon NVIDIA SLI technology. Hybrid SLI™ turbo-charges performance of NVIDIA discrete graphics cards when combined with this series motherboard GPUs.



- Hybrid SLI™ is supported by Windows® Vista OS only.
- Visit the ASUS website at www.asus.com to download the latest Hybrid SLI driver.



Serial ATA 3Gb/s technology

This motherboard supports hard drives based on the Serial ATA (SATA) 3Gb/s storage specifications. It also supports RAID 0, RAID 1, RAID 0+1, RAID 5, and JBOD configurations for Serial ATA drives.



8-channel high definition audio

The onboard 8-channel HD audio (High Definition Audio, previously codenamed Azalia) CODEC enables high-quality 192KHz/24-bit audio output and jack-detect feature that automatically detects and identifies what types of peripherals are plugged into the audio I/O jacks and notifies users of inappropriate connection, which means there will be no more confusion of Line-in, Line-out, and Mic jacks.



HDMI™ Interface

High-Definiton Multimedia Interface (HDMI) is the first and only industry-supported, uncompressed, all digital audio and video interface via a single cable and is HDCP compliant allowing playback of HD DVD, Blu-ray Disc and other protected content.



PCI Express 2.0 support

The motherboard supports the PCI Express 2.0 devices for double speed and bandwidth which enhances system performance.

1.3.2 Innovative ASUS features



ASUS Express Gate

Express Gate is a unique OS built into the motherboard. Five seconds after bootup, you can instantly surf the Internet without entering the Windows® OS.



- The actual boot time depends on the system configuration.
- ASUS Express Gate supports file uploading from SATA HDDs, ODDs and USB drives and downloading to USB drives only.
- Express Gate complies with the OpenGL standard. Refer to <http://support.asus.com> for Express Gate source codes.



ASUS MyLogo2™

This feature allows you to convert your favorite photo into a 256-color boot logo for a more colorful and vivid image on your screen.



ASUS CrashFree BIOS 3

ASUS CrashFree BIOS 3 is an auto-recovery tool that allows you to restore a corrupted BIOS file using the bundled support DVD or a USB flash disk that contains the BIOS file.



ASUS EZ Flash 2

ASUS EZ Flash 2 is a utility that allows you to update the BIOS without using an OS-based utility.



ASUS Q-Fan

ASUS Q-Fan technology intelligently adjusts CPU fan speeds according to system loading to ensure a quiet, cool, and efficient operation.



ASUS EPU

ASUS EPU is a unique power saving technology that detects the current system loadings and adjusts the power consumption in real time.



Turbo Key

ASUS Turbo Key allows you to turn the PC power button into a physical overclocking button. After the easy setup, Turbo Key can boost performances without interrupting ongoing work or games—with just one touch!



ASUS AI NET 2

ASUS AI NET 2 remotely detects the cable connection immediately after turning on the system, and any faulty cable connections are reported back up to 100 meters at 1 meter accuracy.



Green ASUS

This motherboard and its packaging comply with the European Union's Restriction on the use of Hazardous Substances (RoHS). This is in line with the ASUS vision of creating environment-friendly and recyclable products/packaging to safeguard consumers' health while minimizing the impact on the environment.



C.P.R. (CPU Parameter Recall)

The BIOS C.P.R. feature automatically restores the CPU default settings when the system hangs due to overclocking failure. C.P.R. eliminates the need to open the system chassis and clear the RTC data. Simply shut down and reboot the system, and the BIOS automatically restores the CPU parameters to their default settings.

1.4 Before you proceed


Take note of the following precautions before you install motherboard components or change any motherboard settings.



- Unplug the power cord from the wall socket before touching any component.
- Before handling components, use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, to avoid damaging them due to static electricity.
- Hold components by the edges to avoid touching the ICs on them.
- Whenever you uninstall any component, place it on a grounded antistatic pad or in the bag that came with the component.
- Before you install or remove any component, switch off the ATX power supply and detach its power cord. Failure to do so may cause severe damage to the motherboard, peripherals, or components.

Onboard LED

The motherboard comes with a standby power LED that lights up to indicate that the system is ON, in sleep mode, or in soft-off mode. This is a reminder that you should shut down the system and unplug the power cable before removing or plugging in any motherboard component. The illustration below shows the location of the onboard LED.



1.5 Motherboard overview

1.5.1 Placement direction

When installing the motherboard, ensure that you place it into the chassis in the correct orientation. The edge with external ports goes to the rear part of the chassis as indicated in the image below.


1.5.2 Screw holes

Place six screws into the holes indicated by circles to secure the motherboard to the chassis.




DO NOT overtighten the screws! Doing so can damage the motherboard.

Place this side towards
the rear of the chassis.



1.5.3 Motherboard layout



1.5.4 Layout contents

Connectors/Jumpers/Slots/LED	Page	Connectors/Jumpers/Slots/LED	Page
1. Keyboard power (3-pin KBPWR)	1-19	10. USB connectors (10-1 pin USB78, USB910, USB1112)	1-27
2. USB device wake-up (3-pin USBPW1-6, 3-pin USBPW7-12)	1-19	11. LPT connector (26-1 pin LPT)	1-29
3. ATX power connectors (24-pin EATXPWR, 4-pin ATX12V)	1-23	12. Serial port connector (10-1 pin COM1)	1-22
4. CPU, power, and chassis fan connectors (4-pin CPU_FAN, 3-pin PWR_FAN, and 3-pin CHA_FAN)	1-29	13. System panel connector (20-8 pin PANEL)	1-26
5. CPU Socket AM2+	1-8	14. Onboard LED (SB_PWR)	1-5
6. DDR2 DIMM slots	1-29	15. Front panel audio connector (10-1 pin AAFP)	1-28
7. IDE connector (40-1 pin PRI_IDE)	1-24	16. Digital audio connector (4-1 pin SPDIF_OUT)	1-28
8. Clear RTC RAM (3-pin CLRRTC)	1-18	17. Optical drive audio connector (4-pin CD)	1-27
9. SATA connectors (7-pin SATA1-6)	1-25	18. PCI / PCIe x 1 / PCIe x 16 slots	1-17

1.6 Central Processing Unit (CPU)

This motherboard comes with an AM2+ / AM2 socket designed for AMD® Phenom™ x4 / Phenom™ x3 / Athlon™ x2 / Athlon™ / Sempron™ processors. It also supports AM3 CPUs including Phenom™ II / Athlon™ x4 / Athlon™ x3 / Athlon™ x2 processors.




The AM2+ / AM2 socket has a different pinout from the 940-pin socket designed for the AMD Opteron™ processor. Use a CPU that is designed for the AM2+ / AM2 socket.

1.6.1 Installing the CPU

To install a CPU:


1. Locate the CPU socket on the motherboard.



M4N78-VM CPU socket AM2+

2. Press the lever sideways to unlock the socket, then lift it up to a 90°-100° angle.

Socket lever




Ensure that the socket lever is lifted up to a 90°-100° angle; otherwise, the CPU will not fit in completely.


3. Position the CPU above the socket such that the CPU corner with the gold triangle matches the socket corner with a small triangle.
4. Carefully insert the CPU into the socket until it fits in place.




The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to prevent bending the pins and damaging the CPU!



- When the CPU is in place, push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked.
- Install a CPU heatsink and fan following the instructions that comes with the heatsink package. You can also refer to section **1.6.2 Installing heatsink and fan** for instructions.



- Connect the CPU fan cable to the CPU_FAN connector on the motherboard.



M4N78-VM CPU fan connector



DO NOT forget to connect the CPU fan connector! Hardware monitoring errors can occur if you fail to plug this connector.

1.6.2 Installing the heatsink and fan




Ensure that you use only AMD®-certified heatsink and fan assembly.

To install the CPU heatsink and fan:

1. Place the heatsink on top of the installed CPU, ensuring that the heatsink fits properly on the retention module base.




- The retention module base is already installed on the motherboard upon purchase.
- You do not have to remove the retention module base when installing the CPU or installing other motherboard components.
- If you purchased a separate CPU heatsink and fan assembly, ensure that a Thermal Interface Material is properly applied to the CPU heatsink or CPU before you install the heatsink and fan assembly.



Your boxed CPU heatsink and fan assembly should come with installation instructions for the CPU, heatsink, and the retention mechanism. If the instructions in this section do not match the CPU documentation, follow the latter.

2. Attach one end of the retention bracket to the retention module base.



- Align the other end of the retention bracket to the retention module base. A clicking sound denotes that the retention bracket is in place.



Ensure that the fan and heatsink assembly perfectly fits the retention mechanism module base, otherwise you cannot snap the retention bracket in place.

- Push down the retention bracket lock on the retention mechanism to secure the heatsink and fan to the module base.
- When the fan and heatsink assembly is in place, connect the CPU fan cable to the connector on the motherboard labeled CPU_FAN.




DO NOT forget to connect the CPU fan connector! Hardware monitoring errors can occur if you fail to plug this connector.

1.7 System memory

1.7.1 Overview

The motherboard comes with two Double Data Rate 2 (DDR2) Dual Inline Memory Modules (DIMM) sockets. The figure illustrates the location of the DDR2 DIMM sockets:



Channel	Sockets
Channel A	DIMM_A1
Channel B	DIMM_B1

M4N78-VM 240-pin DDR2 DIMM sockets

1.7.2 Memory configurations

You may install 512MB, 1GB, 2GB and 4GB unbuffered ECC and non-ECC DDR2 DIMMs into the DIMM sockets.



- You may install varying memory sizes in Channel A and Channel B. The system maps the total size of the lower-sized channel for the dual-channel configuration. Any excess memory from the higher-sized channel is then mapped for single-channel operation.
- Always install DIMMs with the same CAS latency. For optimum compatibility, we recommend that you obtain memory modules from the same vendor.
- Due to the memory address limitation on 32-bit Windows® OS, when you install 4GB or more memory on the motherboard, the actual usable memory for the OS can be about 3GB or less. For effective use of memory, we recommend that you do any of the following:
 - Install a maximum of 3GB system memory if you are using a 32-bit Windows® OS.
 - Use a 64-bit Windows® OS if you want to install 4GB or more memory on the motherboard.
- This motherboard does not support DIMMs made up of 256 megabits (Mb) chips or less.



The motherboard supports up to 8GB memory modules on Windows® XP Professional x64 and Vista x64 editions. You may install a maximum of 4GB DIMMs on each slot.

M4N78-VM Motherboard Qualified Vendors Lists (QVL)

DDR2-1200MHz capability

Size	Vendor	Part No.	SS/DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional) A* B*
2048MB(Kit of 2)	Kingston	KHX96002K2/2G	DS	5-5-5-15	Heat-Sink Package	N/A	- -
2048MB(Kit of 2)	OCZ	OCZ2FX12002GK	DS	5-5-5-18	Heat-Sink Package	N/A	- -
2048MB(Kit of 2)	Team	TXDD1024M1300HC6	DS	6-6-6-18	Heat-Sink Package	N/A	- -

DDR2-1066MHz capability

Size	Vendor	Part No.	SS/DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional) A* B*
4096MB(Kit of 2)	A-Data	AD21066E002GU	DS	5-5-5-15	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	Apacer	78.AAGAL.9KZ	DS	5-5-5-15	Heat-Sink Package	N/A	- -
1024MB	Corsair	CM2X1024-8500C5	DS		Heat-Sink Package	Corsair	- -
2048MB(Kit of 2)	Corsair	CM2X1024-8500C5D	DS	5-5-5-15	Heat-Sink Package	N/A	- -
2048MB(Kit of 2)	Corsair	CM2X2048-8500C5D	DS	5-5-5-15	Heat-Sink Package	N/A	- -
1024MB	Crucial	BL12864AA1065.8FE5	SS		Heat-Sink Package	N/A	- -
2048MB	Crucial	CT25664AA1067.16FE1	DS	7-7-7-13	9DJKH D9JKH	Micron	- -
1024MB	G.SKILL	F2-8500CL5S-1GBPK	DS	5-5-5-15	Heat-Sink Package	SN:815130037562	- -
2048MB(Kit of 2)	G.SKILL	F2-8500CL5D-2GBPK	DS	5-5-5-15	Heat-Sink Package	N/A	- -
4096MB(Kit of 2)	G.SKILL	F2-8500CL5D-4GBPI	DS	5-5-5-15	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	G.SKILL	F2-8500CL5D-4GBPK	DS	5-5-5-15	Heat-Sink Package	N/A	- -
1024MB	GEIL	GE22GB1066CSDC	SS	5	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GE24GB1066CSQC	SS	5	Heat-Sink Package	GEIL	- -
4096MB(kit of 2)	GEIL	GX24GB8500C5UDC	DS	5	Heat-Sink Package	N/A	- -
1024MB	kingmax	KLED48F-B8KU6-NGES	SS	6-6-6-24	KKB8FNUXF-DXX-18A	kingmax	- -
2048MB	kingmax	KLED88F-B8KU6-NNAS	DS	6-6-6-24	KKB8FNUXF-DXX-18A	kingmax	- -
1024MB(Kit of 2)	Kingston	KHX8500D2K2/1G	SS	5-5-5-15	Heat-Sink Package	N/A	- -

(continued on the next page)

DDR2-1066MHz capability

Size	Vendor	Part No.	SS/DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional)
							A* B*
1024MB(Kit of 2)	Kingston	KHX8500D2K2/1GN(EPP)	SS	5-5-5-18	Heat-Sink Package	Kingston	- -
1024MB	Kingston	KHX8500D2K2/2GN(EPP)	DS	5-5-5-18	Heat-Sink Package	Kingston	- -
1024MB	Kingston	KVR1066D2N7/1G	DS	7	E5108AJBG-1J-E	Elpida	- -
2048MB(Kit of 2)	Kingston	KHX8500D2K2/2G	DS	5-5-5-15	Heat-Sink Package	N/A	- -
2048MB(Kit of 2)	Kingston	KHX8500D2K2/4G	DS	5-5-5-15	Heat-Sink Package	N/A	- -
2048MB(Kit of 2)	OCZ	OCZ2N10662GK(Epp)	DS	5-5-5-15	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	OCZ	OCZ2F10664GK	DS	6-7-7-20	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	OCZ	OCZ2P10664GK(EPP)	DS	5-5-5-18	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	OCZ	OCZ2RPR10664GK	DS	5-5-5-15	Heat-Sink Package	N/A	- -
2048MB	PSC	AL8E8G73F-AE1	DS	5-5-5-12	A3R1GE3FGF907MATOFTAIWAN-G8E	PSC	- -
1024MB	Qimonda	HYS64T128000EU-1.9-C2	DS		HYB18T1G800C2F-1.9FSS25253	Qimonda	- -
2048MB(Kit of 2)	Transcend	TX1066QLU-2GK	SS	5	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	Transcend	TX1066QLU-4GK	DS	5	Heat-Sink Package	Transcend	- -



- DDR2 1200(O.C.)/1066 is supported by AM2+/AM3 CPU only.
- The default DIMM frequency depends on its Serial Presence Detect (SPD), which is the standard way of accessing information from a memory module. Under the default state, some memory modules for overclocking may operate at a lower frequency than the vendor-marked value.

DDR2-800MHz capability

Size	Vendor	Part No.	SS/DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional)
							A* B*
512MB	A-Data	M2GVD6G3H3160Q1E52	SS		VD29608A8A-25EG20813	VDATA	- -
512MB	A-Data	M2OAD6G3H3160Q1E98	SS		AD29608A8A-25EG80812	ADATA	- -
2048MB(Kit of 2)	A-Data	AD2800E001GOU	SS	4-4-4-12	Heat-Sink Package	N/A	- -
1024MB	A-Data	M2GVD6G314170Q1E58	DS		VD29608A8A-25EG80813	VDATA	- -
4096MB(Kit of 2)	A-Data	AD2800E002GOU	DS	4-4-4-12	Heat-Sink Package	N/A	- -
512MB	Apacer	78.91GA1.9K5	SS	5	AM4B5708CQJS8E0751C	Apacer	- -
1024MB	Apacer	78.01GA0.9K5	SS	5	AM4B5808CQJS8E0749D	Apacer	- -
2048MB	Apacer	78.A1GA0.9K4	DS	5	AM4B5808CQJS8E0740E	Apacer	- -
2048MB	Apacer	78.A1GA0.9K4	DS	5	AM4B5808CQJS8E0747D	Apacer	- -
1024MB	Corsair	CM2X1024-6400	DS		Heat-Sink Package	Corsair	- -
1024MB	Corsair	XMS2-6400	DS	4	Heat-Sink Package	Corsair	- -
1024MB	Corsair	XMS2-6400	DS	5	Heat-Sink Package	Corsair	- -
4096MB(Kit of 2)	Corsair	CM2X2048-6400C5DHX	DS	5	Heat-Sink Package	N/A	- -
4096MB(Kit of 2)	Corsair	CM2X2048-6400C5	DS	5	Heat-Sink Package	N/A	- -
2048MB(kit of 2)	Crucial	BL12864AL80A.8FE5(EPP)	SS	4-4-4-12	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	Crucial	BL25664AL80A.16FE5(EPP)	DS	4-4-4-12	Heat-Sink Package	N/A	- -
4096MB(kit of 2)	Crucial	BL25664AR80A.16FE5(EPP)	DS	4-4-4-12	Heat-Sink Package	N/A	- -
512MB	G.SKILL	F2-6400CL5D-1GBNQ	SS	5-5-5-15	Heat-Sink Package SN.8151030036642	G.SKILL	- -
1024MB	G.SKILL	F2-6400CL4D-2GBPK	DS	4	Heat-Sink Package	G.SKILL	- -
1024MB	G.SKILL	F2-6400CL5D-2GBNQ	DS	5	Heat-Sink Package	G.SKILL	- -
2048MB	G.SKILL	F2-6400CL4D-4GBPK	DS	4	Heat-Sink Package	G.SKILL	- -
2048MB	G.SKILL	F2-6400CL5D-4GBPK	DS	5	Heat-Sink Package	G.SKILL	- -
4096MB	G.SKILL	F2-6400CL6Q-16GMQ	DS	5	Heat-Sink Package	N/A	- -
1024MB	GEIL	GB22GB6400C4DC	DS	5	GL2L64M088BA30EB	GEIL	- -
1024MB	GEIL	GB22GB6400C5DC	DS	5	GL2L64M088BA30EB	GEIL	- -
1024MB	GEIL	GB24GB6400C40C	DS	4	GL2L64M088BA30EB	GEIL	- -
1024MB	GEIL	GB24GB6400C5QC	DS	5	GL2L64M088BA30EB	GEIL	- -
1024MB	GEIL	GE22GB800C4DC	DS	4	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GE22GB800C5DC	DS	5	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GE24GB800C4QC	DS	4	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GE24GB800C5QC	DS	5	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GX22GB6400DC	DS	5	Heat-Sink Package	GEIL	- -
1024MB	GEIL	GX22GB6400UDC	DS	4	Heat-Sink Package	GEIL	- -
2048MB	GEIL	GB24GB6400C4DC	DS	4	GL2L128M89BA25AB	GEIL	- -

(continued on the next page)

DDR2-800MHz capability

Size	Vendor	Part No.	SS/ DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional)	
							A'	B'
2048MB	GEIL	GB24GB6400C5DC	DS	5	GL2L128M88BA25AB	GEIL	-	-
2048MB	GEIL	GB28GB6400C4QC	DS	4	GL2L128M88BA25AB	GEIL	-	-
2048MB	GEIL	GB28GB6400C5QC	DS	5	GL2L128M88BA25AB	GEIL	-	-
2048MB	GEIL	GE24GB800C4DC	DS	4	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GE24GB800C5DC	DS	5	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GE28GB800C4QC	DS	4	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GE28GB800C5QC	DS	5	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GX22GB6400CJSC	DS	4	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GX22GB6400LX	DS	5	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GX24GB6400DC	DS	5	Heat-Sink Package	GEIL	-	-
512MB	Kingmax	KLDC28F-A8K15	SS		KA8FF1XF-JFS-25A	Kingmax	-	-
1024MB	Kingmax	KKB8FFBXF-CFA-25U	SS		KLDD48F-B8KB5	Kingmax	-	-
2048MB	kingmax	KLDE88F-B8KB5	DS		KKB8FFBXF-CFA-25U	kingmax	-	-
512MB	Kingston	KVR800D2N6/ 512	SS	6	E5108AJBG-8E-E	Elpida	-	-
1024M(Kit of 2)	Kingston	KHX6400D2LLK2/1GN	SS	4-4-4-12	Heat-Sink Package	Kingston	-	-
1024MB	Kingston	KHX6400D2LL/1G	DS	4-4-4-12	Heat-Sink Package	Kingston	-	-
1024MB	Kingston	KVR800D2N5/1G	DS	5	D6408TR4C4GL25USL3624 06PEXCA	Kingston	-	-
1024MB	Kingston	KVR800D2N6/1G	DS		E5108AJBG-8E-E	Elpida	-	-
2048MB(Kit of 2)	Kingston	KHX6400D2K2/2G	DS	5-5-5-15	Heat-Sink Package	N/A	-	-
2048MB	Kingston	461625.010819 PTGC	DS	6	KVR800D2N6/2G	Kingston	-	-
2048MB	Kingston	KHX6400D2/2G	DS	5	Heat-Sink Package	Kingston	-	-
2048MB	Kingston	KVR800D2N5/2G	DS	5	E1108ACBG-8E-E	Elpida	-	-
4096MB	Kingston	KVR800D2N6/4G	DS	6	E2108ABSE-8G-E	Elpida	-	-
512MB	Micron	MT9HTF6427AY-80ED4	SS		6ED22D9GKX(ECC)	Micron	-	-
1024MB	Micron	MT9HTF12872AY-800E1	SS		D9HNP 7YE22(ECC)	Micron	-	-
1024MB	Micron	MT18HTF12872AY-80ED4	DS		6TD22D9GKX(ECC)	Micron	-	-
1024MB	OCZ	OCZ2G800R22GK	DS	5	Heat-Sink Package	OCZ	-	-
1024MB	OCZ	OCZ2P800R22GK	DS	4	Heat-Sink Package	OCZ	-	-
1024MB	OCZ	OCZ2RPR8002GK	DS	4	Heat-Sink Package	OCZ	-	-
1024MB	OCZ	OCZ2VU8004GK	DS	6	Heat-Sink Package	OCZ	-	-
2048MB(Kit of 2)	OCZ	OCZ2SE8002GK	DS	5-5-5-15	Heat-Sink Package	N/A	-	-
2048MB	OCZ	OCZ2F8004GK	DS	5	Heat-Sink Package	N/A	-	-
4096MB(Kit of 2)	OCZ	OCZ2P8004GK	DS	5	Heat-Sink Package	N/A	-	-
1024MB	PSC	AL7E8F73C-8E1	SS	5	A3R1GE3CFF734MAA0E	PSC	-	-
2048MB	PSC	AL7E8E63H-10E1K	DS		A3R1GE3CFF750RABBP(ECC)	PSC	-	-
2048MB	PSC	AL8E8F73C-8E1	DS	5	A3R1GE3CFF734MAA0E	PSC	-	-
2048MB	PSC	SHG772-AA3G	DS		PL8E8F73C-8E1	PSC	-	-
2048MB	PSC	XCP271A3G-A	DS		PL8E8G73E-8E1	PSC	-	-
2048MB	Qimonda	HYS64T256020EU-2.5-C2	DS	5	HY818T1G800C2F-2.5	Qimonda	-	-
512MB	Samsung	K4T51083QG-HCF7	SS	6	M378T6553GZS-CF7	Qimonda	-	-
1024MB	Samsung	K4T1G084QQ-HCF7	SS	6	M378T2863QZS-CF7	Qimonda	-	-
1024MB	Samsung	M391T2863QZ3-CF7	SS		K4T1G084QQ-HCF7(ECC)	Samsung	-	-
1024MB	Samsung	K4T51083QG-HCF7	DS	6	M378T2953GZ3-CF7	Samsung	-	-
2048MB	Samsung	K4T1G084QQ-HCF7	DS	6	M378T5663QZ3-CF7	Samsung	-	-
2048MB	Samsung	M391T5663QZ3-CF7	DS		K4T1G084QQ-HCF7(ECC)	Samsung	-	-
4096MB	Samsung	M378T5263A23-CF7	DS		K4T2G084QA-HCF7	Samsung	-	-
1024MB	Super Talent	T800UB1GC4	DS	4	Heat-Sink Package	Super Talent	-	-
512MB	Transcend	TS64MLQ64V8J	SS	5	7HD22 D9GMH	Micron	-	-
1024MB	Transcend	JM800QLU-1G	SS	5	TQ1243PCF8	Transcend	-	-
1024MB	Transcend	TS128MLQ64V8U	SS	5	E1108ACBG-8E-E	ELPIDA	-	-
1024MB	Transcend	JM800QLJ-1G	DS	5	TQ123PJF8F0801	Transcend	-	-
1024MB	Transcend	JM800QLJ-1G	DS	5	TQ123YBF8 T0747	Transcend	-	-
1024MB	Transcend	TS128MLQ64V8J	DS	5	7HD22D9GMH	Micron	-	-
2048MB	Transcend	JM800QLU-2G	DS	5	TQ243PCF8	Transcend	-	-
2048MB	Transcend	TS256MLQ64V8U	DS	5	E1108ACBG-8E-E	Elpida	-	-
2048MB	Transcend	TS256MLQ72V8U	DS		E1108ACBG-8E-E(ECC)	Elpida	-	-

DDR2-667MHz capability

Size	Vendor	Part No.	SS/ DS	CL	Chip NO.	Chip Brand	DIMM socket support (Optional)	
							A*	B*
2048MB	A-Data	M2OAD5H3J41701C53	DS		AD20908A8A-3EG 30724	ADATA	-	-
512MB	Apacer	78.91G92.9K5	SS	5	AM4B5708JQS7E0751C	Apacer	-	-
512MB	Apacer	AU 512E667C5KBGC	SS	5	AM4B5708GQJST'E06332F	Apacer	-	-
512MB	Apacer	AU 512E667C5KBGC	SS	5	AM4B5708MIJS7E0627B	Apacer	-	-
1024MB	Apacer	78.01G90.9K5	SS	5	AM4B5808CQJST'E0751C	Apacer	-	-
1024MB	Apacer	AU01GE667C5KBGC	DS		AM4B5708GQJST'E0636B	Apacer	-	-
1024MB	Apacer	AU01GE667C5KBGC	DS	5	AM4B5708MIJS7E0627B	Apacer	-	-
2048MB	Apacer	AM4B5808CQJST'E0749B	DS	5	78.A1G90.9K4	Apacer	-	-
512MB	Corsair	VS 512MB667D2	DS		MIII0052532M8CEC	Corsair	-	-
1024MB	Corsair	VS1GB667D2	DS		MID095D62864M8CEC	Corsair	-	-
1024MB	Corsair	XMS2-5400	DS	4	Heat-Sink Package	Corsair	-	-
2048MB(Kit of 2)	G.SKILL	F2-5400PHU2-2GBNT	DS	5-5-5-15	D2 64M8CCF 0815 C7173S	G.SKILL	-	-
4096MB(Kit of 2)	G.SKILL	F2-5300CL5D-4GBMQ	DS	5-5-5-15	Heat-Sink Package SN:8151030036559	G.SKILL	-	-
1024MB	GEIL	GX21GB5300SX	DS	3	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GX22GB5300LX	DS	5	Heat-Sink Package	GEIL	-	-
2048MB	GEIL	GX24GB5300LDC	DS	5	Heat-Sink Package	GEIL	-	-
512MB	Kingmax	KLCC28F-A8KB5	SS		KKEA88B4LAUG-29DX	Kingmax	-	-
1024MB	Kingmax	KLCD48F-A8KB5	DS		KKEA88B4LAUG-29DX	Kingmax	-	-
512MB	Kingston	KVR667D2N5/ 512	SS	5	SO1237650821 SBP D6408TR4C GL25USL074905PECNB	Kingston	-	-
1024MB	Kingston	KVR667D2E5/1G	DS	5	E5108AJBG-8E-E(ECC)	Elpida	-	-
1024MB	Kingston	KVR667D2N5/1G	DS	5	SO1280420822 SOP D6408TR4C GL25USL156304PECCA	Kingston	-	-
2048MB	Kingston	KVR667D2E5/2G	DS	5	NT5TU128M8DE-3C(ECC)	Elpida	-	-
2048MB	Kingston	KVR667D2N5/2G	DS	5-5-5-15	7RE22 D9HNL	Micron	-	-
2048MB	Kingston	KVR667D2N5/2G	DS	5	E1108ACBG-8E-E 0813A90CC	ELPIDA	-	-
1024MB	Micron	MT8HTF12864AY-667E1	SS	5	D9HNL 7E217	Micron	-	-
512MB	PSC	AL6E8E63J-6E1	SS	5	A3R12E3JFF717B9A00	PSC	-	-
1024MB	PSC	AL7E8F73C-6E1	SS	5	A3R1GE3CFF734MAA0J	PSC	-	-
1024MB	PSC	AL6E8E63J-6E1	DS	5	A3R12E3JFF717B9A01	PSC	-	-
2048MB	PSC	AL8E8F73C-6E1	DS	5	A3R1GE3CFF733MAA00	PSC	-	-
4096MB	Samsung	M378T5263AZ3-CE6	DS		K4T2G084QA-HCE6	Samsung	-	-
1024MB	Super Talent	T667UB1GV	DS	5	PG 64M8-800 0750	Super Talent	-	-
1024MB	Transcend	JM667QLUJ-1G	SS	5	TQ243PCF8T0838	Transcend	-	-
1024MB	Transcend	JM667QLUJ-1G	DS	5	E5108AJBG-6E-E	Elpida	-	-
2048MB	Transcend	JM667QLUJ-2G	DS	5	TQ243PCF8T0834	Transcend	-	-
512MB	Twinmos	8D-A3JK5MPETP	SS	5	A3R12E3GEF633CAOY	PSC	-	-



SS - Single-sided / DS - Double - sided DIMM support:

- **A*:** Supports one module inserted into either slot as the single-channel memory configuration.
- **B*:** Supports one pair of modules inserted into both the yellow slots as one pair of dual-channel memory configuration.




Visit the ASUS website at www.asus.com for the latest QVL.

1.7.3 Installing a DIMM




Unplug the power supply before adding or removing DIMMs or other system components. Failure to do so can cause severe damage to both the motherboard and the components.

1. Press the retaining clips outward to unlock a DDR2 DIMM socket.
2. Align a DIMM on the socket such that the notch on the DIMM matches the break on the socket.



A DDR2 DIMM is keyed with a notch so that it fits in only one direction. DO NOT force a DIMM into a socket to avoid damaging the DIMM.

3. Firmly insert the DIMM into the socket until the retaining clips snap back in place and the DIMM is properly seated.



1.7.4 Removing a DIMM


To remove a DIMM:

1. Simultaneously press the retaining clips outward to unlock the DIMM.



Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged when it flips out with extra force.

2. Remove the DIMM from the socket.



1.8 Expansion slots

In the future, you may need to install expansion cards. The following sub-sections describe the slots and the expansion cards that they support.



Unplug the power cord before adding or removing expansion cards. Failure to do so may cause you physical injury and damage motherboard components.

1.8.1 Installing an expansion card

To install an expansion card:

1. Before installing the expansion card, read the documentation that came with it and make the necessary hardware settings for the card.
2. Remove the system unit cover (if your motherboard is already installed in a chassis).
3. Remove the bracket opposite the slot that you intend to use. Keep the screw for later use.
4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
5. Secure the card to the chassis with the screw you removed earlier.
6. Replace the system cover.

1.8.2 Configuring an expansion card

After installing the expansion card, configure it by adjusting the software settings.

1. Turn on the system and change the necessary BIOS settings, if any. See Chapter 2 for information on BIOS setup.
2. Assign an IRQ to the card.
3. Install the software drivers for the expansion card.



When using PCI cards on shared slots, ensure that the drivers support “Share IRQ” or that the cards do not need IRQ assignments. Otherwise, conflicts will arise between the two PCI groups, making the system unstable and the card inoperable.

1.8.3 PCI slots

The PCI slots support cards such as a LAN card, SCSI card, USB card, and other cards that comply with PCI specifications.

1.8.4 PCI Express x1 slot

This motherboard supports PCI Express x1 network cards, SCSI cards, and other cards that comply with the PCI Express specifications.


1.8.5 PCI Express x16 slot

This motherboard supports a PCI Express x16 graphics card that complies with the PCI Express specifications.

1.9 Jumpers

1. Clear RTC RAM (3-pin CLRTC)

This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which include system setup information such as system passwords.



M4N78-VM Clear RTC RAM

To erase the RTC RAM:

1. Turn OFF the computer and unplug the power cord.
2. Move the jumper cap from pins 1-2 (default) to pins 2-3. Keep the cap on pins 2-3 for about 5~10 seconds, then move the cap back to pins 1-2.
3. Plug the power cord and turn ON the computer.
4. Hold down the key during the boot process and enter BIOS setup to reenter data.




Except when clearing the RTC RAM, never remove the cap on CLRTC jumper default position. Removing the cap will cause system boot failure!



- If the steps above do not help, remove the onboard battery and move the jumper again to clear the CMOS RTC RAM data. After clearing the CMOS, reinstall the battery.
 - You do not need to clear the RTC when the system hangs due to overclocking. For system failure due to overclocking, use the CPU Parameter Recall (C.P.R) feature. Shut down and reboot the system so the BIOS can automatically reset parameter settings to default values.
-

2. Keyboard power (3-pin KBPWR)


This jumper allows you to enable or disable the keyboard wake-up feature. When you set this jumper to pins 2–3 (+5VSB), you can wake up the computer by pressing a key on the keyboard (the default is the Space Bar). This feature requires an ATX power supply that can supply at least 1A on the +5VSB lead, and a corresponding setting in the BIOS.



M4N78-VM Keyboard Power Setting

3. USB device wake-up (3-pin USBPW1-6, 3-pin USBPW7-12)


Set these jumpers to +5V to wake up the computer from S1 sleep mode (CPU stopped, DRAM refreshed, system running in low power mode) using the connected USB devices. Set to +5VSB to wake up from S3 and S4 sleep modes (no power to CPU, DRAM in slow refresh, power supply in reduced power mode).



M4N78-VM USB Device Wake Up

1.10 Connectors


1.10.1 Rear panel ports



1. **PS/2 Keyboard/Mouse Combo port (purple).** This port is for a PS/2 keyboard or mouse.
2. **Optical S/PDIF_OUT port.** This port connects to an external audio output device via an optical S/PDIF cable.
3. **Video Graphics Adapter (VGA) port.** This 15-pin port is for a VGA monitor or other VGA-compatible devices.
4. **LAN (RJ-45) port.** This port allows Gigabit connection to a Local Area Network (LAN) through a network hub.

LAN port LED indications

Activity/Link LED		Speed LED	
Status	Description	Status	Description
OFF	No link	OFF	10Mbps connection
ORANGE	Linked	ORANGE	100Mbps connection
BLINKING	Data activity	GREEN	1Gbps connection



5. **Center/Subwoofer port (orange).** This port connects to the center/subwoofer speakers.
6. **Rear Speaker Out port (black).** This port connects to the rear speakers in the 4, 6, and 8-channel audio configurations.
7. **Line In port (light blue).** This port connects to the tape, CD, DVD player, or other audio sources.
8. **Line Out port (lime).** This port connects to a headphone or a speaker. In the 4, 6 and 8-channel configurations, the function of this port becomes Front Speaker Out.
9. **Microphone port (pink).** This port connects to a microphone.
10. **Side Speaker Out port (gray).** This port connects to the side speakers in the 8-channel audio configuration.



Refer to the audio configuration table below for the function of the audio ports in the 2, 4, 6, or 8-channel configuration.

Audio 2, 4, 6, or 8-channel configuration

Port	Headset 2-channel	4-channel	6-channel	8-channel
Light Blue	Line In	Line In	Line In	Line In
Lime	Line Out	Front Speaker Out	Front Speaker Out	Front Speaker Out
Pink	Mic In	Mic In	Mic In	Mic In
Orange	–	–	Center/Subwoofer	Center/Subwoofer
Black	–	Rear Speaker Out	Rear Speaker Out	Rear Speaker Out
Gray	–	–	–	Side Speaker Out



Ensure the audio device of sound playback is **Realtek High Definition Audio** (the name may be different based on the OS). Go to **Start > Control Panel > Sounds and Audio Devices > Sound Playback** to configure the settings.

- USB 2.0 ports 1 and 2.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.
- USB 2.0 ports 3 and 4.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.
- DVI-D Out port.** This port is for any DVI-D compatible device and is HDCP compliant allowing playback of HD DVD, Blu-Ray, and other protected content.
- HDMI port.** This port is for a High-Definition Multimedia Interface (HDMI) connector, and is HDCP compliant allowing playback of HD DVD, Blu-Ray, and other protected content.



Dual display output support

- This table indicates that whether the following dual display outputs are supported on your motherboard:

Dual display outputs	Supported	Not supported
DVI + D-Sub	•	
DVI + HDMI		•
HDMI + D-Sub	•	

- During POST, only the monitor connected to the D-Sub port has display. The dual display function works only under Windows.



Playback of HD DVD and Blu-Ray discs

- For better playback quality, we recommend that you follow the system requirements listed below.

Suggested list	
CPU	AMD® Athlon 4400+
DIMM	DDR2 800 (1GB or higher)
BIOS setup	Frame Buffer Size--256MB or higher

File format	Best resolution	
	Windows® XP	Windows® Vista
Non-protected clips	1920 x 1080p	1920 x 1080p
HD-DVD	1920 x 1080p	1280 x 1080p
Blu-Ray	1280 x 1080p	1280 x 1080p

- To play HD DVD or Blu-Ray disc, ensure to use HDCP compliant devices and software.

15. **USB 2.0 ports 5 and 6.** These two 4-pin Universal Serial Bus (USB) ports are for USB 2.0 devices.


1.10.2 Internal connectors

1. Serial port connector (10-1 pin COM1)

The connector is for a serial (COM) port. Connect the serial port module cable to the connector, then install the module to a slot opening at the back of the system chassis.




The serial port bracket (COM1) is purchased separately.



2. ATX power connectors (24-pin EATXPWR, 4-pin ATX12V)

These connectors are for an ATX power supply. The plugs from the power supply are designed to fit these connectors in only one orientation. Find the proper orientation and push down firmly until the connectors completely fit.



- For a fully configured system, we recommend that you use a power supply unit (PSU) that complies with ATX 12 V Specification 2.0 (or later version) and provides a minimum power of 300 W.
- Do not forget to connect the 4-pin ATX12V power plug. Otherwise, the system will not boot.
- We recommend that you use a PSU with a higher power output when configuring a system with more power-consuming devices or when you intend to install additional devices. The system may become unstable or may not boot up if the power is inadequate.

3. IDE connector (40-1 pin PRI_IDE)

The onboard IDE connector is for Ultra DMA 133/100/66 signal cable. There are three connectors on each Ultra DMA 133/100/66 signal cable: blue, black, and gray. Connect the blue connector to the motherboard's IDE connector, then select one of the following modes to configure your devices:


	Drive jumper setting	Mode of device(s)	Cable connector
Single device	Cable-Select or Master	-	Black
Two devices	Cable-Select	Master	Black
		Slave	Gray
	Master	Master	Black or gray
	Slave	Slave	



- Pin 20 on the IDE connector is removed to match the covered hole on the Ultra DMA cable connector. This prevents incorrect insertion when you connect the IDE cable.
- Use the 80-conductor IDE cable for Ultra DMA 133/100/66 IDE devices.




If any device jumper is set as "Cable-Select", ensure that all other device jumpers have the same setting.



4. Serial ATA connectors (7-pin SATA1-6)

These connectors are for the Serial ATA signal cables for Serial ATA 3Gb/s hard disk and optical disk drives. The Serial ATA 3Gb/s is backward compatible with Serial ATA 1.5Gb/s specification. The data transfer rate of the Serial ATA 3Gb/s is faster than the standard parallel ATA with 133 MB/s (Ultra DMA133).




Install the Windows® XP Service Pack 1 before using Serial ATA.



- For detailed instructions on RAID configurations, refer to the RAID manual in the Support DVD.
 - If you intend to create a Serial ATA RAID set using these connectors, set the **SATA Mode Select** item in the BIOS to **[RAID Mode]**. See **2.3.4 Storage Configuration** for details.
 - Due to the chipset's limitation, SATA 5 and SATA 6 do not support IDE mode. They only support AHCI and RAID modes.
-

5. System panel connector (20-8 pin PANEL)

This connector supports several chassis-mounted functions.



M4N78-VM System panel connector

- **System power LED (2-pin PLED)**

This 2-pin connector is for the system power LED. Connect the chassis power LED cable to this connector. The system power LED lights up when you turn on the system power, and blinks when the system is in sleep mode.

- **Hard disk drive activity LED (2-pin +IDE_LED)**

This 2-pin connector is for the HDD Activity LED. Connect the HDD Activity LED cable to this connector. The IDE LED lights up or flashes when data is read from or written to the HDD.

- **System warning speaker (4-pin SPEAKER)**

This 4-pin connector is for the chassis-mounted system warning speaker. The speaker allows you to hear system beeps and warnings.

- **Power/Soft-off button (2-pin PWRSW)**


This 2-pin connector is for the system power button. Pressing the power button turns the system ON or puts the system in SLEEP or SOFT-OFF mode depending on the BIOS settings. Pressing the power switch for more than four seconds while the system is ON turns the system OFF.

- **Reset button (2-pin RESET)**

This 2-pin connector is for the chassis-mounted reset button for system reboot without turning off the system power.

6. USB connectors (10-1 pin USB78, USB910, USB1112)

These connectors are for USB 2.0 ports. Connect the USB module cable to any of these connectors, then install the module to a slot opening at the back of the system chassis. These USB connectors comply with USB 2.0 specification that supports up to 480Mbps connection speed.




Never connect a 1394 cable to the USB connectors. Doing so will damage the motherboard!



The USB 2.0 module is purchased separately.

7. Optical drive audio connector (4-pin CD)


This connector allows you to receive stereo audio input from sound sources such as a CD-ROM, TV tuner, or MPEG card.



M4N78-VM Internal audio connector

8. Digital audio connector (4-1 pin SPDIF_OUT)

This connector is for an additional Sony/Philips Digital Interface (S/PDIF) port.




Ensure that the audio device of Sound playback is **Realtek High Definition Audio** (the name may be different based on the OS). Go to **Start > Control Panel > Sounds and Audio Devices > Sound Playback** to configure the setting.



The S/PDIF module is purchased separately.

9. Front panel audio connector (10-1 pin AAFP)

This connector is for a chassis-mounted front panel audio I/O module that supports either High Definition Audio or AC'97 audio standard. Connect one end of the front panel audio I/O module cable to this connector.




- We recommend that you connect a high-definition front panel audio module to this connector to avail of the motherboard high-definition audio capability.
- If you want to connect a high-definition front panel audio module to this connector, set the **Front Panel Type** item in the BIOS setup to **[HD Audio]**. If you want to connect an AC'97 front panel audio module to this connector, set the item to **[AC97]**. By default, this connector is set to **[HD Audio]**. See section **2.4.3 Chipset** for details.

10. Power, CPU, and chassis fan connectors (3-pin PWR_FAN, 4-pin CPU_FAN, 3-pin CHA_FAN)

The fan connectors support cooling fans of 350mA~740mA (8.88W max.) or a total of 1A~2.22A (26.64W max.) at +12V. Connect the fan cables to the fan connectors on the motherboard, ensuring that the black wire of each cable matches the ground pin of the connector.




DO NOT forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components. These are not jumpers! DO NOT place jumper caps on the fan connectors.



Only the CPU fan supports the ASUS Q-Fan feature.

11. LPT connector (26-pin LPT)

The LPT (Line Printing Terminal) connector supports devices such as a printer. LPT is standardized as IEEE 1284, which is the parallel port interface on IBM PC-compatible computers.



1.11 Software support

1.11.1 Installing an operating system

This motherboard supports Windows® XP/Vista Operating Systems (OS). Always install the latest OS version and corresponding updates to maximize the features of your hardware.



- Motherboard settings and hardware options vary. Refer to your OS documentation for detailed information.
- Ensure that you install Windows® XP Service Pack 3 or later versions / Windows® Vista Service Pack 1 or later versions before installing the drivers for better compatibility and system stability.

1.11.2 Support DVD information

The Support DVD that comes with the motherboard package contains the drivers, software applications, and utilities that you can install to avail all motherboard features.




The contents of the Support DVD are subject to change at any time without notice. Visit the ASUS website at www.asus.com for updates.

To run the Support DVD

Place the Support DVD into the optical drive. The DVD automatically displays the Drivers menu if Autorun is enabled on your computer.



The following screen is for reference only.



Click an icon to display Support DVD/motherboard information

Click an item to install



If Autorun is NOT enabled on your computer, browse the contents of the Support DVD to locate the file ASSETUP.EXE from the BIN folder. Double-click the ASSETUP.EXE to run the DVD.

Chapter 2

BIOS information

2.1 Managing and updating your BIOS



Save a copy of the original motherboard BIOS file to a USB flash disk in case you need to restore the BIOS in the future. Copy the original motherboard BIOS using the ASUS Update utility.

2.1.1 ASUS Update utility

The ASUS Update is a utility that allows you to manage, save, and update the motherboard BIOS in Windows® environment.



-
- ASUS Update requires an Internet connection either through a network or an Internet Service Provider (ISP).
 - This utility is available in the support DVD that comes with the motherboard package.
-

Installing ASUS Update

To install ASUS Update:

1. Place the support DVD into the optical drive. The **Drivers** menu appears.
2. Click the **Utilities** tab, then click **ASUS Update**.
3. Follow the onscreen instructions to complete the installation.



Quit all Windows® applications before you update the BIOS using this utility.

Updating the BIOS

To update the BIOS:

1. From the Windows® desktop, click **Start > Programs > ASUS > ASUS Update > ASUS Update** to launch the ASUS Update utility.
2. From the dropdown list, select either of the following methods:

Updating from the Internet

- a. Select **Update BIOS from the Internet**, then click **Next**.
- b. Select the ASUS FTP site nearest you to avoid network traffic, or click **Auto Select** then click **Next**.
- c. From the FTP site, select the BIOS version that you want to download then click **Next**.



The ASUS Update utility is capable of updating itself through the Internet. Always update the utility to avail all its features.

Updating from a BIOS file

- a. Select **Update BIOS from a file**, then click **Next**.
 - b. Locate the BIOS file from the **Open** window, then click **Open**.
3. Follow the onscreen instructions to complete the updating process.

2.1.2 ASUS EZ Flash 2 utility


The ASUS EZ Flash 2 feature allows you to update the BIOS without using an OS-based utility.



Before you start using this utility, download the latest BIOS file from the ASUS website at www.asus.com.

To update the BIOS using EZ Flash 2:

1. Insert the USB flash disk that contains the latest BIOS file to the USB port, then launch EZ Flash 2 in either of these two ways:
 - Press **<Alt> + <F2>** during POST to display the following:



- Enter the BIOS setup program. Go to the **Tools** menu to select **EZ Flash 2** and press **<Enter>** to enable it.
2. Press **<Tab>** to switch between drives until the correct BIOS file is found, then press **<Enter>**. EZ Flash 2 performs the BIOS updating process and automatically reboots the system when done.



- This function supports USB flash disks with **FAT 32/16** format and single partition only.
 - **DO NOT** shut down or reset the system while updating the BIOS to prevent system boot failure!
-

2.1.3 ASUS CrashFree BIOS 3 utility

The ASUS CrashFree BIOS 3 is an auto recovery tool that allows you to restore the BIOS file when it fails or gets corrupted during the updating process. You can update a corrupted BIOS file using the motherboard Support DVD or a USB flash disk that contains the updated BIOS file.



- Prepare the motherboard Support DVD or a USB flash disk containing the updated motherboard BIOS before using this utility.
- Always connect the SATA cable to the SATA1-6 connector; otherwise, the utility will not function.

Recovering the BIOS

To recover the BIOS:

1. Turn on the system.
2. Insert the Support DVD or USB flash disk containing the BIOS file to the optical disk drive or a USB port.

The utility displays the following message and automatically checks the Support DVD or the USB flash disk for the BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...
Checking for CD-ROM...
```

When the BIOS file is found, the utility reads it and starts erasing the corrupted BIOS file.

```
Bad BIOS checksum. Starting BIOS recovery...
Checking for CD-ROM...
CD-ROM found!
Reading file "M4N78VM.ROM". Completed.
Start Erasing...
Start Programming...
```

3. Restart the system after the utility completes the updating process.



- Only a USB flash disk with FAT 32/16 format and single partition supports ASUS CrashFree BIOS 3. The device size should be smaller than 8GB.
- DO NOT shut down or reset the system while updating the BIOS! Doing so can cause system boot failure!



The recovered BIOS may not be the latest BIOS version for this motherboard. Download the latest BIOS file from the ASUS website at www.asus.com.

2.2 BIOS setup program

This motherboard supports a programmable Serial Peripheral Interface (SPI) chip that you can update using the provided utility described in section 2.1 **Managing and updating your BIOS**.

Use the BIOS Setup program when you are installing a motherboard, reconfiguring your system, or prompted to “Run Setup.” This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the SPI chip.

The SPI chip on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press **** during the Power-On Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.

If you want to enter Setup after POST, reboot the system by doing any of the following procedures:

- Restart using the OS standard shut-down procedure.
- Press **<Ctrl>+<Alt>+** simultaneously.
- Press the reset button on the system chassis.
- Press the power button to turn the system off then back on.




Using the **power button**, **reset button**, or the **<Ctrl>+<Alt>+** keys to force reset from a running operating system can cause damage to your data or system. We recommend that you always shut down the system properly from the operating system.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.



-
- The default BIOS settings for this motherboard apply to most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Select the **Load Setup Defaults** item under the **Exit** menu. See section 2.8 **Exit Menu**.
 - The BIOS setup screens in this chapter are for reference only. They may not exactly match what you see on your screen.
 - Visit the ASUS website at www.asus.com to download the latest BIOS file for this motherboard.
-

2.2.1 BIOS menu screen



2.2.2 Menu bar

The menu bar on top of the screen has the following main items:

- Main** For changing the basic system configuration
- Advanced** For changing the advanced system settings
- Power** For changing the advanced power management (APM) configuration
- Boot** For changing the system boot configuration
- Tools** For configuring options for special functions
- Exit** For selecting the exit options and loading default settings.

To select an item on the menu bar, press the right or left arrow key on the keyboard until the desired item is highlighted.

2.2.3 Navigation keys

At the bottom right corner of a menu screen are the navigation keys for that particular menu. Use the navigation keys to select items in the menu and change the settings.



Some of the navigation keys differ from one screen to another.

2.2.4 Menu items

The highlighted item on the menu bar displays the specific items for that menu. For example, selecting Main shows the Main menu items.

The other items (Advanced, Power, Boot, Tools, and Exit) on the menu bar have their respective menu items.

2.2.5 Submenu items

A solid triangle before each item on a menu screen means that the item has a submenu. To display the submenu, select the item and press **<Enter>**.


2.2.6 Configuration fields

These fields show the values for the menu items. If an item is user-configurable, you can change the value of the field opposite the item. You cannot select an item that is not user-configurable.

A configurable field is enclosed in brackets, and is highlighted when selected. To change the value of a field, select it then press **<Enter>** to display a list of options. Refer to **2.2.7 Pop-up window**.

2.2.7 Pop-up window

Select a menu item then press **<Enter>** to display a pop-up window with the configuration options for that item.



2.2.8 Scroll bar

A scroll bar appears on the right side of a menu screen when there are items that do not fit on the screen. Press the **<Up>** / **<Down>** arrow keys or **<Page Up>** / **<Page Down>** keys to display the other items on the screen.

2.2.9 General help


At the top right corner of the menu screen is a brief description of the selected item.

2.3 Main menu

When you enter the BIOS Setup program, the Main menu screen appears, giving you an overview of the basic system information.



Refer to section 2.2.1 **BIOS menu screen** for information on the menu screen items and how to navigate through them.



2.3.1 System Time [xx:xx:xx]

Allows you to set the system time.

2.3.2 System Date [Day xx/xx/xxxx]

Allows you to set the system date.

2.3.3 Primary IDE Master/Slave, SATA 1-4

While entering Setup, the BIOS automatically detects the presence of IDE/SATA devices. There is a separate submenu for each IDE/SATA device. Select a device item then press <Enter> to display the IDE/SATA device information.

The BIOS automatically detects the values opposite the dimmed items (Device, Vendor, Size, LBA Mode, Block Mode, PIO Mode, Async DMA, Ultra DMA, and SMART monitoring). These values are not user-configurable. These items show Not Detected if no IDE/SATA device is installed in the system.

Type [Auto]

Selects the type of IDE drive. Setting this item to **[Auto]** allows automatic selection of the appropriate IDE device type. Select **[CDROM]** if you are specifically configuring a CD-ROM drive. Select **[ARMD]** (ATAPI Removable Media Device) if your device is either a ZIP, LS-120, or MO drive. Configuration options: [Not Installed] [Auto] [CDROM] [ARMD]



This item only appears in the Primary IDE Master/Slave menus.

LBA/Large Mode [Auto]

Enables or disables the LBA mode. Setting this item to **[Auto]** enables the LBA mode if the device supports this mode, and if the device was not previously formatted with LBA mode disabled. Configuration options: [Disabled] [Auto]

Block (Multi-Sector Transfer) M [Auto]

Enables or disables data multi-sectors transfers. When this item is set to **[Auto]**, the data transfer from and to the device occurs multiple sectors at a time if the device supports multi-sector transfer feature. When this item is set to **[Disabled]**, the data transfer from and to the device occurs one sector at a time. Configuration options: [Disabled] [Auto]

PIO Mode [Auto]

Selects the PIO mode. Configuration options: [Auto] [0] [1] [2] [3] [4]

DMA Mode [Auto]

Selects the DMA mode. Configuration options: [Auto]

SMART Monitoring [Auto]

Sets the Smart Monitoring, Analysis, and Reporting Technology.
Configuration options: [Auto] [Disabled] [Enabled]

32Bit Data Transfer [Enabled]

Enables or disables 32-bit data transfer. Configuration options: [Disabled] [Enabled]

2.3.4 Storage Configuration

The **Storage Configuration** menu allows you to configure your storage devices. Select an item then press **<Enter>** to display the submenu.

Onboard PCI IDE Controller [Enabled]

Enables or disables the onboard IDE controller. Configuration options: [Disabled] [Enabled]

OnChip S-ATA Controller [Enabled]

Enables or disables the onchip SATA controller. Configuration options: [Enabled] [Disabled]

SATA Mode Select [SATA Mode]

Selects the SATA mode. Configuration options: [SATA Mode] [RAID Mode] [AHCI Mode]

2.3.5 System Information

This menu gives you an overview of the general system specifications. The BIOS automatically detects the items in this menu.

BIOS Information

Displays the auto-detected BIOS information.

Processor

Displays the auto-detected CPU specification.

System Memory


Displays the auto-detected system memory.

2.4 Advanced menu

The **Advanced** menu items allow you to change the settings for the CPU and other system devices.



Take caution when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction.



2.4.1 JumperFree Configuration



Depending on your AMD® CPU type (AM2, AM2+ or AM3), the items on this section may not exactly match what you see on your screen.

CPU Overclocking [Auto]

Selects the CPU overclocking options to achieve desired CPU internal frequency.

[Manual] - Allows you to manually set overclocking parameters.

[Auto] - Loads the optimal settings for the system.

[Overclock Profile] - Loads overclocking profiles with optimal parameters for stability when overclocking.



The following item appears only when the **CPU Overclocking** item is set to **[Manual]**.

CPU Frequency [200]

Allows you to set the CPU frequency. Configuration options: [Min.=200MHz], [Max.=550MHz]



The following item appears only when the **CPU Overclocking** item is set to **[Overclock Profile]**.

Overclocking Options [Auto]

Allows you to select the overclocking profile. Configuration options: [Auto] [Overclock 3%] [Overclock 5%] [Overclock 7%] [Test Mode]

GPU Overclocking [Auto]

Allows you to select the GPU overclocking options. Configuration options: [Auto] [Manual]



The following items appear only when the **GPU Overclocking** item is set to **[Manual]**.

GPU Frequency [500]

Allows you to set the GPU frequency. Configuration options: [Min.=500MHz]
[Max.=999MHz]

Shader Frequency [1200]

Allows you to set the shader frequency. Configuration options: [Min.=1000MHz]
[Max.=2000MHz]

PCIe Overclocking [Auto]

Allows you to select the PCIe overclocking options. Configuration options: [Auto] [Manual]



The following item appears only when the **PCIe Overclocking** item is set to **[Manual]**.

PCIe Frequency [100]

Allows you to set the PCIe frequency. Configuration options: [Min.=100MHz],
[Max.=150MHz]

Processor Frequency Multiplier [Auto]

Allows you to select the processor frequency. Configuration options: [Auto] [x8.0 1600MHz]
[x8.5 1700MHz] [x9.0 1800MHz] [x9.5 1900MHz] ... [x23.5 4700MHz] [x24.0 4800MHz] [x24.5
4900MHz] [x25.0 5000MHz]

CPU Over Voltage [Auto]

Allows you to set the CPU over voltage. Configuration options: [Auto] [Normal] [+50mv]
[+100mv] [+150mv]

VDDNB Over Voltage [Auto]

Allows you to set the VDDNB over voltage. Configuration options: [Auto] [Normal] [+33mv]
[+66mv] [+100mv]

Hyper Transport Speed [Auto]

The Hyper Transport link will run at this speed if it is slower than or equal to the system clock and the board is capable. Configuration options: [200 Mhz] [400 Mhz] [600 Mhz] [800 Mhz]
[1 GHz] [1.2 GHz] [1.4 GHz] [1.6 GHz] [1.8 GHz] [2.0 GHz] [2.2 GHz] [2.4 GHz] [2.6 GHz]
[Auto]

Hyper Transport Width [16 ↓ 16 ↑]

The Hyper Transport link will run at this width. Configuration options: [8 ↓ 8 ↑] [16 ↓ 16 ↑]

Memory Clock Mode [Auto]

Allows you to set the memory clock mode. Configuration options: [Auto] [Manual]



The following item appears only when the **Memory Clock Mode** item is set to **[Manual]**.

Memclock Value [333 MHz]

Allows you to set the Memclock value. Configuration options: [333 MHz] [400 MHz]
[533 MHz]

DRAM Timing Mode [Auto]

Allows you to set the DRAM timing mode. Configuration options: [Auto] [Both]



The following items appear only when the **DRAM Timing Mode** item is set to [Both].

CAS Latency (CL) [Auto]

Allows you to set CAS latency. Configuration options: [Auto] [3 CLK] [4 CLK] [5 CLK] [6 CLK] [7 CLK DH_Only]

TRCD [Auto]

Allows you to set TRCD. Configuration options: [Auto] [3 CLK] [4 CLK] [5 CLK] [6 CLK]

TRP [Auto]

Allows you to set TRP. Configuration options: [Auto] [3 CLK] [4 CLK] [5 CLK] [6 CLK]

tRTP [Auto]

Allows you to specify the read CAS# to percharge time.

Configuration options: [Auto] [2-4 CLK] [3-5 CLK]

TRAS [Auto]

Allows you to set TRAS.

Configuration options: [Auto] [5 CLK] [6 CLK] [7 CLK] [8 CLK] ... [17 CLK] [18 CLK]

TRC [Auto]

Allows you to set TRC. Configuration options: [Auto]

tWR [Auto]

Allows you to specify when the last write is registered by the DRAM. Configuration options: [Auto] [3 CLK] [4 CLK] [5 CLK] [6 CLK]

TRRD [Auto]

Allows you to set TRRD. Configuration options: [Auto] [2 CLK] [3 CLK] [4 CLK] [5 CLK]

tWTR [Auto]

Allows you to specify the write to read delay when accessing the same DRAM.

Configuration options: [Auto] [1 CLK] [2 CLK] [3 CLK]

tRFC0/1/2/3 [Auto]

Allows you to specify the Trfc0/1/2/3 time. Configuration options: [Auto] [75ns] [105ns] [127.5ns] [195ns] [327.5ns]

Memory Over Voltage [Auto]

Allows you to set the DRAM voltage. The values range from 1.51000V to 2.45500V with a 0.01500V interval.

Chipset Voltage [Auto]

Allows you to set the chipset voltage. Configuration options: [Auto] [+50mv] [+100mv] [+150mv]

2.4.2 CPU Configuration

The items in this menu show the CPU-related information that the BIOS automatically detects.

GART Error Reporting [Disabled]

This option should remain disabled for the normal operation. The driver developer may enable it for testing purpose. Configuration options: [Disabled] [Enabled]

Microcode Updation [Enabled]

Allows you to enable or disable the microcode updation. Configuration options: [Disabled] [Enabled]

Secure Virtual Machine Mode [Disabled]

Allows you to enable or disable the AMD Secure Virtual Machine mode. Configuration options: [Disabled] [Enabled]

Cool 'n' Quiet [Enabled]

Allows you to enable or disable the generation of ACPI_PPC, _PSS, and _PCT objects. Configuration options: [Disabled] [Enabled]

CPU Prefetching [Enabled]

Allows you to enable or disable the CPU prefetching. Configuration options: [Enabled] [Disabled]

C1E Configuration [Disabled]

Allows you to enable or disable C1E Dual-Core related CPU power State. Configuration options: [Disabled] [Enabled]

2.4.3 Chipset

The **Chipset** menu allows you to change the advanced chipset settings. Select an item then press **<Enter>** to display the submenu.

NorthBridge Configuration

Memory Configuration

Bank Interleaving [Auto]

Allows you to enable the bank memory interleaving.

Configuration options: [Disabled] [Auto]

Channel Interleaving [Disabled]

Allows you to enable the channel memory interleaving.

Configuration options: [Disabled] [Address bits 6] [Address bits 12]

[XOR of Address bits [20:16,6]] [XOR of Address bits [20:16,9]]

Enable Clock to All DIMMs [Disabled]

Enables or disables clock to all DIMMs. Configuration options: [Disabled] [Enabled]

MemClk Tristate C3/ALTVID [Disabled]

Enables or disables the MemClk Tristate C3/ALTVID.

Configuration options: [Disabled] [Enabled]

Memory Hole Remapping [Enabled]

Enables or disables the memory remapping around memory hole. Configuration options: [Disabled] [Enabled]

DCT Unganged Mode [Auto]

Allows you to enable or disable ungangd DRAM mode.

Configuration options: [Auto] [Always]

Power Down Enable [Enabled]

Enables or disables the DDR power down mode.

Configuration options: [Disabled] [Enabled]

ECC Configuration

ECC Mode [Disabled]

Enables or disables the DRAM ECC that allows the hardware to report and correct memory errors automatically. Configuration options: [Disabled] [Basic] [Good] [Super] [Max] [User]

SouthBridge Configuration

Primary Graphics Adapter [PCIe VGA Card First]

Allows you to select the primary graphics adapter.

Configuration options: [PCIe VGA Card First] [PCI VGA Card First] [Internal VGA First]

Hybrid SLI Mode [mGPU Auto]

Allows you to select the Hybrid SLI mode.

Configuration options: [mGPU Auto] [mGPU always enable]

iGPU Frame Buffer Size [128MB]

Sets the iGPU frame buffer size. Configuration options: [32MB] [64MB] [128MB] [256MB]

PCIe 2.0 Support [Auto]

Configures the PCIe 2.0 support. Configuration options: [Disabled] [Auto]

OnBoard HD Audio Controller [Internal codec + External codec]

Allows you to set the onboard HD audio controller. Configuration options: [Disabled] [Internal codec + External codec] [Internal codec] [External codec]

Front Panel Type [HD Audio]

Allows you to set the HD audio mode. Configuration options: [AC97] [HD Audio]

Onboard Gigabit LAN [Enabled]

Allows you to enable or disable the onboard Gigabit LAN. Configuration options: [Enabled] [Disabled]

Onboard LAN Boot ROM [Disabled]

Allows you to enable or disable the onboard LAN boot ROM.

Configuration options: [Enabled] [Disabled]

SouthBridge ACPI HPET TABLE [Enabled]

Allows you to enable or disable SouthBridge ACPI HPET TABLE.

Configuration options: [Disabled] [Enabled]

2.4.4 Onboard Devices Configuration

Serial Port1 Address [3F8/IRQ4]

Allows you to select the Serial Port1 base address.

Configuration options: [Disabled] [3F8/IRQ4] [2F8/IRQ3] [3E8/IRQ4] [2E8/IRQ3]

Parallel Port Address [378]

Allows you to select the Parallel Port base addresses.

Configuration options: [Disabled] [378] [278] [3BC]

Parallel Port Mode [Normal]

Allows you to select the Parallel Port mode. Configuration options: [Normal] [Bi-Directional] [EPP] [ECP] [ECP&EPP]

EPP Version [1.9]

Appears only when the Parallel Port Mode is set to [EPP] and [ECP&EPP]. Allows you to select the EPP version. Configuration options: [1.9] [1.7]

ECP Mode DMA Channel [DMA3]

Appears only when the Parallel Port Mode is set to [ECP] and [ECP&EPP]. This item allows you to set the Parallel Port ECP DMA. Configuration options: [DMA0] [DMA1] [DMA3]

2.4.5 PCI PnP

The **PCI PnP** menu items allow you to change the advanced settings for PCI/PnP devices. The menu includes setting IRQ and DMA channel resources for either PCI/PnP or legacy ISA devices, and setting the memory size block for legacy ISA devices.



Be cautious when changing the settings of the PCI PnP menu items. Incorrect field values can cause the system to malfunction.

Plug and Play O/S [No]

When set to **[No]**, BIOS configures all the devices in the system. When set to **[Yes]** and if you install a Plug and Play operating system, the operating system configures the Plug and Play devices not required for boot. Configuration options: [No] [Yes]

2.4.6 USB Configuration

The items in this menu allows you to change the USB-related features. Select an item then press **<Enter>** to display the configuration options.



The Module Version and USB Devices Enabled items show the auto-detected values. If no USB device is detected, the item shows **None**.

USB Functions [Enabled]

Allows you to enable or disable the USB Functions.

Configuration options: [Enabled] [Disabled]

USB 2.0 Controller [Enabled]

Allows you to enable or disable the USB 2.0 Controller.

Configuration options: [Enabled] [Disabled]

Legacy USB Support [Enabled]

Allows you to enable or disable support for USB devices on legacy operating systems (OS). Setting to Auto allows the system to detect the presence of USB devices at startup. If detected, the USB controller legacy mode is enabled. If no USB device is detected, the legacy USB support is disabled. Configuration options: [Disabled] [Enabled] [Auto]

USB 2.0 Controller Mode [HiSpeed]

Allows you to configure the USB 2.0 controller in HiSpeed (480 Mbps) or Full Speed (12 Mbps). Configuration options: [FullSpeed] [HiSpeed]



The following items may only appear when a USB storage device is plugged.

USB Mass Storage Device Configuration

USB Mass Storage Reset Delay [20 Sec]


Allows you to set the maximum time that the BIOS waits for the USB storage device to initialize. Configuration options: [10 Sec] [20 Sec] [30 Sec] [40 Sec]

Emulation Type [Auto]

Allows you to select the emulation type. Configuration options: [Auto] [Floppy] [Forced FDD] [Hard Disk] [CDROM]

2.5 Power menu

The Power menu items allow you to change the settings for the Advanced Configuration and Power Interface (ACPI) and the Advanced Power Management (APM). Select an item then press **<Enter>** to display the configuration options.



2.5.1 Suspend Mode [Auto]

Allows you to select the Advanced Configuration and Power Interface (ACPI) state to be used for system suspend. Configuration options: [S1 (POS) Only] [S3 Only] [Auto]

[S1(POS) Only] - Enables the system to enter the ACPI S1 (Power on Suspend) sleep state. In S1 sleep state, the system appears suspended and stays in a low power mode. The system can be resumed at any time.

[S3 Only] - Enables the system to enter the ACPI S3 (Suspend to RAM) sleep state (default). In S3 sleep state, the system appears to be off and consumes less power than in the S1 state. When signaled by a wake-up device or event, the system resumes to its working state exactly where it was left off.

[Auto] - Detected by OS.

2.5.2 ACPI 2.0 Support [Disabled]

Allows you to add more tables for Advanced Configuration and Power Interface (ACPI) 2.0 specifications. Configuration options: [Disabled] [Enabled]

2.5.3 ACPI APIC Support [Enabled]

Allows you to enable or disable the Advanced Configuration and Power Interface (ACPI) support in the Application-Specific Integrated Circuit (ASIC). When set to **Enabled**, the ACPI APIC table pointer is included in the RSDT pointer list. Configuration options: [Disabled] [Enabled]

2.5.4 APM Configuration

Restore on AC Power Loss [Power Off]

When set to **Power Off**, the system goes into off state after an AC power loss. When set to **Power On**, the system goes on after an AC power loss.
Configuration options: [Power On] [Power Off]

Power On By PCI(E) Device [Disabled]

When set to **[Enabled]**, this parameter allows you to turn on the system through a PCI/PCIE card. This feature requires an ATX power supply that provides at least 1A on the +5VSB lead.
Configuration options: [Disabled] [Enabled]

Power On By On-Chip LAN [Disabled]

Allows you to enable or disable LAN(MAC) to generate a wake event. Configuration options: [Disabled] [Enabled]

Power On By External Modem [Disabled]

This allows either settings of **[Enabled]** or **[Disabled]** for powering up to the computer when the external modem receives a call while the computer is in Soft-off mode. Configuration options: [Disabled] [Enabled]

Power On By PS/2 Keyboard [Disabled]

Allows you to use specific keys on the keyboard to turn on the system. This feature requires an ATX power supply that provides at least 1A on the +5VSB lead. Configuration options: [Disabled] [Space Bar] [Ctrl-ESC] [Power Key]

Power On By RTC Alarm [Disabled]

Allows you to enable or disable RTC to generate a wake event. When this item is set to **Enabled**, the items RTC Alarm Date, RTC Alarm Hour, RTC Alarm Minute, and RTC Alarm Second appear with set values. Configuration options: [Disabled] [Enabled]

2.5.5 Hardware Monitor

CPU Temperature [xxx°C/xxx°F] or [Ignored]

MB Temperature [xxx°C/xxx°F] or [Ignored]

The onboard hardware monitor automatically detects and displays the motherboard and CPU temperatures. Select **Ignored** if you do not wish to display the detected temperatures.

CPU/Chassis/Power Fan Speed [xxxxRPM] or [Ignored]

The onboard hardware monitor automatically detects and displays the CPU, chassis, and power fan speed in rotations per minute (RPM). If the fan is not connected to the motherboard, the field shows **N/A**. Select **Ignored** if you do not wish to display the detected speed.

CPU Q-Fan Control [Disabled]

Allows you to enable or disable the Q-Fan control. Configuration options: [Disabled] [Enabled]

VCORE Voltage, 3.3V Voltage, 5V Voltage, 12V Voltage [xxxxV] or [Ignored]

The onboard hardware monitor automatically detects the voltage output through the onboard voltage regulators. Select **Ignored** if you do not wish to display the detected voltage output.

2.6 Boot menu

The **Boot** menu items allow you to change the system boot options. Select an item then press **<Enter>** to display the sub-menu.



2.6.1 Boot Device Priority

1st ~ xxth Boot Device

These items specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system. Configuration options: [Removable Dev.] [Hard Drive] [ATAPI CD-ROM] [Disabled]

2.6.2 Boot Settings Configuration

Quick Boot [Enabled]

Enabling this item allows the BIOS to skip some power on self tests (POST) while booting to decrease the time needed to boot the system. When set to **[Disabled]**, BIOS performs all the POST items. Configuration options: [Disabled] [Enabled]

Full Screen Logo [Enabled]

This allows you to enable or disable the full screen logo display feature. Configuration options: [Disabled] [Enabled]



Set this item to **[Enabled]** to use the ASUS MyLogo 2™ feature.

AddOn ROM Display Mode [Force BIOS]

Sets the display mode for option ROM. Configuration options: [Force BIOS] [Keep Current]

Bootup Num-Lock [On]

Allows you to select the power-on state for the NumLock. Configuration options: [Off] [On]

Wait for 'F1' If Error [Enabled]

When set to **Enabled**, the system waits for the F1 key to be pressed when error occurs. Configuration options: [Disabled] [Enabled]

Hit 'DEL' Message Display [Enabled]

When set to **Enabled**, the system displays the message **Press DEL to run Setup** during POST. Configuration options: [Disabled] [Enabled]

2.6.3 Security

The Security menu items allow you to change the system security settings. Select an item then press **<Enter>** to display the configuration options.

Change Supervisor Password

Select this item to set or change the supervisor password. The Supervisor Password item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a Supervisor Password:

1. Select the **Change Supervisor Password** item and press **<Enter>**.
2. From the password box, type a password composed of up to six letters and/or numbers, then press **<Enter>**.
3. Confirm the password when prompted.

The message “Password Installed” appears after you successfully set your password.
To change the supervisor password, follow the same steps as in setting a supervisor password.

To clear the supervisor password, select the **Change Supervisor Password** then press **<Enter>** twice. The message “Password Uninstalled” appears.



If you forget your BIOS password, you can clear it by erasing the CMOS Real Time Clock (RTC) RAM. See section **1.9 Jumpers** for information on how to erase the RTC RAM.

After you have set a supervisor password, the other items appear to allow you to change other security settings.

User Access Level [Full Access]

This item allows you to select the access restriction to the Setup items. Configuration options: [No Access] [View Only] [Limited] [Full Access]

No Access prevents user access to the Setup utility.

View Only allows access but does not allow change to any field.

Limited allows changes only to selected fields, such as Date and Time.

Full Access allows viewing and changing all the fields in the Setup utility.

Change User Password

Select this item to set or change the user password. The **User Password** item on top of the screen shows the default **Not Installed**. After you set a password, this item shows **Installed**.

To set a User Password:

1. Select the **Change User Password** item and press **<Enter>**.
2. On the password box that appears, type a password composed of up to six letters and/or numbers, then press **<Enter>**.
3. Confirm the password when prompted.

The message “**Password Installed**” appears after you set your password successfully.

To change the user password, follow the same steps as in setting a user password.

Clear User Password


Select this item to clear the user password.

Password Check [Setup]

When set to **[Setup]**, BIOS checks for user password when accessing the Setup utility. When set to **[Always]**, BIOS checks for user password both when accessing Setup and booting the system. Configuration options: [Setup] [Always]

2.7 Tools menu

The **Tools** menu items allow you to configure options for special functions. Select an item then press **<Enter>** to display the sub-menu.



2.7.1 ASUS EZ Flash 2

Allows you to run ASUS EZ Flash 2. When you press **<Enter>**, a confirmation message appears. Use the left/right arrow key to select between **[Yes]** or **[No]**, then press **<Enter>** to confirm your choice.

2.7.2 Express Gate [Auto]

Allows you to enable or disable the ASUS Express Gate feature. ASUS Express Gate is a unique instant-on environment that provides quick access to the Internet and Skype.

Configuration options: [Enabled] [Disabled] [Auto]

Enter OS Timer [10 Seconds]

Sets countdown duration that the system waits at the Express Gate's first screen before starting Windows or other installed OS. Choose **[Prompt User]** to stay at the first screen of Express Gate for user action. Configuration options: [Prompt User] [1 second] [3 seconds] [5 seconds] [10 seconds] [15 seconds] [20 seconds] [30 seconds]

Reset User Data [No]

Allows you to clear Express Gate's user data. Configuration options: [No] [Reset]

When setting this item to **[Reset]**, ensure to save the setting to the BIOS so that the user data will be cleared the next time you enter the Express Gate. User data includes the Express Gate's settings as well as any personal information stored by the web browser (bookmarks, cookies, browsing history, etc.). This is useful in the rare case where corrupt settings prevent the Express Gate environment from launching properly.



The first time wizard will run again when you enter the Express Gate environment after clearing its settings.


2.7.3 AI NET 2

Check Realtek Phy LAN cable [Disabled]

Enables or disables checking of the Realtek Phy LAN cable during the Power-On Self-Test (POST). Configuration options: [Disabled] [Enabled]

2.8 Exit menu

The **Exit** menu items allow you to load the optimal or failsafe default values for the BIOS items, and save or discard your changes to the BIOS items.



Pressing **<Esc>** does not immediately exit this menu. Select one of the options from this menu or **<F10>** from the legend bar to exit.

Exit & Save Changes

Once you are finished making your selections, choose this option from the Exit menu to ensure the values you selected are saved to the CMOS RAM. An onboard backup battery sustains the CMOS RAM so it stays on even when the PC is turned off. When you select this option, a confirmation window appears. Select **OK** to save changes and exit.

Exit & Discard Changes

Select this option only if you do not want to save the changes that you made to the Setup program. If you made changes to fields other than System Date, System Time, and Password, the BIOS asks for a confirmation before exiting.

Discard Changes

This option allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select **OK** to discard any changes and load the previously saved values.

Load Setup Defaults

This option allows you to load the default values for each of the parameters on the Setup menus. When you select this option or if you press **<F5>**, a confirmation window appears. Select **OK** to load default values. Select **Exit & Save Changes** or make other changes before saving the values to the non-volatile RAM.

