




ASUSTeK COMPUTER INC.

---

**ASUS L7000 Series Notebook**



# SERVICE GUIDE



ASUS L7000 SERIES NOTEBOOK

# Service Guide

---

© ASUSTeK Computer Inc.  
No. 150, Li-Te Rd., Peitou, Taipei, Taiwan, R.O.C.  
Phone +886-2-2894-3447 • Fax +886-2-2895-9254

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

• Intel and Pentium are registered trademarks of Intel Corporation.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARES DESCRIBED IN IT.

**Copyright © 1998 ASUSTeK COMPUTER INC. All Rights Reserved.**

Manual revision 2.1, December 10, 1998



D e s i g n e d   &   M a d e   b y   A S U S T e K

## Table of Contents

### CHAPTER 1: ASUS SERVICE POLICY

ASUS Service Policy Overview	1 - 2
Authorized Service Repair Centers	1 - 3
Worldwide Service Channels	1 - 4
Map of Service Locations	1 - 5
Source of Support	1 - 6

### CHAPTER 2: SERVICE OVERVIEW

L7000 Series Overview and Components	2 - 2
L7000 Overview	2 - 2
Components	2 - 3
Service Overview	2 - 11
Precautions	2 - 11
Appropriate Tools	2 - 12

### CHAPTER 3: DISASSEMBLY PROCEDURE

Keyboard and Heat Sink Plates	3 - 2
CPU Module	3 - 4
LCD Module	3 - 5
HDD Module	3 - 8
Top Case Module	3 - 9
CD-ROM Module	3 - 12
Motherboard Module	3 - 13

### CHAPTER 4: ASSEMBLY PROCEDURE

Motherboard Module	4 - 2
CD-ROM Module	4 - 7
Top Case Module	4 - 8

HDD Module	4 - 10
LCD Module	4 - 11
CPU Module	4 - 13
Keyboard and Heat Sink Plates	4 - 14

## CHAPTER 5: UPGRADE & REPLACEMENT

CPU Upgrade	5 - 2
Memory Upgrade	5 - 2
HDD Upgrade	5 - 3
LCD Module Replacement	5 - 4
CD-ROM Replacement	5 - 4
Modem Installation	5 - 4

## CHAPTER 6: HARDWARE SPECIFICATIONS

Main System General Specifications	6 - 2
Input and Output Specifications	6 - 4
Module Specifications	6 - 7
Hard Disk Drives	6 - 7
CD-ROM Drive	6 - 13
Floppy Disk Drive	6 - 14
LCD Panels	6 - 15
AC Adapter	6 - 16
Battery Pack	6 - 17

## CHAPTER 7: SOFTWARE SPECIFICATIONS

System Resources Map	7 - 2
I/O Address	7 - 2
DMA Channels	7 - 2
Interrupt Vectors	7 - 3
Memory Range	7 - 3
Function Key Definition	7 - 5
LED Indicator Definition	7 - 6
BIOS POST codes	7 - 7

## CHAPTER 8: COMPONENT PARTS LIST

System Assembly	8 - 2
CPU Module	8 - 3
Case & Module Assembly	8 - 4

DIMM Cover Assembly	8 - 9
Heat Sink Plate Assembly	8 - 9
Modem Module	8 - 9
Bottom Case Module	8 - 11
Bottom Case Sub-Assembly	8 - 11
Top Case Module	8 - 13
Top Case Sub-Assembly	8 - 13
Battery Module	8 - 15
CD-ROM Module	8 - 18
CD-ROM Bezel Assembly	8 - 18
HDD Module	8 - 20
LCD Module	8 - 23
Motherboard Module	8 - 27
Main Board (CardBus)	8 - 28

<This page is intentionally left blank>