


Appendix F Pin Assignments



RS-232C Port

| Pin | Descriptions | Pin | Descriptions |
|-----|--------------|-----|--------------|
| 1 | DCD1 | 6 | DSR1 |
| 2 | RXD1 | 7 | RST1 |
| 3 | TXD1 | 8 | CTS1 |
| 4 | DTR1 | 9 | RT1 |
| 5 | GND | 10 | N/C |

Redundant Controller Port

| Pin | Descriptions | Pin | Descriptions |
|-----|--------------|-----|--------------|
| 1 | DCD2 | 6 | DSR2 |
| 2 | RXD2 | 7 | RTS2 |
| 3 | TXD2 | 8 | CTS2 |
| 4 | DTR2 | 9 | RS232 RESET |
| 5 | GND | 10 | N/C |

Fault-bus Plus Port

| Pin | Descriptions | Pin | Descriptions |
|-----|--------------|-----|--------------|
| 1 | Slot 1 | 2 | Slot 5 |
| 3 | Slot 2 | 4 | Slot 6 |
| 5 | Slot 3 | 6 | Slot 7 |
| 7 | Slot 4 | 8 | FBUS_RST |
| 9 | GND | 10 | GND |
| 11 | Slot 8 | 12 | Slot 12 |
| 13 | Slot 9 | 14 | Slot 13 |
| 15 | Slot 10 | 16 | Slot 14 |
| 17 | Slot 11 | 18 | N/C |
| 19 | GND | 20 | GND |
| 21 | UPSOUT# | 22 | N/C |
| 23 | POWER# | 24 | TEMP# |
| 25 | UPSIN# | 26 | FAN# |

DA-ACCY-NM Null Modem

| |
|----------------------|
| Swap pin-2 and pin-3 |
| Swap pin-4 and pin-6 |
| Swap pin-7 and pin-8 |

DA-ACCY-EC RS-232C Extension Cable

| |
|---|
| Extend the cable length only, no wire swap. |
|---|

DA-ACCY-RC Redundant Controller Cable

| |
|----------------------|
| Swap pin-2 and pin-3 |
|----------------------|

| |
|----------------------|
| Swap pin-4 and pin-6 |
|----------------------|

| |
|----------------------|
| Swap pin-7 and pin-8 |
|----------------------|