

# DA-3000

Ultra2-to-Ultra2 SCSI RAID Controller

---

## Instruction Manual

Revision 1.0





# User' s Notice

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

The product name and revision number are both printed on the product itself. Manual revisions are released for each product design represented by the digit before and after the period of the manual revision number. Manual updates are represented by the third digit in the manual revision number.

For previous or updated manuals, BIOS, drivers, or product release information, contact ASUS at <http://www.asus.com.tw> or through any of the means indicated on the following page.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

**Copyright ©1999 ASUSTeK COMPUTER INC. All Rights Reserved.**

# ASUS CONTACT INFORMATION

## ASUSTeK COMPUTER INC. (Asia-Pacific)

### Marketing

Address: 150 Li-Te Road, Peitou, Taipei, Taiwan 112  
Telephone: +886-2-2894-3447  
Fax: +886-2-2894-3449  
Email: info@asus.com.tw

### Technical Support

Tel (English): +886-2-2894-3447 ext. 706  
Tel (Chinese): +886-2-2894-3447 ext. 701  
Fax: +886-2-2895-9254  
Email: tsd@asus.com.tw  
Newsgroup: news2.asus.com.tw  
WWW: www.asus.com.tw  
FTP: ftp.asus.com.tw/pub/ASUS

## ASUS COMPUTER INTERNATIONAL (America)

### Marketing

Address: 6737 Mowry Avenue, Mowry Business Center, Building 2  
Newark, CA 94560, USA  
Fax: +1-510-608-4555  
Email: info-usa@asus.com.tw

### Technical Support

Fax: +1-510-608-4555  
BBS: +1-510-739-3774  
Email: tsd-usa@asus.com.tw  
WWW: www.asus.com  
FTP: ftp.asus.com.tw/pub/ASUS

## ASUS COMPUTER GmbH (Europe)

### Marketing

Address: Harkort Str. 25, 40880 Ratingen, BRD, Germany  
Telephone: 49-2102-445011  
Fax: 49-2102-442066  
Email: sales@asuscom.de

### Technical Support

Hotline: 49-2102-499712  
BBS: 49-2102-448690  
Email: tsd@asuscom.de  
WWW: www.asuscom.de

# Table of Contents

<b>Chapter 1</b>	<b>Introduction .....</b>	<b>1-1</b>
<b>Chapter 2</b>	<b>Features.....</b>	<b>2-1</b>
<b>Chapter 3</b>	<b>Configuration Options.....</b>	<b>3-1</b>
3.1	RAID Management .....	3-1
3.2	Drive Failure Management .....	3-5
3.3	Disk Array Parameters.....	3-11
3.4	Cache Parameters.....	3-12
3.5	Drive-Side SCSI Parameters .....	3-13
3.6	Dynamic Logical Drive Expansion .....	3-17
<b>Chapter 4</b>	<b>Hardware Installation.....</b>	<b>4-1</b>
4.1	Locations of the Parts .....	4-1
4.2	Installing DRAM SIMM.....	4-4
4.3	Installing the SCSI Channel Upgrade Daughterboard.....	4-6
4.4	Battery Back-up .....	4-7
4.5	Power Connection .....	4-10
4.6	Serial Port Connection and Setup .....	4-11
4.7	Basic Operational Setup .....	4-13
4.10	In-band SCSI .....	4-15
<b>Chapter 5</b>	<b>Quick Setup.....</b>	<b>5-1</b>
5.1	Front Panel.....	5-1
5.2	RS-232 Terminal Interface.....	5-3
<b>Chapter 6</b>	<b>Configuring RAID.....</b>	<b>6-1</b>
6.1	Starting to Build a RAID System Drive.....	6-1
6.2	How the RAID Controller Works?.....	6-3
<b>Chapter 7</b>	<b>General Front Panel Operation .....</b>	<b>7-1</b>
7.1	Understanding the Information on the LCD .....	7-1
7.2	Viewing and Editing Logical Drives .....	7-4
7.3	Viewing and Editing Host LUNs .....	7-12
7.4	Viewing and Editing SCSI Drives .....	7-14
7.5	Viewing and Editing SCSI Channels .....	7-20
7.6	Viewing and Editing Configuration Parameters .....	7-29
7.7	Viewing and Editing Peripheral Devices.....	7-37
7.8	System Functions .....	7-37
7.9	Viewing System Information .....	7-39
7.10	Viewing and Editing Event Logs.....	7-39
<b>Chapter 8</b>	<b>RS-232C Terminal Interface.....</b>	<b>8-1</b>
8.1	Understanding the Information on the Screen .....	8-1
8.2	Viewing and Editing Logical Drives .....	8-8
8.3	Viewing and Editing Host LUNs .....	8-18
8.4	Viewing and Editing SCSI Drives .....	8-23
8.5	Viewing and Editing SCSI Channels .....	8-30
8.6	Viewing and Editing Configuration Parameters .....	8-41
8.7	System Functions .....	8-54

8.8	Viewing System Information .....	8-57
<b>Chapter 9</b>	<b>Redundant Controller .....</b>	<b>9-1</b>
9.1	Before You Begin... ..	9-1
9.2	Setting Up The Redundant Controllers.....	9-4
9.3	When One of the Controller Fails... ..	9-12
<b>Chapter 10</b>	<b>Redundant Host, Multiple Host.....</b>	<b>10-1</b>
10.1	Redundant Host.....	10-1
10.2	Using Microsoft® Cluster Server (MSCS).....	10-2
10.3	Multiple Host .....	10-6
<b>Chapter 11</b>	<b>Remote Administration.....</b>	<b>11-1</b>
11.1	GUI RAID Manager Using SNMP Service.....	11-1
11.2	Remote Terminal Emulation Using PPP+Telnet .....	11-3
11.3	Remote Terminal Emulation Using Modem.....	11-9
11.4	Dial-out for Event Notifications .....	11-21
<b>Chapter 12</b>	<b>Fault-Bus.....</b>	<b>12-1</b>
12.1	What is Fault-Bus? Why the Need for Fault-Bus?.....	12-1
12.2	How Does the Fault-Bus Work? .....	12-2
12.3	How to Setup the Fault-bus?.....	12-4
<b>Appendix A</b>	<b>Front Panel Navigation Map .....</b>	<b>A-1</b>
<b>Appendix B</b>	<b>SCSI Cable Specifications .....</b>	<b>B-1</b>
<b>Appendix C</b>	<b>Upgrading the Firmware .....</b>	<b>C-1</b>
	Upgrading firmware using In-band SCSI + GUI RAID Manager ..	C-1
	Upgrading firmware using RS-232 Terminal Emulation.....	C-3
<b>Appendix D</b>	<b>Sync. Clock Period &amp; Sync. Clock Frequency... ..</b>	<b>D-1</b>
<b>Appendix E</b>	<b>Troubleshooting Guide.....</b>	<b>E-1</b>
<b>Appendix F</b>	<b>Pin Assignments.....</b>	<b>F-1</b>
	RS-232C Port.....	F-1
	Redundant Controller Port.....	F-2
	Fault-bus Plus Port.....	F-2
	DA-ACCY-NM Null Modem .....	F-2
	DA-ACCY-EC RS-232C Extension Cable .....	F-3
	DA-ACCY-RC Redundant Controller Cable .....	F-3
<b>Appendix G</b>	<b>Specifications.....</b>	<b>G-1</b>
<b>Appendix H</b>	<b>Record the Settings .....</b>	<b>H-1</b>
	View and Edit Logical Drives .....	H-1
	View and Edit Host LUNs .....	H-2
	View and Edit SCSI Drives.....	H-2
	View and Edit SCSI Channels .....	H-3
	View and Edit Configuration Parameters .....	H-3
	View and Edit Peripheral Devices.....	H-5
{ RD ch1.doc"}{ RD ch2.doc}{ RD ch3.doc}{ RD ch4.doc }{ RD ch5.doc}{ RD ch6.doc}{ RD ch7.doc}{ RD ch8.doc}{ RD ch9.doc}{ RD ch10.doc}{ RD ch11.doc}{ RD ch12.doc}{ RD Apxa.doc }{ RD Apxb.doc }{ RD Apxc.doc }{ RD Apxd.doc }{ RD Apxe.doc }{ RD Apxf.doc }{ RD Apxg.doc }{ RD Apxh.doc }		
	<b>Index</b>	