




RT-N12 B1

华硕 Wireless Superspeed N 路由器



用户手册

C6473

修订版

2011 年 6 月发行

版权所有 • 不得翻印 © 2011 华硕电脑

本用户手册包括但不限于其所包含的所有信息受到着版权法之保护，未经华硕电脑股份有限公司（以下简称「华硕」）许可，不得任意地仿制、拷贝、摘抄、转译或为其他使用或处分。本用户手册没有任何型式的担保、立场表达或其它暗示。若有任何因本用户手册或其所提到之产品的所有信息，所引起直接或间接的数据流失、利益损失或事业终止，华硕及其所属员工恕不为其担负任何责任。除此之外，本用户手册所提到的产品规格及信息仅供参考，内容亦会随时升级，恕不另行通知。华硕不负责本用户手册的任何错误或疏失。

本用户手册中所提及的产品名称仅做为识别之用，而前述名称可能是属于其他公司的注册商标或是著作权。

Offer to Provide Source Code of Certain Software

This product contains copyrighted software that is licensed under the General Public License ("GPL"), under the Lesser General Public License Version ("LGPL") and/or other Free Open Source Software Licenses. Such software in this product is distributed without any warranty to the extent permitted by the applicable law. Copies of these licenses are included in this product.

Where the applicable license entitles you to the source code of such software and/or other additional data, such data should have been shipped along with this product.

You may also download it for free from <http://support.asus.com/download>.

The source code is distributed WITHOUT ANY WARRANTY and licensed under the same license as the corresponding binary/object code.

ASUSTeK is eager to duly provide complete source code as required under various Free Open Source Software licenses. If however you encounter any problems in obtaining the full corresponding source code we would be much obliged if you give us a notification to the email address gpl@asus.com, stating the product and describing the problem (please do NOT send large attachments such as source code archives etc to this email address).

目录内容

关于这本用户手册	5
用户手册的编排方式	5
提示符号	5
第一章：认识您的无线路由器	
包装内容物	7
系统需求	7
开始安装之前	7
硬件设备	8
前面板	8
后面板	9
底部	10
第二章：开始使用	
设置无线路由器	11
使用网络设置向导（QIS）	11
在“IP 分享模式”中设置无线路由器	12
在“中继模式”中设置无线路由器	15
在“无线基地台模式”中设置无线路由器	17
第三章：设置网络客户端	
访问无线路由器	19
设置正确系统 IP 地址，以顺利登录无线路由器页面	19
使用网页图形界面进行设置	27
第四章：使用网页图形界面设置无线路由器	
使用网络地图	29
建立多个 SSID	30
管理 EzQoS 带宽	31
固件升级	32
恢复 / 导出 / 上传设置	33

目录内容

第五章：安装华硕应用程序

安装华硕应用程序	35
侦测设备 (Device Discovery)	37
固件恢复 (Firmware Restoration)	38

第六章：疑难排解

疑难排解	39
华硕 DDNS 服务	42
常见问题解答 (FAQ)	42

附录

注意事项	44
注册步骤	44
Notices	45
华硕的联络信息	53

关于这本用户手册

产品用户手册包含了所有当您在安装华硕无线路由器时所需用到的信息。

用户手册的编排方式

用户手册是由下面几个章节所组成：

- **第一章：认识您的无线路由器**
本章介绍了此华硕无线路由器的包装内容物、系统要求、硬件功能与LED指示灯的信息。
- **第二章：开始使用**
本章介绍如何设置华硕无线路由器的 IP 分享模式、中继模式、无线基地台模式。
- **第三章：设置局域网内的客户端**
本章介绍如何设置无线路由器局域网内的客户端。
- **第四章：使用网页图形界面设置无线路由器**
本章介绍如何使用网页界面设置华硕无线路由器。
- **第五章：安装华硕应用程序**
本章介绍了应用程序光盘内的应用程序信息。
- **第六章：疑难排解**
本章介绍了您在使用华硕无线路由器过程中可能遇到的一些常见问题的解决方法。
- **附录**
本章介绍一些常用安全信息。

提示符号



警告：提醒您在进行某一项工作时要注意您本身的安全。



小心：提醒您在进行某一项工作时要注意勿伤害到设备元件。



重要：此符号表示您必须要遵照手册所描述之方式完成一项或多项软硬件的安装或设置。



注意：提供有助于完成某项工作的诀窍与其他额外的信息。

1 认识您的 无线路由器

包装内容物

请检查以下配件是否齐全：

- RT-N12 B1 无线路由器 × 1
- 电源适配器 × 1
- 应用程序光盘（用户手册、应用程序） × 1
- RJ45 网线 × 1
- 分离式天线 × 2
- 快速使用指南 × 1



注意：若以上列出的任何一项配件有损坏或是短缺的情形，请尽快与您的经销商联络。

系统需求

安装华硕无线路由器之前，请确认您的系统/网络是否符合以下要求：

- 一个以太网络 RJ-45 接口 (10Base-T/100Base-TX)
- 至少一个支持无线功能的 IEEE 802.11b/g/n 设备
- 一台已安装 TCP/IP 与网络浏览器的电脑


开始安装之前

安装华硕无线路由器之前，请注意以下几点：

- 连接设备与网络（网络集线器、ADSL/Cable Modem、路由器）的网线长度须小于 100 米。
- 将设备放在平坦、稳定的地方，并尽量靠近地面。
- 请勿将设备放在靠近金属物品与阳光直射的地方。
- 请将路由器远离适配器、重型发动机、荧光照明器、微波炉、冰箱与其他工业设备以防信号丢失。
- 建议将路由器放置在中心区域，以覆盖所有无线移动设备。
- 请将路由器放置在远离人体至少 20 厘米的地方。

硬件设备


前面板



状态指示灯

LED	状态	代表含义
⏻ (电源)	熄灭	电源关闭
	灯亮	已接通电源，系统待机中
	闪烁	救援模式
📶 (无线网络)	熄灭	电源关闭 / WLAN 信号关闭
	灯亮	无线系统待机中
	闪烁	传输或接收数据中 (无线网络)
📶 LAN 1-4 (局域网)	熄灭	电源关闭 / 无实体连接
	灯亮	与一组以太网络建立实体连接
	闪烁	传输或接收数据中 (通过有线以太网络)
🌐 WAN (广域网)	熄灭	电源关闭 / 无实体连接
	灯亮	与一组以太网络建立实体连接
	闪烁	传输或接收数据中 (通过有线以太网络)


后面板



项目	描述
Internet	连接 RJ-45 以太网线，建立 WAN 连接。
LAN1-LAN4	连接 RJ-45 以太网线，建立 LAN 连接。
DC IN	插入电源适配器连接电源。
WPS	按下此按钮建立无线连接。
Restore	按住此按钮超过 5 秒，系统恢复至出厂初始模式。

项目	描述
操作模式选择	<p>用于选择操作模式：</p> <p>IP 分享模式：在此模式中，RT-N12 B1 通过 PPPoE、自动 IP 或静态 IP 连线到 WAN，在 LAN 内提供无线信号、NAT、防火墙与 IP 分享服务。</p> <p>中继模式：在此模式中，RT-N12 B1 可扩大您的无线网路覆盖范围，并为使用者提供更高品质的无线信号。NAT、防火墙与 IP 分享服务自动关闭。</p> <p>无线基地台模式：在此模式中，RT-N12 B1 从连接到 WAN 接口的路由器收到 WAN IP 地址，并为用户提供无线信号。NAT、防火墙与 IP 分享服务自动关闭。</p>

底部



项目	描述
1	安装挂钩 在墙上安装两颗螺丝后可将路由器挂在墙面上。
2	通风孔 这些通风孔用于路由器的通风散热。



注意：不建议您将路由器安装在墙壁上，以防无线性能变差。

2 开始使用

设置无线路由器

华硕无线路由器包含一个网页图形界面（web GUI），您可以利用电脑上的网络浏览器进行无线路由器的设置。



更多关于通过网页图形界面设置无线路由器的信息，请参考“第四章：使用网页图形界面设置无线路由器”。

您可以把无线路由器设为以下三种操作模式：IP 分享模式、中继模式、无线基地台模式。可通过网络设置向导（QIS）来设置这三种操作模式。

使用网络设置向导（QIS）

网络设置向导（QIS）功能，整合在无线路由器的网页图形界面中，可自动侦测网络连接类型，并引导您快速设置网络。


当您连接了所有设备，并开启网络浏览器后，网络设置向导（QIS）页面自动出现。您也可以在网页图形界面中的网络地图页面开启 QIS。然后在【互联网状态】中选择【前往设置】。

在“IP 分享模式”中设置无线路由器


在“IP 分享模式”中，无线路由器通过 PPPoE、自动取得 IP、PPTP、L2TP 或静态 IP 方式连接互联网，并提供无线信号。LAN 客户端的 NAT、防火墙与 IP 共享服务开启。

请依据以下步骤设置“IP 分享模式”中的无线路由器：

1. 选择“IP 分享模式”。



2. 连接装置。



注意：初始设置时，我们建议您使用一条以太网线（有线连接）将您的电脑连接到无线路由器，以避免无线连接造成不明设置问题。

3. 开启网络浏览器，QIS 开始侦测您的互联网联机类型。



注意：若您开启网络浏览器后 QIS 网页未自动出现，请将网络浏览器的代理服务器功能 (proxy) 关闭。

4. 输入用户名称与密码，然后选择【应用目前所有设置】。



注意：

- 以上设置操作使用 PPPoE 互联网联机类型。互联网联机的类型不同，设置画面会不同。
- 从您的互联网服务供应商 (ISP) 取得所需信息，如用户名称与密码。

4. 互联网联机设置完成。

- 选择【前往我的首页】连接互联网。
- 选择【到高级设置页面】手动进行无线路由器的高级设置。
- 选择【加入我的最爱】将此 URL 新增至您的最爱列表，以快速进入网页图形界面。




在“中继模式”中设置无线路由器


在“中继模式”中，无线路由器可扩大您的无线网络覆盖范围，并为用户提供更高品质的无线信号。NAT、防火墙与 IP 共享服务会主动关闭。

请依据以下步骤设置“中继模式”中的无线路由器：

1. 选择“中继模式”。



2. 连接装置。



注意：初始设置时，我们建议您使用一条以太网线（有线连接）将您的电脑连接到无线路由器，以避免无线连接造成不明设置问题。

3. 开启网络浏览器，QIS 网页自动出现。选择您要扩展无线信号的基地台，然后选择【建立联机】。



注意：若您开启网络浏览器后 QIS 网页未自动出现，请将网络浏览器的代理服务器功能（proxy）关闭。

在“无线基地台模式”中设置无线路由器




注意：在“无线基地台模式”中设置无线路由器，可使用驱动程序与应用程序光盘内的“Device Discovery”进入网页图形使用界面。


在“无线基地台模式”中，无线路由器从连接到 WAN 口的路由器收到 WAN IP 地址，并为用户提供无线信号。NAT、防火墙与 IP 共享服务会自动关闭。

请依据以下步骤设置“无线基地台模式”中的无线路由器：

1. 选择“无线基地台模式”。



2. 连接设备。



注意：初始设置时，我们建议您使用一条以太网线（有线连接）将您的电脑连接到无线路由器，以避免无线连接造成不明设置问题。

3. 开启“Device Discovery”应用程序，点击【设置】进入网页图形使用界面。
4. 在登入页面中，输入初始用户名（admin）与密码（admin）。



5. 接着会出现华硕无线路由器主页。主页显示快速连接，可设置无线路由器。



3 设置网络客户端

访问无线路由器

设置正确系统 IP 地址，以顺利登录无线路由器页面

为使用华硕无线路由器，您的有线或无线客户端上必须有正确的 TCP/IP 设置。请确认客户端的 IP 地址与华硕无线路由器网段一致。

华硕路由器内置 DHCP 服务器功能，当系统开启时，它将自动指定 IP 地址到网络中的客户端。

但在某些情况下，您可能需要手动指定某些您网络内的客户端或电脑的静态 IP 地址，而不是通过您的无线路由器自动取得 IP 地址。

以下是设置您电脑的步骤。请依照您所使用的操作系统选择适当的操作步骤。




注意：在“IP 分享模式”中，如果您想手动指定一个 IP 地址，推荐使用下列设置：


- IP 地址：192.168.1.xxx (xxx 可为 2 至 254 之间的数字)。请确认该 IP 地址没有被其他设备使用。
 - 子网掩码：255.255.255.0 (与华硕无线路由器一致)
 - 默认网关：192.168.1.1 (华硕无线路由器的 IP 地址)
 - DNS：192.168.1.1 (华硕无线路由器) 或者指定一个网络内的已知 DNS 服务器。
-

Windows® 9x/ME


1. 依次点击【Start】>【Control Panel】>【Network】，此时将会出现「Network」设置窗口。
2. 在「TCP/IP」标签页中，点击【Properties】。




3. 若您想让电脑自动获取 IP 地址，请点击【Obtain an IP address automatically】，然后按下【OK】。或者，您也可以点击【Specify an IP address】，手动输入 IP 地址（IP Address）与子网络掩码（Subnet Mask）。



4. 选择【Gateway】标签页，在「New gateway」栏位输入新的网关地址，然后点击【Add】。




5. 选择【DNS configuration】标签页，点击【Enable DNS】。输入 Host、Domain 与 DNS Server Search Order，然后点击【Add】。
6. 点击【OK】。




Windows® NT4.0


1. 依次点击【Control Panel】>【Network】，此时将会出现「Network」设置窗口。
选择【Protocols】标签页。
2. 从「Network Protocols」列表中选择【TCP/IP Protocol】，然后点击【Properties】。



3. 在「Microsoft TCP/IP Properties」窗口的「IP Address」标签页，您可以：
 - 选择您的系统的网卡类型。
 - 让路由器自动指定 IP 地址。
 - 手动设置 IP 地址，子网络掩码与预设网关。




4. 选择「DNS」标签页并点击「DNS Service Search Order」列表下面的【Add】按钮，然后输入 DNS。




Windows® 2000

1. 依次选择【Start】>【Control Panel】>【Network and Dial-up Connection】。右键选择【Local Area Connection】，然后选择【Properties】。




2. 选择【Internet Protocol (TCP/IP)】，然后选择【Properties】。
3. 若您想要使用路由器自动指定的 IP 地址，请选择【Obtain an IP address automatically】。或者，您也可以选择【Use the following IP address】，手动输入 IP 地址 (IP Address)、子网掩码 (Subnet Mask) 与默认网关 (Default gateway)。
4. 若您想要自动获取 DNS 服务器，请选择 Obtain DNS server address automatically。或者，您也可以选择【Use the following DNS server address】，手动输入首选与备用 DNS 服务器 IP 地址 (Preferred/Alternate DNS server)。
5. 完成后选择【OK】。




Windows® XP

1. 依次选择【Start】>【Control Panel】>【Network Connection】。右键选择【Local Area Connection】，然后选择【Properties】。




2. 选择【Internet Protocol (TCP/IP)】，然后选择【Properties】。
3. 若您想要使用路由器自动指定的 IP 地址，请选择【Obtain an IP address automatically】。或者，您也可以选择【Use the following IP address】，接着手动输入 IP 地址 (IP Address)、子网掩码 (Subnet Mask) 与默认网关 (Default gateway)。
4. 若您想要自动获取 DNS 服务器，请选择【Obtain DNS server address automatically】。或者，您也可以选择【Use the following DNS server address】，手动输入首选与备用 DNS 服务器 IP 地址 (Preferred/Alternate DNS server)。
5. 完成后选择【OK】。




Windows® Vista/7

1. 依次选择【Start】>【Control Panel】>【Network and Internet】>【Network and Sharing Center】，接着选择【View status】>【Properties】>【Continue】。



2. 选择【Internet Protocol Version 4 (TCP/IPv4)】，接着选择【Properties】。
3. 若您想要使用路由器自动指定的 IP 地址，请选择【Obtain an IP address automatically】或者，您也可以选择【Use the following IP address】，接着手动输入 IP 地址 (IP Address)、子网掩码 (Subnet Mask) 与默认网关 (Default gateway)。
4. 若您想要自动获取 DNS 服务器，请选择 Obtain DNS server address automatically 或者，您也可以选择 Use the following DNS server addresses 手动输入首选与备用 DNS 服务器 IP 地址 (Preferred/Alternate DNS server)。
5. 完成后选择【OK】。



使用网页图形界面 设置无线路由器

使用网页图形界面进行设置

网页图形界面 (web GUI) 允许您设置以下功能：网络地图与 EzQoS 带宽管理。

请依照以下步骤通过网页图形界面进行设置：

1. 建立有线或无线连接后，开启一个网络浏览器。登入页面会自动出现。



注意：

- 在 IP 分享模式中，路由器的 IP 地址为：192.168.1.1。
- 在无线基地台模式中，请使用应用程序中的 Device Discovery 来获取路由器的 IP 地址。

2. 在登入页面中，输入初始用户名称 (admin) 与密码 (admin)。



3. 接着会出现华硕无线路由器主页。主页显示网络地图，可设置无线路由器。



使用网络地图

网络地图 可以让您浏览互联网、系统与您网络中客户端的状态，并进行连接设置。也可以让您利用网络设置向导 (QIS) 功能建立英特网连接。

欲浏览状态或进行连接设置，请选择主画面上的图示：

图示	描述
	<p>互联网状态</p> <p>按下此图示显示互联网状态、外部网络 IP、DNS、连接类型与网关的信息。在互联网状态画面中，可以使用网络设置向导 (QIS) 功能快速建立英特网连接。</p>
	<p>系统状态</p> <p>按下此图示显示有关 SSID、授权方式、WEP 加密、内部网络 IP、PIN 码、MAC 地址的信息，或者开启 / 关闭无线信号。</p>
	<p>客户端状态</p> <p>按下此图示显示网络内客户端或电脑的有关信息，并可让您阻止 / 允许客户端连接。</p>

建立多个 SSID

无线路由器允许您建立多个 SSID，满足不同的运行环境。

请依照以下步骤建立 SSID：

1. 在 SSID 中，选择【新增】。



2. 进行设置，然后选择【新增】。



管理 EzQoS 带宽

EzQoS 带宽管理可让您设置带宽优先级。

请依照以下步骤设置带宽优先级：

1. 在画面左边的导航菜单里选择【EzQoS 带宽管理】。



2. 选择下面四个应用程序进行优先级设置：

图示	描述
	网络游戏 路由器将游戏流量设为最高优先级。
	网络应用程序 路由器将电子邮件、网页浏览以及其他网络应用程序设为最高优先级。
	FTP 路由器将从 FTP 服务器下载 / 上传数据流量设为最高优先级。
	在线影音 路由器将音频 / 视频流量设为最高优先级。

3. 选择【保存】保存设置。

固件升级



注意：请访问华硕简体中文网站 (<http://www.asus.com.cn>) 下载最新固件。

请依照以下步骤进行固件升级：

1. 选择屏幕左边导航菜单中的【高级设置】。



2. 选择【系统管理】菜单下的【固件升级】。
3. 在 新固件文件中选择【浏览】，开启您要升级的固件文件。
4. 选择【上传】，过程将需要大约三分钟。



注意：如果升级进程失败，请使用 Firmware Restoration 应用程序恢复系统。详情请参考“第五章：固件恢复（Firmware Restoration）”的有关内容。

恢复 / 导出 / 上传设置

请依照以下步骤进行恢复 / 导出 / 上传设置：

1. 选择屏幕左边导航菜单中的【高级设置】。
2. 选择【系统管理】菜单下的【恢复 / 导出 / 上传设置】。



3. 选择您想要进行的操作：
 - 想恢复为原厂默认设置，选择【恢复】，然后按下确认信息中的【确定】。
 - 想导出现有系统设置，选择【保存】，然后选择文件下载窗口中的【保存】将您的系统文件储存在您想要储存的位置下。
 - 想恢复系统设置，选择【浏览】开启您欲恢复的系统文件，然后按下【上传】。

5 安装华硕 应用程序

安装华硕应用程序

应用程序光盘包含用于设置华硕无线路由器的应用程序。在 Microsoft® Windows 操作系统下安装华硕无线路由器应用程序，请将应用程序光盘插入光盘机。如果未开启“自动播放”功能，请选择应用程序光盘根目录中的 setup.exe。

请依照以下步骤安装应用程序：

1. 选择主菜单【安装华硕无线路由器应用程序】选项，来执行安装程序。



2. 选择【下一步】继续。



侦测设备（Device Discovery）

Device Discovery 是一款华硕 WLAN 应用程序，可以侦测到一个华硕无线路由器设备，并且允许您设置该设备。

请依照以下步骤开启 Device Discovery 应用程序：

- 在您的电脑桌面上选择【开始】>【所有程序】>【ASUS Utility】>【RT-N12 B1 Wireless Router】>【Device Discovery】。



- 选择【配置】进入网页图形界面来设置无线路由器。
- 选择【搜索】来搜寻华硕无线路由器。
- 选择【退出】退出此应用程序。

固件恢复 (Firmware Restoration)

Firmware Restoration 应用程序用于在固件升级失败时搜寻升级失败的华硕无线路由器。然后恢复或上传您指定的固件。此过程需要 3 至 4 分钟。



重要：在使用 Firmware Restoration 之前，请开启救援模式。

请依照以下步骤开启救援模式并使用 Firmware Restoration 应用程序：

1. 把无线路由器拔除电源。
2. 持续按住后面板上的 Restore 按钮，同时把路由器重新接上电源。当前面板上的 Power 指示灯开始慢闪时，放开按钮。此时，路由器已进入救援模式。
3. 在您的电脑桌面上选择【开始】>【所有程序】>【ASUS Utility】>【RT-N12 B1 Wireless Router】>【Firmware Restoration】。



4. 选择固件文件，然后选择【上传】。



注意：Firmware Restoration 不是固件升级应用程序，并且不能用于正在运行的华硕无线路由器上。正常固件升级应该在网页图形界面中完成，详细信息请参考“第四章：使用网页图形界面设置无线路由器”。

疑难排解

本章节帮您排解在安装与使用华硕无线路由器时的常见疑难问题。若有无法自行解决的疑难或本章节未提及问题，请联络华硕技术支持。

疑难	排解
无法进入网页图形界面进行路由器设置	<ol style="list-style-type: none"> 1. 开启网络浏览器（如 IE），然后选择工具 下拉式菜单，并选择【Internet 选项】。 2. 在 Internet 临时文件中，选择【删除 Cookies】与【删除文件】。 3. 关闭网络浏览器的代理设置。
无法建立无线网络连接	<p>超出有效范围：</p> <ul style="list-style-type: none"> • 请将路由器放置于较靠近客户端设备之处。 • 尝试进行频道设置的变更。 <p>认证问题：</p> <ul style="list-style-type: none"> • 请使用有线连接的电脑来连接路由器。 • 检查网络安全设置。 • 您可以尝试按路由器后方的重置（Restore）按钮超过 5 秒钟后，进行硬件重置（hardware reset）的动作。 <p>无法搜寻到路由器：</p> <ul style="list-style-type: none"> • 您可以尝试按路由器后方的重置（Restore）按钮超过 5 秒钟后，进行硬件重置（hardware reset）的动作。 • 检查无线网卡上的 SSID 与加密等设置。

疑难	排解
无法通过无线路由器来连接至互联网	<ul style="list-style-type: none"> • 请将路由器更换至客户端可以连接到的范围内。 • 检查您所使用的无线网卡是否有连接到正确的路由器。 • 检查所使用的无线网络频道是符合您的所在地区 / 国家所规范的频道。 • 检查加密设置。 • 检查您所使用的 ADSL 或 Cable Modem 是否有连接至正确的网络口。 • 重新更换另一条以太网线来连接。
无法进入互联网	<ul style="list-style-type: none"> • 请检查 ADSL 调制解调器与无线路由器上的 LED 灯所显示的信号是否正确。 • 请检查 WAN 灯号在路由器上是否有亮。若灯号没有显示亮着 (on) 的状态, 请检查连接两者的网线, 并再重新测试一遍。
当 ADSL 调制解调器“Link” (连接) 的灯号亮着 (不是闪烁), 这表示已经可以连接至互联网。	<ul style="list-style-type: none"> • 重新启动您的电脑。 • 重新设置华硕路由器, 请参考快速使用指南。 • 检查 WAN LED 信号灯是否亮着。 • 检查无线网络加密的设置。 • 检查欲与路由器连接的电脑是否能取得 IP 地址 (经由有线网络与无线网络两者是否皆可)。 • 检查您的网络浏览器 (如 IE) 是否设置为采用局域网, 并且不采用代理服务器 (proxy)。

疑难	排解
<p>如何将系统恢复到初始值？</p>	<p>以下为原厂初始的参考数值，若您按住在路由器上的 Restore(重置)钮超过 5 秒钟，或于【系统设置】>【原厂默认值】画面中，按【恢复】按钮而回到初始值状态时，则在路由器上的相关的设置，会恢复到原厂初始的数值，其数值则如以下所列。</p> <p>用户名称：admin 密码：admin 启用 DHCP:Yes (如果已连接 WAN 缆线) IP 地址：192.168.1.1 网域名称：(空白) 子网掩码：255.255.255.0 DNS 服务器 1：192.168.1.1 DNS 服务器 2：(空白) SSID：default</p>
<p>无法使用 192.168.1.1 进入网页图形界面。</p>	<p>请检查路由器的作业模式。</p> <ul style="list-style-type: none"> • 在 IP 分享模式中，初始 IP 地址为：192.168.1.1。 • 在无线基地台模式中，使用 Device Discovery 来获取路由器的 IP 地址。

华硕 DDNS 服务

RT-N12 B1 是一款支持华硕 DDNS 服务的产品。当您更换设备时，若您已注册华硕 DDNS 服务，并想要保留网域名称，就必须进行数据传输。请咨询当地华硕技术支持了解详细信息。



注意：

若在网域中没有活动 --- 如重新设置路由器或访问注册的网域名称 --- 90 天内，系统自动删除 DDNS 注册数据。

在使用过程中若您碰到任何问题，请连络华硕技术支持。

常见问题解答 (FAQ)

1. DDNS 注册数据会丢失或被其他人使用吗？

若您 90 天内没有升级 DDNS 注册数据，系统自动删除 DDNS 注册数据，网域名称可能会被其他人使用。

2. 6 个月前我购买了路由器，但没有注册华硕 DDNS 服务。现在我还可以注册吗？

您仍可以注册华硕 DDNS 服务。DDNS 服务内置在您的路由器中，所以您可以随时注册。在注册前，选择【查询】查询主机名称是否已被注册。若没有，系统会自动进行注册。

3. 我以前注册过一个网域名称，并且能正常使用，后来我的朋友说无法访问我的网域名称了，为什么？

请确认：

1. 互联网联机正常。
2. DNS 服务器工作正常。
3. 最近 90 天内升级过网域名称。

若仍不能访问您的网域名称，请连络华硕技术支持。

4. 我是否可以注册二个网域名称，分开访问 http 与 ftp 服务器？

不可以。一台路由器只可注册一个网域名称。

5. 重新启动路由器后，为什么在路由器设置画面与 MS DOS 中会看到不同的 WAN IP？

这是正常的。ISP DNS 服务器与华硕 DDNS 的升级间隔时间不同导致在路由器设置画面与 MS DOS 中出现不同的 WAN IP。不同的 ISP 会有不同的 IP 升级间隔时间。

6. 华硕 DDNS 服务是免费的吗？它只是个试用版本吗？

华硕 DDNS 服务是免费的，一些华硕路由器中内置 DDNS 服务。请确认您的华硕路由器是否支持 DDNS 服务。

注意事项

当您购买本产品后，为保障购买人权益，请于购买后一个月内务必上网填写完整个人数据及产品信息并完成注册手续。

1. 通过网络注册，请您先加入华硕会员，再进行产品登入之作业（网址：<http://member.asus.com>）。
2. 妥善保留购买当时之发票或是发票凭证(影本亦可)，经销商之售货单据(加盖经销商店章始生效力)，于机台故障送修时出示,始享有保修服务之权益；
若不慎遗失相关证明单据且于购买华硕无线网络产品一个月内，未上网进行注册，本公司将以华硕“出货日”为保修起始日期。
3. 无论在任何情况下，您都不可以自行拆解修理本机,这将导致本机的保修作废。

注册步骤

注册网址：<http://member.asus.com>

步骤1：加入会员（如已是会员，请跳到步骤5，直接“加入会员”可注册新购买的产品）

步骤2：个人数据填写完成后按“同意并且继续”

步骤3：注册系统将会发送启用帐号的“确认码”认证信件

步骤4：请依照确认码信件指示进行帐号认证，以确认您会员权益

步骤5：选择产品注册，填写完整的产品信息即可完成注册

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Prohibition of Co-location

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Safety Information

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance 20cm between the radiator and your body. Use on the supplied antenna.

Declaration of Conformity for R&TTE directive 1999/5/EC

Essential requirements – Article 3

Protection requirements for health and safety – Article 3.1a

Testing for electric safety according to EN 60950-1 has been conducted. These are considered relevant and sufficient.

Protection requirements for electromagnetic compatibility – Article 3.1b

Testing for electromagnetic compatibility according to EN 301 489-1 and EN 301 489-17 has been conducted. These are considered relevant and sufficient.

Effective use of the radio spectrum – Article 3.2

Testing for radio test suites according to EN 300 328- 2 has been conducted. These are considered relevant and sufficient.

CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Operation Channels: Ch1~11 for N. America, Ch1~14 Japan, Ch1~13 Europe (ETSI)

IC Warning

The Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulation.

Cet appareil numérique de la class B respecte toutes les exigences du Reglement sur le materiel brouilleur du Canada.

GNU General Public License

Licensing information

This product includes copyrighted third-party software licensed under the terms of the GNU General Public License. Please see The GNU General Public License for the exact terms and conditions of this license. We include a copy of the GPL with every CD shipped with our product. All future firmware updates will also be accompanied with their respective source code. Please visit our web site for updated information. Note that we do not offer direct support for the distribution.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

Terms & conditions for copying, distribution, & modification

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The “Program”, below, refers to any such program or work, and a “work based on the Program” means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program’s source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
 - a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
 - b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
 - c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
 - a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
 - b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
 - c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.
10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12 IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

NCC Warning

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

REACH

注意：谨遵守 REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) 管理规范，我们会将产品中的化学物质公告在华硕 REACH 网站，详细请参考<http://csr.asus.com/english/REACH.htm>

Safety Warning

SAFE TEMP: This wireless router should be only used in environments with ambient temperatures between 5°C(41°F) and 40°C(104°F).

DO NOT expose to or use near liquids, rain, or moisture. DO NOT use the modem during electrical storms.

华硕的联络信息

华硕电脑（上海）有限公司 ASUSTEK COMPUTER (SHANGHAI) CO., LTD (中国)

市场信息

地址：上海市闵行莘庄工业区春东路
508 号
电话：+86-21-54421616
传真：+86-21-54420099
互联网：<http://www.asus.com.cn/>

技术支持

电话：+86-21-34074610
(800-820-6655)
电子邮件：<http://www.asus.com.cn/email>
在线支持：<http://support.asus.com/techserv/techserv.aspx>

华硕电脑公司 ASUSTeK COMPUTER INC. (亚太地区)

市场信息

地址：台湾台北市北投区立德路15 号
电话：+886-2-2894-3447
传真：+886-2-2890-7798
电子邮件：info@asus.com.tw
互联网：<http://www.asus.com.tw>

技术支持

电话：+86-21-38429911
传真：+86-21-58668722, ext. 9101#
在线支持：<http://support.asus.com/techserv/techserv.aspx>

ASUS COMPUTER INTERNATIONAL (美国)

市场信息

地址：800 Corporate Way, Fremont,
California 94539, USA
电话：+1-510-739-3777
传真：+1-510-608-4555
互联网：<http://usa.asus.com>

技术支持

电话：+1-812-282-2787
传真：+1-812-284-0883
在线支持：<http://support.asus.com/techserv/techserv.aspx>

ASUS COMPUTER GmbH (德国/奥地利)

市场信息

地址：Harkort Str. 21-23, D-40880
Ratingen, Deutschland
传真：+49-2102-959911
互联网：<http://www.asus.de>
在线联络：<http://www.asus.de/sales>
(仅回答市场相关事务的问题)

技术支持

电话：+49-1805-010923 (配件) *
电话：+49-1805-010920 (系统 / 笔记本电脑 / 易家族 / LCD) *
传真：+49-2102-9599-11
在线支持：<http://support.asus.com/techserv/techserv.aspx>

* 使用德國固定電話撥打每分鐘話費為 0.14 歐元，使用手機撥打每分鐘話費為 0.42 歐元。

Manufacturer:	ASUSTeK Computer Inc. Tel: +886-2-2894-3447 Address: No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY
Authorised distributors in Turkey:	BOGAZICI BIL GISAYAR SAN. VE TIC. A.S. Tel: +90 212 3311000 Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/ISTANBUL
	INDEX BILGISAYAR SISTEMLERI MUHENDISLIK SAN. VE TIC. A.S. Tel: +90 212 3312121 Address: AYAZAGA MAH. CENDERE YOLU NO.9 AYAZAGA/ISTANBUL

EEE Yönetmeliğine Uygundur.