



Bluetooth USB Dongle *Quick Start Guide v5.0*

© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

The Bluetooth name and the Bluetooth trademarks are owned by Bluetooth SIG, Inc.

System requirements

- Processor : Intel Celeron / Pentium III, IV; AMD Duron / Athlon
- Operating System : Microsoft Windows 2000 / XP and Vista .
- System memory : 32MB at least, Hard Drive Free Space : 11.5MB

Before you start

- 1). Remove any Microsoft native driver
- 2). Please remove any previous version of ASUS/Broadcom Bluetooth software in your system.

Step 1 : Click [Start]->[Settings]->select Control Panel->double click Add/Remove programs icon.

Step 2 : Find out the item ASUS/Broadcom Bluetooth Software and then remove it.

Install Driver/Utility in Windows 2000 / XP / Vista

Step 1 : Insert support CD into CD Drive of your PC, an Auto-Install program will start

Step 2 : Choose “Install Bluetooth Utilities/Driver” to complete the installation step by step

Begin to Use

Before you start to enjoy various Bluetooth applications, you have to pair and link with other Bluetooth devices. Please refer to user manuals for instruction.

- 1). Click [Start]->[All Programs]->[ASUS Utility]->[Bluetooth Software]->Bluetooth Help, or
- 2). Find User Manual in <Manual> folder in the support CD