




Wireless Local Area Network Adapter

WL-167g

(For 802.11g & 802.11b Wireless Networks)



User's Manual

Copyright Information

Copyright © 2008 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK Computer Inc. (“ASUS”).

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners’ benefit, without intent to infringe.

ASUSTeK COMPUTER INC. (Asia Pacific)

Address 15 Li-Te Road, Peitou, Taipei, Taiwan 11259
Website www.asus.com.tw

Technical Support

Telephone +886228943447
Support Fax +886228907698
Software download support.asus.com*

ASUS COMPUTER INTERNATIONAL (America)

Address 800 Corporate Way, Fremont, CA 94539, USA
Telephone +15029550883
Fax +15029338713
Website usa.asus.com
Software download support.asus.com*

ASUS COMPUTER GmbH (Germany and Austria)

Address Harkort Str. 25, D40880 Ratingen, Germany
Telephone +49210295990
Fax +492102959911
Online contact www.asus.com.de/sales

Technical Support

Telephone +49210295990
Fax +492102959911
Online support www.asus.com.de/support
Website www.asus.com.de/news

* Available on this site is an online Technical Inquiry Form that you can fill out to contact technical support.

Table of Contents

1. Introduction	6
Overview.....	6
Package contents	7
Features	8
LED indicators	8
Network setup.....	9
Ad-hoc network	9
Infrastructure network	9
System requirements.....	10
Installation procedures	10
Installing drivers and utilities	10
Installing the ASUS USB Wireless LAN Adapter	11
Support software overview	12
One Touch Wizard (new wireless LAN).....	13
One Touch Wizard (existing LAN)	14
Configuring the Wireless LAN utility	15
Soft AP (Windows XP Only).....	16
3. Software Reference	19
Control Center	19
Control Center icons	19
Control Center right-click menu.....	20
Control Center left-click menu.....	20
Wireless Settings.....	21
Status	21
Status tab	21
Configuration.....	24
Site Survey.....	26
About Wireless Settings	27
Link State	27
Command icons	28
Other right-click options	28
Mobile Manager.....	29
Creating a new configuration	31
Editing a configuration.....	34
Site Monitor	38
Launching Site Monitor	38
Site Monitor main window	38

Table of Contents

Monitoring a connection	39
Troubleshooting	40

1. Introduction

Overview

Thank you for choosing the ASUS USB Wireless LAN Adapter!

The ASUS USB Wireless LAN Adapter is an easy-to-install and use wireless LAN adapter. Conforming to IEEE 802.11g standard for wireless local area network (WLAN), the ASUS USB Wireless LAN Adapter is capable of up to 54Mbps data transmission rate using the Direct Sequence Spread Spectrum (DSSS) and the Orthogonal Frequency Division Multiplexing technologies.

The ASUS USB Wireless LAN Adapter also comes with the latest wireless technology developed by ASUS to keep you ahead in the world of wireless computing.


Package contents

Check the following items in your ASUS USB Wireless LAN Adapter package. Contact your retailer if any item is damaged or missing.

- ☑ ASUS USB Wireless LAN Adapter (WL-167g)
- ☑ USB 2.0 extension cable (type A to type A)
- ☑ USB 2.0 universal joint
- ☑ Neck lace
- ☑ Support CD
- ☑ Quick Start Guide



Note: Unless otherwise specified, the term “device” in this User Guide refers to the ASUS USB Wireless LAN Adapter.




Features

USB 2.0, OFDM, DSSS, Supports Infrastructure and Ad-hoc networks, Compatible with IEEE 802.11b and 802.11g devices, USB bus-powered, Software support

LED indicators

The device comes with a Power, Activity, and Link LED indicators. Refer to the table below for LED indications.




LED	Status	Indication
ACT	Blinking	The adapter is transmitting or receiving data packets.
	OFF	There is no wireless data activity.
PWR	ON	The adapter is receiving power from the USB port.
	OFF	The adapter is not receiving power from the USB port.

Network setup

The ASUS USB Wireless LAN Adapter may be used in both Ad-hoc and Infrastructure network types. The following sections describe the device functions in these network types.


Ad-hoc network

In an Ad-hoc network type, the device connects to another wireless LAN adapter in a wireless network. No access point (AP) is present in this wireless environment.



Infrastructure network

In an Infrastructure network, the wireless network is centered on an access point (AP) that provides a central link for wireless clients to communicate with each other or with a wired network.



System requirements

Before installing the ASUS USB Wireless LAN Adapter, make sure that your system meets the following requirements:

- Intel® Pentium® 4 or AMD K7/K8 **system**
- Minimum 64MB system memory
- Windows® 98SE/ME/2000/XP operating system
- Optical drive (for software installation)
- An available USB port (USB 2.0 recommended because USB 1.1 cannot achieve maximum wireless performance)

Installation procedures

Follow these instructions to install the ASUS USB Wireless LAN Adapter on your computer.

1. Install the device drivers and utilities from the support CD.
2. Connect the device to your computer.



NOTE: You must install the ASUS USB Wireless LAN Adapter drivers and utilities before connecting the device to your computer.

Installing drivers and utilities

To install the device driver and utilities on your computer:

1. Insert the support CD to the optical drive.
2. Click “**Install ASUS WLAN Utilities/Driver**” when the ASUS Wireless LAN installation window appears.
3. The device drivers and utilities are copied on your computer.






NOTE: If Autorun is NOT enabled in your computer, browse the contents of the support CD and double click the Setup.exe file to run the CD.

Installing the ASUS USB Wireless LAN Adapter

To install the ASUS USB Wireless LAN Adapter in your computer:


1. Insert to any USB port.

- Notebook PC: Insert into any USB port using the correct orientation.
- Desktop PC: A USB 2.0 extension cable is provided.



USB Universal Joint

A USB universal joint is provided to allow orientation of the USB Wireless LAN adapter for better signal strength or for convenient placement issues.



Chapter 2 - Installation

Installation procedures (Cont.)

2. Follow the installation wizard

When “Found New Hardware” dialog box appears, select “Install... automatically” and follow the instructions.



Windows® 2000 users - A Digital Signature Not Found dialog box may appear. Click Yes to proceed.



Windows® XP users - A Windows Logo Testing Not Found dialog box may appear. Click Continue Anyway to proceed.

3. Configure the ASUS USB Wireless LAN Adapter

After completing installation, configure the ASUS USB Wireless LAN Adapter using **ASUS Wireless Settings**.

Support software overview

Control Center

The Control Center utility is a management software that launches applications and configures network settings. The Control Center starts automatically when the system boots and displays the Control Center icon in the Windows® taskbar. The Control Center icon serves as an application launcher, and indicator of signal quality and



Control Center right-click menu

Right-clicking the Control Center icon displays the right-click menu. The following sections describe the right-click menu utilities.



One Touch Wizard (new wireless LAN)

Use the One Touch Wizard to setup your wireless connection.




1. Select **Create a new...** and click **Next** to use the simplest configuration or select another option first.



2. Enter the SSID name of the access point that you wish to connect to. Select **Data encryption** if secured connections are enabled.



3. Setup is complete. Click **Finish** to exit the wizard or click **Next** to continue with more advanced features.



4. Click **OK** to start ICSS setup.



5. Select your Internet connection from the list.



6. Setup is complete. You can review your settings here.

Chapter 2 - Installation

One Touch Wizard (existing LAN)

Use the One Touch Wizard to setup your wireless connection.



1. Select **Connect to...** and click **Next** to use the simplest configuration or select another option first.

2. Select an AP from the available networks.



3. Click **Next** to continue.

4. Setup is complete. Click **Finish** to exit the wizard.

Configuring the Wireless LAN utility

After installing the Wireless LAN Utilities, you will need to make some settings before being able to use your wireless connection.

Double-click the Wireless LAN Control Center icon to start the utility.




ASUS WLAN Control Center



1. Right-click the Wireless LAN icon and select "Wireless Settings"



2. Set the Network Name (SSID) to the same name as the SSID set in your wireless access point.



3. Use "Site Survey" if you don't know the name of your access point(s).



4. Encryption settings must also match those set in the access point. Ask your network administrator about settings if necessary. Click **Apply** to save your settings



5. Check the "Status" page to see the "Association State". It should show "Connected - xx:xx:xx:xx:xx:xx".



6. You can also see the connection quality on the "Connection" page. Click **OK** to exit the utility.

Soft AP (Windows XP Only)

Soft AP mode allows the Wireless LAN card to act as a virtual access point. The computer needs to be connected to a wired network using an Ethernet connection in order to provide network access to Wireless LAN clients.




1. Select Soft AP Mode



2. Drag and drop a wired network connection next to the globe icon.



3. Enable ICS* and Firewall if desired. Refer to Windows help for information on "Internet Connection Sharing".



4. You can easily switch between Soft AP and Station mode by right clicking the taskbar icon and selecting "A-S Change Mode".

*ICS is used to share this computer's Internet connection with the rest of the computers on your network. When this computer is connected to the Internet, communication to and from the Internet to all the computers on your network are sent through this computer, called the host computer. Other computers can send and receive email and access the Web as if it were connected directly to the Internet.

Soft AP (Windows XP Only) Cont.

Soft AP mode allows for Access Control configuration.

Access Control

The AP provides facilities to limit the wireless clients that associate with it and the data packets that can forward through it. Filters provide network security or improve performance by eliminating broadcast/multicast packets from the radio network.

The Access Control List (ACL) contains MAC addresses for wireless clients allowed to associate with the AP. This provides security by preventing unauthorized access. The AP also uses a disallowed address list of destinations.

This feature prevents the AP from communicating with specified destinations. This can include network devices that do not require communication with the AP or its wireless clients.



Status Page



Encryption Page



Clicking **Apply** after configuring Soft AP will show the "Access Control" tab.



Enter a MAC Address on the Access Control page and select "Accept" or "Reject" or "Disable" from the pull-down menu.

Chapter 2 - Installation

Soft AP (Windows XP Only) Cont.



Soft AP Mode will also provide two extra tabs on the Status pages - Association Table and Event Log. The Association Table shows clients that are currently connected to the Soft AP.



The Event Log tracks messages associated with the Soft AP.



IMPORTANT: If the end points of a chain are connected to each other a loop is created. Normally it is advised to avoid loops involving bridges as it can lead to performance breakdowns, and broadcast and multicast storms.

3. Software Reference

Control Center

The Control Center utility is a management software that launches applications and configures network settings. The Control Center starts automatically when the system boots and displays the Control Center icon in the Windows® taskbar. The Control Center icon serves as an application launcher, and indicator of signal quality and Internet connection.



Control Center icons

The Control Center icon indicates the quality of link to the access point and connection to the Internet. Refer to the table below for icon indications.

Infrastructure network (wireless LAN adapter to an access point)

	Excellent link quality and connected to the Internet		Excellent link quality but not connected to the Internet
	Good link quality and connected to the Internet		Good link quality but not connected to the Internet
	Fair link quality and connected to the Internet		Fair link quality but not connected to the Internet
	Poor link quality but connected to the Internet		Poor link quality and not connected to the Internet
	Not linked but connected to the Internet		Not linked and not connected to the Internet

Ad-hoc network (wireless LAN adapter to other Wi-Fi device)

	Linked
	Not Linked
	Connected to the Internet

Control Center right-click menu

Right-clicking the Control Center icon displays the softwares and utilities the ASUS USB Wireless LAN Adapter supports. Refer to the succeeding sections for details on these utilities and softwares.



Control Center left-click menu

Left-clicking the Control Center icon displays the left-click menu.



Search & Connect – View available wireless networks within range.


Wireless Option – Sets your Windows® XP wireless networking environment. The **Wireless Option** window appears when you select this option. Select “**Only use ASUS utilities and disable XP wireless function**” to avail all ASUS USB wireless LAN adapter features. Click **OK**.



Wireless Settings

The Wireless Settings is the main interface that allows you to control the ASUS wireless LAN adapter. Use the Wireless Settings to view the operational and connection status, or to modify the wireless LAN adapter configuration.

The Wireless Settings window is composed of the property window and tabbed property sheets. Click the icons in the property window to display their tabbed property sheets.



Tabbed property sheets

Property window



Status

Status tab

The Status tab provides general information on the wireless LAN adapter.

Association State. This field displays the connection status and MAC address of the network **where the system is connected.**

Service Set Identifier (SSID). This field displays the SSID of the network to which the card is associated or is intending to join. The **SSID** is a group name shared by every member of a wireless network. Only client PCs with the same SSID are allowed to establish a connection.

The **MAC Address** field displays the hardware address of a device connected to a network.

The **Current Channel** field displays the radio channel that the card is currently tuned. The channel changes as wireless LAN adapter scans the available channels.



Chapter 3 - Reference


Rescan button - Click to allow wireless LAN adapter to scan available wireless networks and to connect to the network with the best signal quality.

Change SSID button - Click to change the SSID. Clicking this button opens the Config-Basic window. See “Basic tab” on page 3-7.

Search and Connect button - Click to view all wireless networks within the range of your system. Clicking this button opens the Site Survey window. See page 3-9.

Connection tab

The Connection tab provides real-time information on connection throughput, frame errors, signal strength, link quality and overall connection quality in graphical representation.



IP Config tab

The IP Config tab displays the current host and Ethernet adapter configurations. IP Config displays TCP/IP information including the IP address, subnet mask, default gateway, DNS and Windows Internet Naming Service (WINS) configurations.

Use the IP Config Tab to verify your network settings.



IP Release. Click to release the DHCP IP address for the wireless LAN adapter.

IP Renew. Click to renew the DHCP IP address for the wireless LAN adapter.

Ping. Click to display the Ping tab. Use ping to verify a connection to a **particular host name** or IP address.



Note: The IP Release and IP Renew buttons may only be used on a DHCP-configured wireless LAN adapter.

Ping tab

The Ping tab allows you to verify the connection of your computer with another computer in a network. To ping a connection:

1. Type the IP address of the connection you want to verify in the **IP Address** field.
2. Configure the ping session by assigning the size and count of packet to send, and the time limit for a ping session to continue (in milliseconds).
3. Click the **Ping** button.

During the ping session, the **Ping** button toggles into a **Stop** button. Click **Stop** anytime to cancel the ping session.

The session field displays information on the verified connection including the roundtrip time (minimum, maximum, and average) and packets sent, received, and lost after a ping session.

Click the **Clear** button to clear the session field.



Configuration

Basic tab

The **Basic** tab provides general information on network types and other configurations.

Network Type. Select the type of network that you wish to use. Select *Infrastructure* mode to establish a connection with an access point (AP). In this mode, your system can access wireless LAN and wired LAN (Ethernet) via the AP. Select the *Ad Hoc* mode to communicate directly with other mobile clients within the wireless LAN adapter range.



Network Name - Displays the network SSID. The network SSID is a string use to identify a wireless LAN. Assign different SSIDs to segment the wireless LAN and increase network security. Set the SSID to a null string to allow your station to connect to any available access point. Null string may not be used in Ad-hoc mode.

Channel. In Infrastructure mode, wireless LAN adapter automatically tunes in to the access point channel. In Ad-hoc mode, select a channel that is allowed for use in your country/region.

Data Rate. Sets the data transmission rate to Fix or Auto. Select *Fully Auto* to allow the device to adjust to the most suitable connection. You may also fix data transfer rates to 54, 48, 36, 24, 18, 12, 11, 9, 6, 5.5, 2 and 1 Mbps.



Note: Operating the device at very high data rates reduces the operating range. When the “Data Rate” is changed, the adapter will survey available APs and connect to the AP with the strongest signal.

Others. Click the *WEP* or *Advanced* link to open the Encryption or Advanced property tab sheet.


Encryption tab

Wireless data transmissions between your wireless LAN adapter and the AP are secured using the Wired Equivalent Privacy (WEP) encryption. Check the *Data encryption (WEP enabled)* option to assign the WEP keys.

Check the *Network Authentication (Shared Mode)* option if you wish to use a network key to authenticate a preferred wireless network. Unchecking this option allows the network to operate on an Open System mode.

Key Format allows you to set a hexadecimal digit or ASCII character WEP key.

Key Length allows you to choose a 64-bit or a 128-bit WEP key. A 64-bit encryption contains 10 hexadecimal digits or 5 ASCII characters. A 128-bit encryption contains 26 hexadecimal digits or 13 ASCII characters.



Note: All wireless clients in a network must have identical WEP keys to communicate with each other or with an access point.

Two ways to assign WEP keys

Manual Assignment. For a 64-bit encryption, enter 10 hexadecimal digits (0~9, a~f, A~F) or 5 ASCII characters in each of the four WEP keys. For 128-bit encryption enter 26 hexadecimal digits (0~9, a~f, A~F) or 13 ASCII characters in each of the four WEP keys.

Automatic Generation. Type a combination of up to 64 letters, numbers, or symbols in the Passphrase field. The Wireless Settings utility uses an algorithm to generate four WEP keys based on the typed combination.




Note: 64-bit and 40-bit WEP keys use the same encryption method and can interoperate on wireless networks. This lower level of WEP encryption uses a 40-bit (10 hexadecimal digits assigned by the user) secret key and a 24-bit Initialization Vector assigned by the wireless LAN adapter. 104-bit and 128-bit WEP keys use the same encryption method.

Chapter 3 - Reference

 **Note:** After assigning the WEP keys, click **APPLY** to save and activate the encryption. Manually assigned encryptions are more secure than automatically generated encryptions.

 **Note:** Use **Manual Assignment** instead of **Automatic Generation** if you are not sure whether other wireless clients use the same algorithm as that of wireless LAN adapter.

 **Note:** Keep a record of the WEP encryption keys.

Site Survey

The **Site Survey** window displays the available networks within the wireless LAN adapter range and the following network settings.

SSID - SSID (service set identifier) of the network.


CH - Direct sequence channel used by the network.

RSSI - Received Signal Strength Indicator (RSSI) in dBm.

Security - shows whether a network has an enabled (On) or disabled (Off) the security encryption.

BSSID - The IEEE MAC address of the available wireless networks.

Select an available network and click **Connect** to establish connection. Click **Search** to rescan available networks.



About Wireless Settings

Click the **About** icon to view the software version, driver version, and copyright information.



Link State

Displays the current connection status of the wireless LAN adapter to the AP or to other Wi-Fi devices. An icons represents the Link State for easy identification. Refer to the table below for icon indications.

Table of Icon Indications

	Excellent link quality (Infrastructure)		Not linked (Infrastructure)
	Good link quality (Infrastructure)		Linked (Ad-hoc)
	Fair link quality (Infrastructure)		Not linked (Ad-hoc)
	Poor link quality (Infrastructure)		Scanning

Chapter 3 - Reference

Command icons

Apply. Click to apply the changes made on the Wireless Settings utility.

OK. Click to close the Wireless Settings utility window.

Cancel. Click to cancel any changes made on the Wireless Settings utility. Clicking **Cancel** closes the Wireless Settings utility window.

Help. Click to display the help menu.



Other right-click options


Activate Configuration - This option allows you to select the wireless profile to use.

Mobile Manager - Click this button to launch the Mobile Manager utility. See section 3.2 “Mobile Manager” for details.

Site Monitor - Click this button to launch the Site Monitor utility. See section 3.3 “Site Monitor” for details.

Help Menu - The Control Center utility has a Help menu to guide you in using the Control Center and Wireless Settings utilities. Right-click the Control Center icon, then select **Help**. Select a utility to display the help window.

Preferences - The **Preferences** window allows you to customize the Control Center Utility settings.



About Control Center

Select the **About Control Center** option to display the Control Center software version and copyright information.




Mobile Manager

The Mobile Manager is a convenient tool to setup and manage network location settings. This utility allows users to configure multiple alternative configurations for different locations. You need to set up this utility once so you can easily switch configurations when you change your location.

To launch the Mobile Manager utility:

1. Click the Windows® **Start** button. Select **Programs > ASUS Utility > WLAN Card > Mobile Manager**, or right-click the **Control Center** icon on the Windows® taskbar, then select **Mobile Manager**.
2. The Mobile Manager main window appears.





You may use the Mobile Manager utility main window to create, edit, or activate a configuration. The main window displays the menu bar, tool bar, and existing configurations.


The toolbar buttons allow quick access to some common commands in the Mobile Manager utility. All toolbar button commands are also available from the menu bar.


Chapter 3 - Reference

File menu


New Configuration  – Select this option to launch the New Configuration Wizard. See the next section for details.


Import Configuration  – Select this option to load a configuration from an INI File.

Export Configuration  – Save the selected configuration (containing Wireless Settings, TCP/IP Settings, Network Settings, etc.) to an INI file. The INI file may be saved on a floppy disk, and may be imported by other computers with the Mobile Manager utility. You may also use this file as backup.

Exit  – Select to close the Mobile Manager utility.

Mobilize menu


Auto Roaming  – Activating this option allows the ASUS USB Wireless LAN Adapter to switch to another association you have specified when changes to an existing association occurred. If no associations are made, Auto Roaming automatically connects to a wireless network based on your specified configurations.

Activate Configuration  – Applies the configuration you selected from the list. Follow the screens instructions to activate a configuration.





Note: Activating a configuration requires system restart when you are using Windows® 98/ME OS. Windows® 2000/XP OS does not require system restart after you activate a configuration.


Edit menu

Edit Configuration  – The Edit Configuration option allows you to edit selected configuration items. See the “Editing a Configuration” section on page 3-19 for details.

Rename  – Changes the name of the selected configuration.

Copy  – Duplicates the selected configuration.

Delete  – Discards the selected configuration.

Up  – Raises the position of a selected wireless network configuration in the preferred network list.

Down – Lowers the position of the selected wireless network configuration in the preferred network list.





Note: Edit menu commands appear when you right-click a configuration in the Mobile Manager window.

View menu

Large Icons  – Displays large icons for each configuration.

Small Icons  – Displays small icons for each configuration.

List  – Shows a list of available configurations.

Details  – Displays the name, type, and description of a selected configuration.

Help menu

Contents  – Displays the WinHelp window for online help.

About Mobile Manager  – Displays the Mobile Manager version number and copyright information. Click on the ASUS logo to open the ASUS website.

Creating a new configuration

To create a new configuration:


1. Launch the New Configuration Wizard by clicking **File** from the menu bar, then select **New Configuration** from the drop-down menu, or double-clicking the **New Configuration**  icon on the Mobile Manager toolbar. The New Configuration Wizard dialog box appears.

Chapter 3 - Reference


2. Choose the type of configuration you want to create. The configuration types are described below. Click **Next** when done.
- **ASUS Wireless Local Area Network Configuration.** Select this option if you have an installed ASUS USB Wireless LAN Adapter in your computer.
 - **Wired Local Area Network Configuration.** Select this if your computer has an installed network interface card other than ASUS USB Wireless LAN Adapter.
 - **Dialup Networking Configuration.** Select this option if your computer has an installed modem.



3. Enter the name and description of the configuration you wish to create, then click **Next**.



4. Configure the wireless settings including the network type, SSID, channel and WEP encryption. Click **Next** when done.



- Set the IP address of the configuration using this window. Specify the IP address using the DHCP server (automatic) or manual assignment. The wizard auto-detects and displays the current system settings. Click **Next** when done.




- Enter the computer name, then click **Next**.



- Use this window to set the proxy server and printer sharing. Click **Advanced** to display the proxy server and printer sharing options. Click **Next** when finished.



- Check the **Activate Configuration Now** option to start using the created configuration. The Mobile Manager window displays the created configuration when it is not activated. Click **Finish** to close the wizard.



Editing a configuration

To edit a configuration:

1. Select a configuration from the Mobile Manager window.
2. Click **Edit** from the menu bar, then select **Edit Configuration**.

The **Edit Configuration** dialog box appears. Navigate through the windows by clicking the buttons on the left.



General settings

Name – The configuration name indicates the location from where you are dialing or connecting to a network. For example, name your configuration “Work-Meeting Room” if you are using this connection at your workplace meeting room.

Description – Enter additional details of the configuration in this field. This field is optional.

Network settings -Wireless tab

Priority of Preferred Network – This field allows you to select the priority of the preferred network.

Network Type

Infrastructure – Select the Infrastructure mode to establish connection to an access point.

Ad-hoc – Select the Ad-hoc mode to communicate directly with other Wireless LAN devices without using an access point.



SSID – SSID stands for Service Set Identifier, a string used to identify a wireless LAN. You can only connect with an Access Point, that has the same SSID. Use different SSIDs to segment the wireless LAN and add security.

Channel – The Channel field allow you to select the radio channel for the ASUS USB Wireless LAN Adapter. In an Infrastructure network, your wireless LAN adapter automatically selects the correct frequency channel required to communicate with an Access Point.

WEP – This option allows you to disable or enable (64-bit or 128-bit) WEP encryption. The WEP Key is a 64-bit (5 byte) or 128-bit (13 byte) hexadecimal digit use to encrypt transmitted data packets and decrypt received data packets.

Network settings -Identification tab

Computer name – Assign your computer a unique name of up to 15 characters. The computer name allows other users in a network to recognize your computer. The computer name is generally the same with the DNS hostname.



Note: Avoid using spaces or symbols in your computer name.

TCP/IP settings-Device tab

Select the network adapter you want to use for this configuration.



Note: This item appears only when you are editing a wired LAN configuration.



TCP/IP settings-IP Address tab

Obtain an IP address from a DHCP server – The Dynamic Host Configuration Protocol (DHCP) server assigns IP addresses automatically within a specified range of devices.

Chapter 3 - Reference

Specify an IP address – Ask your network administrator for the IP address and subnet mask you should use. Type in the IP Address and Subnet Mask manually.

TCP/IP settings-Gateway tab

Specify the gateways. You may specify more than one gateway. Set up the primary gateway first.

Add – Click this button to add a new TCP/IP gateway address. The added gateway appears in the **Default gateways** list. Repeat the process to add another gateway. The value in each gateway field must be between 0 and 255. You can have up to eight IP addresses for gateways.

Edit – Click this button to edit a selected gateway address.

Remove – Click this button to delete a selected gateway address.

TCP/IP settings-DNS tab

The DNS tab allows you to configure the DNS settings of the selected configuration. This tab also allows you to add a DNS server and arrange them in order of their use. You may also assign a DNS suffix for a specified DNS server.

TCP/IP settings-WINS tab

The WINS tab allows you to configure the WINS settings of the selected configuration. This tab allows you to add WINS addresses and arrange them in order of their use. This tab also allows you to enable or import LMHOST lookup and adjust the NetBIOS settings.

Internet settings

A proxy server acts as a security barrier between your internal network (Intranet) and the Internet. A proxy server restricts other people on the Internet from gaining access to confidential information on your internal network or your computer.

Disable Proxy Server – Allows you to disable the proxy server.



Enable Proxy Server – Use the Proxy server to access the Internet.

Use the same proxy server for all protocols – Specifies whether you want to use the same proxy server to gain access to the Internet using all protocols.

Servers field – Provides fields for you to type the address and port number of the proxy server you want to use to gain access to the Internet over HTTP, Secure, FTP, Gopher, and Socks protocol.

Exceptions field

Do not use proxy server for address beginning with – Type the Web addresses that do not need to be accessed through the proxy server. If you want to connect to a computer on your Intranet, make sure you type its address in this box. You may use wild cards to match domain and host names or addresses, for example, “*.company.com”, “192.72.111.*”.

Bypass proxy server for local addresses – This option allows you to use the proxy server for all local (Intranet) addresses.



Note: You may gain access to local addresses easier and faster if you do not use the proxy server.

Sharing settings

I want to set the default printer– Allows you to select the default printer for printer sharing.

Default printer – Allows you to select the default printer from a list of installed printers.

Click **New** to add a new printer using the Windows® Add Printer Wizard.

Click **Properties** to display the properties of a selected printer.



Command buttons

Use these buttons to activate, save, or cancel changes made in the configuration. Click **Close** to close the Edit Configuration window. Click **Help** to view the help files.


Site Monitor

The Site Monitor utility measures the signal-to-noise (SNR) values of all available wireless networks. Use this utility to determine the best placement of access points in a wireless network.

Launching Site Monitor

To launch the Site Monitor:


- Click the Windows® **Start** button, then select **Programs > ASUS Utility > WLAN Card > Site Monitor**, or
- Right-click the **Control Center** icon on the Windows taskbar, then select **Site Monitor**.



The Site Monitor survey message appears. Click **OK**.

Site Monitor main window

The Site Monitor main window displays the available wireless connections and the signal-to-noise (SNR) value of a selected connection.




 **Note:** Some Access Points disable their SSID broadcasting to hide themselves from “Site Survey” or “Site Monitor”. You may join these APs if you know their SSID.

Monitoring a connection

To monitor a connection:

1. Select the connection from the list.
2. Click Command from the menu bar, then select monitor. You may also press <Ctrl> <M> in your keyboard.

The Monitor window appears.



The following connection parameters are displayed in graphical representation.

SNR. This indicates the quality of communications within the current network. The communication quality is based on signal level and noise level measurements. The higher the SNR, the better the connection quality.

Communication Quality. This indicates the communication quality of the Basic Service Set to which the station is connected.

Signal Level. This line specifies the average signal level of the Basic Service Set to which the station is connected.

Noise Level. Specifies the average noise level of the Frequency Channel currently used for connection.

Throughput. The Throughput graph sends a specified number of data packets to the remote host and calculates the average transmission rate in megabytes per second.

Troubleshooting

This troubleshooting guide provides answers to some common problems which you may encounter while installing and/or using ASUS Wireless LAN card products. These problems requires simple troubleshooting that you can perform by yourself. Contact the Wireless LAN Technical Support if you encounter problems not mentioned in this section.

My computer does not recognize the installed ASUS USB Wireless LAN Adapter.

Verify if the ASUS USB Wireless LAN Adapter drivers are properly installed by following these instructions:

1. Open the Control Panel window from the Windows® desktop.
2. Double-click on the **System** icon.
3. *Windows® 98SE/Me users:* Select the **Device Manager** tab.
Windows® 2000/XP users: Select the **Hardware** tab then click the **Device Manager** button.
4. Click the “+” symbol preceeding the **Network Adapters** item, then check the **ASUS 802.11 Network Adapter** item.

A yellow exclamation point or a red plus sign preceeding the network adapter means that the device driver is not properly installed. Re-install the device driver following the instructions below.

A yellow exclamation point or a red plus sign appears on the ASUS 802.11b Network Adapter or ASUS 802.11g Network Adapter item.

The device driver is not properly installed. Follow these instructions to uninstall and re-install the driver.

1. Insert the Support CD into the CD-ROM drive.
2. When the ASUS Wireless LAN installation window appears, click “**Uninstall ASUS WLAN Utilities/Driver**” option.
3. Restart your computer and repeat the software installation following the instructions contained in this documentation.

Troubleshooting (Cont.)

I cannot connect to an Access Point.

- Check if the **Network Type** of the device is set to **Infrastructure** mode.
- Check if the device has the same **Service Set Identifier (SSID)** as that of the AP.
- Check if the device and the AP have the same **Encryption**. If WEP encryption is enabled, set the same WEP keys for the device and the AP.
- Check if the MAC address of the device is added in the AP Authorization Table. Inquire this with your LAN administrator.
- There is poor signal reception. Shorten the distance between the device and the access point.

I can connect to an Access Point but I cannot connect to the Internet.

- Check if the device and the AP have the same **Encryption**. If WEP encryption is enabled, set the same WEP keys for the device and the AP.
- Make sure the network protocol parameters (IP address, subnet mask, gateway, and DNS) of your computer are correctly set.
- Check the proxy settings of the web browser.

I cannot connect to another station with a wireless LAN device.

- Check if the **Network Type** of the device is set to **Ad-hoc** mode.
- Check if the device has the same **Service Set Identifier (SSID)** with that of the other station.
- There is poor signal reception. Shorten the distance between the device and the station.
- Check if the device and the other station have the same **Encryption**. If WEP encryption is enabled, set the same WEP keys for the device and the AP.

I cannot connect to other computers linked via an Access Point or Ad-hoc network.

- Check if the device and the other APs and/or clients have the same **Encryption**. If you enable WEP encryption, you must set the same WEP keys for the device and the other AP/s and/or clients.
- Check the TCP/IP settings (IP address, subnet mask, gateway, and DNS) of your computer.
- Enable file and printer sharing in each client computer to allow file sharing.

Troubleshooting (Cont.)

I always have poor link quality and low signal.

Do the following to achieve better link quality and stronger signal:

- Keep the device away from microwave ovens and large metal objects to avoid radio interference.
 - Shorten the distance between the device and the AP/station.
-

Why do I get the warning “Hi-Speed USB Device Plugged Into Non-Hi-Speed USB Hub” message when I connected the ASUS USB Wireless LAN Adapter to the USB port?

This warning message appears when you plug the ASUS USB Wireless LAN Adapter to a USB 1.1 port.

- For Windows® XP users, you need to upgrade your OS to Service Pack 1 to convert your USB ports to USB 2.0.
 - For Windows® 2000 users, you must install Service Pack 4 in order to convert your USB ports into USB 2.0. You can download these service packs from the Windows Update website (windowsupdate.microsoft.com)
-

When I remove the wireless adapter from my computer running Windows 98SE, my system becomes very slow and stops responding.

- This is a limitation with computers equipped with Intel/NVIDIA USB 2.0 controller and running the newest OrangeWare USB 2.0 driver.
-

Notices

Federal Communications Commission

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Reprinted from the Code of Federal Regulations #47, part 15.193, 1993. Washington DC: Office of the Federal Register, National Archives and Records Administration, U.S. Government Printing Office.

Safety statements

Regulatory Information/Disclaimers

Installation and use of this Wireless LAN device must be in strict accordance with the instructions included in the user documentation provided with the product. Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. The manufacturer is not responsible for any radio or television interference caused by unauthorized modification of this device, or the substitution of the connecting cables and equipment other than manufacturer specified. It is the responsibility of the user to correct any interference caused by such unauthorized modification, substitution or attachment. Manufacturer and its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failing to comply with these guidelines.



CAUTION! To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance [20cm] between the radiator and your body. Use on the supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.

Safety Information

In order to maintain compliance with the FCC RF exposure guidelines, this equipment should be installed and operated with minimum distance [20cm] between the radiator and your body. Use only with supplied antenna.

Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.



CAUTION! Any changes or modifications not expressly approved in this manual could void your authorization to use this device.

MPE Statement

Your device contains a low power transmitter. When device is transmitted it sends out Radio Frequency (RF) signal.

Safety statements

FCC Radio Frequency Exposure

This Wireless LAN radio device has been evaluated under FCC Bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 Sections 2.1091, 2.1093, and 15.247(b)(4) addressing RF Exposure from radio frequency devices. The radiation output power of this Wireless LAN device is far below the FCC radio frequency exposure limits. Nevertheless, this device shall be used in such a manner that the potential for human contact during normal operation – as a mobile or portable device but use in a body-worn way is strictly prohibit. When using this device, a certain separation distance between antenna and nearby persons has to be kept to ensure RF exposure compliance. In order to comply with the RF exposure limits established in the ANSI C95.1 standards, the distance between the antennas and the user should not be less than [20cm].

RF Exposure

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

DGT 警語

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Declaration of Conformity

We, the under signed,

Company	ASUSTeK Computer Inc.
Address, City	4Fl., No.150, Li-Te Rd., Peitou, Taipei,
Country	Taiwan 112
Phone number	886-2-28943447
Fax number	886-2-28950113
E-mail	lawrence_yu@asus.com.tw

certify and declare under our sole responsibility that the following equipment:

Product Description / Supplementary Info	ASUS USB WLAN Adapter
Manufacturer	ASUSTeK COMPUTER INC.
Brand	ASUS; SAGEM
Type	WL-167g

is tested to and conforms with the essential radio test suites included in the following standards:

Standard	Issue date
ETSI EN 300 328-2	V1.2.1 Dec. 2001
ETSI EN 301 489-1/17	V1.4.1 Aug. 2002 / V1.2.1 Apr. 2002
EN 60950	2000

and therefore complies with the essential requirements and provisions of the **R&TTE directive 1999/5/EC** of the European Parliament and of the council of 9 March 1999 on radio equipment and Telecommunications Terminal Equipment and the mutual recognition of their conformity and the requirements of Annex III (conformity Assessment procedure referred to in article 10(4)).

The technical documentation as required by the Conformity Assessment procedure is kept at the following address:

Company	ASUSTeK Computer Inc.
Address, City	4Fl., No.150, Li-Te Rd., Peitou, Taipei,
Country	Taiwan 112
Phone number	886-2-28943447
Fax number	886-2-28950113
E-mail	lawrence_yu@asus.com.tw



Draw up in	Taiwan
Date	2004/08/13
	ASUSTek Computer Inc. 4/F, 150, Li-Te Rd., Peitou, Taipei, Taiwan 112
Signature & company stamp	Lawrence Yu / Manager