



## Setup ASUS Speaker Express for Windows Media Player 9.0

1. Update Windows Media Player 9.0 (version least above 9.0)
2. Double click “Asus Speaker Express.exe”




3. Press “Next”




4. Press “Finish” and then ASUS Speaker Express is installed.
5. Open Windows Media Player


6. When Windows Media Player displays a **smile icon**, it represents that ASUS Speaker Express Manager Plug-in is loaded successfully.



7. If not display, clicking the name of **ASUS Speaker Express Manager** from the Plug-ins tab of Tools menu.



8. You can play music. When starting to play music, plug-in tries to connect to Remote speaker and Windows Media Player display a **state icon** in the lower left.




Note:

 : "Device not Found/Connect Failed"


 : "Connect Success"

## Setup ASUS Speaker Express for Windows Media Player 10.0

1. Update Windows Media Player 10.0
2. Double click “ASUS Speaker Express.exe”




3. Press “Next”




4. Press “Finish” and then ASUS Speaker Express is installed.
5. Open Windows Media Player


6. If the names of **ASUS Speaker Express Manager** and **ASUS Speaker Express Transmitter** from the Plug-ins tab of Tools menu have been enabled, ASUS Speaker Express Manager Plug-in is loaded successfully.



7. If the name of **ASUS Speaker Express Manager** from the Plug-ins tab of Tools menu is not enabled, clicking the name of **ASUS Speaker Express Manager** from the Plug-ins tab of Tools menu.



8. You can play music. When starting to play music, plug-in tries to connect to Remote speaker and Windows Media Player display a **state icon** in the lower left.




Note:

 : "Device not Found/Connect Failed"


 : "Connect Success"

## ASUS Speaker Express Manager Property Page for Windows Media Player 9.0

1. Click **smile icon** on Windows Media Player, then options dialog box is opened.



2. Select the name of **ASUS Speaker Express Manager** from Plug-ins tab and then click **Properties**.



3. Properties display versions and states information. The version information includes the versions of manager plug-in, transmitter plug-in, and remote waveserver. You can set Local/Remote speaker that change the behaviors of WL-Speaker.




State information:


- I. Waiting for playing!!
- II. Device not found!!
- III. Connect Success/Failed and IP of remote device
- IV. Incompatible USB Speaker!!
- V. Sample Size: A -> B  
It represents Resample size from A to B
- VI. Sample Rate: A -> B  
It represents Resample rate from A to B

## ASUS Speaker Express Manager Property Page for Windows Media Player10.0

1. Click **Option** dialog box from the Plug-ins tab of Tools menu.



2. Select the name of **ASUS Speaker Express Manager** from Plug-ins tab and then click **Properties**.



3. Properties display versions and states information. The version information includes the versions of manager plug-in, transmitter plug-in, and remote waveserver. You can set Local/Remote speaker that change the behaviors of WL-Speaker.



State information:

- I. Waiting for playing!!
- II. Device not found!!
- III. Connect Success/Failed and IP of remote device
- IV. Incompatible USB Speaker!!
- V. Sample Size: A -> B  
It represents Resample size from A to B
- VI. Sample Rate: A -> B  
It represents Resample rate from A to B