



ASUS Essentio Desktop PC

CM1730

User Manual



E6444

First Edition

March 2011

Copyright © 2011 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK Computer Inc. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Notices	5
Safety information.....	7
Conventions used in this guide.....	8
Where to find more information	8
Package contents	9

Chapter 1: Getting started

Welcome!.....	11
Getting to know your computer.....	11
Setting up your computer.....	15
Turning your computer ON/OFF	18

Chapter 2: Using Windows® 7

Starting for the first time.....	19
Using Windows® 7 desktop.....	20
Managing your files and folders.....	22
Restoring your system settings.....	24
Protecting your computer.....	25
Getting Windows® Help and Support.....	26

Chapter 3: Connecting devices to your computer

Connecting a USB storage device.....	27
Connecting microphone and speakers	28
Connecting multiple external displays	31
Connecting an HDTV.....	33

Chapter 4: Using your computer

Proper posture when using your Desktop PC.....	35
Using the memory card reader	36
Using the optical drive	37
Using the multimedia keyboard (on selected models only)	38

Chapter 5: Connecting to the Internet

Wired connection.....	43
Wireless connection (on selected models only).....	45

Contents

Chapter 6: Using the utilities

ASUS AI Manager.....	47
ASUS EPU-4 Engine	50
ASUS Update	54
ASUS MyLogo2™	55
Nero 9	56
Recovering your system	57

Chapter 7: Troubleshooting

Troubleshooting	59
ASUS contact information.....	66

Notices

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

Macrovision Corporation Product Notice

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only **unless otherwise authorized by Macrovision Corporation**. Reverse engineering or disassembly is prohibited.

Lithium-Ion Battery Warning

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for detail recycling information in different region.

Safety information



Disconnect the AC power and peripherals before cleaning. Wipe the Desktop PC using a clean cellulose sponge or chamois cloth dampened with solution of nonabrasive detergent and a few drops of warm water then remove any extra moisture with a dry cloth.

- **DO NOT** place on uneven or unstable work surfaces. Seek servicing if the casing has been damaged.
- **DO NOT** expose to dirty or dusty environments. **DO NOT** operate during a gas leak.
- **DO NOT** place or drop objects on top and do not shove any foreign objects into the Desktop PC.
- **DO NOT** expose to strong magnetic or electrical fields.
- **DO NOT** expose to or use near liquids, rain, or moisture. **DO NOT** use the modem during electrical storms.
- Battery safety warning: **DO NOT** throw the battery in fire. **DO NOT** short circuit the contacts. **DO NOT** disassemble the battery.
- Use this product in environments with ambient temperatures between 0°C (32°F) and 35°C (95°F).
- **DO NOT** cover the vents on the Desktop PC to prevent the system from getting overheated.
- **DO NOT** use damaged power cords, accessories, or other peripherals.
- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Conventions used in this guide

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Instructions that you **MUST** follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.










ASUS websites

The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS website www.asus.com.

ASUS Local Technical Support

Visit ASUS website at <http://support.asus.com/contact> for the contact information of local Technical Support Engineer.

Package contents

		
ASUS Essentio Desktop PC	Keyboard x1	Mouse x1
		
Power cord x1	Installation Guide x1	Warranty card x1
		
Nero 9 burning software DVD x1	Support DVD (optional) x1 Recovery DVD (optional) x1	Antenna (optional) x2



- If any of the above items is damaged or missing, contact your retailer.
- The illustrated items above are for reference only. Actual product specifications may vary with different models.

Chapter 1

Getting started

Welcome!

Thank you for purchasing the ASUS Essentio CM1730 Desktop PC!

The ASUS Essentio CM1730 Desktop PC provides cutting-edge performance, uncompromised reliability, and user-centric utilities. All these values are encapsulated in a stunningly futuristic and stylish system casing.




Read the ASUS Warranty Card before setting up your ASUS Desktop PC.

Getting to know your computer



Illustrations are for reference only. The ports and their locations, and the chassis color vary with different models.

Front panel




1. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
2. **Microphone port.** This port connects to a microphone.
3. **Headphone port.** This port connects to a headphone or speaker.
4. **Optical disk drive eject button.** Press this button to eject the optical disk drive tray.
5. **Secure Digital™ / MultiMediaCard slot.** Insert a Secure Digital™ / MultiMediaCard card into this slot.

Memory Stick™ / Memory Stick Pro™ card slot. Insert a Memory Stick™ / Memory Stick Pro™ card into this slot.

Extreme Digital card slot. Insert an Extreme Digital card into this slot.

6. **Power button.** Press this button to turn on your computer.
7. **Optical disk drive bay.** There is an optical disk drive in this bay.

Rear panel



1. **Voltage selector switch.** Switch to select the appropriate system input voltage.
2. **Power connector.** Plug the power cord to this connector.
3. **Air vents.** These vents allow air ventilation.




DO NOT block the air vents on the chassis. Always provide proper ventilation for your computer.

4. **PS/2 Keyboard / Mouse Combo port (purple).** This port is for a PS/2 keyboard.
5. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
6. **Optical S/PDIF_OUT port.** This port connects to an external audio output device via an optical S/PDIF cable.
7. **HDMI port.** This port is for a High-Definition Multimedia Interface (HDMI) connector, and is HDCP compliant allowing playback of HD DVD, Blu-ray, and other protected content.
8. **DVI-D port.** This port is for any DVI-D compatible device and is HDCP compliant allowing playback of HD DVD, Blu-ray, and other protected content.
9. **VGA port.** This port is for VGA-compatible devices such as a VGA monitor.
10. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
11. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
12. **LAN (RJ-45) port.** This port allows Gigabit connection to a Local Area Network (LAN) through a network hub.

LAN port LED indications

Activity/Link LED		Speed LED	
Status	Description	Status	Description
OFF	No link	OFF	10Mbps connection
ORANGE	Linked	ORANGE	100Mbps connection
BLINKING	Data activity	GREEN	1Gbps connection

ACT/LINK SPEED
LED LED



LAN port

13. **Rear Speaker Out port (black).** This port connects to the rear speakers in a 4, 6, and 8-channel audio configuration.
14. **Side Speaker Out port (gray).** This port connects to the side speakers in an 8-channel audio configuration.
15. **Microphone port (pink).** This port connects to a microphone.
16. **Line Out port (lime).** This port connects to a headphone or speaker. In a 4, 6, or 8-channel configuration, the function of this port becomes Front Speaker Out.
17. **Center/Subwoofer port (orange).** This port connects to the center/subwoofer speakers.
18. **Line In port (light blue).** This port connects to a tape, CD, DVD player, or other audio sources.



Refer to the audio configuration table below for the function of the audio ports in a 2, 4, 6, or 8-channel configuration.

Audio 2, 4, 6, or 8-channel configuration

Port	Headset 2-channel	4-channel	6-channel	8-channel
Light Blue	Line In	Line In	Line In	Line In
Lime	Line Out	Front Speaker Out	Front Speaker Out	Front Speaker Out
Pink	Mic In	Mic In	Mic In	Mic In
Orange	—	—	Center/Subwoofer	Center/Subwoofer
Black	—	Rear Speaker Out	Rear Speaker Out	Rear Speaker Out
Gray	—	—	—	Side Speaker Out

19. **ASUS WLAN Card (on selected models only).** This optional WLAN card allows your computer to connect to a wireless network.
20. **ASUS Graphics Card (on selected models only).** The display output ports on this optional ASUS Graphics Card may vary with different models.
21. **Expansion slot bracket.** Remove the expansion slot bracket when installing an expansion card.

Setting up your computer

This section guides you through connecting the main hardware devices, such as the external monitor, keyboard, mouse, and power cord, to your computer.

Connecting an external monitor

Using the ASUS Graphics Card (on selected models only)


Connect your monitor to the display output port on the discrete ASUS Graphics Card.

To connect an external monitor using the ASUS Graphics Card:

1. Connect a monitor to a display output port on the ASUS Graphics Card.
2. Plug the monitor to a power source.



The display output ports on the ASUS Graphics Card may vary with different models.



Using the onboard display output ports

Connect your monitor to the onboard display output port.

To connect an external monitor using the onboard display output ports:


1. Connect a VGA monitor to the VGA port, or a DVI-D monitor to the DVI-D port, or an HDMI monitor to the HDMI port on the rear panel of your computer.
2. Plug the monitor to a power source.



- If your computer comes with an ASUS Graphics Card, the graphics card is set as the primary display device in the BIOS. Hence, connect your monitor to a display output port on the graphics card.
- To connect multiple external monitors to your computer, refer to **Connecting multiple external monitors** in Chapter 3 of this user manual for details.


Connecting a USB keyboard and a USB mouse

Connect a USB keyboard and a USB mouse to the USB ports on the rear panel of your computer.



Connecting the power cord

Connect one end of the power cord to the power connector on the rear panel of your computer and the other end to a power source.




Turning your computer ON/OFF

This section describes how to turn on/off your computer after setting up your computer.

Turning your computer ON

To turn your computer ON:



1. Turn on the power switch.
2. Turn your monitor ON.
3. Press the power button on your computer.



4. Wait until the operating system loads automatically.

Turning your computer OFF

To turn your computer OFF:

1. Close all running applications.
2. Click  on the Windows® desktop.
3. Click  to shut down the operating system.

Chapter 2

Using Windows® 7

Starting for the first time

When you start your computer for the first time, a series of screens appear to guide you in configuring the basic settings of your Windows® 7 operating system.

To start for the first time:

1. Turn your computer on. Wait for a few minutes until the **Set Up Windows** screen appears.
2. From dropdown list, select your language, then click **Next**.
3. From the dropdown lists, select your **Country or region**, **Time and currency**, and **Keyboard layout**, then click **Next**.
4. Key in unique names for the **user name** and **computer name**, then click **Next**.
5. Key in the necessary information to set up your password, then click **Next**. You may also click **Next** to skip this step without entering any information.




If you want to set up a password for your account later, refer to the section **Setting up a user account and password** in this chapter.

6. Carefully read the license terms. Tick **I accept the license terms** and click **Next**.
7. Select **Use recommended settings** or **Install important updates only** to set up the security settings for your computer. To skip this step, select **Ask me later**.
8. Review your date and time settings. Click **Next**. The system loads the new settings and restarts. You may now start using your computer.

Using Windows® 7 desktop




Click the Start icon  > Help and Support to obtain more information about Windows® 7.

Using the Start menu

The Start menu gives you access to programs, utilities, and other useful items on your computer. It also provides you with more information about Windows 7 through its **Help and Support** feature.

Launching items from the Start menu

To launch items from the Start menu:

1. From the Windows® taskbar, click the Start icon .
2. From the Start menu, select the item that you want to launch.




You may pin programs that you want constantly displayed on the Start menu. For more details, refer to the section **Pinning programs on the Start menu or taskbar** on this chapter.

Using the Getting Started item

The **Getting Started** item on the Start menu contains information about some basic tasks such as personalizing Windows®, adding new users, and transferring files to help you to familiarize yourself with using Windows® 7.

To use the Getting Started item:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Select **Getting Started**. The list of available tasks appears.
3. Select the task that you want to do.

Using the taskbar

The taskbar allows you to launch and manage programs or items installed on your computer.

Launching a program from the taskbar

To launch a program from the taskbar:

- From the Windows® taskbar, click an icon to launch it. Click the icon again to hide the program.



You may pin programs that you want constantly displayed on the taskbar. For more details, refer to the section **Pinning programs on the Start menu or taskbar** on this chapter.

Pinning items on the jumplists

When you right-click an icon on the taskbar, a jumplist launches to provide you with quick-access to the program's or item's related links. You may pin items on the jumplist such as favorite websites, often-visited folders or drives, or recently played media files.

To pin items to the jumplist:

1. From the taskbar, right-click an icon.
2. From the jumplist, right-click the item that you want to pin, then select **Pin to this list**.


Unpinning items from the jumplist

To unpin items from the jumplist:

1. From the taskbar, right-click an icon.
2. From the jumplist, right-click the item that you want to remove from the jumplist, then select **Unpin from this list**.

Pinning programs on the Start menu or taskbar

To pin programs on the Start menu or taskbar:


1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Right-click the item that you want to pin on the Start menu or taskbar.
3. Select **Pin to Taskbar** or **Pin to Start menu**.



You may also right-click on the icon of a running program on the taskbar, then select **Pin this program to taskbar**.

Unpinning programs from the Start menu

To unpin programs from the Start menu:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. From the Start menu, right-click the program that you want to unpin, then select **Remove from this list**.




Unpinning programs from the taskbar

To unpin programs from the taskbar:

1. From the taskbar, right-click the program that you want to remove from the taskbar, then select **Unpin this program from taskbar**.

Using the notification area

By default, the notification area shows these three icons:

	Action Center notification Click this icon to display all the alert messages/notifications and launch the Windows® Action Center.
	Network connection This icon displays the connection status and signal strength of the wired or wireless network connection.
	Volume Click this icon to adjust the volume.

Displaying an alert notification

To display an alert notification:

- Click the Notification icon , then click the message to open it.




For more details, refer to the section **Using Windows® Action Center** in this chapter.

Customizing icons and notifications

You may choose to display or hide the icons and notifications on the taskbar or on the notification area.

To customize icons and notifications:

- From the notification area, click on the arrow icon .
- Click **Customize**.
- From the dropdown list, select the behaviors for the icons or items that you want to customize.


Managing your files and folders

Using Windows® Explorer

Windows® Explorer allows you to view, manage, and organize your files and folders.

Launching Windows® Explorer

To launch Windows Explorer:

- From the Windows® taskbar, click the Start icon  to launch the Start menu.
- Click **Computer** to launch Windows Explorer.


Exploring files and folders

To explore files and folders:

1. Launch Windows® Explorer.
2. From the navigation or view pane, browse for the location of your data.
3. From the breadcrumb bar, click the arrow to display the contents of the drive or folder.

Customizing the file/folder view

To customize the file/folder view:

1. Launch Windows Explorer.
2. From the navigation pane, select the location of your data.
3. From the toolbar, click the View icon .
4. From the View menu, move the slider to select how you want to view the file/folder.



You may also right-click anywhere on the View pane, click **View**, and select the view type that you want.

Arranging your files

To arrange your files:

1. Launch Windows Explorer.
2. From the **Arrange by** field, click to display the dropdown list.
3. Select your preferred arrangement type.

Sorting your files

To sort your files:

1. Launch Windows Explorer.
2. Right-click anywhere on the View pane.
3. From the menu that appears, select **Sort by**, then select your preferred sorting type.

Grouping your files

To group your files:

1. Launch Windows Explorer.
2. Right-click anywhere on the View pane.
3. From the menu that appears, select **Group by**, then select your preferred grouping type.

Adding a new folder

To add a new folder:

1. Launch Windows Explorer.
2. From the toolbar, click **New folder**.
3. Key in a name for the new folder.




You may also right-click anywhere on the View pane, click **New > Folder**.

Backing up your files

Setting up a backup

To set up a backup:

1. Click  > **All Programs > Maintenance > Backup and Restore**.
2. Click **Set up backup**. Click **Next**.
3. Select your backup destination. Click **Next**.
4. Select **Let Windows choose (recommended)** or **Let me choose as your backup mode**.




If you select **Let Windows choose**, Windows will not back up your programs, FAT-formatted files, Recycle Bin files, or temporary files that are 1GB or more.

5. Follow the onscreen instructions to finish the process.

Restoring your system settings

The Windows® System Restore feature creates a restore point where the computer's system settings are stored at certain time and date. It allows you to restore or undo changes to your computer's system settings without affecting your personal data.

To restore your system:

1. Close all running applications.
2. Click  > **All Programs > Accessories > System Tools > System Restore**.
3. Follow the onscreen instructions to complete the process.

Protecting your computer

Using Windows® 7 Action Center


Windows® 7 Action Center provides you with alert notifications, security information, system maintenance information, and the option to automatically troubleshoot and fix some common computer problems.



You may customize the notifications. For more details, refer to the previous section **Customizing icons and notifications** in this chapter.

Launching Windows® 7 Action Center

To launch Windows® 7 Action Center:


1. To launch Windows 7 Action Center, click the Notification icon , then click **Open Action Center**.
2. From Windows 7 Action Center, click the task that you want to do.

Using Windows® Update

Windows Update allows you to check and install the latest updates to enhance the security and performance of your computer.

Launching Windows® Update

To launch Windows® Update:


1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Select **All Programs > Windows Update**.
3. From the Windows Update screen, click the task that you want to do.

Setting up a user account and password

You may create user accounts and passwords for people who will use your computer.

Setting up a user account

To set up a user account:

1. From the Windows® taskbar, click  > **Getting Started > Add new users**.
2. Select **Manage another account**.
3. Select **Create a new account**.
4. Key in the name of the new user.
5. Select either **Standard user** or **Administrator** as the user type.
6. When done, click **Create Account**.

Setting up a user's password

To set up a user's password:

1. Select the user that you would like to set a password.
2. Select **Create a password**.
3. Key in a password and confirm it. Key in your password's hint.
4. When done, click **Create password**.

Activating the anti-virus software

Trend Micro Internet Security is pre-installed on your computer. It is a third-party anti-virus software protecting your computer from virus. It is purchased separately. You have a 30-day trial period after activating it.

To activate Trend Micro Internet Security:

1. Run the Trend Micro Internet Security application.
2. Carefully read the license terms. Click **Agree & Activate**.
3. Input your e-mail address and select your location. Click **Next**.
4. Click Finish to complete the activation.

Getting Windows® Help and Support

Windows® Help and Support provides you with guides and answers in using the applications in Windows® 7 platform.

To launch Windows® Help and Support, click  > **Help and Support**.



Ensure that you are connected to the Internet to obtain the latest Windows® online help.

Chapter 3

Connecting devices to your computer

Connecting a USB storage device

This desktop PC provides USB 2.0/1.1 ports on both the front and rear panels and USB3.0 ports on the rear panel. The USB ports allow you to connect USB devices such as storage devices.

To connect a USB storage device:

- Insert the USB storage device to your computer.






Front panel



Rear panel

To remove a USB storage device:

1. Click  from the Windows notification area on your computer, then click **Eject USB2.0 FlashDisk**.
2. When the **Safe to Remove Hardware** message pops up, remove the USB storage device from your computer.



DO NOT remove a USB storage device when data transfer is in progress. Doing so may cause data loss or damage the USB storage device.


Connecting microphone and speakers

This desktop PC comes with microphone ports and speaker ports on both the front and rear panels. The audio I/O ports located on the rear panel allow you to connect 2-channel, 4-channel, 6-channel, and 8-channel stereo speakers.


Connecting Headphone and Mic




Connecting 2-channel Speakers




Connecting 4-channel Speakers



Connecting 6-channel Speakers



Connecting 8-channel Speakers



Connecting multiple external displays

Your desktop PC may come with VGA, HDMI, or DVI ports and allows you to connect multiple external displays.




When a graphics card is installed in your computer, connect the monitors on the output ports of the graphics card.

Setting up multiple displays


When using multiple monitors, you are allowed to set display modes. You can use the additional monitor as a duplicate of your main display, or as an extension to enlarge your Windows desktop.

To set up multiple displays:

1. Turn off your computer.
2. Connect the two monitors to your computer and connect the power cords to the monitors. Refer to **Setting up your computer** section in Chapter 1 for details on how to connect a monitor to your computer.



For some graphic cards, only the monitor that is set to be the primary display has display during POST. The dual display function works only under Windows.

3. Turn on your computer.
4. Do any of the following to open the **Screen Resolution** setting screen:
 - Click  > **Control Panel > Appearance and Personalization > Display > Change display settings.**
 - Right click anywhere on your Windows desktop. When the pop-up menu appears, click **Personalize > Display > Change display settings.**
5. Select the display mode from the **Multiple displays:** drop-down list.
 - **Duplicate these displays:** Select this option to use the additional monitor as a duplicate of your main display.
 - **Extend these displays:** Select this option to use the additional monitor as an extension display. This increases your desktop space.
 - **Show desktop only on 1 / 2:** Select this option to show desktop only on monitor 1 or monitor 2.
 - **Remove this display:** Select this options to remove the selected display.
6. Click **Apply** or **OK**. Then click **Keep Changes** on the confirmation message.

Connecting an HDTV

Connect a High Definition TV (HDTV) to the HDMI port of your computer.



- You need an HDMI cable to connect the HDTV and the computer. The HDMI cable is purchased separately.
- To get the best display performance, ensure that your HDMI cable is less than 15 meters.



[illegible]

Chapter 4

Using your computer

Proper posture when using your Desktop PC

When using your Desktop PC, maintaining the proper posture is necessary to prevent strain to your wrists, hands, and other joints or muscles. This section provides you with tips on avoiding physical discomfort and possible injury while using and fully enjoying your Desktop PC.




To maintain the proper posture:

- Position your computer chair to make sure that your elbows are at or slightly above the keyboard to get a comfortable typing position.
- Adjust the height of your chair to make sure that your knees are slightly higher than your hips to relax the backs of your thighs. If necessary, use a footrest to raise the level of your knees.
- Adjust the back of your chair so that the base of your spine is firmly supported and angled slightly backward.
- Sit upright with your knees, elbows and hips at an approximately 90° angle when you are at the PC.
- Place the monitor directly in front of you, and turn the top of the monitor screen even with your eye level so that your eyes look slightly downward.
- Keep the mouse close to the keyboard, and if necessary, use a wrist rest for support to reduce the pressure on your wrists while typing.
- Use your Desktop PC in a comfortably-lit area, and keep it away from sources of glare such as windows and straight sunlight.
- Take regular mini-breaks from using your Desktop PC.

Using the memory card reader

Digital cameras and other digital imaging devices use memory cards to store digital picture or media files. The built-in memory card reader on the front panel of your system allows you to read from and write to different memory card drives.



To use the memory card:

1. Insert the memory card into the card slot.



- A memory card is keyed so that it fits in only one direction. DO NOT force a card into a slot to avoid damaging the card.
- You can place media in one or more of the card slots and use each media independently. Place only one memory card in a slot at one time.

2. Select a program from the AutoPlay window to access your files.



- If AutoPlay is NOT enabled in your computer, click Windows® 7 **Start** button on the taskbar, click **Computer**, and then double-click the memory card icon to access the data on it.
- Each card slot has its own drive icon which is displayed on the **Computer** screen.
- The memory card reader LED lights up and blinks when data is being read from or written to the memory card.

3. When finished, right-click the memory card drive icon on the **Computer** screen, click **Eject**, and then remove the card.




Never remove cards while or immediately after reading, copying, formatting, or deleting data on the card or else data loss may occur.



To prevent data loss, use "Safely Remove Hardware and Eject Media" in the Windows notification area before removing the memory card.

Using the optical drive



Inserting an optical disc

To insert an optical disc:

1. While your system is on, press the eject button below the drive bay cover to open the tray.
2. Place the disc to the optical drive with the label side facing up.
3. Push the tray to close it.
4. Select a program from the AutoPlay window to access your files.



If AutoPlay is NOT enabled in your computer, click Windows® 7 **Start** button on the taskbar, click **Computer**, and then double-click the CD/DVD drive icon to access the data on it.

Removing an optical disc

To remove an optical disc:

1. While the system is on, do either of the following to eject the tray:
 - Press the eject button below the drive bay cover.
 - Right-click the CD/DVD drive icon on the **Computer** screen, and then click **Eject**.
2. Remove the disc from the disc tray.

Using the multimedia keyboard (on selected models only)



The keyboard varies with models. The illustrations on this section are for reference only.

ASUS SK-2045 keyboard











Keys	Description	Keys	Description
1.	Launches Windows® gadgets.	12.	Press <Fn + F7> to launch Microsoft® MSN or, if not installed, connects to the MSN download page.
2.	Activates Windows® Flip 3D.	13.	Press <Fn + F8> to launch Windows® Search screen.
3.	Reduces picture size in Windows® Photo Viewer.	14.	Press <Fn + F9> to play or pause playback in Windows® Media Player.
4.	Increases picture size in Windows® Photo Viewer.	15.	Press <Fn + F10> to stop playback in Windows® Media Player.
5.	Functions with keys F1~F12.	16.	Press <Fn + F11> to go to the previous track in Windows® Media Player.
6.	Press <Fn + F1> to launch Microsoft® Word.	17.	Press <Fn + F12> to go to the next track in Windows® Media Player.
7.	Press <Fn + F2> to launch Microsoft® Excel.	18.	Decreases the system volume.
8.	Press <Fn + F3> to launch Microsoft® PowerPoint.	19.	Increases the system volume.
9.	Press <Fn + F4> to launch Microsoft® Internet Explorer.	20.	Turns the volume's mute mode on/off.
10.	Press <Fn + F5> to launch Microsoft® Outlook.	21.	Launches Windows® Media Player.
11.	Press <Fn + F6> to launch the Favorites folder in Windows® Internet Explorer.	22.	Launches Windows® Media Center.




The special function keys only work on Windows® Vista / Windows® 7 operating systems.

ASUS-Razer Arctosa Gaming keyboard



Keys	Description
1. 	Plays or pauses playback in a media player.
2. 	Stops playback in a media player.
3. 	Goes to the previous track in a media player.
4. 	Goes to the next track in a media player.
5. 	Decreases the system volume.
6. 	Increases the system volume.
7. 	Turns the volume's mute mode on/off.
8. 	Switches profiles working with F1 ~ F10 keys.



- The special function keys work on Windows® XP / Vista / 7 operating systems.
- Install the keyboard driver before using. Visit the Razer website at www.razer-support.com to download the driver.

BTC 6200C keyboard




Keys	Description	Keys	Description
1.	Enters into sleep mode. Press any key to wake up your computer and return to the previous working status.	8.	Increases the system volume.
2.	Returns to the last page you viewed.	9.	Turns the volume's mute mode on/off.
3.	Goes to the next page you viewed before.	10.	Goes to the previous track in a media player.
4.	Launches the default homepage in Windows® Internet Explorer.	11.	Plays or pauses playback in a media player.
5.	Launches the Favorites folder in Windows® Internet Explorer.	12.	Goes to the next track in a media player.
6.	Launches your default email application.	13.	Stops playback in a media player.
7.	Decreases the system volume.		



- The special function keys work on Windows® ME / 2000 / XP / Vista / 7 operating systems without installing a driver. For Windows® 98SE operating system, visit the BTC website at www.btc.com.tw to download the driver.
- Install Microsoft® Internet Explorer 5.0 or later versions before using the Internet keys.

ASUS KB34211 modern wired keyboard



Hot keys	Description
1.	Turns the volume's mute mode on/off.
2.	Decreases the system volume.
3.	Increases the system volume.



The special function keys only work on Windows® Vista / Windows® 7 / XP operating systems.

[illegible]

Chapter 5

Connecting to the Internet

Wired connection

Use an RJ-45 cable to connect your computer to a DSL/cable modem or a local area network (LAN).

Connecting via a DSL/cable modem


To connect via a DSL/cable modem:

1. Set up your DSL/cable modem.



Refer to the documentation that came with your DSL/cable modem.

2. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to a DSL/cable modem.



3. Turn on the DSL/cable modem and your computer.
4. Configure the necessary Internet connection settings.




Contact your Internet Service Provider (ISP) for details or assistance in setting up your Internet connection.

Connecting via a local area network (LAN)

To connect via a LAN:

1. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to your LAN.



2. Turn on your computer.
3. Configure the necessary Internet connection settings.




Contact your network administrator for details or assistance in setting up your Internet connection.

Wireless connection (on selected models only)

Connect your computer to the Internet through a wireless connection.





To establish a wireless connection, you need to connect to a wireless access point (AP).



- To increase the range and sensitivity of the wireless radio signal, connect the external antennas to the antenna connectors on the ASUS WLAN Card.
- Place the antennas on the top of your computer for the best wireless performance.
- The external antennas are optional items.

To connect to a wireless network:

1. Click the network icon  in the notification area to display the available wireless networks.
2. Select the wireless network that you want to connect to, then click **Connect**.
3. You may need to key in the network security key for a secured wireless network, then click **OK**.
4. Wait while your computer is connecting to the wireless network.
5. The wireless connection is established successfully. The connection status is displayed and the network icon displays the connected  status.

[illegible]

Chapter 6

Using the utilities



The support DVD and Recovery DVD are not included in the package. You can burn it by yourself. Refer to section **Recovering your system** for details.

ASUS AI Manager

ASUS AI Manager is a utility which gives you quick and easy access to frequently-used applications.

Installing AI Manager

To install AI Manager:

1. Place the support DVD in the optical drive. If Autorun is enabled, the Drivers installation wizard appears.



If Autorun is disabled, double-click the **setup.exe** file from the ASUS AI Manager folder in the support DVD.

2. Click the **Utilities** tab, then click **ASUS AI Manager**.
3. Follow the onscreen instructions to complete the installation.


Launching AI Manager

To launch the AI Manager from the Windows® desktop, click **Start > All Programs > ASUS > AI Manager > AI Manager 1.xx.xx**. The AI Manager quick bar appears on the desktop.



After launching the application, the AI Manager icon appears in the Windows® taskbar.




Right-click this icon to switch between the quick bar and the main window, and to launch the AI Manager either from the quick bar or taskbar.



AI Manager quick bar


The AI Manager quick bar saves the desktop space and allows you to launch the ASUS utilities or display system information easily. Click any of the Main, My Favorites, Support or Information tab to display the menu's contents.



Click the Maximize/restore button  to switch between full window and quick bar. Click the Minimize button  to keep the AI Manager on the taskbar. Click the Close button  to quit the AI Manager.

Main

The Main menu contains five utilities: **AI Disk**, **AI Security**, **AI Boosting**, and **AI Probe**. Click the arrow on the Main menu icon to browse through the utilities in the main menu.



AI Disk

AI Disk allows you to easily clear temporary IE files, IE cookies, IE URLs, IE history, or the Recycle Bin. Click the AI Disk icon on the quick bar to display the full AI Disk window and select the items you want to clear. Click **Apply** when done.

AI Security

AI Security enables you to set a password to secure your devices, such as USB flash disks and CD/DVD disks, from unauthorized access.

To lock a device:

1. When using AI Security for the first time, you are asked to set a password. Key in a password with at most 20 alphanumeric characters.
2. Confirm the password.
3. Key in the password hint (recommended).
4. When done, click **Ok**.
5. Select the device you want to lock, then click **Apply**.
6. Key in the password you have set previously, then click **Ok**.

To unlock the device:

1. Deselect the locked device, then click **Apply**.
2. Key in the password you have set previously, then click **Ok**.

To change the password:

- Click **Change Password**, then follow the onscreen instructions to change password.

AI Booting

AI Booting allows you to specify the boot device priority sequence.

To specify the boot sequence:

1. Select a device, then click the left/right button to specify the boot sequence.
2. When done, press **Apply**.

AI Probe

AI Probe automatically detects and displays the motherboard and CPU temperatures, CPU fan speed, and the voltage output. You can adjust the values as you need.

Click the **Temperature**, **Voltage**, or **Fan Speed** tab, then select an item to enable and change the value by dragging the bar.

My Favorites

My Favorites allows you to add applications that you frequently use, saving you from searching for the applications throughout your computer.

To add an application:

1. Click **Add**, then locate the application you want to add to **My Favorites**.
2. Click **Open** on the file location window. The application is added to **My Favorites** list.

Right click on the application icon to launch, delete, or rename the selected application. You can also double click to launch the selected application.

Support

Click any links on the **Support** window to go to the ASUS website, technical support website, download support website, or contact information.

Information

Click the tab on the **Information** window to see the detailed information about your system, motherboard, CPU, BIOS, installed device(s), and memory.

ASUS EPU-4 Engine

ASUS EPU-4 Engine is an energy-efficient tool that provides you with a total system power-saving solution. It detects the current computer loading and intelligently adjusts the power in real-time. It automatically adjusts the power usage for the CPU, VGA card, hard drives, and CPU fan. It provides you with these modes to choose from: **Auto**, **High Performance**, and **Maximum Power Saving Mode**.



Refer to the section **ASUS EPU-4 main screen** for more details about these modes.

Installing ASUS EPU-4

To install ASUS EPU-4 Engine:

1. Place the support DVD into the optical drive. The **Drivers** menu appears if Autorun is enabled on your computer.

If Autorun is disabled, double-click the **setup.exe** file from the ASUS EPU-4 Engine folder in the support DVD.


2. Click **ASUS EPU-4 Engine**.
3. Follow the onscreen instructions to complete the installation.

Launching ASUS EPU-4

To launch ASUS EPU-4:

1. From the Windows taskbar, click the ASUS EPU-4 icon.
2. When you launch ASUS EPU-4 for the first time, a message appears asking you to calibrate the EPU functions.

Click **Calibrate** and wait for a few seconds for the calibration process to complete. The ASUS EPU-4 main menu appears.



Calibration allows the system to detect the CPU properties for optimal power management.

ASUS EPU-4 main screen



1

CPU status

Displays the current CPU power and the total CPU power saved.

2

VGA card status

Displays the status of the graphics card. If your graphics card is not compatible with the motherboard, a "No VGA card detected" message appears.



Refer to the ASUS VGA QVL List at http://event.asus.com/mb/EPU-4_Engine/ for compatible VGA cards.

-
- 3 **HDD status**
Lights up when the power saving mode is activated.

 - 4 **Fan status**
Display the current fan status.

 - 5 **CO2 Emission button**
Displays the current or total reduced CO2 emission.

 - 6 **Mode properties**
Displays the properties of each mode.

 - 7 **Exit button**
Closes the ASUS EPU-4 utility,

 - 8 **Calibrate button**
Allows the system to detect the CPU properties for optimal power management.

 - 9 **Setting button**
Click this button to configure the mode settings.



Refer to the section **Configuring the mode settings** for more details.

10 Modes



Auto Mode

When you select this mode, the system changes modes automatically according to the current system status.



High Performance Mode

When you select this mode, the system overlocks the components for maximum performance.



Maximum Power Saving Mode



When you select this mode, the system automatically adjusts the power usage for critical components in real-time to save power.

Configuring the mode settings

To configure the mode settings:

1. From the ASUS EPU-4 main menu, click **Setting** to launch the Setting screen.



2. Click the  tab to configure the settings of High Performance mode. Click the  tab to configure the settings of Maximum Power Saving mode.
3. Configure any of these mode settings:
 - **vCore Voltage Downgrade:** Lowers CPU vCore voltage.
 - **Heavy:** Downgrades voltage to the highest level for CPU power saving.
 - **Medium:** Downgrades voltage to the medium level.
 - **Small:** Downgrades voltage to the minimum level.
 - **Turn Off hard disks:** Turns off hard disk drives when they are not accessed after a certain time.
 - **CPU Loadline:** Sets up the CPU loadline to manage CPU power saving.
 - **Light:** Saves CPU power to the minimum level.
 - **Medium:** Saves CPU power to the medium level.
 - **Heavy:** Saves CPU power to the highest level.
 - **Turn Off Screen:** After the specified idle time, the screen turns off while all background tasks are still running.
4. Click **OK** to apply the settings made.

ASUS Update

The ASUS Update is a utility that allows you to manage, save, and update the motherboard BIOS in Windows® environment.



- ASUS Update requires an Internet connection either through a network or an Internet Service Provider (ISP).
- This utility is available in the support DVD.

Installing ASUS Update

To install ASUS Update:

1. Place the support DVD in the optical drive. The **Drivers** menu appears.



If Autorun is disabled, double-click the **setup.exe** file from the ASUS Update folder in the support DVD.

2. Click the **Utilities** tab, then click **Install ASUS Update**.
3. Follow the onscreen instructions to complete the installation.



Quit all Windows® applications before you update the BIOS using this utility.

Updating the BIOS

To update the BIOS:

1. From the Windows® desktop, click **Start > Programs > ASUS > ASUS Update > ASUS Update** to launch the ASUS Update utility.
2. From the dropdown list, select any of the updating process:

Updating from the Internet

- a. Select **Update BIOS from the Internet**, then click **Next**.
- b. Select the ASUS FTP site nearest you to avoid network traffic, or click **Auto Select** then click **Next**.
- c. From the FTP site, select the BIOS version that you wish to download then click **Next**.



The ASUS Update utility is capable of updating itself through the Internet. Always update the utility to avail all its features.

Updating from a BIOS file

- a. Select **Update BIOS from a file**, then click **Next**.
 - b. Locate the BIOS file from the **Open** window, then click **Open**.
3. Follow the onscreen instructions to complete the updating process.

ASUS MyLogo2™

The ASUS MyLogo2™ utility lets you customize the boot logo. The boot logo is the image that appears on screen during the Power-On Self-Tests (POST). ASUS MyLogo2™ is automatically installed when you install the ASUS Update utility from the Support DVD.



- Obtain the latest BIOS file from the ASUS website at www.asus.com.
- You can create your own boot logo image in GIF file format.

To launch ASUS MyLogo2™:

1. Launch the ASUS Update utility. Refer to the section “**ASUS Update**” in this user manual for details.
2. Select **Options** from the drop down menu, then click **Next**.
3. Check the option **Launch MyLogo to replace system boot logo before flashing BIOS**, then click **Next**.
4. Select **Update BIOS from file** from the drop down menu, then click **Next**.
5. When prompted, locate the new BIOS file, then click **Next**. ASUS MyLogo window appears.
6. From the left window pane, locate the image that you want to use as your boot logo. Click **Next**.
7. From the **Ratio** dropdown list, select your desired size for the boot logo. Click **Next**.
8. The system starts updating the BIOS and loading the new boot logo.
9. After the updating process, the system restarts and displays the new boot logo during POST.



Nero 9

Nero 9 allows you to create, copy, burn, edit, share, and update different kinds of data.

Installing Nero 9

To install Nero 9:

1. Insert the Nero 9 DVD into your optical drive.
2. If Autorun is enabled, the main menu appears automatically.



If Autorun is disabled, double-click the **SetupX.exe** file from the main directory of your Nero 9 DVD.

3. From the main menu, click **Nero 9 Essentials**.
4. Select the language you want to use for Installation Wizard. Click **Next**.
5. Click **Next** to continue.
6. Tick **I accept the License Conditions**. When done, click **Next**.
7. Select **Typical** then click **Next**.
8. Tick **Yes, I want to help by sending anonymous application data to Nero** then click **Next**.
9. When done, click **Exit**.

Burning files

To burn files:

1. From the main menu, click **Data Burning > Add**.
2. Select the files that you want to burn. When done, click **Add**.
3. After selecting files that you want to burn, click **Burn** to burn the files to a disc.



For more details about using Nero 9, refer to the Nero website at www.nero.com

Recovering your system

Using the Recovery Partition


The Recovery Partition quickly restores your Desktop PC's software to its original working state. Before using the Recovery Partition, copy your data files (such as Outlook PST files) to USB storage devices or to a network drive and make note of any customized configuration settings (such as network settings).

About the Recovery Partition

The Recovery Partition is a reserved space on your hard disk drive used to restore the operating system, drivers, and utilities installed on your Desktop PC at the factory.



DO NOT delete the partition named **RECOVERY**. The Recovery Partition is created at the factory and cannot be restored if deleted. Take your Desktop PC to an authorized ASUS service center if you have problems with the recovery process.



Using the Recovery Partition:

1. Press <F9> during bootup.
2. Press <Enter> to select Windows Setup [EMS Enabled].
3. Select one of the following recovery options.

System Recovery:

This feature allows you to restore the system to the factory default settings.

System Image Backup:

This feature allows you to burn the system image backup in DVD discs, which you can use later to restore the system to its default settings.

System DVD Backup:

This feature allows you to make a backup copy of the support DVD.

4. Follow the onscreen instructions to complete the recovery process.



Visit the ASUS website at www.asus.com for updated drivers and utilities.

Using the Recovery DVD (on selected models)



Prepare 1~3 blank writable DVDs as instructed to create the Recovery DVD.



Remove the external hard disk drive before performing system recovery on your Desktop PC. According to Microsoft, you may lose important data because of setting up Windows on the wrong disk drive or formatting the incorrect drive partition.

To use the Recovery DVD:

1. Insert the Recovery DVD into the optical drive. Your Desktop PC needs to be powered ON.
2. Restart the Desktop PC and press **<F8>** on bootup and select the optical drive (may be labeled as "CD/DVD") and press **<Enter>** to boot from the Recovery DVD.
3. Select OK to start to restore the image.
4. Select OK to confirm the system recovery.



Restoring will overwrite your hard drive. Ensure to back up all your important data before the system recovery.

5. Follow the onscreen instructions to complete the recovery process.



DO NOT remove the Recovery disc, unless instructed to do so, during the recovery process or else your partitions will be unusable.



Visit the ASUS website at www.asus.com for updated drivers and utilities.

Chapter 7

Troubleshooting

Troubleshooting

This chapter presents some problems you might encounter and the possible solutions.

? *My computer cannot be powered on and the power LED on the front panel does not light up*

- Check if your computer is properly connected.
- Check if the wall outlet is functioning.
- Check if the Power Supply Unit is switched on. Refer to the section **Turning your computer ON/OFF** in Chapter 1.

? *My computer hangs.*

- Do the following to close the programs that are not responding:
 1. Simultaneously press <Alt> + <Ctrl> + <Delete> keys on the keyboard, then click **Start Task Manager**.
 2. Click **Applications** tab.
 3. Select the program that is not responding, then click **End Task**.
- If the keyboard is not responding. Press and hold the Power button on the top of your chassis until the computer shuts down. Then press the Power button to turn it on.

? *I cannot connect to a wireless network using the ASUS WLAN Card (on selected models only)?*

- Ensure that you enter the correct network security key for the wireless network you want to connect to.
- Connect the external antennas (optional) to the antenna connectors on the ASUS WLAN Card and place the antennas on the top of your computer chassis for the best wireless performance.

? *The arrow keys on the number key pad are not working.*

Check if the Number Lock LED is off. When the Number Lock LED is on, the keys on the number key pad are used to input numbers only. Press the Number Lock key to turn the LED off if you want to use the arrow keys on the number key pad.

? *No display on the monitor.*

- Check if the monitor is powered on.
- Ensure that your monitor is properly connected to the video output port on your computer.
- If your computer comes with a discrete graphics card, ensure that you connect your monitor to a video output port on the discrete graphics card.
- Check if any of the pins on the monitor video connector is bent. If you discover bent pins, replace the monitor video connector cable.
- Check if your monitor is plugged to a power source properly.
- Refer to the documentation that came with your monitor for more troubleshooting information.

? *When using multiple monitors, only one monitor has display.*

- Ensure that the both monitors are powered on.
- During POST, only the monitor connected to the VGA port has display. The dual display function works only under Windows.
- When a graphics card is installed on your computer, ensure that you connect the monitors to the output port on the graphics card.
- Check if the multiple displays settings are correct. Refer to section **Connecting multiple external displays** in Chapter 3 for details.


? *My computer cannot detect my USB storage device.*

- The first time you connect your USB storage device to your computer, Windows automatically installs a driver for it. Wait for a while and go to My Computer to check if the USB storage device is detected.
- Connect your USB storage device to another computer to test if the USB storage device is broken or malfunctions.





? *I want to restore or undo changes to my computer's system settings without affecting my personal files or data.*

The Windows® System Restore feature allows you to restore or undo changes to your computer's system settings without affecting your personal data such as documents or photos. For more details, refer to the section **Restoring your system** in Chapter 2.

? *The picture on the HDTV is distorted.*

- It is caused by the different resolutions of your monitor and your HDTV. Adjust the screen resolution to fit your HDTV. To change the screen resolution:
 1. Do any of the following to open the **Screen Resolution** setting screen:
 - Click  > **Control Panel** > **Appearance and Personalization** > **Display** > **Change display settings**.
 - Right click anywhere on your Windows desktop. When the pop-up menu appears, click **Personalize** > **Display** > **Change display settings**.
 2. Adjust the resolution. Refer to the documentation came with your HDTV for the resolution.
 3. Click **Apply** or **OK**. Then click **Keep Changes** on the confirmation message.



? *My speakers produce no sound.*

- Ensure that you connect your speakers to the Line out port (lime) on the front panel or the rear panel.
- Check if your speak is connected to a electrical source and turned on.
- Adjust your speakers' volume.
- Ensure that your computer's system sounds are not Muted.
 - If it is muted, the volume icon is displayed as . To enable the system sounds, click  from the Windows notification area, then click .
 - If it is not muted, click  and drag the slider to adjust the volume.
- Connect your speakers to another computer to test if the speakers arer working properly.

? *The DVD drive cannot read a disc.*

- Check if the disc is placed with the label side facing up.
- Check if the disc is centered in the tray, especially for the discs with non-standard size or shape.
- Check if the disc is scratched or damaged.

? *The DVD drive eject button is not respond.*

1. Click  > **Computer**.
2. Right-click , then click **Eject** from the menu.

Power

Problem	Possible Cause	Action
No power (The power indicator is off)	Incorrect power voltage	<ul style="list-style-type: none"> • Set your computer's power voltage switch to your area's power requirements. • Adjust the voltage settings. Ensure that the power cord is unplugged from the power outlet.
	Your computer is not turned on.	Press the power key on the front panel to ensure that your computer is turned on.
	Your computer's power cord is not properly connected.	<ul style="list-style-type: none"> • Ensure that the power cord is properly connected. • Use other compatible power cord.
	PSU (Power supply unit) problems	Try installing another PSU on your computer.

Display

Problem	Possible Cause	Action
No display output after turning the computer on (Black screen)	The signal cable is not connected to the correct VGA port on your computer.	<ul style="list-style-type: none"> • Connect the signal cable to the correct display port (onboard VGA or discrete VGA port). • If you are using a discrete VGA card, connect the signal cable to the discrete VGA port.
	Signal cable problems	Try connecting to another monitor.

LAN

Problem	Possible Cause	Action
Cannot access the Internet	The LAN cable is not connected.	Connect the LAN cable to your computer.
	LAN cable problems	Ensure the LAN LED is on. If not, try another LAN cable. If it still does not work, contact the ASUS service center.
	Your computer is not properly connected to a router or hub.	Ensure that your computer is properly connected to a router or hub.
	Network settings	Contact your Internet Service Provider (ISP) for the correct LAN settings.
	Problems caused by the anti-virus software	Close the anti-virus software.
	Driver problems	Reinstall the LAN driver

Audio

Problem	Possible Cause	Action
No Audio	Speaker or headphone is connected to the wrong port.	<ul style="list-style-type: none"> Refer to your computer's user manual for the correct port. Disconnect and reconnect the speaker to your computer.
	Speaker or headphone does not work.	Try using another speaker or headphone.
	The front and back audio ports do not work.	Try both the front and back audio ports. If one port failed, check if the port is set to multi-channel.
	Driver problems	Reinstall the audio driver

System

Problem	Possible Cause	Action
System speed is too slow	Too many programs are running.	Close some of the programs.
	Computer virus attack	<ul style="list-style-type: none"> • Use an anti-virus software to scan for viruses and repair your computer. • Reinstall the operating system.
The system often hangs or freezes.	Hard disk drive failure	<ul style="list-style-type: none"> • Send the damaged hard disk drive to ASUS Service Center for servicing. • Replace with a new hard disk drive.
	Memory module problems	<ul style="list-style-type: none"> • Replace with compatible memory modules. • Remove the extra memory modules that you have installed, then try again.
	There is not enough air ventilation for your computer.	Move your computer to an area with better air flow.
	Incompatible softwares are installed.	Reinstall the OS and reinstall compatible softwares.

CPU

Problem	Possible Cause	Action
Too noisy right after turning on the computer.	Your computer is booting up.	It is normal. The fan runs on its full speed when the computer is powering on. The fan slows down after entering the OS.
	The BIOS settings have been changed.	Restore the BIOS to its default settings.
	Old BIOS version	Update the BIOS to the latest version. Visit the ASUS Support site at http://support.asus.com to download the latest BIOS versions.
Computer is too noisy when in use.	The CPU fan has been replaced.	Ensure that you are using a compatible or ASUS-recommended CPU fan.
	There is not enough air ventilation for the computer.	Ensure that your computer is working in an area with good air flow.
	The system temperature is too high.	<ul style="list-style-type: none"> • Update the BIOS. • If you know how to reinstall the motherboard, try to clean the inner space of the chassis.



If the problem still persists, refer to your Desktop PC's warranty card and contact the ASUS Service Center. Visit the ASUS Support site at <http://support.asus.com> for the service center information.

ASUS contact information

ASUSTeK COMPUTER INC.

Address	15 Li-Te Road, Peitou, Taipei, Taiwan 11259
Telephone	+886-2-2894-3447
Fax	+886-2-2890-7798
E-mail	info@asus.com.tw
Web site	www.asus.com.tw

Technical Support

Telephone	+86-21-38429911
Online support	support.asus.com

ASUS COMPUTER INTERNATIONAL (America)

Address	800 Corporate Way, Fremont, CA 94539, USA
Telephone	+1-510-739-3777
Fax	+1-510-608-4555
Web site	usa.asus.com

Technical Support

Telephone	+1-812-282-2787
Support fax	+1-812-284-0883
Online support	support.asus.com

ASUS COMPUTER GmbH (Germany and Austria)

Address	Harkort Str. 21-23, D-40880 Ratingen, Germany
Fax	+49-2102-959911
Web site	www.asus.de
Online contact	www.asus.de/sales

Technical Support

Telephone (Component)	+49-1805-010923*
Telephone (System/Notebook/Eee/LCD)	+49-1805-010920*
Support Fax	+49-2102-9599-11
Online support	support.asus.com

*** EUR 0.14/minute from a German fixed landline; EUR 0.42/minute from a mobile phone.**

Manufacturer:	ASUSTeK Computer Inc.
Address:	No.150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH
Address:	HARKORT STR. 21-23, 40880 RATINGEN, GERMANY



華碩個人電腦

CM1730

使用手冊



T6444

第一版

2011 年 3 月

本使用手冊包括但不限於其所包含的所有資訊受到著作權法之保護，未經華碩電腦股份有限公司（以下簡稱“華碩”）許可，不得任意地仿製、拷貝、謄抄、轉譯或為其他使用或處分。本使用手冊沒有任何型式的擔保、立場表達或其它暗示。若有任何因本使用手冊或其所提到之產品的所有資訊，所引起直接或間接的資料流失、利益損失或事業終止，華碩及其所屬員工恕不為其擔負任何責任。除此之外，本使用手冊所提到的產品規格及資訊僅供參考，內容亦會隨時更新，恕不另行通知。華碩不負責本使用手冊的任何錯誤或疏失。

本使用手冊中所提及的產品名稱僅做為識別之用，而前述名稱可能是屬於其他公司的註冊商標或是著作權。

關於產品規格最新的升級訊息，請您到華碩的網站瀏覽或是直接與華碩公司聯絡。

版權所有 • 不得翻印 © 2010 華碩電腦

目錄內容

注意事項.....	71
安全性須知.....	73
提示符號.....	74
哪裡可以找到更多的產品資訊.....	74
包裝內容.....	75

第一章 系統導覽

歡迎	77
了解您的個人電腦.....	77
安裝您的個人電腦.....	81
開啟或關閉您的電腦	84

第二章 使用 Windows 7（選配）

第一次啟動.....	85
使用 Windows® 7 桌面.....	86
管理檔案與資料夾.....	88
還原您的系統.....	90
保護您的電腦.....	91
進入 Windows® 說明及支援.....	92

第三章 裝置連接

連接 USB 儲存裝置.....	93
連接麥克風與喇叭.....	94
連接多個外接顯示器.....	97
連接高解析電視 HDTV.....	99

第四章 使用您的電腦

使用電腦時的適當姿勢.....	101
使用讀卡機.....	102
使用光碟機.....	103
使用多媒體鍵盤(僅限指定型號).....	104

第五章 網路連線

有線連接.....	109
無線連接（選配）.....	111

目錄內容

第六章 使用應用程式（選配）

華碩 AI Manager	113
華碩 EPU-4 Engine	116
華碩線上更新（ASUS Update）	120
華碩 MyLogo2™	121
回復您的系統（僅限預裝 Windows 作業系統的機型）	123

第七章 疑難解決

華碩的連絡資訊	129
---------------	-----

注意事項

REACH

謹遵守 REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) 管理規範，我們會將產品中的化學物質公告在華碩 REACH 網站，詳細請參考 <http://csr.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

Macrovision 公司產品公告

本產品包含使用 Macrovision 公司的版權保護技術，受美國與其它智慧專利權註冊保護，使用此保護技術必需經 Macrovision 公司授權，限用於家庭及有限人數範圍觀賞，除非經 Macrovision 特別授權，禁止逆向工程或拆解此技術。

鋰電池安全警告

RTC（Real-Time Clock 實時時鐘）電池如果更換不正確，會有爆炸的危險，請依照製造商說明書使用相同或同款式電池，並請依照製造商指示處理用過的電池。

安全性須知



在清潔電腦之前，請先關機並移除電源與所有周邊裝置。您可以使用干淨柔軟的海綿或清潔布，沾上少許中性清潔劑與溫水，來擦拭您的個人電腦，接著用干布擦去多余的水跡。

- 請勿將個人電腦放置於不平坦或不穩定的表面。若個人電腦的機殼損壞，請連絡維修服務人員。
- 請勿在灰塵飛揚或環境髒亂的場所使用台式電腦。請勿在泄漏的可燃氣體附近操作個人電腦。
- 請勿在個人電腦上放置其他物品。請勿將任何物品塞入電腦機件內，以避免引起機件短路或電路損毀。
- 請勿將個人電腦放置於具備強大電磁場的環境中。
- 請保持機器在乾燥的環境下使用，雨水、溼氣、液體等含有礦物質將會腐蝕電子線路。請勿在雷電天氣下使用資料機。
- 電池安全警示：請勿將電池丟入火中。請勿將電池的正負極短路。請勿自行拆解電池。
- 請在溫度為 5°C (41°F) 至 35°C (95°F) 之間的環境中使用本電腦。
- 請勿堵塞個人電腦的通風孔，以避免因散熱不良而導致系統過熱。
- 請勿使用破損的電源線、附件或其他周邊裝置。
- 為了防止電擊風險，在搬動電腦主機之前，請先將電腦電源插頭暫時從電源插座上移除。
- 在使用變壓器或電源延長線前，我們推薦您先尋求專業人士的協助。這些裝置有可能會干擾接地的迴路。
- 請確定電源的電壓設定已調整到本國/本區域所使用的電壓標準值。若您不確定您所屬區域的供應電壓值為何，請就近詢問當地的電力公司人員。
- 如果電源已損壞，請不要嘗試自行修復。請將之交給專業技術服務人員或經銷商來處理。

提示符號

為了能夠確保您正確地完成主機板設定，請務必注意下面這些會在本手冊中出現的標示符號所代表的特殊含意。



警告：提醒您在進行某一項工作時要注意您本身的安全。



小心：提醒您在進行某一項工作時要注意勿傷害到電腦主機板元件。



重要：此符號表示您必須要遵照手冊所描述之方式完成一項或多項軟硬體的安裝或設定。



注意：提供有助於完成某項工作的訣竅和其他額外的資訊。

哪裡可以找到更多的產品資訊

您可以經由下面所提供的兩個管道來獲得您所使用的華碩產品資訊以及軟硬體的最新資訊等。










1. 華碩網站

您可以到 <http://tw.asus.com> 華碩電腦全球資訊網站取得所有關於華碩軟硬體產品的各項資訊。

2. 華碩當地技術支援

您可以造訪 <http://support.asus.com/contact> 華碩網站取得您所在地區的技術支援工程師的聯繫資訊。

包裝內容

		
華碩個人電腦	鍵盤 x1	滑鼠 x1
		
電源線 x1	安裝指南 x1	華碩保固服務卡 x1
		
Nero 9 燒錄軟體光碟 x1	驅動程式與公用程式光碟 (選配) x1 回復光碟 (選配) x1	天線 (選配) x2
		
PC CILLIN		



- 若包裝內容有所損壞或丟失，請速與經銷商聯繫。
- 上述圖中所示物品僅供參考。實際產品規格及外觀依不同型號而定。

[illegible]

第一章

系統導覽

歡迎

感謝您購買華碩 CM1730 個人電腦。

華碩 CM1730 個人電腦擁有一流的效能，超凡的可靠性與以使用者為中心的應用程式，並安裝在華碩特別設計的機殼中。




請在安裝您的機殼前先參閱您的華碩保固服務卡。

了解您的個人電腦




本手冊中的機殼圖片描述僅供參考。各連接埠及其位置，與外殼顏色均依不同機型而異。

主機前面板



1. USB 2.0 連接埠：可連接 USB 裝置等，如滑鼠、打印機、掃描儀、相機、PDA 等。
2. 麥克風接頭：此接頭可連接麥克風。
3. 耳機連接埠：該連接埠可連接耳機或外接音箱。
4. 光碟機彈出按鈕：按此按鈕彈出光碟。
5. Secure Digital™ / MultiMedia 卡槽：將 Secure Digital™ / MultiMedia 卡插入此槽。
- Memory Stick™ / Memory Stick Pro™ 卡槽：將 Memory Stick™ / Memory Stick Pro™ 卡插入此槽。
- Extreme Digital 卡槽：將 Extreme Digital 卡插入此插槽。
6. 電源按鈕：按下此按鈕啟動您的電腦。
7. 光碟機槽蓋：此處有光碟機。

後面板



- 1. 電壓的選擇：使用此開關以切換到適合您所在區域所使用的電壓值。額定功率：115Vac/220-230Vac、7A/4A、60/50Hz。
- 2. 電源連接埠：將電源線連接至此連接埠。
- 3. 通風孔：進行空氣流通。




請勿堵住通風孔。經常為您的電腦通風。

- 4. PS/2 鍵盤/鼠標接口（紫色）：可連接 PS/2 鍵盤或鼠標。
- 5. USB 2.0 連接埠：可連接 USB 裝置等，如滑鼠、打印機、掃描儀、相機、PDA 等。
- 6. 光纖 S/PDIF 數位音效輸出連接埠：此連接埠透過光纖 S/PDIF 線纜連接外接音頻輸出裝置。
- 7. HDMI 連接埠：連接 HDMI 裝置。
- 8. DVI-D 連接埠：連接 DVI-D 相容裝置。
- 9. VGA 連接埠：可連接 VGA 相容裝置，如 VGA 顯示器。
- 10. USB 2.0 連接埠：可連接 USB 裝置等，如滑鼠、打印機、掃描儀、相機、PDA 等。
- 11. USB 2.0 連接埠：可連接 USB 裝置等，如滑鼠、打印機、掃描儀、相機、PDA 等。
- 12. LAN (RJ-45) 接口：透過網絡中心連接到一個局域網（LAN）。

網絡指示燈說明

Activity/Link 指示燈		速度指示燈	
狀態	描述	狀態	描述
關閉	沒有連線	關閉	連接速度 10Mbps
關閉	已連線	關閉	連接速度 100Mbps
閃爍	資料傳送中	綠色	連接速度 1Gbps



13. 後置環繞喇叭接頭（黑色）：本接口在四聲道、六聲道、八聲道設置下是用來連接後置環繞喇叭。
14. 側邊環繞喇叭接頭（灰色）：在八聲道音頻設置下，這個接口可以連接側邊環繞喇叭。
15. 麥克風接頭（粉紅色）：此接頭連接至麥克風。
16. 音頻輸出接頭（草綠色）：您可以連接耳機或喇叭等的音頻接收設備。在四聲道、六聲道、八聲道的喇叭設置模式時，本接頭是作為連接前置主聲道喇叭之用。
17. 中央聲道與重低音喇叭接頭（橘色）：這個接口可以連接中央聲道與重低音喇叭。
18. 音頻輸入接頭（淺藍色）：您可以將磁帶、CD、DVD 播放器等的音頻輸出端連接到此音頻輸入接頭。



在 2、4、6、8 聲道音頻設置上，音頻輸出、音頻輸入與麥克風接頭的功能會隨著聲道音頻設置的改變而改變，如下表所示。

二、四、六或八聲道音頻設置

接頭	耳機 / 二聲道 喇叭輸出	四聲道 喇叭輸出	六聲道 喇叭輸出	八聲道 喇叭輸出
淺藍色	聲音輸入端	聲音輸入端	聲音輸入端	聲音輸入端
草綠色	聲音輸出端	前置喇叭輸出	前置喇叭輸出	前置喇叭輸出
粉紅色	麥克風輸入端	麥克風輸入端	麥克風輸入端	麥克風輸入端
橘色	-	-	中央重低音喇叭輸出	中央重低音喇叭輸出
黑色	-	後置喇叭輸出	後置喇叭輸出	後置喇叭輸出
灰色	-	-	-	側邊喇叭輸出

19. 華碩無線網路卡（僅限已選型號）：次選配無線網路卡允許您的電腦連接一個無線網絡。
20. 華碩顯示卡（僅限已選型號）：在此選配的華碩顯示卡上的顯示輸出連接埠依型號而定。
21. 擴充卡插槽托架：安裝擴充卡時移除擴充卡插槽托架。

安裝您的個人電腦

該章節引導您連接主要硬體裝置，例如外部顯示器、鍵盤、滑鼠以及電源線至您的電腦。

連接一個外部顯示器

使用華碩顯示卡（選購）

將您的顯示器連接至華碩獨立顯示卡的顯示連接埠。

請依照以下步驟使用華碩顯示卡連接一個外部顯示器：

1. 將您的顯示器連接至華碩獨立顯示卡的顯示連接埠。
2. 將顯示器插上電源。



華碩獨立顯示卡的顯示連接埠隨機種不同而改變。



使用內建顯示輸出連接埠

將您的顯示器連接至內建顯示輸出連接埠。

請按照以下步驟使用內建顯示輸出連接埠連接一個外接顯示器：


1. 將一個 VGA 連接埠的顯示器連接至 VGA 連接埠，或一個 DVI-D 連接埠的顯示器連接至 DVI-D 連接埠，或一個 HDMI 連接埠的顯示器連接至 HDMI 連接埠。
2. 將顯示器連接至電源。



- 若您的電腦配有一張華碩顯示卡，則這張顯示卡在 BIOS 中被設為主顯示裝置。因此，請將您的顯示器連接至顯示卡上的顯示輸出連接埠。
- 欲連接多個外接顯示器至您的電腦，請參考第三章「[連接多個外接顯示器](#)」部分的内容。


連接 USB 鍵盤與滑鼠

將一個 USB 鍵盤與滑鼠連接至後面板的 USB 連接埠。



連接電源線

將電源線的一端連接至後面板的電源連接埠，另一端插上電源。



開啟或關閉您的電腦

本章節引導您在安裝完成后如何開啟或關閉您的電腦。

開啟您的電腦



請按照以下步驟開啟您的電腦：

1. 開啟您的顯示器。
2. 開啟電源開關，然後按下電源按鈕。



關閉您的電腦

請按照以下步驟關閉您的電腦：

1. 關閉所有執行中的程式。
2. 在 Windows® 桌面上點選 .
3. 點選  關閉作業系統。
4. 關閉電源開關。

第二章

使用 Windows® 7（選配）

第一次啟動

若您的電腦預裝了 Windows® 7 作業系統，則您第一次啟動電腦時，螢幕上會出現一系列畫面以引導您進行 Windows® 7 作業系統的基本設定。

當電腦第一次啟動時，請按照以下步驟操作：

1. 啟動您的電腦。等待幾分鐘直至 **設定 Windows** 畫面出現。
2. 在下拉選單中選擇您想要的語言，然後點選 **下一步**。
3. 在下拉選單中選擇您的國家或地區、時區、貨幣以及鍵盤佈局，然後點選 **下一步**。
4. 輸入使用者名稱與電腦名稱，然後點選 **下一步**。
5. 輸入所需資訊來設定您的密碼，然後點選 **下一步**。您也可以不輸入任何資訊，點選 **下一步 跳過這一步**。




若您想稍後為您的帳戶設定密碼，請參閱本章節「設定使用者帳號及密碼」。

6. 請仔細閱讀許可條款。勾選 **我願意接受許可條款**，然後點選 **下一步**。
7. 選擇 **使用推薦設定** 或 **僅安裝重要更新** 來為您的電腦進行安全設定。若您想要跳過這一步請選擇 **以後問我**。
8. 請再次確認您的日期與時間設定，然後點選 **下一步**。系統開始載入新設定並重新啟動。您可以現在開始使用您的電腦。

使用 Windows® 7 桌面




點選開始圖示  > 說明及支援 來獲取更多關於 Windows® 7 作業系統的資訊。

使用開始功能表

開始功能表允許您進入電腦上的程式或其它使用項目。它透過 說明及支援 功能提供您更多 Windows® 7 的資訊。

從開始功能表進入選項

請按照以下步驟由開始功能表進入選項：

1. 在 Windows® 工作列中點選開始圖示 。
2. 在開始功能表中選擇您想要進入的選項。




您可以將您常用的程式釘在開始功能表中成為一個小圖示。更多資訊請參閱本章節「在開始功能表或工作列中新增程式」。

使用 開始使用 選項

開始功能表中的 開始使用 選項包括一些基本操作的資訊，例如個人化 Windows®，新增新使用者，傳輸檔案等，幫助您更了解如何使用 Windows® 7 作業系統。

請按照以下步驟使用 開始使用：

1. 在 Windows® 工作列中點選開始圖示  進入開始功能表。
2. 選擇 開始使用 展開一系列任務選項。您也可以點選 開始 > 控制台 > 開始使用 進入作業。
3. 選擇您想要的任務選項。

使用工作列

工作列允許您進入以及管理已安裝在您的電腦上的程式或選項。

從工作列進入程式

請按照以下步驟從工作列進入程式：

- 在工作列中點選一個圖示進入此程式。再次點選圖示可隱藏此程式。



您可以將您常用的程式釘在開始功能表中成為一個小圖示。更多資訊請參閱本章節「在開始功能表或工作列中新增程式」。

在捷徑中新增選項

當您用滑鼠右鍵點選工作列中的一個圖示時，螢幕上會出現捷徑以提供您快速進入該程式或選項的相關連結。您也可以將所需選項釘在捷徑上，例如您喜愛的網站、經常瀏覽的資料夾、驅動程式或最近播放的媒體檔案。

請按照以下步驟將選項釘在捷徑：

1. 用滑鼠右鍵點選工作列中的一個圖示。
2. 在捷徑中用滑鼠右鍵點選你想要釘入的選項，然後選擇 **將此程式釘選到工作列**。


在捷徑中移除選項

請按照以下步驟在捷徑中移除選項：

1. 用滑鼠右鍵點選工作列中的一個圖示。
2. 在捷徑中用滑鼠右鍵點選你想要移除的選項，然後選擇 **將此程式從工作列取消釘選**。

在開始功能表或工作列中新增程式

請按照以下步驟在開始功能表或工作列中新增程式：


1. 在 Windows 工作列中點選開始圖示  進入開始功能表。
2. 在開始功能表或工作列中用滑鼠右鍵點選你想要釘入的選項。
3. 選擇 **釘選到工作列** 或 **釘選到 [開始]** 選單。



您也可以用滑鼠右鍵點選工作列中一個正在執行的程式的圖示，然後選擇 **將此程式釘選到工作列**。

在開始功能表中移除程式

請按照以下步驟在開始功能表中移除程式：

1. 在 Windows 工作列中點選開始圖示  進入開始功能表。
2. 在開始功能表中用滑鼠右鍵點選你想要移除的程式。然後選擇 **從開始功能表取消釘選**。




在工作列中移除程式

請按照以下步驟在工作列中移除程式：

1. 在工作列中用滑鼠右鍵點選你想要移除的程式。然後選擇 **將此程式從工作列取消釘選**。

使用通知區域

預設的通知區域顯示以下三種圖示：

	作業中心通知 點選該圖示顯示所有警示資訊或通知，以及進入 Windows [®] 作業中心。
	網路連線 該圖示顯示有線/無線網路連線狀態以及訊號強度。
	音量 點選此圖示調節音量。

顯示通知

請按照以下步驟顯示通知：

- 點選通知圖示 ，然後點選第一行的 **重要訊息** 開啟。




更多資訊請參閱本章節「Windows[®] 作業中心」。

個人化圖示與通知

您可以選擇在工作列或通知區域顯示或隱藏圖示與通知。

請按照以下步驟個人化圖示或通知：

- 在通知區域點選箭頭圖示 。
- 點選 **個人化**。
- 在下拉選單中選擇您想要個性化的圖示或選項的行為。

管理檔案與資料夾

使用 Windows[®] 瀏覽器

Windows[®] 瀏覽器允許您檢視或管理您的檔案與資料夾。

進入 Windows[®] 瀏覽器

請按照以下步驟進入 Windows[®] 瀏覽器：

- 在工作列中點選開始圖示  進入開始功能表。
- 點選 **電腦** 進入 Windows[®] 瀏覽器。


瀏覽檔案與資料夾

請按照以下步驟瀏覽檔案與資料夾：

1. 進入 Windows[®] 瀏覽器。
2. 在功能窗格或顯示面板中尋找所需資料的位置。
3. 在位址列中點選箭頭顯示磁碟機或資料夾。

個人化檔案或資料夾圖示

請按照以下步驟個人化資料夾預覽方式圖示：

1. 進入 Windows[®] 瀏覽器。
2. 在功能窗格中選擇您所需資料的位置。
3. 在工具列中點選顯示圖示 。
4. 在圖示選單中移動滑塊選擇你想要檢視檔案或資料夾的方式。



您也可以在顯示面板上用滑鼠右鍵點選任何一處，在展開的選項中點選 **檢視**，並選擇您想要檢視檔案或資料夾的方式。

排列您的檔案

請按照以下步驟排列您的檔案：

1. 進入 Windows[®] 瀏覽器。
2. 點選 **排列方式** 顯示下拉選單及選項。
3. 選擇您想要的排列方式。

排序您的檔案

請按照以下步驟排列您的檔案：

1. 進入 Windows[®] 瀏覽器。
2. 在顯示面板上用滑鼠右鍵點選任何一處。
3. 在出現的選單中選擇 **排序方式**，然後選擇您想要的排序方式。

將檔案進行分組

請按照以下步驟將檔案進行分組：

1. 進入 Windows[®] 瀏覽器。
2. 在顯示面板上用滑鼠右鍵點選任何一處。
3. 在出現的選單中選擇 **分組方式**，然後選擇您想要的分組方式。

新增一個新資料夾

請按照以下步驟新增一個新資料夾：

1. 進入 Windows[®] 瀏覽器。
2. 在工具欄中點選 **新增**。
3. 輸入新資料夾名稱。




您也可以顯示面板上用滑鼠右鍵點選任何一處，點選 **新增 > 資料夾**。

備份檔案

設定備份

請按照以下步驟設定備份：

1. 點選  > 所有程式 > 維護 > 備份與還原。
2. 點選 **設定備份**，然後再點選 **下一步**。
3. 選擇備份檔案的目標位置，點選 **下一步**。
4. 選擇 **讓 Windows[®] 選擇（推薦）** 或 **讓我選擇**。




若您選擇 **讓 Windows 選擇**，Windows[®] 將不會備份 1GB 或以上的程式，FAT 格式檔案，垃圾桶檔案或臨時檔案。

5. 按照螢幕出現的步驟完成設定。

還原您的系統

Windows[®] 系統還原功能可能會建立還原點，在那裡系統可以在特定時間或日期儲存設定。此功能允許您還原或撤銷您對系統的更改且不影響您的個人資料。

請按照以下步驟還原您的系統：

1. 關閉所有正在執行的程式。
2. 點選  > 所有程式 > 附件 > 系統工具 > 系統還原。
3. 按照螢幕出現的步驟完成設定。

保護您的電腦

使用 Windows® 7 作業中心


Windows® 7 作業中心為您提供警示通知、安全資訊、系統維護資訊、自動疑難解決選項以及修復一些電腦常見問題。



您可以自行制定警示通知。更多資訊請參閱本章節的「個性化圖示與通知」。

進入 Windows® 7 作業中心

請按照以下步驟進入 Windows® 7 作業中心：

1. 點選通知圖示 ，再點選 開啟行動作業中心。
2. 在作業中心裡點選您想要進行的操作。

使用 Windows® Update

Windows® Update 允許您檢查與安裝最近的更新內容，以增強電腦的安全與效能。

進入 Windows® Update

請按照以下步驟進入 Windows® Update：


1. 在 Windows® 工作列中點選開始圖示  進入開始功能表。
2. 選擇 所有程式 > Windows® Update。
3. 在 Windows Update® 畫面中點選您想要進行的操作。

設定使用者帳戶與密碼

您可以為使用您電腦的使用者設定帳戶與密碼。

設定使用者帳戶

請按照以下步驟設定使用者帳戶：

1. 在 Windows® 工作列中點選  > 開始使用 > 新增新使用者。
2. 選擇 管理其他帳戶。
3. 選擇 建立一個新帳戶。
4. 輸入新使用者名稱。
5. 選擇 標準使用者 或 系統管理員 作為使用者類型。
6. 完成後點選 建立帳戶。

設定使用者密碼

請按照以下步驟設定使用者密碼：

1. 選擇您想要設定密碼的使用者。
2. 選擇 **變更您的使用者帳戶**。
3. 輸入密碼並確認。輸入密碼提示。
4. 完成後點選 **變更密碼**。

啟動防毒軟體（視具體機型而定）


部分電腦預裝了趨勢科技網路安全程式（Trend Micro Internet Security）。它是一個第三方防毒軟體，保護您的電腦免受病毒侵襲。該軟體需另行購買。在啟動它之後您將會有一段時間的試用期，通常為 60 天。

請按照以下步驟啟動趨勢科技網路安全（Trend Micro Internet Security）：

1. 執行趨勢科技網路安全（Trend Micro Internet Security）應用程式。
2. 仔細閱讀許可條款，然後點選 **同意並啟動**。
3. 輸入您的郵件地址並選擇您的位置。點選 **下一步**。
4. 點選 **完成** 結束啟動。

進入 Windows® 說明及支援

Windows® 說明及支援提供您 Windows® 7 作業平臺中使用應用程式的說明與解決方法。

點選  > **說明及支援** 進入 Windows® 說明及支援。



請確認您已連接網路以獲得最新 Windows® 線上支援。


第三章

裝置連接


連接 USB 儲存裝置

個人電腦的前後面板均有 USB2.0/1.0 連接埠。USB 連接埠允許您連接 USB 裝置，例如儲存裝置。

欲連接 USB 儲存裝置，請將 USB 儲存裝置插入您的電腦。





前面板



後面板

請按照以下步驟移除 USB 儲存裝置：

1. 在 Windows 通知區域中點選  然後點選 退出對應裝置。
2. 當出現 可以放心移除硬體 資訊後，將 USB 儲存裝置從電腦上移除。




請勿在資料傳輸過程中移除 USB 儲存裝置。這樣做會導致資料遺失或損壞 USB 儲存裝置。


連接麥克風與喇叭

個人電腦的前後面板均有麥克風連接埠與喇叭連接埠。後面板的音效 I/O 連接埠允許您連接二、四、六、八聲道立體聲喇叭。


連接耳機與麥克風




連接二聲道喇叭




連接四聲道喇叭



連接六聲道喇叭



連接八聲道喇叭



連接多個外接顯示器

您的個人電腦視具體配置而定，可能配有 VGA、HDMI、DVI 等連接埠，允許您連接多個外接顯示器。




當您的電腦安裝好顯示卡後，將顯示器接連至顯示卡輸出連接埠。

設定多個顯示器


當您連接多個顯示器後，您可以設定顯示模式，讓新增顯示器與主顯示器顯示相同的內容，或作為主顯示器的延伸顯示器以擴充 Windows 桌面。

請按照以下步驟設定多個顯示器：

1. 關閉您的電腦。
2. 將兩個顯示器與您的電腦相連，並將電源線連接至這兩個顯示器。請參閱第一章「設定您的電腦」獲得更多連接顯示器的方法。



對於顯示卡，僅被設為主要顯示的顯示器才能在開機自我檢測時顯示出來。雙重顯示功能只可在 Windows 作業系統中運作。

3. 啟動您的電腦。
4. 請參考以下步驟開啟 **螢幕解析度** 進行設定：（由於機型不同，系統功能也會有差異，部分系統的控制台中直接可以看到顯示選項，而沒有個性選項）
 - 點選  > 控制台 > 個人化 > 顯示 > 螢幕解析度。
 - 用滑鼠右鍵點選桌面，在隨即出現的選單中點選 **個人化 > 顯示 > 螢幕解析度**。
5. 選擇多個顯示器的顯示模式：下拉式選單
 - **在這些顯示器上同步顯示**：選擇此項將新增的顯示器作為主顯示器的副本。
 - **延伸這些顯示器**：選擇此項將新增的顯示器作為延伸顯示器。這將增加您的電腦使用空間。
 - **只在 1/2 上顯示桌面**：選擇此項將僅在顯示器 1 或 2 上顯示桌面。
6. 點選 **套用** 或 **確定**。然後在確認訊息畫面上點選 **保留變更**。

連接高解析電視 HDTV

將高解析電視機與您電腦上的 HDMI 連接埠相連。



- 您需要一根 HDMI 線將高解析電視機與電腦相連。HDMI 線需另行購買。
- 為得到最佳顯示效果，請確認您的 HDMI 線不長於 15 公尺。



[illegible]

第四章

使用您的電腦

使用電腦時的適當姿勢

使用者需要在使用電腦時保持適當的姿勢，防止腕部，手以及其他關節或肌肉的損傷。本章節可為您提供如何避免不良姿勢造成的傷害，防止您在使用個人電腦時感到身體不適或受傷。



請參考以下幾項保持適當姿勢：

- 適當放置您的電腦椅，確保您的肘部平行於或略高於鍵盤，使得到舒適的打字位置。
- 調節座椅的高度，確保您的膝蓋略高於您的臀部，使得您的大腿後側得到放鬆。如有需要，請使用腳凳抬高您的膝蓋。
- 調節座椅的後側，使其完全支撐您的脊椎並且稍向後傾斜。
- 挺直坐正，使您的膝蓋，肘部以及臀部成約 90 度。
- 將顯示器放在您的正前方，將顯示器頂部與您的視線持平，使您的視線稍向下。
- 使滑鼠靠近鍵盤，如有需要，請使用肘托以緩解打字時肘部的壓力。
- 請在舒適平整的地方使用您的個人電腦，避開光源，如窗或直射陽光。
- 使用一段時間後請稍作休息。

使用讀卡機

數位相機或其他數位影像裝置，都是採用記憶卡來儲存數位相片或多媒體檔案。視機型而定，本系統的前面板提供一部內建的多合一讀卡機，讓您可以隨時插入這些記憶卡來讀取 / 寫入數位檔案。



請按照以下步驟使用記憶卡：

1. 將記憶卡插入卡槽。



- 由於記憶卡上均有缺口設計，因此只能以一個固定方向插入。請勿將卡強制插入卡槽以免卡受到損傷。
- 您可以在一個或多個卡槽中插入記憶卡，並逐一使用。請注意每個插槽只能插入一張記憶卡。

2. 在 **自動播放** 視窗中選擇一個程式來讀取檔案。



- 若您的電腦沒有自動播放功能，請點選 Windows 7 工作列中的開始按鈕，選擇 **電腦**，然後雙按記憶卡圖示進行資料讀取。
- 每個卡槽均有自己的磁碟機圖示，並顯示在 **電腦** 目錄下。
- 當資料被讀取或寫入記憶卡時，讀卡機顯示燈會亮起或閃爍。

3. 完成後用滑鼠右鍵點選記憶卡磁碟機圖示，點選 **退出**，然後移除記憶卡。




請勿在讀取、複製、格式化或移除記憶卡資料時或之後立即移除記憶卡，否則將可能導致資料遺失。



為了防止資料遺失，請在移除記憶卡之前使用通知區域中的 **安全移除硬體或退出媒體光碟**。

使用光碟機



放入光碟

請按照以下步驟放入光碟：

1. 系統開啟時，按下光碟機上的按鈕退出光碟托盤。
2. 將光碟有印刷圖案的那一面朝上放入。
3. 將托盤推入光碟機中。
4. 從 **自動播放** 選擇程式來讀取檔案。



若您的電腦沒有自動播放功能，請點選 Windows 7 工作列中的開始按鈕，選擇 **電腦**，然後雙按 CD/DVD 磁碟機圖示進行資料讀取。

退出光碟

請按照以下步驟退出光碟：

1. 系統開啟時，按下光碟機上的按鈕退出光碟托盤。
 - 按下光碟機上的 **退出** 按鈕。
 - 用滑鼠右鍵點選 **電腦** 畫面中的 CD/DVD 磁碟機圖示，然後點選 **退出**。
2. 將光碟從托盤中取出。

使用多媒體鍵盤 (僅限指定型號)



鍵盤依型號而異。以下描述僅供參考。

華碩 SK-2045 鍵盤



按鍵	功能	按鍵	功能
1.	開啟 Windows® 小工具。	12.	按 <Fn + F7> 開啟 Microsoft® MSN，若沒有安裝 MSN，可直接開啟下載頁面。
2.	開啟 Windows® Flip 3D。	13.	按 <Fn + F8> 開啟 Windows® 搜尋畫面。
3.	在 Windows® Photo Viewer 中縮小照片尺寸。	14.	按 <Fn + F9> 播放或暫停 Windows® Media Player。
4.	在 Windows® Photo Viewer 中放大照片尺寸。	15.	按 <Fn + F10> 停止 Windows® Media Player。
5.	同時按下此鍵與 F1-F12 中任一鍵開啟各種功能。	16.	按 <Fn + F11> 返回上一軌。
6.	按 <Fn + F1> 開啟 Microsoft® Word。	17.	按 <Fn + F12> 跳至下一軌。
7.	按 <Fn + F2> 開啟 Microsoft® Excel。	18.	降低音量。
8.	按 <Fn + F3> 開啟 Microsoft® PowerPoint。	19.	增加音量。
9.	按 <Fn + F4> 開啟 Microsoft® Internet Explorer。	20.	開啟或關閉靜音模式。
10.	按 <Fn + F5> 開啟 Microsoft® Outlook。	21.	開啟 Windows® Media Player。
11.	按 <Fn + F6> 開啟 Windows® Internet Explorer 中的我的最愛。	22.	開啟 Windows® Media Center。












這些特殊功能按鍵只能在 Windows® Vista / Windows® 7 作業系統中使用。

華碩-Razer Arctosa 遊戲鍵盤



繁體中文

按鍵	功能
1. 	播放或暫停一個媒體播放器。
2. 	停止播放一個媒體播放器。
3. 	返回上一軌。
4. 	跳至下一軌。
5. 	降低音量。
6. 	增加音量。
7. 	開啟或關閉靜音模式。
8. 	同時按下此鍵與 F1-F10 中任一鍵 切換各預設檔。



- 這些特殊功能按鍵只能在 Windows® Vista / Windows® 7 作業系統中使用。
- 請在使用前安裝鍵盤驅動程式。請登入 Razer 網站 www.razer.com 下載驅動程式。

BTC 6200C 鍵盤






按鍵	功能	按鍵	功能
1.	開啟睡眠狀態。按任意鍵喚醒您的電腦，返回上次工作狀態。	8.	增加音量。
2.	返回上一頁。	9.	開啟或關閉靜音模式。
3.	跳至下一頁。	10.	返回上一軌。
4.	開啟 Windows® Internet Explorer 預設主頁。	11.	播放或停止一個媒體播放器。
5.	開啟 Windows® Internet Explorer 的我的最愛。	12.	跳至下一軌。
6.	開啟預設郵件應用。	13.	停止一個媒體播放器。
7.	降低音量。		



- 這些特殊功能鍵無需安裝驅動程式就能在 Windows® ME / 2000 / XP / Vista / 7 作業系統中使用。若您使用的是 Windows® 98SE 作業系統，請登入 BTC 網站 www.btc.com.tw 下載驅動程式。
- 請在使用網路功能鍵之前先安裝 Microsoft® Internet Explorer 5.0 或更新版本。

華碩 KB34211 有線鍵盤



按鍵	功能
1. 	開啟或關閉音量靜音模式
2. 	降低系統音量
3. 	增強系統音量



這些特殊功能按鍵只能在 Windows[®] Vista / Windows[®] 7 操作系統中使用。

[illegible]

第五章

網路連線

有線連接

使用 RJ-45 網路線將您的電腦與 DSL/Cable modem 或區域網路相連 (LAN)。

透過 DSL/Cable modem 連接網路


請按照以下步驟透過 DSL/Cable modem 連接網路：

1. 設定您的 DSL/cable modem。



請參閱您的 DSL/Cable modem 手冊。

2. 將 RJ-45 網路線的一端連接至電腦後面板的 LAN (RJ-45) 連接埠，另一端連接至 DSL/Cable modem。



3. 開啟 DSL/Cable modem 與您的電腦。
4. 進行所需網路連接設定。




更多關於網路設定的資訊與支援請洽詢您的網路服務提供商 (ISP)。

透過區域網路連接網路 (LAN)

請按照以下步驟透過區域網路連接網路：

1. 將 RJ-45 網路線的一端連接至電腦后面板的 LAN (RJ-45) 連接埠，另一端連接至區域網路。



2. 啟動您的電腦。
3. 進行所需網路連接設定。




更多關於網路設定的資訊與支援請洽詢您的網路管理員。

無線連接（選配）

透過無線將您的電腦與網路連接。



您需要連接一個無線存取點來建立無線連接。



- 請將外接天線連接至華碩無線網路卡的天線連接埠，以增強無線電訊號的接收範圍與靈敏度。
- 請將天線放置於電腦頂部以獲得最佳無線效能。
- 外接天線為選購配備。

請按照以下步驟連接無線網路：

1. 在通知區域中點選網路圖示  顯示可連線的無線網路。
2. 選擇您想要連接的無線網路，然後點選 **連線**。
3. 若要連接加密的無線網路，您需要輸入網路安全金鑰，然後點選 **確定**。
4. 您的電腦正在連接無線網路，請稍候。
5. 連線成功。畫面中顯示連接狀態，網路圖示  顯示已連線狀態。

[illegible]

第六章

使用應用程式（選配）



驅動程式與公用程式光碟以及回復光碟可能不包含於包裝內容。您可以自行燒錄這兩張光碟。請參考「回復您的系統」獲得更多資訊。

華碩 AI Manager

華碩 AI Manager 是一款提供您快速便捷作業的電腦常用應用程式。

安裝 AI Manager

請依照以下的步驟，安裝 AI Manager：

1. 於光碟機中放入驅動與公用程式光碟，若您有開啟自動播放功能，則會立即顯示驅動程式安裝精靈畫面。



如果自動播放功能為被開啟，請在驅動及公用程式光碟中的 ASUS AI Manager 檔案夾裡雙按 setup.exe 主程式以開啟此功能。

2. 點選 Utilities（工具程式）標籤，然後點選 ASUS AI Manager。
3. 依照畫面的指示，進行安裝。



根據軟體版本的不同，軟體安裝介面與使用方法可能略有不同。

啟用 AI Manager

欲開啟 AI Manager，請從 Windows 系統的桌面左下角點選 **開始 > 程式集 > ASUS > AI Manager > AI Manager 1.xx.xx**。後，則 AI Manager 會快速啟動並顯示捷徑列（Quick Bar，如下圖）。



在開啟應用程式後，AI Manager 的小圖示將會顯示在 Windows 桌面下方的工作列中（如右圖）。






使用滑鼠右鍵點選這個圖示，可以在捷徑列與主應用程式之間切換，而且您也可以透過捷徑列或 Windows 工作列中的 AI Manager 小圖示來啟動 AI Manager。



AI Manager 捷徑列 (Quick Bar)

AI Manager 捷徑列的設計為節省桌面空間，並讓您快速開啟華碩工具程式與顯示系統資訊。點選在工具列上的主應用程式、我的最愛、技術支援或系統資訊項目來顯示該項目的選項。



點選放到最大/還原鈕  可以在全螢幕與捷徑列之間做切換；點選縮到最小鈕  則可以將 AI Manager 保留在桌面下方的工具列中；點選關閉鈕  則會離開 AI Manager 程式。

主應用程式 (Main)

主應用程式畫面中提供以下幾個工具程式：AI Disk、AI Security 與 AI Probe。點選主應用程式畫面上的箭頭小圖示來瀏覽主應用程式中的各個工具程式項目。

AI Disk

AI Disk 可讓您很輕鬆地選擇如下圖中的清除網際網路的暫存檔案、清除網際網路的 Cookies、清除資源回收筒的檔案、清除最近存取的 URL(S)、清除網站的瀏覽記錄或清除最近開啟的檔案清單項目。在捷徑列上點選 AI Disk 小圖示開啟 AI Disk 畫面，您可以在這裡選擇您所要清除的項目。完成時請點選 套用。

AI Security

AI Security 提供您設定密碼來保護您的裝置如 USB 隨身磁碟、CD\DVD，以防止未經授權下被他人盜取資料。

請依照以下步驟進行裝置的加密：

1. 第一次使用 AI Security 時，您會被要求輸入一組新密碼，請輸入一組最多不超過 20 個字母數字或符號組合而成的密碼。
2. 再次輸入新密碼。
3. 輸入新密碼的提示（建議）。
4. 當完成時，請點選 確定。
5. 接著如下圖，選擇您所要進行加密的裝置，然後點選 套用。
6. 輸入您事先設定的密碼，然後點選 確定。則此一被選擇的裝置就會變成已加密且無法存取。

若要將已加密的裝置解除，請依照以下步驟進行：

1. 請取消勾選已加密的裝置名稱，然後點選 套用。
2. 輸入您事先已經設定的密碼，然後點選 確定。該裝置就會變成解除加密的狀態。

欲變更密碼，則請依照以下步驟進行：

點選 修改密碼，然後依照畫面的指示進行變更。

AI Booting

AI Booting 提供您設定開機裝置的優先次序。

請依照以下步驟指定開機順序：

1. 選擇一個裝置，然後點選下方左邊或右邊的按鈕以排定開機順序。
2. 當完成選擇後，請點選 套用。

AI Probe

AI Probe 會自動偵測並顯示主機板與 CPU 的溫度、CPU 風扇的轉速，以及輸出的電壓，您也可以在此調整您所需要的數值。

點選溫度、電壓或風扇轉速標籤頁，然後選擇其中一項來開啟或變更您所要的數值。

我的最愛

在 我的最愛 項目中提供您加入常用的應用程式，保留給您自行從電腦中加入您所要的應用程式項目。

請依照以下步驟加入我的最愛應用程式：

1. 點選 加入，然後找到您所要增加至 我的最愛 中的應用程式。
2. 點選 開啟 檔案所在的視窗位置，應用程式將會增加到 我的最愛 中。
在該應用程式小圖示上使用滑鼠右鍵點選，則可以進行開啟、移除該應用程式，或變更名稱，您也可以使用滑鼠左鍵雙按以開啟該程式。

技術支援

在 技術支援 選單畫面中，您可以點選相關的連結來連線至華碩電腦-全球網站、華碩電腦-線上技術支援網站、華碩電腦-線上檔案下載網站或華碩電腦-聯絡資訊。

系統資訊

點選 系統資訊 選單可以看到關於您的系統、主機板、處理器、BIOS、安裝的裝置與記憶體的相关資訊。

華碩 EPU-4 Engine

華碩 EPU-4 Engine 可偵測當前電腦負載，並智能地實時調節電量，為系統提供一套完整的節能方案。它自動調整 CPU、顯卡、硬盤與 CPU 風扇的用電量。EPU-4 Engine 提供了三種用電模式：自動（最佳省電）（Auto）、高效能（High Performance）與最佳省電（Maximum Power Saving）模式，您可依據自己的使用情況選擇。



關於三種模式的詳細信息，請參考“華碩 EPU-4 主頁”部分的詳細說明。

安裝華碩 EPU-4

請依據以下步驟安裝 EPU-4 Engine：

1. 將驅動程序與應用程序光碟放入光碟機。若您的電腦打開了“自動播放”功能。則“驅動程序”選單自動出現。



若“自動播放”功能未打開，您可以到驅動程序與應用程序光碟中的 ASUS EPU-4 Engine 文件夾中雙擊 setup.exe 文件。

2. 點擊【ASUS EPU-4 Engine】。
3. 然後依據屏幕指示完成安裝。

打開華碩 EPU-4

請依據以下步驟打開華碩 EPU-4：

1. 在 Windows 任務欄中雙擊 ASUS EPU-4 圖標。



2. 當您第一次打開華碩 EPU-4 時，會出現一條信息，請您校準 EPU 功能。

點擊【校準】，開始校準，請等待幾秒。然後 ASUS EPU-4 主頁出現。



進行校準可使系統偵測 CPU 屬性，以獲得最佳的電能管理方案。

華碩 EPU-4 主頁



- 1 CPU 狀態
顯示當前 CPU 功率與 CPU 節能總量。

- 2 VGA 卡狀態
顯示顯卡狀態。若主板不兼容您的顯卡，會出現“找不到可支持的顯卡”信息。



請訪問 http://event.asus.com/mb/EPU-4_Engine/ 獲取華碩支持 EPU-4 功能的顯卡列表。

3 硬盤狀態
當節能模式激活時，此處亮起。

4 風扇狀態
顯示風扇狀態。

5 CO2 減少排放量按鈕
顯示 CO2 的當前減少排放量或減少排放總量。

6 模式屬性
顯示每種模式的屬性。

7 離開按鈕
關閉華碩 EPU-4 應用程序。




8 校準按鈕
允許系統偵測硬件屬性，以取得最佳電能使用方案。

9 設置按鈕
點擊此按鈕進行模式設置。



詳細信息請參考“設置模式”部分的詳細說明。

10 模式



	自動（最佳省電）模式 當您選擇此模式，系統依據當前系統狀態自動變更用電模式。
	高效能模式 當您選擇此模式，系統元件將超頻到最大性能。
	最佳省電模式 當您選擇此模式，系統自動為重要元件即時調整最佳用電方案，以節省電能。

設置模式

請依據以下步驟設置模式：

1. 在華碩 EPU-4 主頁中，點擊【設置】打開“Setting”畫面。



2. 點擊  來設置“高效能”模式。點擊  來設置“最佳省電”模式。
3. 依據您主板上使用的 CPU 通過以下一種方式進行設置：
 - vCore 降低：降低 CPU vCore 電壓。
 - 低：使電壓降低到最低。
 - 中：使電壓降低到中等水平。
 - 高：使電壓達到 CPU 節能的最高水平。
 - 關閉硬盤：在特定的閒置時間後，系統將關閉硬盤。
 - CPU Loadline：設置 CPU 負載量，以使 CPU 節能。
 - 低：使 CPU 功率保持最小水平。
 - 中：使 CPU 功率保持中等水平。
 - 高：使 CPU 功率保持最大水平。
 - 關閉屏幕：在特定的閒置時間後，系統關閉屏幕，並進入睡眠模式。
4. 點擊【確定】應用設置。

華碩線上更新 (ASUS Update)

華碩線上更新程式是一套可以讓您在 Windows 作業系統下，用來管理、儲存與更新主機板 BIOS 檔案的公用程式。



- 在使用華碩線上更新程式之前，請先確認您已經透過內部網路對外連線，或者透過網際網路服務供應商 (ISP) 所提供的連接方式連線到網際網路。
- 隨主機板附贈的驅動程式與公用程式光碟中包含此公用程式。

安裝華碩線上更新程式

1. 將驅動程式與公用程式光碟放入光碟機，會出現 **驅動程式** 選單。
2. 點選 **公用程式** 標籤，然後點選 **安裝華碩線上更新程式**。
3. 華碩線上更新程式將被複製到您的系統中。



在您要使用華碩線上更新程式來更新 BIOS 程式之前，請先關閉其他所有的 Windows[®] 應用程式。

更新 BIOS 程式

1. 點選 **開始 > 程式集 > ASUS > ASUS Update > ASUS Update** 執行華碩線上更新主程式。
2. 在下拉式選單中點選下列作業之一：

使用網路更新 BIOS 程式

- a. 選擇 **Update BIOS from the Internet**，然後按下 **Next** 繼續。
- b. 請選擇離您最近的華碩 FTP 站台可避免網路堵塞，或者您也可以直接選擇 **Auto Select** 由系統自行決定。按下 **Next** 繼續。
- c. 接著再選擇您欲下載的 BIOS 版本。按下 **Next** 繼續。



華碩線上更新程式可以自行透過網路下載 BIOS 程式。經常的更新才能得到最新的功能。

使用 BIOS 檔案更新 BIOS 程式

- a. 在下拉式選單中選擇 **Update BIOS from a file**，然後按下 **Next** 繼續。
 - b. 在 **開啟** 視窗中選擇 BIOS 檔案的所在位置，然後點選 **開啟**。
3. 最後再依照螢幕畫面的指示來完成 BIOS 更新的程式。

華碩 MyLogo2™

華碩 MyLogo2™ 應用程式使您能夠客製化啟動圖示。啟動圖示會在開機自我檢測時出現。華碩 MyLogo2™ 會在您安裝華碩線上更新程式時一並安裝到您的系統。



- 請造訪華碩官網 www.asus.com 獲取最新 BIOS 檔案。
- 您可以將檔案存成 GIF 格式作為啟動圖示。

請按照以下步驟進入華碩 MyLogo2™：

1. 執行華碩線上更新程式。請參閱「華碩線上更新」一節。
2. 選擇下拉選單中的選項，然後點選 下一步。
3. 在更新 BIOS 之前請先執行 MyLogo 來置換系統啟動圖示。
4. 在下拉選單中選擇 以檔案更新 BIOS 然後點選 下一步。
5. 按照提示找到新的 BIOS 檔案，然後點選 下一步。華碩 MyLogo 視窗即在螢幕上出現。
6. 在視窗的左面板找到您想要用來作為啟動圖示的圖示，點選 下一步。
7. 在 Ratio 下拉選單中選擇您想要的圖示大小，點選 下一步。
8. 系統開始更新 BIOS，並載入新的啟動圖示。
9. 更新完成後，系統將重新啟動，並在開機自我檢測時顯示新圖示。

安裝 Nero（以 Nero 9 為例）

請按照以下步驟安裝 Nero 9：

1. 將 Nero 9 驅動程式光碟插入光碟機。
2. 若您的電腦有自動播放功能，螢幕上會自動跳出主選單。



若您的電腦沒有自動播放功能，請雙按 Nero 9 光碟根目錄下的 SetupX.exe 安裝檔案。

3. 在主選單中點選 Nero 9 Essentials。
4. 選擇安裝精靈的語言，然後點選 下一步。
5. 點選 下一步 繼續。
6. 勾選 我接受授權條款，完成後點選 下一步。
7. 選擇 典型，然後點選 下一步。
8. 勾選 是，我想傳送匿名應用程式資料給 Nero，協助進行改善，然後點選 下一步。
7. 選擇“典型”，然後點擊【下一步】。
8. 勾選“是，我想通過向 Nero 傳送匿名應用程序數據以提供幫助”，然後點擊【下一步】。
9. 完成後點擊【退出】。

燒錄文件

請參考以下步驟燒錄文件：

1. 在主選單中點擊【數據燒錄】>【添加】。
2. 選擇您想要燒錄的文件，點擊【添加】。
3. 選擇您想要燒錄的文件後，點擊【燒錄】將已選文件燒錄至光碟。



更多關於 Nero 9 的使用方法請訪問 Nero 網站 www.nero.com。

回復您的系統 (僅限預裝 Windows 作業系統的機型)

華碩個人電腦回復 DVD 光碟幫助您重灌作業系統並將其還原至預設工作狀態。



在回復過程中所有資料將會丟失。在回復系統前，請確認您已備份所有資料，並記錄下所有自訂設定，如網路設定。

請按照以下步驟回復您的電腦：

1. 開機時，當顯示 ASUS 標誌，請按下 <F8> 鍵進入 Please select boot device 選單。
2. 放入還原 DVD 光碟，然後選擇光碟機為開機裝置，按下 <Enter> 鍵，然後按任一鍵繼續。
3. 等待直至硬碟資訊畫面出現。選擇如何安裝一個新系統，選項有：

Recover System to a partition

本選項將會移除以下您所選擇的分割區 (Partition)，並允許您保留其他的既有分割區，以及創建一個新的分割區如磁碟 C。選擇一個分割區後，按 NEXT 繼續。

Recover Windows to entire HD

本項目將會回復整顆硬碟成為單一分割區，執行此項目將會覆蓋您硬碟內所有資料，並創建一個全新的分割區，如磁碟 C，選定後，並選擇 **Yes** 繼續。

4. 勾選 **我接受**，然後點選 **下一步**。
5. 接著請依照畫面上的指示，完成還原的動作。
6. 當完成系統還原時，畫面會顯示請您放入產品的驅動與應用程式 DVD 光碟，請放入後並按 **OK** 與重新開機。
7. 在電腦重新開機後，Windows® 7 系統將會開始進行系統設定。請按照畫面上的指示來完成安裝，然後會再重新開機。



華碩個人電腦回復 DVD 光碟僅能使用在本個人電腦，請勿任意使用於其他的電腦上。有關本產品的最新資訊，請上華碩網站 <http://tw.asus.com> 查詢。

快速回復系統

（僅限預裝 Windows 作業系統的機器，且隱藏分割區未破壞）

1. 開啟華碩個人電腦，當顯示 ASUS 標誌時，按下 <F9> 進入 System Recovery。
2. 此時畫面顯示 Windows is loading files。隨後，Recovery CD/DVD 視窗出現。
3. 按照螢幕上的說明完成回復過程。在系統重新開機後，顯示解析度與系統設定將回復為預設值。



無論您使用何種方法回復系統，請備份好電腦中的重要資料，以免資料丟失。

第七章

疑難解決

本章節為您提供您可能遇到的疑難的解決方法。

？ 我的電腦無法開機，並且前面板電源指示燈未亮起。

- 檢查您的電腦是否連接電源。
- 檢查牆上的電源插座是否可用。
- 檢查是否開啟電源。更多資訊請參閱第一章「開啟或關閉您的電腦」。

？ 我的電腦當機。

- 請按照以下步驟關閉無回應的程式：
 1. 同時按下 <Alt> + <Ctrl> + <Delete>，然後點選 工作管理員。
 2. 點選 應用程式。
 3. 選擇未響應程式，然後用鼠標右鍵點選 工作結束。
- 若鍵盤也無回應，請按住機殼頂部的電源按鈕直至電腦關閉。然後再按下電源按鈕重新啟動電腦。

？ 我無法使用華碩無線網路卡連接無線網路（僅限指定型號）。

- 請確認您為想要連接的無線網路輸入了正確的網路安全金鑰。
- 將外接天線（選購）連接至華碩無線網路卡上的天線連接埠，並將天線放置在機殼的頂部已獲得最佳無線效能。

？ 數字鍵盤區域的方向鍵不起作用。

請確認數字鎖定指示燈已關閉。當指示燈亮起時這些數字鍵僅被用於輸入數字；若您想要使用該區域中的方向鍵，請按下數字鎖定鍵關閉指示燈。

? 顯示器無法顯示。

- 請檢查顯示器是否開啟。
- 請確認您的顯示器與電腦上的視訊輸出連接埠正確相連。
- 若您的電腦內建獨立顯示卡，請確認您的顯示器與獨立顯示卡的視訊輸出連接埠相連。
- 請檢查顯示器視訊連接埠上的針腳是否彎曲。若您發現彎曲的針腳，請立即替換顯示器視訊連接埠接線。
- 請檢查您的顯示器是否正確連接電源。
- 更多疑難解決資訊請參考您的顯示器使用手冊。

? 使用多個顯示器時，僅一個顯示器能顯示。

- 請確認這些顯示器電源已開啟。
- 在開機自我檢測時僅連接至 VGA 連接埠的顯示器可以顯示。雙顯示功能僅在 Windows 系統中適用。
- 若您的電腦安裝了顯示卡，請確認將顯示器連接至顯示卡的輸出連接埠。
- 請檢查多個顯示器是否正確設定。更多資訊請參閱第三章「連接多個外接顯示器」。


? 我的電腦無法偵測 USB 儲存裝置。

- 當您第一次將 USB 儲存裝置與電腦相連時，Windows 會自動安裝它的驅動程式。完成後請點選進入 **電腦** 來檢查是否偵測到 USB 儲存裝置。
- 將您的 USB 儲存裝置連接至另一台電腦來檢測此 USB 儲存裝置是否損壞。

? 我想要還原或撤銷對電腦系統的更改，同時不影響我的個人檔案或資料。

Windows® 系統還原功能允許您還原或撤銷對電腦系統的更改，同時不影響您的個人檔案或資料如文檔或圖片。更多資訊請參閱第二章「還原您的電腦」。

？ 高畫質電視上的圖像變形。（由於機型不同，系統功能也會有差異）

- 您的顯示器或高畫質電視的不同解析度會導致圖像變形。請調整螢幕解析度至適合您的高畫質電視。請按照以下步驟改變您的螢幕解析度：
 1. 請參考以下任意一項打開螢幕解析度設定；
 - 點選  > 控制台 > 個人化 > 顯示 > 改變顯示器設定。
 - 用鼠標右鍵點選桌面。選單出現後，點選 個人化 > 顯示 > 改變顯示器設定。
 2. 調整解析度。相關資訊請參閱您的高畫質電視的使用手冊。
 3. 點選 套用 或 確定。然後在確認資訊中點選 保留變更。

？ 我的喇叭沒有聲音。

- 請確認您將您的喇叭連接至前面板或後面板的音效輸出埠（草綠色）。
- 請確認您的喇叭是否連接電源並開啟。
- 調節喇叭的音量。
- 請確認您沒有啟動靜音模式。
- 若您啟動靜音，音量圖標將顯示為 。若要開啟系統聲音，請點選通知區域的 ，然後點選 。
- 若沒有啟動靜音，點選  滑動卷軸調節音量。
- 將您的喇叭與另一台電腦相連測試它是否正常運作。

？ DVD 光碟機無法讀取光碟。

- 請確認光碟是以標籤面朝上放入光碟機。
- 請確認光碟是否正確放入托盤，尤其是非標準大小的光碟。
- 請檢查光碟是否有所掛上或損壞。

？ DVD 光碟機退出按鈕不起作用。

1. 點選  > 電腦。
2. 用滑鼠右鍵點選 ，然後在選單中點選 離開。

華碩的連絡資訊

華碩電腦公司 ASUSTeK COMPUTER INC. (台灣)

市場訊息

地址：台灣臺北市北投區立德路 15號

電話：+886-2-2894-3447

傳真：+886-2-2890-7798

電子郵件：info@asus.com.tw

全球資訊網：http://tw.asus.com

技術支援

電話：+886-2-2894-3447

(0800-093-456)

線上支援：http://support.asus.com/
techserv/techserv.aspx

華碩電腦公司 ASUSTeK COMPUTER INC. (亞太地區)

市場訊息

地址：台灣臺北市北投區立德路 15號

電話：+886-2-2894-3447

傳真：+886-2-2890-7798

電子郵件：info@asus.com.tw

全球資訊網：http://tw.asus.com

技術支援

電話：+86-21-38429911

傳真：+86-21-58668722, ext. 9101#

線上支援：http://support.asus.com/
techserv/techserv.aspx

ASUS COMPUTER INTERNATIONAL (美國)

市場訊息

地址：800 Corporate Way, Fremont,
California 94539, USA

電話：+1-510-739-3777

傳真：+1-510-608-4555

全球資訊網：http://usa.asus.com

技術支援

電話：+1-812-282-2787

傳真：+1-812-284-0883

線上支援：http://support.asus.com/
techserv/techserv.aspx

ASUS COMPUTER GmbH (德國/奧地利)

市場訊息

地址：Harkortstr. 21-23, 40880 Ratingen,
Germany

傳真：+49-2102-959911

全球資訊網：http://www.asus.de

線上連絡：http://www.asus.de/sales (僅
回答市場相關事務的問題)

技術支援

電話：+49-1805-010923 (配件) *

電話：+49-1805-010920 (系統 / 筆記型
電腦 / 易家族 / LCD) *

傳真：+49-2102-9599-11

線上支援：http://support.asus.com/
techserv/techserv.aspx

* 使用德國座機撥打每分鐘話費為 0.14 歐元，使用行動電話撥打每分鐘話費為 0.42 歐元。

华硕台式电脑 CM1730 用户手册

简体中文



C6444

第一版

2011 年 3 月

版权所有 • 不得翻印 © 2011 华硕电脑

本产品的所有部分，包括配件与软件等，其相关知识产权等归华硕电脑公司（以下简称华硕）或授权华硕使用的相关主体所有，未经权利主体许可，不得任意地仿制、拷贝、摘抄或转译。本用户手册没有任何形式的担保、立场表达或其它暗示。若有任何因本用户手册或其所提到之产品信息，所引起直接或间接的数据流失、利益损失或事业终止，华硕及其所属员工恕不为其担负任何责任。除此之外，本用户手册所提到的产品规格及信息只作参考，内容亦会随时更新，恕不另行通知。

下列因素导致的产品故障或损坏不在免费保修范围内：

- A. 因天灾(水灾、火灾、地震、雷击、台风等)、遇不可抗拒外力或人为之操作使用不慎造成之损害。
- B. 自行拆装、修理、或将产品送至非华硕认证之维修点进行检测维修。
- C. 用户擅自或请第三人修改、修复、变更规格及安装、添加、扩充非本公司原厂销售、授权或认可之配件所引起之故障与损坏。
- D. 因用户自行安装软件及设置不当所造成之使用问题及故障。
- E. 计算机病毒所造成之问题及故障。
- F. 本公司保修识别标签撕毁或无法辨认，涂改保修服务卡或与产品不符。
- G. 要求华硕提供软件安装服务(用户需自行提供原版软件)、软件故障排除或清除密码等。
- H. 其它不正常使用所造成之问题及故障。

用户手册中所谈论到的产品名称仅做识别之用，而这些名称可能是属于其他公司的注册商标或是版权。

关于产品规格最新的升级信息请您到华硕的官方网站浏览或是直接与华硕公司联络。

目录内容

注意事项 134
 安全性须知 136
 提示符号 137
 哪里可以找到更多的产品信息 137
 包装内容 138

第一章 系统导览
 欢迎 140
 了解您的台式机 140
 安装您的台式机 144
 开启或关闭您的电脑 147

第二章 使用 Windows® 7（选配）
 第一次启动 148
 使用 Windows® 7 桌面 149
 管理文件与文件夹 151
 还原您的系统 153
 保护您的电脑 154
 进入 Windows® 帮助和支持 155

第三章 设备连接
 连接 USB 存储设备 156
 连接麦克风与喇叭 157
 连接多个外接显示器 160
 连接高清电视 HDTV 162

第四章 使用您的电脑
 使用电脑时的适当姿势 164
 使用读卡器 165
 使用光驱 166
 使用多媒体键盘（仅限指定型号） 167

第五章 网络连接
 有线连接 172
 无线连接（选配） 174

目录内容

第六章 使用应用程序（选配）

华硕 AI Manager	176
华硕 EPU-4 Engine	179
华硕在线升级程序（ASUS Update）	183
华硕 MyLogo2™	184
Nero	185
恢复您的系统（仅限预装 Windows 操作系统的机器）	186

第七章 疑难解决

华硕台式电脑常见问题疑难排除快速指南	191
华硕的联络信息	193

注意事项

REACH

□遵守 REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) 管理规范, 我们会将产品中的化学物质公告在华硕 REACH 网站, 详情请参考 <http://csr.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

电池警告

注意：若更换了不正确电池可能会有爆炸的危险。请使用制造商推荐的同种或相同电池。请依照制造商的指示来处理使用过的电池。



电子信息产品污染控制标示：图中之数字为产品之环保使用期限。仅指电子信息产品中含有的有毒有害物质或元素不致发生外泄或突变从而对环境造成污染或对人身、财产造成严重损害的期限。

有毒有害物质或元素的名称及含量说明标示：

部件名称	有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六 价 铬 (Cr(VI))	多 溴 联 苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板及其电子组件	×	○	○	○	○	○
硬盘	×	○	○	○	○	○
光驱	×	○	○	○	○	○
外壳	×	○	○	○	○	○
电源适配器	×	○	○	○	○	○
外部信号连接头及线材	×	○	○	○	○	○
散热设备	×	○	○	○	○	○
中央处理器与内容	×	○	○	○	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。

×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求，然该部件仍符合欧盟指令 2002/95/EC 的规范。

备注：此产品所标示之环保使用期限，系指在一般正常使用状况下。

安全性须知



在清洁电脑之前，请先关机并移除电源与所有外围设备。您可以使用干净柔软的海绵或清洁布，沾上少许中性清洁剂与温水，来擦拭您的台式电脑，接着用干布擦去多余的水迹。

- 请勿将台式电脑放置于不平坦或不稳定的表面。若台式电脑的机箱损坏，请联络维修服务人员。
- 请勿在灰尘飞扬或环境脏乱的场所使用台式电脑。请勿在泄漏的可燃气体附近操作台式电脑。
- 请勿在台式电脑上放置其他物品。请勿将任何物品塞入电脑机件内，以避免引起机件短路或电路损毁。
- 请勿将台式电脑放置于具备强大电磁场的环境中。
- 请保持机器在干燥的环境下使用，雨水、湿气、液体等含有矿物质将会腐蚀电子线路。请勿在雷电天气下使用调制解调器。
- 电池安全警告：请勿将电池丢入火中。请勿将电池的正负极短路。请勿自行拆解电池。
- 请在温度为 5°C (41°F) 至 35°C (95°F) 之间的环境中使用本电脑。
- 请勿堵塞台式电脑的通风孔，以避免因散热不良而导致系统过热。
- 请勿使用破损的电源线、附件或其他外围设备。
- 为了防止电击风险，在搬动电脑主机之前，请先将电脑电源插头暂时从电源插座上拔除。
- 在使用电源适配器或电源延长线前，我们推荐您先寻求专业人士的协助。这些设备有可能会干扰接地的回路。
- 请确定电源的电压设置已调整到本国/本区域所使用的电压标准值。若您不确定您所属区域的供应电压值，请就近询问当地的电力公司人员。
- 如果电源已损坏，请不要尝试自行修复。请将其交给专业技术服务人员或经销商来处理。

提示符号

为了能够确保您正确地完成主板设置，请务必注意下面这些会在本手册中出现的标示符号所代表的特殊含意。



警告：提醒您在进行某一项工作时要注意您本身的安全。



小心：提醒您在进行某一项工作时要注意勿伤害到电脑主板元件。



重要：此符号表示您必须要遵照手册所描述之方式完成一项或多项软硬件的安装或设置。



注意：提供有助于完成某项工作的诀窍和其他额外的信息。

哪里可以找到更多的产品信息

您可以通过下面所提供的两个渠道来获得您所使用的华硕产品信息以及软硬件的更新信息等。










1. 华硕网站

您可以到 <http://www.asus.com.cn> 华硕网站取得所有关于华硕软硬件产品的各项信息。

2. 华硕本地技术支持

您可以到 <http://support.asus.com/contact> 华硕网站取得您所在地区的技术支持工程师的联系信息。

包装内容

		
华硕台式电脑	键盘 x1	鼠标 x1
		
电源线 x1	安装指南 x1	华硕保修服务卡 x1
		
Nero 9 刻录软件光盘 x1	驱动程序与应用程序光盘 (选配) x1 恢复光盘 (选配) x1	天线 (选配) x2



- 若包装内容有所损坏或丢失，请速与经销商联系。
- 上述图中所示物品仅供参考。实际产品规格及外观依不同型号而定。

第一章

系统导览

欢迎

感谢您购买华硕 CM1730 台式电脑。

华硕 CM1730 台式电脑拥有一流的性能，超凡的可靠性与以用户为中心的应用程序，并安装在华硕特别设计的机箱中。




请在安装您的机箱前先参阅您的华硕保修服务卡。

了解您的台式电脑




本手册中的机箱图片描述仅供参考。各接口及其位置，与外壳颜色均依不同机型而变。

主机前面板



1. USB 2.0 接口：可连接 USB 设备等，如鼠标、打印机、扫描仪、相机、PDA 等。
2. 麦克风接口：此接头可连接麦克风。
3. 耳机接口：该接口可连接耳机或喇叭。
4. 光驱弹出按钮：按此按钮弹出光盘。
5. Secure Digital™ / MultiMedia 卡槽：将 Secure Digital™ / MultiMedia 卡插入此槽。
- Memory Stick™ / Memory Stick Pro™ 卡槽：将 Memory Stick™ / Memory Stick Pro™ 卡插入此槽。
- Extreme Digital 卡槽：将 Extreme Digital 卡插入此插槽。
6. 电源按钮：按下此按钮启动您的电脑。
7. 光驱槽盖：此处有光驱。

后面板接口



1. 电压的选择：使用此开关以切换到适合您所在区域所使用的电压值。额定功率：115Vac/220-230Vac、7A/4A、60/50Hz。
2. 电源接口：将电源线连接至此接口。
3. 通风孔：进行空气流通。




请勿堵住通风孔。经常为您的电脑通风。

4. PS/2 键盘/鼠标接口（紫色）：可连接 PS/2 键盘或鼠标。
5. USB 2.0 接口：可连接 USB 设备等，如鼠标、打印机、扫描仪、相机、PDA 等。
6. 光纤 S/PDIF 数字音频输出接口：此端口通过光纤 S/PDIF 线缆连接外接音频输出设备。
7. HDMI 接口：连接 HDMI 设备。
8. DVI-D 接口：连接 DVI-D 兼容设备。
9. VGA 接口：可连接 VGA 兼容设备，如 VGA 显示器。
10. USB 2.0 接口：可连接 USB 设备等，如鼠标、打印机、扫描仪、相机、PDA 等。
11. USB 2.0 接口：可连接 USB 设备等，如鼠标、打印机、扫描仪、相机、PDA 等。
12. LAN (RJ-45) 接口：通过网络中心连接到一个局域网（LAN）。

网络指示灯说明

Activity/Link 指示灯		速度指示灯	
状态	描述	状态	描述
关闭	没有连接	关闭	连接速度 10Mbps
关闭	已连接	关闭	连接速度 100Mbps
闪烁	资料传输中	绿色	连接速度 1Gbps



13. 后置环绕喇叭接口（黑色）：本接口在四声道、六声道、八声道设置下是用来连接后置环绕喇叭。
14. 侧边环绕喇叭接口（灰色）：在八声道音频设置下，这个接口可以连接侧边环绕喇叭。
15. 麦克风接头（粉红色）：此接头连接至麦克风。
16. 音频输出接头（草绿色）：您可以连接耳机或喇叭等的音频接收设备。在四声道、六声道、八声道的喇叭设置模式时，本接头是作为连接前置主声道喇叭之用。
17. 中央声道与重低音喇叭接口（橘色）：这个接口可以连接中央声道与重低音喇叭。
18. 音频输入接头（浅蓝色）：您可以将磁带、CD、DVD 播放器等的音频输出端连接到此音频输入接头。



在 2、4、6、8 声道音频设置上，音频输出、音频输入与麦克风接头的功能会随着声道音频设置的变化而改变，如下表所示。

二、四、六或八声道音频设置

接头	耳机 / 二声道喇叭输出	四声道喇叭输出	六声道喇叭输出	八声道喇叭输出
浅蓝色	声音输入端	声音输入端	声音输入端	声音输入端
草绿色	声音输出端	前置喇叭输出	前置喇叭输出	前置喇叭输出
粉红色	麦克风输入端	麦克风输入端	麦克风输入端	麦克风输入端
橘色	-	-	中央重低音喇叭输出	中央重低音喇叭输出
黑色	-	后置喇叭输出	后置喇叭输出	后置喇叭输出
灰色	-	-	-	侧边喇叭输出

19. 华硕无线网卡（仅限已选型号）：此选配无线网卡允许您的电脑连接一个无线网络。
20. 华硕显卡（仅限已选型号）：在此选配的华硕显卡上的显示输出接口依型号而定。
21. 扩展卡插槽托架：安装扩展卡时移除扩展卡插槽托架。

安装您的台式机

该章节引导您连接主要硬件设备，例如外部显示器、键盘、鼠标以及电源线至您的电脑。

连接一个外部显示器

使用华硕显卡

将您的显示器连接至华硕独立显卡的显示输出接口。

请依照以下步骤使用华硕显卡连接一个外部显示器：

1. 将您的显示器连接至华硕独立显卡的显示输出接口。
2. 将显示器插上电源。



华硕独立显卡的显示输出接口随机型不同而改变。



使用内置显示输出接口

将您的显示器连接至内置显示输出接口。

请按照以下步骤使用内置显示输出接口连接一个外接显示器：


1. 讲一个 VGA 接口的显示器连接至 VGA 接口，或一个 DVI-D 接口的显示器连接至 DVI-D 接口，或一个 HDMI 接口的显示器连接至 HDMI 接口。
2. 将显示器连接至电源。



- 若您的电脑配有一张华硕显卡，则这张独立显卡在 BIOS 中被设为主显示设备。因此，请将您的显示器连接至独立显卡上的显示输出接口。
- 欲连接多个外接显示器至您的电脑，请参考第三章“连接多个外接显示器”部分的内容。


连接 USB 键盘与鼠标

将一个 USB 键盘与鼠标连接至后面板的 USB 接口。



连接电源线

将电源线的一端连接至后面板的电源接口，另一端插上电源。



开启或关闭您的电脑

本章节引导您在安装完成后如何开启或关闭您的电脑。

开启您的电脑



请按照以下步骤开启您的电脑：

1. 开启您的显示器。
2. 开启电源开关，然后按下电源按钮。



关闭您的电脑

请按照以下步骤关闭您的电脑：

1. 关闭所有运行着的程序。
2. 在 Windows® 桌面上点击 .
3. 点击  关闭操作系统。
4. 关闭电源开关。

第二章

使用 Windows[®] 7（选配）

第一次启动

若您的机器出厂预装了 Windows 7 操作系统，则您第一次启动电脑时，屏幕上会出现一系列画面以引导您进行 Windows[®] 7 操作系统的基本设置。

当电脑第一次启动时，请按以下步骤操作：

1. 启动您的电脑。等待几分钟直至“设置 Windows”画面出现。
2. 在下拉菜单中选择您想要的语言，然后点击【下一步】。
3. 在下拉菜单中选择您的国家或地区、时区、货币以及键盘布局，然后点击【下一步】。
4. 输入用户名与电脑名称，然后点击【下一步】。
5. 输入所需信息来设置您的密码，然后点击【下一步】。您也可以不输入任何信息，点击【下一步】跳过这一步。





若您想稍后为您的帐户设置密码，请参阅本章节“设置用户帐号及密码”。

6. 请仔细阅读许可条款。勾选“我愿意接受许可条款”，然后点击【下一步】。
7. 选择“使用推荐设置”或“仅安装重要更新”来为您的电脑进行安全设置。若您想要跳过这一步请选择“以后问我”。
8. 请再次检查一遍您的日期与时间设置，然后点击【下一步】。系统开始加载新设置并重新启动。您可以现在开始使用您的电脑。

使用 Windows® 7 桌面




点  **开始**  > **【帮助和支持】** 来获取更多信息。于 Windows® 7 操作系统的信息。

使用开始菜单

开始菜单允许您进入电脑上的程序或其它使用项目。它通过“帮助和支持”功能提供更多 Windows 7 的信息。

从开始菜单进入选项

请按照以下步骤由开始菜单进入选项：

1. 在 Windows 任务栏中点击开始图标 .
2. 在开始菜单中选择您想要进入的选项。




您可以将您常用的程序钉在开始菜单中成为一个小图标。更多信息请参阅本章节“在开始菜单或任务栏中添加程序”。

使用“入门”选项

开始菜单中的“入门”选项包括一些基本任务的信息，例如个性化 Windows®，添加新用户，传输文件等，帮助您更了解如何使用 Windows 7 操作系统。

请按照以下步骤使用“入门”：

1. 在 Windows 任务栏中点击开始图标  进入开始菜单。
2. 选择“入门”展开一系列任务选项。您也可以点击 **【开始】** > **【控制面板】** > **【入门】** 进入操作。
3. 选择您想要的任务选项。

使用任务栏

任务栏允许您进入以及管理已安装在您的电脑上的程序或选项。

从任务栏进入程序

请按照以下步骤从任务栏进入程序：

- 在任务栏中点击一个图标进入此程序。再次点击图标可隐藏此程序。



您可以将您常用的程序钉在开始菜单中成为一个小图标。更多信息请参阅本章节“在开始菜单或任务栏中添加程序”。

在快捷方式中添加选项

当您右击任务栏中的一个图标时，屏幕上会出现快捷方式以提供您快速进入该程序或选项的相关链接。您也可以将所需选项钉在快捷方式上，例如您喜爱的网站、经常浏览的文件夹、驱动程序或最近播放的媒体文件。

请按照以下步骤将选项钉在快捷方式：

1. 右击任务栏中的一个图标。
2. 在快捷方式中右击你想要钉入的选项，然后选择“将此程序锁定到任务栏”。


在快捷方式中删除选项

请按照以下步骤在快捷方式中删除选项：

1. 右击任务栏中的一个图标。
2. 在快捷方式中右击你想要删除的选项，然后选择“将此程序从任务栏解锁”。

在开始菜单或任务栏中添加程序

请按照以下步骤在开始菜单或工作列中新增程式：


1. 在 Windows 任务栏中点击开始图标  进入开始菜单。
2. 在开始菜单或任务栏中右击你想要钉入的选项。
3. 选择“锁定到任务栏”或“附到开始菜单”。



您也可以右击任务栏中一个正在运行的程序的图标，然后选择“将此程序锁定到任务栏”。

在开始菜单中删除程序

请按照以下步骤在开始菜单中删除程序：

1. 在 Windows 任务栏中点击开始图标  进入开始菜单。
2. 在开始菜单中右击你想要删除的程序。然后选择“从开始菜单解锁”。




在任务栏中删除程序

请按照以下步骤在任务栏中删除程序：

1. 在任务栏中右击你想要删除的程序。然后选择“将此程序从任务栏解锁”。


使用通知区域

默认的通知区域显示以下三种图标：

	<p>操作中心通知</p> <p>点击该图标显示所有警告信息或通知，以及进入 Windows[®] 操作中心。</p>
	<p>网络连接</p> <p>该图标显示有线/无线网络连接状态以及信号强度。</p>
	<p>音量</p> <p>点击此图标调节音量。</p>

显示通知

请按照以下步骤显示通知：

- 点击通知图标 ，然后点击第一行的“重要信息”打开。




更多信息请参阅本章节“Windows[®] 操作中心”。

自定义图标与通知

您可以选择在任务栏或通知区域显示或隐藏图标与通知。

请按照以下步骤自定义图标或通知：

1. 在通知区域点击箭头图标 。
2. 点击“自定义”。
3. 在下拉菜单中选择您想要自定义的图标或选项的行为。


管理文件与文件夹

使用 Windows[®] 浏览器

Windows[®] 浏览器允许您查看或管理您的文件与文档。

进入 Windows[®] 浏览器

请按照以下步骤进入 Windows[®] 浏览器：

1. 在任务栏中点击开始图标  进入开始菜单。
2. 点击【计算机】进入 Windows[®] 浏览器。


浏览文件与文件夹

请按照以下步骤浏览文件与文件夹：

1. 进入 Windows® 浏览器。
2. 在导航面板或视图面板中寻找所需数据的位置。
3. 在地址栏中点击箭头显示磁盘驱动器或文件夹。

自定义文件或文件夹视图

请按照以下步骤自定义文件夹预览方式视图：

1. 进入 Windows® 浏览器。
2. 在导航面板中选择您所需数据的位置。
3. 在工具栏中点击视图图标 。
4. 在视图菜单中滑动滑块选择你想要查看文件或文件夹的方式。



您也可以在视图面板上右击任何一处，在展开的选项中点击【查看】，并选择您想要查看文件或文件夹的方式。

排列您的文件（在 Windows 库文件夹下）

请按照以下步骤排列您的文件：

1. 进入 Windows® 浏览器。
2. 点击【排列方式】显示下拉菜单及选项。
3. 选择您想要的排列方式。

排序您的文件

请按照以下步骤排列您的文件：

1. 进入 Windows® 浏览器。
2. 在视图面板上右击任何一处。
3. 在出现的菜单中选择【排序方式】，然后选择您想要的排序方式。

分组您的文件

请按照以下步骤分组您的文件：

1. 进入 Windows® 浏览器。
2. 在视图面板上右击任何一处。
3. 在出现的菜单中选择【分组依据】，然后选择您想要的分组方式。

添加一个新文件夹

请按照以下步骤添加一个新文件夹：

1. 进入 Windows® 浏览器。
2. 在工具栏中点击【新建文件夹】。
3. 输入新文件夹名称。




您也可以在视图面板上右击任何一处，点击【新建】>【文件夹】。

备份文件

设置备份

请按照以下步骤设置备份：

1. 点击  > 【所有程序】> 【维护】> 【备份与还原】。
2. 点击【设置备份】，然后再点击【下一步】。
3. 选择备份文件的方位，点击【下一步】。
4. 选择“让 Windows 选择（推荐）”或“让我选择”。




若您选择“让 Windows 选择”，Windows 将不会备份 1GB 或以上的程序，FAT 格式文件，回收站文件或临时文件。

5. 按照屏幕出现的步骤完成设置。

还原您的系统

Windows 系统还原功能可能会创建还原点，在那里系统可以在特定时间或日期存储设置。此功能允许您还原或撤销您对系统设置的更改且不影响您的个人数据。

请按照以下步骤还原您的系统：

1. 关闭所有正在运行的程序。
2. 点击  > 【所有程序】> 【附件】> 【系统工具】> 【系统还原】。
3. 按照屏幕出现的步骤完成设置。

保护您的电脑

使用 Windows® 7 操作中心


Windows® 7 操作中心为您提供警告通知、安全信息、系统维护信息、自动疑难解决选项以及修复一些电脑常见问题。



您可以自行制定警告通知。更多信息请参阅本章节的“制定图标与通知”。

进入 Windows 7® 操作中心

请按照以下步骤进入 Windows® 7 操作中心：


1. 点击通知图标 ，再点击“打开操作中心”。
2. 在操作中心里点击您想要进行的操作。

使用 Windows® Update

Windows® Update 允许您检查与安装最近的更新内容，以增强电脑的安全与性能。

进入 Windows® Update

请按照以下步骤进入 Windows® Update：


1. 在 Windows® 任务栏中点击开始图标  进入开始菜单。
2. 选择【所有程序】>【Windows® Update】。
3. 在 Windows® Update 画面中点击您想要进行的操作。

设置用户帐户与密码

您可以为使用您电脑的用户设置帐户与密码。

设置用户帐户

请按照以下步骤设置用户帐户：

1. 在 Windows® 任务栏中点击  >【入门】>【添加新用户】。
2. 选择【管理其他帐户】。
3. 选择【创建一个新帐户】。
4. 输入新用户名称。
5. 选择“标准用户”或“管理员”作为用户类型。
6. 完成后点击【创建帐户】。

设置用户密码

请按照以下步骤设置用户密码：

1. 选择您想要设置密码的用户。
2. 选择“为您的帐户创建密码”。
3. 输入密码并确认。输入密码提示。
4. 完成后点击【创建密码】。

激活杀毒软件（视具体机型而定）


部分电脑预装了趋势科技网络安全程序（Trend Micro Internet Security）。它是一个第三方杀毒软件，保护您的电脑免受病毒侵袭。该软件需另行购买。在激活它之后您将会有一段时间的试用期，通常为 60 天。

请按照以下步骤激活趋势科技网络安全（Trend Micro Internet Security）：

1. 执行趋势科技网络安全（Trend Micro Internet Security）应用程序。
2. 仔细阅读许可条款，然后点击【同意并激活】。
3. 输入您的邮件地址并选择您的位置。点击【下一步】。
4. 点击【完成】结束激活。

进入 Windows® 帮助和支持

Windows® 帮助和支持提供您 Windows® 7 操作平台中使用应用程序的指导与解决方法。

点击  > 【帮助和支持】进入 Windows® 帮助和支持。



请确认您已连接网络以获得最新 Windows 在线帮助。


第三章

设备连接

连接 USB 存储设备

台式机的前后面板均有 USB2.0 接口。USB 接口允许您连接 USB 设备，例如存储设备。

欲连接 USB 存储设备，请将 USB 存储设备插入您的电脑。





前面板




后面板

请按照以下步骤移除 USB 存储设备：

1. 在 Windows 通知区域中点击  然后点击“弹出对应设备”。



2. 当出现“安全地移除硬件”信息后，将 USB 存储设备从电脑上移除。



请勿在数据传输过程中移除 USB 存储设备。这样做会导致数据丢失或损坏 USB 存储设备。


连接麦克风与喇叭

台式机的前后面板均有麦克风接口与喇叭接口。后面板的音频 I/O 接口允许您连接二、四、六、八声道立体声喇叭。


连接耳机与话筒




连接二声道喇叭




连接四声道喇叭



连接六声道喇叭



连接八声道喇叭



连接多个外接显示器

您的台式机视机型配置而定，可能配有 VGA、HDMI、DVI 等接口，允许您连接多个外接显示器。




当您的电脑安装好独立显卡后，将显示器接连至独立显卡输出接口。

设置多个显示器


当您连接多个显示器后，您可以设置显示模式。您可以让增加显示器与主显示器显示相同的内容，或作为主显示器的扩展显示器以扩展 Windows 桌面。

请按照以下步骤设置多个显示器：

1. 关闭您的电脑。
2. 将两个显示器与您的电脑相连，并将电源线连接至这两个显示器。请参阅第一章“设置您的电脑”获得更多连接显示器的方法。



对于某些显卡，仅被设为主要显示的显示器才能在开机自检时显示出来。双重显示功能只可在 Windows 操作系统中运行。


3. 启动您的电脑。
4. 请参考以下步骤打开“屏幕分辨率”进行设置：（由于机型不同，系统功能也会有差异，部分系统的控制面板中可直接看到【显示】选项，而没有【个性化】选项）
 - 点击  > 【控制面板】> 【个性化】> 【显示】> 【调整屏幕分辨率】。
 - 右击桌面，在随即出现的菜单中点击【个性化】> 【显示】> 【调整屏幕分辨率】。
5. 选择多个显示器的显示模式：下拉菜单
 - 复制这些显示：选择此项将添加的显示器作为主显示器的副本。
 - 扩展这些显示：选择此项将添加的显示器作为扩充显示器。这将增加您的电脑使用空间。
 - 只在1/2 上显示桌面：选择此项将仅在显示器 1或 2 上显示桌面。
6. 点击【应用】或【确定】。然后在确认信息画面上点击【保留更改】。

连接高清电视 HDTV

将高清电视机与您电脑上的 HDMI 接口相连。



- 您需要一根 HDMI 线将高清电视机与电脑相连。HDMI 线需另行购买。
- 为得到最佳显示效果，请确认您的 HDMI 线不长于 15 公尺。



第四章

使用您的电脑

使用电脑时的适当姿势

用户需要在使用电脑时保持适当的姿势，防止腕部，手以及其他关节或肌肉的损伤。本章节将为您提供一些小贴士，防止您在使用台式机时感到身体不适或受伤。




请参考以下几项保持适当姿势：

- 适当放置您的电脑椅，确保您的肘部平行于或略高于键盘，使得到舒适的打字位置。
- 调节座椅的高度，确保您的膝盖略高于您的臀部，使得您的大腿后侧得到放松。如有需要，请使用脚凳抬高您的膝盖。
- 调节座椅的后侧，使其完全支撑您的脊椎并且稍向后倾斜。
- 挺直坐正，使您的膝盖，肘部以及臀部成约 90 度。
- 将显示器放在您的正前方，将显示器顶部与您的视线持平，使您的视线稍向下。
- 使鼠标靠近键盘，如有需要，请使用肘托以缓解打字时肘部的压力。
- 请在舒适平整的地方使用您的台式机，避开光源，如窗或直射阳光。
- 使用一段时间后请稍作休息。

使用读卡器

数码相机或其他数码影像设备，都是采用存储卡来存储数码相片或媒体文件。视机型而定，本系统的前面板提供一部内置的多合一读卡器，让您可以随时插入这些存储卡来读取/写入数码文件。



请按照以下步骤使用存储卡：

1. 将存储卡插入卡槽。



- 由于存储卡上均有缺口设计，因此只能以一个固定方向插入。请勿将卡强制插入卡槽以免卡受到损伤。
- 您可以在一个或多个卡槽中插入存储卡，并逐一使用。请注意每个插槽只能插入一张存储卡。

3. 在“自动播放”窗口中选择一个程序来读取文件。



- 若您的电脑没有自动播放功能，请点击 Windows 7 任务栏中的开始按钮，选择【计算机】，然后双击存储卡图标进行数据读取。
- 每个卡槽均有自己的驱动程序图标，并显示在“计算机”目录下。
- 当数据被读取或写入存储卡时，读卡器显示灯会亮起或闪烁。

4. 完成后右击存储卡图标，点击【弹出】，然后移除存储卡。




请勿在读取、复制、格式化或删除存储卡数据时或之后立即移除存储卡，否则将可能导致数据丢失。



为了防止数据丢失，请在移除存储卡之前使用通知区域中的“安全移除硬件或弹出媒体光盘”。

使用光驱



放入光盘

请按照以下步骤放入光盘：

1. 系统开启时，按下光驱上的按钮退出光盘托盘。
2. 将光盘有印刷图案的那一面朝上放入。
3. 将托盘推入光驱中。
4. 在“自动播放”窗口中选择一个程序来读取文件。



若您的电脑没有自动播放功能，请点击 Windows 7 任务栏中的开始按钮，选择【计算机】，然后双击 CD/DVD 驱动图标进行数据读取。

退出光盘

请按照以下步骤退出光盘：

1. 系统开启时，按下光驱上的按钮退出光盘托盘。
 - 按下光驱上的【退出】按钮。
 - 右击“计算机”画面中的 CD/DVD 驱动程序图标，然后点击【弹出】。
2. 将光盘从托盘中取出。

使用多媒体键盘 (仅限指定型号)



键盘依型号而异。以下描述仅供参考。

华硕 SK-2045 键盘



按键	功能	按键	功能
1.	开启 Windows® 小工具。	12.	按 <Fn + F7> 开启 Microsoft® MSN，若没有安装 MSN，可直接开启下载页面。
2.	开启 Windows® Flip 3D。	13.	按 <Fn + F8> 开启 Windows® 搜索画面。
3.	在 Windows® Photo Viewer 中缩小照片尺寸。	14.	按 <Fn + F9> 播放或暂停 Windows® Media Player。
4.	在 Windows® Photo Viewer 中放大照片尺寸。	15.	按 <Fn + F10> 停止 Windows® Media Player。
5.	同时按下此键与 <F1> ~ <F12> 中任一键开启各种功能。	16.	按 <Fn + F11> 返回上一轨。
6.	按 <Fn + F1> 开启 Microsoft® Word。	17.	按 <Fn + F12> 跳至下一轨。
7.	按 <Fn + F2> 开启 Microsoft® Excel。	18.	降低音量。
8.	按 <Fn + F3> 开启 Microsoft® PowerPoint。	19.	增加音量。
9.	按 <Fn + F4> 开启 Microsoft® Internet Explorer。	20.	开启或关闭静音模式。
10.	按 <Fn + F5> 开启 Microsoft® Outlook。	21.	开启 Windows® Media Player。
11.	按 <Fn + F6> 开启 Windows® Internet Explorer 中的收藏夹。	22.	开启 Windows® Media Center。












这些特殊功能按键只能在 Windows® Vista / Windows® 7 操作系统中使用。

华硕-Razer Arctosa 游戏键盘



简体中文

按键	功能
1. 	播放或暂停一个媒体播放器。
2. 	停止播放一个媒体播放器。
3. 	返回上一轨。
4. 	跳至下一轨。
5. 	降低音量。
6. 	增加音量。
7. 	开启或关闭静音模式。
8. 	同时按下此键与 <F1> ~ <F10> 中任一键切换各默认档。



- 这些特殊功能按键只能在 Windows® Vista / Windows® 7 操作系统中使用。
- 请在使用前安装键盘驱动程序。请登录 Razer 网站 www.razersupport.com 下载驱动程序。

BTC 6200C 键盘



按键	功能	按键	功能
1.	开启睡眠状态。按任意键唤醒您的电脑，返回上次工作状态。	8.	增加音量。
2.	返回上一页。	9.	开启或关闭静音模式。
3.	跳至下一页。	10.	返回上一轨。
4.	开启 Windows® Internet Explorer 默认主页。	11.	播放或停止一个媒体播放器。
5.	开启 Windows® Internet Explorer 的收藏夹。	12.	跳至下一轨。
6.	开启默认邮件应用。	13.	停止一个媒体播放器。
7.	降低音量。		



- 这些特殊功能键无需安装驱动程序就能在 Windows® ME / 2000 / XP / Vista / 7 操作系统中使用。若您使用的是 Windows® 98SE 操作系统，请登录 BTC 网站 www.btc.com.tw 下载驱动程序。
- 请在使用网络功能键之前先安装 Microsoft® Internet Explorer 5.0 或更新版本。

华硕 KB34211 有线键盘



按键	功能
1. 	开启或关闭音量静音模式
2. 	降低系统音量
3. 	增强系统音量

这些特殊功能按键只能在 Windows[®] Vista / Windows[®] 7 操作系统中使用。

简体中文



第五章

网络连接

有线连接

使用 RJ-45 网络线将您的电脑与 DSL/Cable modem 或局域网相连 (LAN)。

通过 DSL/Cable modem 连接网络


请按照以下步骤通过 DSL/Cable modem 连接网络：

1. 设置您的 DSL/Cable modem。



请参阅您的 DSL/Cable modem 手册。

2. 将 RJ-45 网络线的一端连接至电脑后面板的 LAN (RJ-45) 接口，另一端连接至 DSL/Cable modem。



3. 打开 DSL/Cable modem 与您的电脑。
4. 进行所需网络连接设置。




更多关于网络设置的信息与帮助请咨询您的网络服务提供商 (ISP)。

通过局域网连接网络 (LAN)

请按照以下步骤通过局域网连接网络：

1. 将 RJ-45 网络线的一端连接至电脑后面板的 LAN (RJ-45) 接口，另一端连接至局域网。



2. 启动您的电脑。
3. 进行所需网络连接设置。




更多关于网络设置的信息与帮助请洽询您的网络管理员。

无线连接（选配）

通过无线将您的电脑与网络连接。





您需要连接一个无线接入点来建立无线连接。



- 请将外接天线连接至华硕无线网卡的天线接口，以增强无线电信号的接收范围与灵敏度。
- 请将天线放置于电脑顶部以获得最佳无线性能。
- 外接天线为选购配备。

请按照以下步骤连接无线网络：

1. 再通知区域中点击网络图标  显示可连接的无线网络。
2. 选择您想要连接的无线网络，然后点击【连接】。
3. 若要连接加密的无线网络，您需要输入网络安全密钥，然后点击【确定】。
4. 您的电脑正在连接无线网络，请稍候。
5. 连接成功。画面中显示连接状态，网络图标  显示已连接状态。

第六章

使用应用程序（选配）



驱动程序与公用程序光盘以及恢复光盘可能不包含于包装内容。您可以自行刻录这两张光盘。请参考“恢复您的系统”获得更多信息。

华硕 AI Manager

华硕 AI Manager 是一款快捷工具程序，可以让您更方便地操作您的电脑。



根据机型不同，安装的 AI Manager 可能实现的功能也会有差异。

安装 AI Manager

请依照以下的步骤，安装 AI Manager：

1. 于光驱中放入驱动与应用程序光盘，若您有开启“自动播放”功能，则会立即显示驱动程序安装向导画面。



如果欢迎窗口并未自动出现，那么您也可以到驱动及应用程序光盘中的 ASUS AI Manager 文件夹里直接点击 Setup.exe 主程序以开启菜单窗口。

2. 点击【应用程序】标签，然后点击【华硕 AI Manager】。
3. 依照画面的指示，开始安装。



根据软件版本的不同，软件安装界面与使用方法可能略有不同。

启用 AI Manager

欲开启 AI Manager，请从 Windows 系统的桌面左下角点击【开始】>【所有程序】>【ASUS】>【AI Manager】>【AI Manager 1.xx.xx.】后，则 AI Manager 会快速启动并显示快捷方式栏（Quick Bar，如下图）。



在开启应用程序后，AI Manager 的缩略图将会显示在 Windows 桌面下方的任务栏中（如右图）。






使用鼠标右键点击这个图标，可以在快捷方式栏与主应用程序之间切换，而且您也可以通过快捷方式栏或 Windows 任务栏中的 AI Manager 缩略图来启动 AI Manager。



AI Manager 快捷方式栏 (Quick Bar)

AI Manager 快捷方式栏的设计可节省桌面空间，且可以让您快速开启华硕工具程序与显示系统信息。点击快捷方式栏上的主应用程序、我的最爱、技术支持或系统信息项目来显示该项目的选项。



点击放到最大/还原按钮  可以在全屏与快捷方式栏之间做切换；点击缩到最小按钮  则可以将 AI Manager 保留在桌面下方的工具栏中；点击关闭按钮  则会离开 AI Manager 程序。

主应用程序 (Main)

主应用程序画面中提供数个工具程序：AI Disk、AI Security、AI Gear 与 AI Probe。点击主应用程序画面上的箭头缩略图来浏览主应用程序中的各个工具程序项目。

AI Disk

AI Disk 提供您轻松地选择下图中的清除网际网络的暂存文件、清除网际网络的 Cookies、清除资源回收筒的文件、清除最近存取的 URL(s)、清除网站的浏览记录或清除最近开启的文件列表项目。在快捷方式栏上点击 AI Disk 缩略图开启 AI Disk 画面，您可以在这里选择您所要进行清除的项目。当完成后请点击【应用】。

AI Security

AI Security 提供您设置密码来保护您的设备如 USB 随身磁碟、CD/DVD，以防止未经授权下被他们盗取资料。

请依照以下步骤进行设备的加密：

1. 当第一次使用 AI Security 时，您会先被要求输入一组新密码，请输入一组最多不超过 20 个字母数字或符号组合而成的密码。
2. 再次输入新的密码。
3. 输入新密码的提示（建议）。
4. 当完成时，请点击【确定】。
5. 如下图，选择您所要进行加密的设备，然后点击【应用】。
6. 输入您事先设置的密码，然后点击【确定】。该被选择的设备就会变成已加密且无法存取。

请依照以下步骤将已加密的设备解除：

1. 取消勾选已加密的设备名称，然后点击【应用】。
2. 输入您事先已经设置的密码，然后点击【确定】。该被选择的设备则会变成解除加密的状态。

欲更改密码，则请依照以下的步骤进行：

点击【修改密码】，然后依照画面的指示进行更改。

AI Booting

AI Booting 提供您设置开机设备的优先次序。

欲指定开机顺序，请依照以下步骤进行：

1. 选择一个设备，然后点击下方左边或右边的按钮以排定开机顺序。
2. 当完成选择后，请点击【应用】。

AI Probe

AI Probe 会自动侦测并显示主板与 CPU 的温度、CPU 风扇的转速，以及输出的电压，您也可以在此调整您所需要的数值。

点击“温度”、“电压”或“风扇转速”标签页，然后选择其中一项来开启或变更您所要的数值。（建议使用程序预设值）

我的最爱

在“我的最爱”项目中提供您加入常用的应用程序，保留给您自行从电脑中加入您所添加的应用程序项目。

请依照以下步骤，进行增加应用程序：

1. 点击【加入】，然后找到您所要添加至“我的最爱”中的应用程序。
2. 点击【开启】文件所在的窗口位置，应用程序将会添加到“我的最爱”中。

在该应用程序图标上使用鼠标右键点击，则可以进行开启、删除该应用程序，或更改名称，您也可以使用鼠标左键双击以开启该程序。

技术支持

在“技术支持”菜单画面中，您可以点击相关的连结来连接至华硕电脑-全球网站、华硕电脑-联机技术支持网站、华硕电脑-联机文件下载网站或华硕电脑-联络信息。

系统信息

点击【系统信息】菜单可以看到关于您的系统、主板、处理器、BIOS、安装的设备与内存的相关信息。

华硕 EPU-4 Engine

华硕 EPU-4 Engine 可侦测当前电脑负载，并智能地实时调节电量，为系统提供一套完整的节能方案。它自动调整 CPU、显卡、硬盘与 CPU 风扇的用电量。EPU-4 Engine 提供了三种用电模式：自动（最佳省电）（Auto）、高效能（High Performance）与最佳省电（Maximum Power Saving）模式，您可依据自己的使用情况选择。



关于三种模式的详细信息，请参考“华硕 EPU-4 主页”部分的详细说明。

安装华硕 EPU-4

请依据以下步骤安装 EPU-4 Engine：

1. 将驱动程序与应用程序光盘放入光驱。若您的电脑打开了“自动播放”功能。则“驱动程序”菜单自动出现。



若“自动播放”功能未打开，您可以到驱动程序与应用程序光盘中的 ASUS EPU-4 Engine 文件夹中双击 setup.exe 文件。

2. 点击【ASUS EPU-4 Engine】。
3. 然后依据屏幕指示完成安装。

打开华硕 EPU-4

请依据以下步骤打开华硕 EPU-4：

1. 在 Windows 任务栏中双击 ASUS EPU-4 图标。



2. 当您第一次打开华硕 EPU-4 时，会出现一条信息，请您校准 EPU 功能。
点击【校准】，开始校准，请等待几秒。然后 ASUS EPU-4 主页出现。



进行校准可使系统侦测 CPU 属性，以获得最佳的电能管理方案。

华硕 EPU-4 主页



1 CPU 状态
显示当前 CPU 功率与 CPU 节能总量。

2 VGA 卡状态
显示显卡状态。若主板不兼容您的显卡，会出现“找不到可支持的显卡”信息。






请访问 http://event.asus.com/mb/EPU-4_Engine/ 获取华硕支持 EPU-4 功能的显卡列表。

- 3 硬盘状态
当节能模式激活时，此处亮起。
- 4 风扇状态
显示风扇状态。
- 5 CO2 减少排放量按钮
显示 CO2 的当前减少排放量或减少排放总量。
- 6 模式属性
显示每种模式的属性。
- 7 离开按钮
关闭华硕 EPU-4 应用程序。
- 8 校准按钮
允许系统侦测硬件属性，以取得最佳电能使用方案。
- 9 设置按钮
点击此按钮进行模式设置。



详细信息请参考“设置模式”部分的详细说明。

10 模式



	<p>自动（最佳省电）模式</p> <p>当您选择此模式，系统依据当前系统状态自动变更用电模式。</p>
	<p>高效能模式</p> <p>当您选择此模式，系统元件将超频到最大性能。</p>
	<p>最佳省电模式</p> <p>当您选择此模式，系统自动为重要元件即时调整最佳用电方案，以节省电能。</p>

设置模式

请依据以下步骤设置模式：

1. 在华硕 EPU-4 主页中，点击【设置】打开“Setting”画面。



2. 点击  来设置“高效能”模式。点击  来设置“最佳省电”模式。
3. 依据您主板上使用的 CPU 通过以下一种方式进行设置：
 - vCore 降低：降低 CPU vCore 电压。
 - 低：使电压降低到最低。
 - 中：使电压降低到中等水平。
 - 高：使电压达到 CPU 节能的最高水平。
 - 关闭硬盘：在特定的闲置时间后，系统将关闭硬盘。
 - CPU Loadline：设置 CPU 负载量，以使 CPU 节能。
 - 低：使 CPU 功率保持最小水平。
 - 中：使 CPU 功率保持中等水平。
 - 高：使 CPU 功率保持最大水平。
 - 关闭屏幕：在特定的闲置时间后，系统关闭屏幕，并进入睡眠模式。
4. 点击【确定】应用设置。

华硕在线升级程序（ASUS Update）

华硕在线升级程序是一套可以让您在 Windows 操作系统下，用来管理、保存与更新主板 BIOS 文件的应用程序。



- 在使用华硕在线升级程序之前，请先确认您已经通过内部网络对外连接，或者通过互联网服务供应商（ISP）所提供的连接方式连接到互联网。
- 随主板附赠的驱动程序与应用程序光盘中包含此应用程序。

安装华硕在线升级程序

1. 将驱动程序与应用程序光盘放入光驱，会出现【驱动程序】菜单。
2. 点击【应用程序】标签，然后点击【安装华硕在线升级程序】。
3. 按照屏幕指示完成安装。



在使用华硕在线升级程序来升级 BIOS 程序之前，请先退出其他所有的 Windows® 应用程序。

升级 BIOS 程序

1. 点击【开始】>【程序】>【ASUS】>【ASUS Update】>【ASUS Update】运行华硕在线升级主程序。
2. 在下拉菜单中选择下列操作之一：

使用网络升级 BIOS 程序

- a. 选择【Update BIOS from the Internet】，然后按下【Next】继续。
- b. 请选择离您最近的华硕 FTP 站点可避免网络堵塞，或者您也可以直接选择【Auto Select】由系统自行决定。按下【Next】继续。
- c. 接着再选择您欲下载的 BIOS 版本。按下【Next】继续。



华硕在线升级程序可以自行通过网络下载 BIOS 程序。经常更新才能获得最新的功能。

使用 BIOS 文件升级 BIOS 程序

- a. 选择【Update BIOS from a file】，然后按下【Next】继续。
 - b. 在【打开】的窗口中选择 BIOS 文件的所在位置，然后点击【打开】。
3. 最后再依照屏幕画面的指示来完成 BIOS 更新的程序。



请您先将需要添加的 BIOS 文件下载，并解压缩放到您可以找到的位置。

华硕 MyLogo2™

华硕 MyLogo2™ 应用程序使您能够自定义启动图标。启动图标会在开机自检时出现。华硕 MyLogo2™ 会在您安装华硕在线升级程序时一并安装到您的系统。



-
- 请访问华硕官网 www.asus.com 获取最新 BIOS 文件。
 - 您可以将文件存成小于 150KB 的 GIF 格式作为启动图标。
-

请按照以下步骤进入华硕 MyLogo2™：

1. 运行华硕在线升级程序。请参阅“华硕在线升级”一节。
2. 选择下拉菜单中的选项，然后点击【下一步】。
3. 在升级 BIOS 之前请先运行【MyLogo】来置换系统启动图标。
4. 在下拉菜单中选择“以文件升级 BIOS”然后点击【下一步】。
5. 按照提示找到新的 BIOS 文件，然后点击【下一步】。华硕 MyLogo 窗口即在屏幕上出现。
6. 在窗口的左面板找到您想要用来作为启动图标的图标，点击【下一步】。
7. 在 Ratio 下拉菜单中选择您想要的图标大小，点击【下一步】。
8. 系统开始升级 BIOS，并加载新的启动图标。
9. 升级完成后，系统将重新启动，并在开机自检时显示新图标。

Nero

Nero 允许您建立、复制、刻录、编辑、共享以及更新不同类型的数据。

安装 Nero（以 Nero 9 为例）

请按照以下步骤安装 Nero 9：

1. 将 Nero 9 驱动程序光盘插入光驱。
2. 若您的电脑有自动播放功能，屏幕上会自动跳出主菜单。



若您的电脑没有开启“自动播放”功能，请双击 Nero 9 光盘根目录下的 SetupX.exe 安装文件。

3. 在主菜单中点击【Nero 9 Essentials】。
4. 选择安装向导的语言，然后点击【下一步】。
5. 点击【下一步】继续。
6. 勾选“我接受许可证条款”，完成后点击【下一步】。
7. 选择“典型”，然后点击【下一步】。
8. 勾选“是，我想通过向 Nero 传送匿名应用程序数据以提供帮助”，然后点击【下一步】。
9. 完成后点击【退出】。

刻录文件

请参考以下步骤刻录文件：

1. 在主菜单中点击【数据刻录】>【添加】。
2. 选择您想要刻录的文件，点击【添加】。
3. 选择您想要刻录的文件后，点击【刻录】将已选文件刻录至光盘。



更多关于 Nero 9 的使用方法请访问 Nero 网站 www.nero.com。

恢复您的系统

（仅限预装 Windows 操作系统的机器）

华硕台式机恢复 DVD 光盘帮助您重装操作系统并将其还原至出厂工作状态。



在恢复过程中所有数据将会丢失。在恢复系统前，请确认您已备份所有资料，并记录下所有自订设置，如网络设置。

请按照以下步骤恢复您的电脑：

1. 开机时，当显示 ASUS 标题画面，请点击 <F8> 键进入 Please select boot device 菜单。
2. 放入还原 DVD 光盘，然后选择光驱 ("CDROM:XXX") 为开机设备，点击 <Enter> 键，然后按任一键继续。
3. 等待直至硬盘信息画面出现。选择如何安装一个新系统，选项有：

Recover System to a partition

本选项将会删除以下您所选择的分区 (Partition)，并允许您保留其他的既有分区，以及创建一个新的分区如磁盘 "C"。选择一个分区后，按 NEXT 继续。

Recover Windows to entire HD

本项目将会还原整颗硬盘成为单一分区，运行此项目将会复盖您硬盘内所有数据，并创建一个全新的分区，如磁盘 "C"，选定后，并选择 Yes 继续。

4. 勾选“我接受”，然后点击【下一步】。
5. 接着请依照画面上的指示，完成还原的动作。
6. 当完成系统还原时，画面会显示请您放入产品的驱动与应用程序 DVD 光盘，请放入后并按 OK 与重新开机。
7. 在电脑重新开机后，Windows® 7 系统将会开始进行系统设置。请按照画面上的指示来完成安装，然后会再重新开机。



华硕个人电脑还原 DVD 光盘仅能使用在本台式电脑，请勿任意使用于其他的电脑上。有关本产品的最新信息，请上华硕网站 <http://www.asus.com.cn> 查询。

快速恢复系统

（仅限预装 Windows 操作系统的机器，且隐藏分区未破坏）

1. 开启华硕台式电脑，当显示 ASUS 标题画面时，按下 <F9> 进入 System Recovery。
2. 此时画面显示 Windows is loading files。随后，Recovery CD/DVD 窗口出现。
3. 按照屏幕上的说明完成还原过程。在系统重新开机后，显示分辨率与系统设置将还原为默认值。



无论您使用何种方法恢复系统，请备份好电脑中的重要数据，以免数据丢失。

第七章

疑难解决

本章节为您提供您可能遇到的疑难的解决方法。

？ 我的电脑无法开机，并且前面板电源指示灯未亮起。

- 检查您的电脑是否连接电源。
- 检查墙上的电源插座是否可用。
- 检查是否开启电源。更多信息请参阅第一章“开启或关闭您的电脑”。

？ 我的电脑死机。

- 请按照以下步骤关闭无回应的程序：
 1. 同时按下 <Alt> + <Ctrl> + <Delete>，然后点击【任务管理器】。
 2. 点击【应用程序】。
 3. 选择为回应程序，然后右击【结束任务】。
- 若键盘也无响应，请按住机箱顶部的电源按钮直至电脑关闭。然后再按下电源按钮重新启动电脑。

？ 我无法使用华硕无线网卡连接无线网络（仅限指定型号）。

- 请确认您为想要连接的无线网络输入了正确的网络安全密钥。
- 将外接天线（选购）连接至华硕无线网卡上的天线接口，并将天线放置在机箱的顶部已获得最佳无线性能。

？ 数字键区域的方向键不起作用。

请确认数字锁定指示灯已关闭。当指示灯亮起时这些数字键仅被用于输入数字；若您想要使用该区域中的方向键，请按下数字锁定键关闭指示灯。

? 显示器无法显示。

- 请检查显示器是否开启。
- 请确认您的显示器与电脑上的视频输出接口正确相连。
- 若您的电脑内置独立显卡，请确认您的显示器与独立显卡的视频输出接口相连。
- 请检查显示器视频端口上的针脚是否弯曲。若您发现弯曲的针脚，请立即替换显示器视频端口接线。
- 请检查您的显示器是否正确连接电源。
- 更多疑难解决信息请参考您的显示器使用手册。

? 使用多个显示器时，仅一个显示器能显示。

- 请确认这些显示器电源已开启。
- 在开机自检时仅连接至 VGA 接口的显示器可以显示。双显示功能仅在 Windows 系统中适用。
- 若您的电脑安装了显卡，请确认将显示器连接至显卡的输出接口。
- 请检查多个显示器是否正确设置。更多信息请参阅第三章“连接多个外接显示器”。


? 我的电脑无法侦测 USB 存储设备。

- 当您第一次将 USB 存储设备与电脑相连时，Windows 会自动安装它的驱动程序。完成后请点击进入“计算机”来检查是否侦测到 USB 存储设备。
- 将您的 USB 存储设备连接至另一台电脑来检测此 USB 存储设备是否损坏。





? 我想要恢复或撤销对电脑系统设定的更改，同时不影响我的个人文件或数据。

Windows® 系统还原功能允许您还原或撤销对电脑系统设置的更改，同时不影响您的个人文件或数据如文档或图片。建议您在恢复前备份重要数据资料，以免恢复异常带来不必要的损失。更多信息请参阅第二章“还原您的电脑”。

？ 高清电视上的图像变形。（由于机型不同，系统功能也会有差异）

- 您的显示器或高清电视的不同分辨率会导致图像变形。请调节屏幕分辨率至适合您的高清电视。请按照以下步骤改变您的屏幕分辨率：
- 请参考以下任意一项打开屏幕分辨率设置；
 - 点击  >【控制面板】>【个性化】>【显示】>【改变显示器设置】。
 - 右击桌面。菜单出现后，点击【个性化】>【显示】>【改变显示器设置】。（部份操作系统进入控制面板后没有【个性化】选项，可直接看到【显示】选项）
 - 调节分辨率。相关信息请参阅您的高清电视的使用手册。
 - 点击【应用】或【确定】。然后在确认信息中点击【保存更改】。


？ 我的喇叭没有声音。

- 请确认您将您的喇叭；连接至前面板货后面板的声输出端口（草绿色）。
- 请确认您的喇叭是否连接电源并开启。
- 调节喇叭的音量。
- 请确认您没有启动静音模式。
- 若您启动静音，音量图标将显示为 。若要开启系统声音，请点击通知区域的 ，然后点击 。
- 若没有启动静音，点击  滑动滚轴调节音量。
- 将您的喇叭与另一台电脑相连测试它是否正常运行。

？ DVD 光驱无法读取光盘。

- 请确认光盘是以标签面朝上放入光驱。
- 请确认光盘是否正确放入托盘，尤其是非标准大小的光盘。
- 请检查光盘是否有划伤或损坏。

？ DVD 光驱退出按钮不起作用。

- 点击  >【计算机】。
- 右击 ，然后在菜单中点击【退出】。

华硕台式电脑常见问题疑难排除快速指南

电源问题

不良现象描述	可能的问题	请用户确认
无电源 (电源指示灯不亮)	确认电源开关是否符合当地电压要求(110V/220V)	请自行调整符合当地的电压设置值 110V/220V
	确认电脑是否开机？	请按一下前置面板的电源键，确认是否能正常开机
	确认电源线是否接好？	先确认电脑的电源线是否有接好，确认看看是否有电源线是否有脱落，或改用其他产品附的电源线接在电脑上
	确认有没有尝试换过电源供应器	(如果具备拆装电脑能力且备有其他电源供应器的话) 请用户换电源供应器确认是否能正常开机

画面无法显示

不良现象描述	可能的问题	请用户确认
开机后无法显示任何画面（黑屏）	确认信号线确实接在电脑的输出接口	要确认显卡是外接还是内置的，若是外接的显卡，要用用户接在外接显卡上
	可能是信号线的问题	（如果有其他显示器的话）用其他显示器试试看，是否有画面

网络相关问题

不良现象描述	可能的问题	请用户确认
无法上网	网线没有正确接上	请确认把网线接上
	可能是网线的问题	确认网络孔灯号是否有亮，请换一条线测试，若还不行请送修
	确认是否有接 IP 分享器或 Hub 分接器	请购置或是确实连接妥当
	确认是否有跟网络运营商确认连接设置	请询问网络运营商关于设置信息
	是否为杀毒软件所引起	在确认安全状况下，关闭杀毒软件
	确认是否有重装过驱动程序	请重新安装网络驱动程序

音效相关问题

不良现象描述	可能的问题	请用户确认
没有声音	确认插入孔位是否正确	请按照说明书执行确认动作
	确认扬声器是否有重新插拔试过	请拔除并且重新插入扬声器。
	扬声器或耳机故障	请更换扬声器或耳机测试
	确认是否前后置音效输出接口都有测试过	请测试前后置音效输出接口，若只有一边无声音，请确认音效是否设为多声道，若不是请送修
	驱动程序是否有误	请重装音效驱动程序

执行速度变慢或当机相关问题

不良现象描述	可能的问题	请用户确认
OS 执行速度变慢	检查常驻程序是否太多	请关掉某些常驻程序测试看看
	是否为电脑一买来才刚开机	使用一段时间后发生的，有可能为电脑中毒，请杀毒或重装系统
使用中电脑常会死机	(主板有发出异音) 是否有换过或加装内存	有可能硬盘坏轨，换硬盘测试或送修。 请更换内存或把加装的内存拔掉测试。
	散热效果不佳	请移到较为通风环境测试
	是否有装了不相容的软件	请尝试重装 OS

无法启动微软金钥

不良现象描述	可能的问题	请用户确认
开机后停在启动金钥的画面	是否有自行更新过 BIOS	确认会不会更新到主板单板的 BIOS，请用户更新回华硕台式机专用的 BIOS 试试看
	金钥是否输入错误	请输入正确金钥，每组 5 个英文数字，共 5 组
	输入正确仍无法正常启动	请去电微软客服，请微软协助启动金钥，微软客服 (0800-008833)

华硕的联络信息

华硕电脑（上海）有限公司 ASUSTEK COMPUTER (SHANGHAI) CO., LTD（中国）

市场信息

地址：上海市闵行莘庄工业区春东路
508 号

电话：+86-21-54421616

传真：+86-21-54420099

互联网：<http://www.asus.com.cn/>

技术支持

电话：+86-21-34074610

(800-820-6655)

电子邮件：<http://www.asus.com.cn/email>

在线支持：<http://support.asus.com/techserv/techserv.aspx>

华硕电脑公司 ASUSTeK COMPUTER INC.（亚太地区）

市场信息

地址：台湾台北市北投区立德路15 号

电话：+886-2-2894-3447

传真：+886-2-2890-7798

电子邮件：info@asus.com.tw

互联网：<http://www.asus.com.tw>

技术支持

电话：+86-21-38429911

传真：+86-21-58668722, ext. 9101#

在线支持：<http://support.asus.com/techserv/techserv.aspx>

ASUS COMPUTER INTERNATIONAL（美国）

市场信息

地址：800 Corporate Way, Fremont,
California 94539, USA

电话：+1-510-739-3777

传真：+1-510-608-4555

互联网：<http://usa.asus.com>

技术支持

电话：+1-812-282-2787

传真：+1-812-284-0883

在线支持：<http://support.asus.com/techserv/techserv.aspx>

ASUS COMPUTER GmbH（德国/奥地利）

市场信息

地址：Harkort Str. 21-23, D-40880
Ratingen, Deutschland

传真：+49-2102-959911

互联网：<http://www.asus.de>

在线联络：<http://www.asus.de/sales>
(仅回答市场相关事务的问
题)

技术支持

电话：+49-1805-010923（配件）*

电话：+49-1805-010920（系统 / 笔
记本电脑 / 易家族 / LCD）*

传真：+49-2102-9599-11

在线支持：<http://support.asus.com/techserv/techserv.aspx>

* 使用德国固定电话拨打每分钟话费为 0.14 欧元，使用手机拨打每分钟话费为 0.42 欧元。