

Index

1. English
2. 繁体中文
3. 简体中文




ASUS Essentio Desktop PC

CP1130

User Manual

English



E5313

First Edition V1

January 2010

Copyright © 2010 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK Computer Inc. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Noticesv

Safety information..... vii

Conventions used in this guide..... viii

Where to find more information viii

Package contents ix

Chapter 1: Getting started

Welcome!..... 1-1

Getting to know your computer..... 1-1

Setting up your computer..... 1-5

Turning your computer ON/OFF 1-8

Chapter 2: Using Windows® 7

Starting for the first time..... 2-1

Using Windows® 7 desktop..... 2-2

Managing your files and folders..... 2-7

Restoring your system 2-10

Protecting your computer.....2-11

Getting Windows® Help and Support..... 2-15

Chapter 3: Connecting devices to your computer

Connecting a USB storage device..... 3-1

Connecting microphone and speakers 3-2

Connecting multiple external displays 3-5

Connecting an HDTV..... 3-7

Chapter 4: Using your computer

Proper posture when using your Desktop PC..... 4-1

Using the memory card reader 4-2

Using the optical drive 4-3

Using the multimedia keyboard (on selected models only) 4-4

Chapter 5: Connecting to the Internet

Wired connection 5-1

Wireless connection (on selected models only)..... 5-3

Contents

Chapter 6: Using the Utilities

ASUS AI Manager.....	6-1
ASUS EPU-4 Engine	6-6
ASUS Update	6-10
ASUS MyLogo2™	6-11
Nero 9	6-12
Recovering your system	6-16

Chapter 7: Troubleshooting

Notices

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://green.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

Lithium-Ion Battery Warning

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Safety information



Disconnect the AC power and peripherals before cleaning. Wipe the Desktop PC using a clean cellulose sponge or chamois cloth dampened with solution of nonabrasive detergent and a few drops of warm water then remove any extra moisture with a dry cloth.

- **DO NOT** place on uneven or unstable work surfaces. Seek servicing if the casing has been damaged.
- **DO NOT** expose to dirty or dusty environments. **DO NOT** operate during a gas leak.
- **DO NOT** place or drop objects on top and do not shove any foreign objects into the Desktop PC.
- **DO NOT** expose to strong magnetic or electrical fields.
- **DO NOT** expose to or use near liquids, rain, or moisture. **DO NOT** use the modem during electrical storms.
- Battery safety warning: **DO NOT** throw the battery in fire. **DO NOT** short circuit the contacts. **DO NOT** disassemble the battery.
- Use this product in environments with ambient temperatures between 0°C (32°F) and 35°C (95°F).
- **DO NOT** cover the vents on the Desktop PC to prevent the system from getting overheated.
- **DO NOT** use damaged power cords, accessories, or other peripherals.
- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Conventions used in this guide

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Instructions that you **MUST** follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.











ASUS websites

The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS website www.asus.com.

ASUS Local Technical Support

Visit ASUS website at <http://support.asus.com/contact> for the contact information of local Technical Support Engineer.

Package contents

		
ASUS Essentio Desktop PC	Keyboard x1	Mouse x1
		
Power cord x1	Support DVD x1	Recovery DVD x1
		
Nero 9 burning software DVD x1	Installation Guide x1	Warranty card x1
		
Antenna (optional) x2		



- If any of the above items is damaged or missing, contact your retailer.
- The illustrated items above are for reference only. Actual product specifications may vary with different models.

Chapter 1

Getting started

Welcome!

Thank you for purchasing the ASUS Essentio CP1130 Desktop PC!

The ASUS Essentio CP1130 Desktop PC provides cutting-edge performance, uncompromised reliability, and user-centric utilities. All these values are encapsulated in a stunningly futuristic and stylish system casing.




Read the ASUS Warranty Card before setting up your ASUS Desktop PC.

Getting to know your computer



Illustrations are for reference only. The ports and their locations, and the chassis color vary with different models.


Front panel



Click the number to view its corresponding description.

1. **Power button.** Press this button to turn on your computer.
2. **Optical disk drive eject button.** Press this button to eject the optical disk drive tray.
3. **Optical disk drive bay.** There is an optical disk drive in this bay.
4. **Microphone port (pink).** This port connects to a microphone.
5. **Headphone port (lime).** This port connects to a headphone or speaker.
6. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
7. **MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ card slot.** Insert a MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ card into this slot.
8. **Front I/O ports cover.**

Rear panel



Click the number to view its corresponding description.

1. **Air vents.** These vents allow air ventilation.




DO NOT block the air vents on the chassis. Always provide proper ventilation for your computer.

2. **Power connector.** Plug the power cord to this connector.
3. **Line Out port (lime).** This port connects to a headphone or speaker. In a 4, 6, or 8-channel configuration, the function of this port becomes Front Speaker Out.
4. **Microphone port (pink).** This port connects to a microphone.
5. **Side Speaker Out port (gray).** This port connects to the side speakers in an 8-channel audio configuration.
6. **Rear Speaker Out port (black).** This port connects to the rear speakers in a 4, 6, and 8-channel audio configuration.
7. **Line In port (light blue).** This port connects to a tape, CD, DVD player, or other audio sources.
8. **Center/Subwoofer port (orange).** This port connects to the center/subwoofer speakers.
9. **LAN (RJ-45) port.** This port allows Gigabit connection to a Local Area Network (LAN) through a network hub.

LAN port LED indications

Activity/Link LED		Speed LED	
Status	Description	Status	Description
OFF	No link	OFF	10Mbps connection
ORANGE	Linked	ORANGE	100Mbps connection
BLINKING	Data activity	GREEN	1Gbps connection

ACT/LINK SPEED



Refer to the audio configuration table below for the function of the audio ports in a 2, 4, 6, or 8-channel configuration.

Audio 2, 4, 6, or 8-channel configuration

Port	Headset 2-channel	4-channel	6-channel	8-channel
Light Blue	Line In	Line In	Line In	Line In
Lime	Line Out	Front Speaker Out	Front Speaker Out	Front Speaker Out
Pink	Mic In	Mic In	Mic In	Mic In
Orange	—	—	Center/Subwoofer	Center/Subwoofer
Black	—	Rear Speaker Out	Rear Speaker Out	Rear Speaker Out
Gray	—	—	—	Side Speaker Out

10. **USB 2.0 ports.** These Universal Serial Bus 2.0 (USB 2.0) ports connect to USB 2.0 devices such as a mouse, printer, scanner, camera, PDA, and others.
11. **VGA port.** This port is for VGA-compatible devices such as a VGA monitor.
12. **HDMI port.** This port is for a High-Definition Multimedia Interface (HDMI) connector, and is HDCP compliant allowing playback of HD DVD, Blu-ray, and other protected content.
13. **ASUS Graphics Card (on selected models only).** The display output ports on this optional ASUS Graphics Card may vary with different models.
14. **ASUS WLAN Card (on selected models only).** This optional WLAN card allows your computer to connect to a wireless network.

Setting up your computer

This section guides you through connecting the main hardware devices, such as the external monitor, keyboard, mouse, and power cord, to your computer.

Connecting an external monitor

Using the ASUS Graphics Card (on selected models only)

Connect your monitor to the display output port on the discrete ASUS Graphics Card.

To connect an external monitor using the ASUS Graphics Card:

1. Connect a monitor to a display output port on the ASUS Graphics Card.
2. Plug the monitor to a power source.



The display output ports on the ASUS Graphics Card may vary with different models.




Using the onboard display output ports

Connect your monitor to the onboard display output port.

To connect an external monitor using the onboard display output ports:

1. Connect a VGA monitor to the VGA port, or a DVI-D monitor to the DVI-D port, or an HDMI monitor to the HDMI port on the rear panel of your computer.
2. Plug the monitor to a power source.



- If your computer comes with an ASUS Graphics Card, the graphics card is set as the primary display device in the BIOS. Hence, connect your monitor to a display output port on the graphics card.
- To connect multiple external monitors to your computer, refer to **Connecting multiple external monitors** in Chapter 3 of this user manual for details.


Connecting a USB keyboard and a USB mouse

Connect a USB keyboard and a USB mouse to the USB ports on the rear panel of your computer.



Connecting the power cord

Connect one end of the power cord to the power connector on the rear panel of your computer and the other end to a power source.



Turning your computer ON/OFF

This section describes how to turn on/off your computer after setting up your computer.

Turning your computer ON

To turn your computer ON:

1. Turn your monitor ON.
2. Press the power button on your computer.



Power button



3. Wait until the operating system loads automatically.

Turning your computer OFF

To turn your computer OFF:

1. Close all running applications.
2. Click  on the Windows® desktop.
3. Click  to shut down the operating system.

Chapter 2

Using Windows® 7

Starting for the first time

When you start your computer for the first time, a series of screens appear to guide you in configuring the basic settings of your Windows® 7 operating system.

To start for the first time:

1. Turn your computer on. Wait for a few minutes until the **Set Up Windows** screen appears.
2. From dropdown list, select your language. Click **Next**.
3. From the dropdown lists, select your **Country or region**, **Time and currency**, and **Keyboard layout**. Click **Next**.
4. Key in unique names for the **user name** and **computer name**. Click **Next**.
5. Key in the necessary information to set up your password, then click **Next**. You may also click **Next** to skip this step without entering any information.





If you want to set up a password for your account later, refer to the section **Setting up a user account and password** in this chapter.

6. Carefully read the license terms. Tick **I accept the license terms** and click **Next**.
7. Select **Use recommended settings** or **Install important updates only** to set up the security settings for your computer. To skip this step, select **Ask me later**.
8. Review your date and time settings. Click **Next**. The system loads the new settings and restarts. You may now start using your computer.

Using Windows® 7 desktop



Click the Start icon  > Help and Support to obtain more information about Windows® 7.




Using the Start menu

The Start menu gives you access to programs, utilities, and other useful items on your computer. It also provides you with more information about Windows 7 through its **Help and Support** feature.

Launching items from the Start menu

To launch items from the Start menu:

1. From the Windows® taskbar, click the Start icon .
2. From the Start menu, select the item that you want to launch.




You may pin programs that you want constantly displayed on the Start menu. For more details, refer to the section **Pinning programs on the Start menu or taskbar** on this chapter.

Using the Getting Started item

The **Getting Started** item on the Start menu contains information about some basic tasks such as personalizing Windows®, adding new users, and transferring files to help you to familiarize yourself with using Windows® 7.

To use the Getting Started item:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Select **Getting Started**. The list of available tasks appears.
3. Select the task that you want to do.




Using the taskbar

The taskbar allows you to launch and manage programs or items installed on your computer.

Launching a program from the taskbar

To launch a program from the taskbar:

- From the Windows® taskbar, click an icon to launch it. Click the icon again to hide the program.



You may pin programs that you want constantly displayed on the taskbar. For more details, refer to the section **Pinning programs on the Start menu or taskbar** on this chapter.

Pinning items on the jumplists

When you right-click an icon on the taskbar, a jumplist launches to provide you with quick-access to the program's or item's related links. You may pin items on the jumplist such as favorite websites, often-visited folders or drives, or recently played media files.



To pin items to the jumplist:

- 1. From the taskbar, right-click an icon.
- 2. From the jumplist, right-click the item that you want to pin, then select **Pin to this list**.


Unpinning items from the jumplist


To unpin items from the jumplist:

- 1. From the taskbar, right-click an icon.
- 2. From the jumplist, right-click the item that you want to remove from the jumplist, then select **Unpin from this list**.


Pinning programs on the Start menu or taskbar

To pin programs on the Start menu or taskbar:

- 1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
- 2. Right-click the item that you want to pin on the Start menu or taskbar.
- 3. Select **Pin to Taskbar** or **Pin to Start menu**.




You may also right-click on the icon of a running program on the taskbar, then select **Pin this program to taskbar**.



Unpinning programs from the Start menu

To unpin programs from the Start menu:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. From the Start menu, right-click the program that you want to unpin, then select **Remove from this list**.

Unpinning programs from the taskbar




To unpin programs from the taskbar:

1. From the taskbar, right-click the program that you want to remove from the taskbar, then select **Unpin this program from taskbar**.




Using the notification area


By default, the notification area shows these three icons:

	Action Center notification Click this icon to display all the alert messages/notifications and launch the Windows® Action Center.
	Network connection This icon displays the connection status and signal strength of the wired or wireless network connection.
	Volume Click this icon to adjust the volume.

Displaying an alert notification

To display an alert notification:

- Click the Notification icon , then click the message to open it.





For more details, refer to the section **Using Windows® Action Center** in this chapter.

Customizing icons and notifications

You may choose to display or hide the icons and notifications on the taskbar or on the notification area.

To customize icons and notifications:

1. From the notification area, click on the arrow icon .
2. Click **Customize**.
3. From the dropdown list, select the behaviors for the icons or items that you want customize.




Managing your files and folders

Using Windows® Explorer

Windows® Explorer allows you to view, manage, and organize your files and folders.

Launching Windows® Explorer

To launch Windows Explorer:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Click **Computer** to launch Windows Explorer.



Exploring files and folders


To explore files and folders:


1. Launch Windows Explorer.
2. From the navigation or view pane, browse for the location of your data.
3. From the breadcrumb bar, click the arrow to display the contents of the drive or folder.




Customizing the file/folder view

To customize the file/folder view:

1. Launch Windows Explorer.
2. From the navigation pane, select the location of your data.
3. From the toolbar, click the View icon .
4. From the View menu, move the slider to select how you want to view the file/folder.




You may also right-click anywhere on the View pane, click **View**, and select the view type that you want.



Arranging your files

To arrange your files:


1. Launch Windows Explorer.
2. From the **Arrange by** field, click to display the dropdown list.
3. Select your preferred arrangement type.



Sorting your files

To sort your files:


1. Launch Windows Explorer.
2. Right-click anywhere on the View pane.
3. From the menu that appears, select **Sort by**, then select your preferred sorting type.



Grouping your files

To group your files:


1. Launch Windows Explorer.
2. Right-click anywhere on the View pane.
3. From the menu that appears, select **Group by**, then select your preferred grouping type.




Adding a new folder

To add a new folder:

1. Launch Windows Explorer.
2. From the toolbar, click **New folder**.
3. Key in a name for the new folder.




You may also right-click anywhere on the View pane, click **New > Folder**.




Backing up your files

Setting up a backup

To set up a backup:

1. Click  > **All Programs > Maintenance > Backup and Restore.**
2. Click **Set up backup.** Click **Next.**



3. Select your backup destination. Click **Next.**
4. Select **Let Windows choose (recommended)** or **Let me choose as your backup mode.**




If you select **Let Windows choose**, Windows will not back up your programs, FAT-formatted files, Recycle Bin files, or temporary files that are 1GB or more.

5. Follow the onscreen instructions to finish the process.

Restoring your system

The Windows® System Restore feature creates a restore point where the computer's system settings are stored at certain time and date. It allows you to restore or undo changes to your computer's system settings without affecting your personal data.

To restore your system:

1. Close all running applications.
2. Click  > **All Programs > Accessories > System Tools > System Restore.**
3. Follow the onscreen instructions to complete the process.

Protecting your computer

Using Windows® 7 Action Center


Windows® 7 Action Center provides you with alert notifications, security information, system maintenance information, and the option to automatically troubleshoot and fix some common computer problems.



You may customize the notifications. For more details, refer to the previous section **Customizing icons and notifications** in this chapter.


Launching Windows® 7 Action Center

To launch Windows® 7 Action Center:

1. To launch Windows 7 Action Center, click the Notification icon , then click **Open Action Center**.



2. From Windows 7 Action Center, click the task that you want to do.




Using Windows® Update

Windows Update allows you to check and install the latest updates to enhance the security and performance of your computer.

Launching Windows® Update

To launch Windows® Update:

1. From the Windows® taskbar, click the Start icon  to launch the Start menu.
2. Select **All Programs > Windows Update**.
3. From the Windows Update screen, click the task that you want to do.





Setting up a user account and password

You may create user accounts and passwords for people who will use your computer.

Setting up a user account

To set up a user account:

1. From the Windows® taskbar, click  > **Getting Started > Add new users.**
2. Select **Manage another account.**
3. Select **Create a new account.**
4. Key in the name of the new user.
5. Select either **Standard user** or **Administrator** as the user type.
6. When done, click **Create Account.**




Setting up a user's password

To set up a user's password:

1. Select the user that you would like to set a password.
2. Select **Create a password**.



3. Key in a password and confirm it. Key in your password's hint.
4. When done, click **Create password**.



Activating the anti-virus software

Trend Micro Internet Security is pre-installed on your computer. It is a third-party anti-virus software protecting your computer from virus attacking. It is purchased separately. You have a 60-day trial period after activating it.


To activate Trend Micro Internet Security:

1. Run the Trend Micro Internet Security application.
2. Carefully read the license terms. Click **Agree & Activate**.
3. Input your e-mail address and select your location. Click **Next**.
4. Click Finish to complete the activation.

Getting Windows® Help and Support

Windows® Help and Support provides you with guides and answers in using the applications in Windows® 7 platform.

To launch Windows® Help and Support, click  > **Help and Support**.



Ensure that you are connected to the Internet to obtain the latest Windows® online help.

Chapter 3


Connecting devices to your computer

Connecting a USB storage device


This desktop PC provides USB 2.0/1.1 ports on both the front and rear panels. The USB ports allow you to connect USB devices such as storage devices.


To connect a USB storage device:

- Insert the USB storage device to your computer.



To remove a USB storage device:

1. Click  from the Windows notification area on your computer, then click **Eject USB2.0 FlashDisk**.
2. When the **Safe to Remove Hardware** message pops up, remove the USB storage device from your computer.




DO NOT remove a USB storage device when data transfer is in progress. Doing so may cause data loss or damage the USB storage device.


Connecting microphone and speakers

This desktop PC comes with microphone ports and speaker ports on both the front and rear panels. The audio I/O ports located on the rear panel allow you to connect 2-channel, 4-channel, 6-channel, and 8-channel stereo speakers.


Connecting Headphone and Mic




Connecting 2-channel Speakers




Connecting 4-channel Speakers



Connecting 6-channel Speakers



Connecting 8-channel Speakers



Connecting multiple external displays

Your desktop PC may come with VGA, HDMI, or DVI ports and allows you to connect multiple external displays.




When a graphics card is installed in your computer, connect the monitors on the output ports of the graphics card.

Setting up multiple displays


When using multiple monitors, you are allowed to set display modes. You can use the additional monitor as a duplicate of your main display, or as an extension to enlarge your Windows desktop.


To set up multiple displays:

1. Turn off your computer.
2. Connect the two monitors to your computer and connect the power cords to the monitors. Refer to **Setting up your computer** section in Chapter 1 for details on how to connect a monitor to your computer.




For some graphic cards, only the monitor that is set to be the primary display has display during POST. The dual display function works only under Windows.

3. Turn on your computer.
4. Do any of the following to open the **Screen Resolution** setting screen:
 - Click  > **Control Panel** > **Appearance and Personalization** > **Display** > **Change display settings**.
 - Right click anywhere on your Windows desktop. When the pop-up menu appears, click **Personalize** > **Display** > **Change display settings**.
5. Select the display mode from the **Multiple displays**: drop-down list.
 - **Duplicate these displays**: Select this option to use the additional monitor as a duplicate of your main display.
 - **Extend these displays**: Select this option to use the additional monitor as an extension display. This increases your desktop space.
 - **Show desktop only on 1 / 2**: Select this option to show desktop only on monitor 1 or monitor 2.
 - **Remove this display**: Select this options to remove the selected display.



6. Click **Apply** or **OK**. Then click **Keep Changes** on the confirmation message.



Connecting an HDTV

Connect a High Definition TV (HDTV) to the HDMI port of your computer.



- You need an HDMI cable to connect the HDTV and the computer. The HDMI cable is purchased separately.
- To get the best display performance, ensure that your HDMI cable is less than 15 meters.



Chapter 4

Using your computer

Proper posture when using your Desktop PC

When using your Desktop PC, maintaining the proper posture is necessary to prevent strain to your wrists, hands, and other joints or muscles. This section provides you with tips on avoiding physical discomfort and possible injury while using and fully enjoying your Desktop PC.




To maintain the proper posture:

- Position your computer chair to make sure that your elbows are at or slightly above the keyboard to get a comfortable typing position.
- Adjust the height of your chair to make sure that your knees are slightly higher than your hips to relax the backs of your thighs. If necessary, use a footrest to raise the level of your knees.
- Adjust the back of your chair so that the base of your spine is firmly supported and angled slightly backward.
- Sit upright with your knees, elbows and hips at an approximately 90° angle when you are at the PC.
- Place the monitor directly in front of you, and turn the top of the monitor screen even with your eye level so that your eyes look slightly downward.
- Keep the mouse close to the keyboard, and if necessary, use a wrist rest for support to reduce the pressure on your wrists while typing.
- Use your Desktop PC in a comfortably-lit area, and keep it away from sources of glare such as windows and straight sunlight.
- Take regular mini-breaks from using your Desktop PC.

Using the memory card reader

Digital cameras and other digital imaging devices use memory cards to store digital picture or media files. The built-in memory card reader on the front panel of your system allows you to read from and write to different memory card drives.



To use the memory card:

1. Press **PUSH** on the front I/O ports cover to open it.
2. Insert the memory card into the card slot.



- A memory card is keyed so that it fits in only one direction. DO NOT force a card into a slot to avoid damaging the card.
- You can place media in one or more of the card slots and use each media independently. Place only one memory card in a slot at one time.

3. Select a program from the AutoPlay window to access your files.



- If AutoPlay is NOT enabled in your computer, click Windows® 7 **Start** button on the taskbar, click **Computer**, and then double-click the memory card icon to access the data on it.
- Each card slot has its own drive icon which is displayed on the **Computer** screen.
- The memory card reader LED lights up and blinks when data is being read from or written to the memory card.

4. When finished, right-click the memory card drive icon on the **Computer** screen, click **Eject**, and then remove the card.



Never remove cards while or immediately after reading, copying, formatting, or deleting data on the card or else data loss may occur.



To prevent data loss, use "Safely Remove Hardware and Eject Media" in the Windows notification area before removing the memory card.

Using the optical drive



Inserting an optical disc

To insert an optical disc:

1. While your system is on, press **PUSH** on the drive bay cover to open the tray.
2. Place the disc to the optical drive with the label side facing up.
3. Push the tray to close it.
4. Select a program from the AutoPlay window to access your files.



If AutoPlay is NOT enabled in your computer, click Windows® 7 **Start** button on the taskbar, click **Computer**, and then double-click the CD/DVD drive icon to access the data on it.

Removing an optical disc

To remove an optical disc:


1. While the system is on, do either of the following to eject the tray:
 - Press **PUSH** on the drive bay cover.
 - Right-click the CD/DVD drive icon on the **Computer** screen, and then click **Eject**.
2. Remove the disc from the disc tray.

Using the multimedia keyboard (on selected models only)



The keyboard varies with models. The illustrations on this section are for reference only.

ASUS SK-2045 keyboard



Keys	Description	Keys	Description
1.	Launches Windows® gadgets.	12.	Press <Fn + F7> to launch Microsoft® MSN or, if not installed, connects to the MSN download page.
2.	Activates Windows® Flip 3D.	13.	Press <Fn + F8> to launch Windows® Search screen.
3.	Reduces picture size in Windows® Photo Viewer.	14.	Press <Fn + F9> to play or pause playback in Windows® Media Player.
4.	Increases picture size in Windows® Photo Viewer.	15.	Press <Fn + F10> to stop playback in Windows® Media Player.
5.	Functions with keys F1~F12.	16.	Press <Fn + F11> to go to the previous track in Windows® Media Player.
6.	Press <Fn + F1> to launch Microsoft® Word.	17.	Press <Fn + F12> to go to the next track in Windows® Media Player.
7.	Press <Fn + F2> to launch Microsoft® Excel.	18.	Decreases the system volume.
8.	Press <Fn + F3> to launch Microsoft® PowerPoint.	19.	Increases the system volume.
9.	Press <Fn + F4> to launch Microsoft® Internet Explorer.	20.	Turns the volume's mute mode on/off.
10.	Press <Fn + F5> to launch Microsoft® Outlook.	21.	Launches Windows® Media Player.
11.	Press <Fn + F6> to launch the Favorites folder in Windows® Internet Explorer.	22.	Launches Windows® Media Center.



The special function keys only work on Windows® Vista / Windows® 7 operating systems.

Chapter 5

Connecting to the Internet

Wired connection

Use an RJ-45 cable to connect your computer to a DSL/cable modem or a local area network (LAN).

Connecting via a DSL/cable modem


To connect via a DSL/cable modem:

1. Set up your DSL/cable modem.



Refer to the documentation that came with your DSL/cable modem.

2. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to a DSL/cable modem.



3. Turn on the DSL/cable modem and your computer.
4. Configure the necessary Internet connection settings.




Contact your Internet Service Provider (ISP) for details or assistance in setting up your Internet connection.

Connecting via a local area network (LAN)

To connect via a LAN:

1. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to your LAN.



2. Turn on your computer.
3. Configure the necessary Internet connection settings.




Contact your network administrator for details or assistance in setting up your Internet connection.

Wireless connection (on selected models only)

Connect your computer to the Internet through a wireless connection.




To establish a wireless connection, you need to connect to a wireless access point (AP).




- To increase the range and sensitivity of the wireless radio signal, connect the external antennas to the antenna connectors on the ASUS WLAN Card.
- Place the antennas on the top of your computer for the best wireless performance.
- The external antennas are optional items.

To connect to a wireless network:


1. Click the network icon  in the notification area to display the available wireless networks.



2. Select the wireless network that you want to connect to, then click **Connect**.




3. You may need to key in the network security key for a secured wireless network, then click **OK**.



4. Wait while your computer is connecting to the wireless network.



5. The wireless connection is established successfully. The connection status is displayed and the network icon displays the connected  status.



Chapter 6

Using the Utilities

ASUS AI Manager

ASUS AI Manager is a utility which gives you quick and easy access to frequently-used applications.

Installing AI Manager

To install AI Manager:

1. Place the support DVD in the optical drive. If Autorun is enabled, the Drivers installation wizard appears.



If Autorun is disabled, double-click the **setup.exe** file from the ASUS AI Manager folder in the support DVD.

2. Click the **Utilities** tab, then click **ASUS AI Manager**.
3. Follow the onscreen instructions to complete the installation.


Launching AI Manager

To launch the AI Manager from the Windows® desktop, click **Start > All Programs > ASUS > AI Manager > AI Manager 1.xx.xx**. The AI Manager quick bar appears on the desktop.



After launching the application, the AI Manager icon appears in the Windows® taskbar.

Right-click this icon to switch between the quick bar and the main window, and to launch the AI Manager either from the quick bar or taskbar.



AI Manager quick bar


The AI Manager quick bar saves the desktop space and allows you to launch the ASUS utilities or display system information easily. Click any of the Main, My Favorites, Support or Information tab to display the menu's contents.



Click the Maximize/restore button to switch between full window and quick bar. Click the Minimize button to keep the AI Manager on the taskbar. Click the Close button to quit the AI Manager.

Main

The Main menu contains five utilities: **AI Disk**, **AI Security**, **AI Boosting**, and **AI Probe**. Click the arrow on the Main menu icon to browse through the utilities in the main menu.



AI Disk

AI Disk allows you to easily clear temporary IE files, IE cookies, IE URLs, IE history, or the Recycle Bin. Click the AI Disk icon on the quick bar to display the full AI Disk window and select the items you want to clear. Click **Apply** when done.



AI Security


AI Security enables you to set a password to secure your devices, such as USB flash disks and CD/DVD disks, from unauthorized access.

To lock a device:

1. When using AI Security for the first time, you are asked to set a password. Key in a password with at most 20 alphanumeric characters.
2. Confirm the password.
3. Key in the password hint (recommended).
4. When done, click **Ok**.



5. Select the device you want to lock, then click **Apply**.
6. Key in the password you have set previously, then click **Ok**.



To unlock the device:

1. Deselect the locked device, then click **Apply**.
2. Key in the password you have set previously, then click **Ok**.

To change the password:

- Click **Change Password**, then follow the onscreen instructions to change password.

AI Booting

AI Booting allows you to specify the boot device priority sequence.



To specify the boot sequence:

1. Select a device, then click the left/right button to specify the boot sequence.
2. When done, press **Apply**.

AI Probe

AI Probe automatically detects and displays the motherboard and CPU temperatures, CPU fan speed, and the voltage output. You can adjust the values as you need.

Click the **Temperature**, **Voltage**, or **Fan Speed** tab, then select an item to enable and change the value by dragging the bar.



My Favorites

My Favorites allows you to add applications that you frequently use, saving you from searching for the applications throughout your computer.



To add an application:

1. Click **Add**, then locate the application you want to add to **My Favorites**.
2. Click **Open** on the file location window. The application is added to **My Favorites** list.

Right click on the application icon to launch, delete, or rename the selected application. You can also double click to launch the selected application.

Support

Click any links on the **Support** window to go to the ASUS website, technical support website, download support website, or contact information.



Information

Click the tab on the **Information** window to see the detailed information about your system, motherboard, CPU, BIOS, installed device(s), and memory.



ASUS EPU-4 Engine

ASUS EPU-4 Engine is an energy-efficient tool that provides you with a total system power-saving solution. It detects the current computer loading and intelligently adjusts the power in real-time. It automatically adjusts the power usage for the CPU, VGA card, hard drives, and CPU fan. It provides you with these modes to choose from: **Auto**, **High Performance**, and **Maximum Power Saving Mode**.



Refer to the section **ASUS EPU-4 main screen** for more details about these modes.

Installing ASUS EPU-4

To install **ASUS EPU-4 Engine**:

1. Place the support DVD into the optical drive. The **Drivers** menu appears if Autorun is enabled on your computer.



If Autorun is disabled, double-click the **setup.exe** file from the ASUS EPU-4 Engine folder in the support DVD.

2. Click **ASUS EPU-4 Engine**.
3. Follow the onscreen instructions to complete the installation.

Launching ASUS EPU-4


To launch **ASUS EPU-4**:

1. From the Windows taskbar, click the ASUS EPU-4 icon.



- When you launch ASUS EPU-4 for the first time, a message appears asking you to calibrate the EPU functions.

Click **Calibrate** and wait for a few seconds for the calibration process to complete. The ASUS EPU-4 main menu appears.



Calibration allows the system to detect the CPU properties for optimal power management.

ASUS EPU-4 main screen



1 CPU status

Displays the current CPU power and the total CPU power saved.

2 VGA card status

Displays the status of the graphics card. If your graphics card is not compatible with the motherboard, a "No VGA card detected" message appears.






Refer to the ASUS VGA QVL List at http://event.asus.com/mb/EPU-4_Engine/ for compatible VGA cards.

-
- | | |
|----------|---|
| 3 | HDD status
Lights up when the power saving mode is activated. |
| 4 | Fan status
Display the current fan status. |
| 5 | CO2 Emission button
Displays the current or total reduced CO2 emission. |
| 6 | Mode properties
Displays the properties of each mode. |
| 7 | Exit button
Closes the ASUS EPU-4 utility, |
| 8 | Calibrate button
Allows the system to detect the CPU properties for optimal power management. |
| 9 | Setting button
Click this button to configure the mode settings. |
-



Refer to the section **Configuring the mode settings** for more details.



10	Modes
	Auto Mode When you select this mode, the system changes modes automatically according to the current system status.
	High Performance Mode When you select this mode, the system overclocks the components for maximum performance.
	Maximum Power Saving Mode When you select this mode, the system automatically adjusts the power usage for critical components in real-time to save power.

Configuring the mode settings

To configure the mode settings:

1. From the ASUS EPU-4 main menu, click **Setting** to launch the Setting screen.



2. Click the  tab to configure the settings of High Performance mode. Click the  tab to configure the settings of Maximum Power Saving mode.
3. Configure any of these mode settings:
 - **vCore Voltage Downgrade:** Lowers CPU vCore voltage.
 - **Heavy:** Downgrades voltage to the highest level for CPU power saving.
 - **Medium:** Downgrades voltage to the medium level.
 - **Small:** Downgrades voltage to the minimum level.
 - **Turn Off hard disks:** Turns off hard disk drives when they are not accessed after a certain time.
 - **CPU Loadline:** Sets up the CPU loadline to manage CPU power saving.
 - **Light:** Saves CPU power to the minimum level.
 - **Medium:** Saves CPU power to the medium level.
 - **Heavy:** Saves CPU power to the highest level.
 - **Turn Off Screen:** After the specified idle time, the screen turns off while all background tasks are still running.
4. Click **OK** to apply the settings made.

ASUS Update

The ASUS Update is a utility that allows you to manage, save, and update the motherboard BIOS in Windows® environment.



- ASUS Update requires an Internet connection either through a network or an Internet Service Provider (ISP).
- This utility is available in the support DVD that comes with the motherboard package.

Installing ASUS Update

To install ASUS Update:

1. Place the support DVD in the optical drive. The **Drivers** menu appears.



If Autorun is disabled, double-click the **setup.exe** file from the ASUS Update folder in the support DVD.

2. Click the **Utilities** tab, then click **Install ASUS Update**.
3. Follow the onscreen instructions to complete the installation.



Quit all Windows® applications before you update the BIOS using this utility.

Updating the BIOS

To update the BIOS:

1. From the Windows® desktop, click **Start > Programs > ASUS > ASUS Update > ASUS Update** to launch the ASUS Update utility.
2. From the dropdown list, select any of the updating process:

Updating from the Internet

- a. Select **Update BIOS from the Internet**, then click **Next**.
- b. Select the ASUS FTP site nearest you to avoid network traffic, or click **Auto Select** then click **Next**.
- c. From the FTP site, select the BIOS version that you wish to download then click **Next**.



The ASUS Update utility is capable of updating itself through the Internet. Always update the utility to avail all its features.

Updating from a BIOS file

- a. Select **Update BIOS from a file**, then click **Next**.
 - b. Locate the BIOS file from the **Open** window, then click **Open**.
3. Follow the onscreen instructions to complete the updating process.

ASUS MyLogo2™

The ASUS MyLogo2™ utility lets you customize the boot logo. The boot logo is the image that appears on screen during the Power-On Self-Tests (POST). ASUS MyLogo2™ is automatically installed when you install the ASUS Update utility from the Support DVD.



- Obtain the latest BIOS file from the ASUS website at www.asus.com.
- You can create your own boot logo image in GIF file format.

To launch ASUS MyLogo2™:

1. Launch the ASUS Update utility. Refer to the section “**ASUS Update**” in this user manual for details.
2. Select **Options** from the drop down menu, then click **Next**.
3. Check the option **Launch MyLogo to replace system boot logo before flashing BIOS**, then click **Next**.
4. Select **Update BIOS from file** from the drop down menu, then click **Next**.
5. When prompted, locate the new BIOS file, then click **Next**. ASUS MyLogo window appears.
6. From the left window pane, locate the image that you want to use as your boot logo. Click **Next**.
7. From the **Ratio** dropdown list, select your desired size for the boot logo. Click **Next**.
8. The system starts updating the BIOS and loading the new boot logo.
9. After the updating process, the system restarts and displays the new boot logo during POST.



Nero 9

Nero 9 allows you to create, copy, burn, edit, share, and update different kinds of data.



Installing Nero 9

To install Nero 9:

1. Insert the Nero 9 DVD into your optical drive.
2. If Autorun is enabled, the main menu appears automatically.



If Autorun is disabled, double-click the **SeupX.exe** file from the main directory of your Nero 9 DVD.

3. From the main menu, click **Nero 9 Essentials**.




4. Select the language you want to use for Installation Wizard. Click **Next**.



5. Click **Next** to continue.



6. Tick **I accept the License Conditions**. When done, click **Next**.



7. Select **Typical** then click **Next**.



8. Tick **Yes, I want to help by sending anonymous application data to Nero** then click **Next**.



9. When done, click **Exit**.



Burning files

To burn files:

1. From the main menu, click **Data Burning > Add**.



2. Select the files that you want to burn. When done, click **Add**.



3. After selecting files that you want to burn, click **Burn** to burn the files to a disc.



For more details about using Nero 9, refer to the Nero website at www.nero.com

Recovering your system

The bundled Recovery DVD assists you in reinstalling the operating system and restoring it to its original working state.



All data will be lost during the recovery process. Before recovering the system, ensure that you back up all your data and take note of any customized settings such as network settings.

To recover your system:

1. Turn on your ASUS Desktop PC. When the ASUS logo appears, press **<F8>** to enter the **Please select boot device** menu.
2. Insert the recovery DVD into the optical drive and select the optical drive (CDROM: XXX) as the boot device. Press **Enter** and then press any key to continue.
3. Wait until the Hard-Disk Information screen appears. Select where to install a new system. Options are:

Recover system to a partition

This option deletes only the partition you selected, allows you to keep other partitions, and creates a new system partition as drive "C." Select a partition and click **NEXT**.

Recover system to entire HD

This option deletes all partitions from your hard disk drive and creates a new system partition as drive "C." Select and click **Yes**.

4. Tick **I accept** then click **Next**.
5. Follow the onscreen instructions to complete the recovery process.
6. Click **OK** on the confirmation message to eject the disc from the optical drive and the system restarts.
7. After the system restarts, Windows® 7 begins its system configurations. Follow the onscreen instructions to complete the process, and the system automatically restarts.



This recovery DVD is for ASUS Desktop PC only. DO NOT use it on other computers. Visit the ASUS website www.asus.com for any updates.

Quickly recover your system

1. Turn on your ASUS Desktop PC. When the ASUS logo appears, press **F9** to enter the **System Recovery**.
2. **Windows is loading files** is shown. Wait until the **Recovery CD/DVD** window appears.
3. Follow the onscreen instructions to complete the recovery process. After the system reboots, display resolution and system settings are restored to their default values.

Chapter 7

Troubleshooting

This chapter presents some problems you might encounter and the possible solutions.

? *My computer cannot be powered on and the power LED on the front panel does not light up*

- Check if your computer is properly connected.
- Check if the wall outlet is functioning.
- Check if the Power Supply Unit is switched on. Refer to the section **Turning your computer ON/OFF** in Chapter 1.

? *My computer hangs.*

- Do the following to close the programs that are not responding:
 1. Simultaneously press <Alt> + <Ctrl> + <Delete> keys on the keyboard, then click **Start Task Manager**.
 2. Click **Applications** tab.
 3. Select the program that is not responding, then click **End Task**.
- If the keyboard is not responding. Press and hold the Power button on the top of your chassis until the computer shuts down. Then press the Power button to turn it on.

? *I cannot connect to a wireless network using the ASUS WLAN Card (on selected models only)?*

- Ensure that you enter the correct network security key for the wireless network you want to connect to.
- Connect the external antennas (optional) to the antenna connectors on the ASUS WLAN Card and place the antennas on the top of your computer chassis for the best wireless performance.

? *The arrow keys on the number key pad are not working.*

Check if the Number Lock LED is off. When the Number Lock LED is on, the keys on the number key pad are used to input numbers only. Press the Number Lock key to turn the LED off if you want to use the arrow keys on the number key pad.

? *No display on the monitor.*

- Check if the monitor is powered on.
- Ensure that your monitor is properly connected to the video output port on your computer.
- If your computer comes with a discrete graphics card, ensure that you connect your monitor to a video output port on the discrete graphics card.
- Check if any of the pins on the monitor video connector is bent. If you discover bent pins, replace the monitor video connector cable.
- Check if your monitor is plugged to a power source properly.
- Refer to the documentation that came with your monitor for more troubleshooting information.

? *When using multiple monitors, only one monitor has display.*

- Ensure that the both monitors are powered on.
- During POST, only the monitor connected to the VGA port has display. The dual display function works only under Windows.
- When a graphics card is installed on your computer, ensure that you connect the monitors to the output port on the graphics card.
- Check if the multiple displays settings are correct. Refer to section **Connecting multiple external displays** in Chapter 3 for details.


? *My computer cannot detect my USB storage device.*

- The first time you connect your USB storage device to your computer, Windows automatically installs a driver for it. Wait for a while and go to My Computer to check if the USB storage device is detected.
- Connect your USB storage device to another computer to test if the USB storage device is broken or malfunctions.





? *I want to restore or undo changes to my computer's system settings without affecting my personal files or data.*

The Windows® System Restore feature allows you to restore or undo changes to your computer's system settings without affecting your personal data such as documents or photos. For more details, refer to the section **Restoring your system** in Chapter 2.

? *The picture on the HDTV is stretched.*

- It is caused by the different resolutions of your monitor and your HDTV. Adjust the screen resolution to fit your HDTV. To change the screen resolution:
 1. Do any of the following to open the **Screen Resolution** setting screen:
 - Click  > **Control Panel** > **Appearance and Personalization** > **Display** > **Change display settings**.
 - Right click anywhere on your Windows desktop. When the pop-up menu appears, click **Personalize** > **Display** > **Change display settings**.
 2. Adjust the resolution. Refer to the documentation came with your HDTV for the resolution.
 3. Click **Apply** or **OK**. Then click **Keep Changes** on the confirmation message.



? *My speakers produce no sound.*

- Ensure that you connect your speakers to the Line out port (lime) on the front panel or the rear panel.
- Check if your speak is connected to a electrical source and turned on.
- Adjust your speakers' volume.
- Ensure that your computer's system sounds are not Muted.
 - If it is muted, the volume icon is displayed as . To enable the system sounds, click  from the Windows notification area, then click .
 - If it is not muted, click  and drag the slider to adjust the volume.
- Connect your speakers to another computer to test if the speakers arer working properly.

? *The DVD drive cannot read a disc.*

- Check if the disc is placed with the label side facing up.
- Check if the disc is centered in the tray, especially for the discs with non-standard size or shape.
- Check if the disc is scratched or damaged.

? *The DVD drive eject button is not respond.*


1. Click  > **Computer**.
2. Right-click  , then click **Eject** from the menu.



華碩個人電腦

CP1130

使用手冊



T5313

第一版

2010 年 1 月

本使用手冊包括但不限於其所包含的所有資訊受到著作權法之保護，未經華碩電腦股份有限公司（以下簡稱“華碩”）許可，不得任意地仿製、拷貝、謄抄、轉譯或為其他使用或處分。本使用手冊沒有任何型式的擔保、立場表達或其它暗示。若有任何因本使用手冊或其所提到之產品的所有資訊，所引起直接或間接的資料流失、利益損失或事業終止，華碩及其所屬員工恕不為其擔負任何責任。除此之外，本使用手冊所提到的產品規格及資訊僅供參考，內容亦會隨時更新，恕不另行通知。華碩不負責本使用手冊的任何錯誤或疏失。

本使用手冊中所提及的產品名稱僅做為識別之用，而前述名稱可能是屬於其他公司的註冊商標或是著作權。

關於產品規格最新的升級訊息，請您到華碩的網站瀏覽或是直接與華碩公司聯絡。

版權所有・不得翻印 © 2010 華碩電腦

目錄內容

注意事項.....	v
安全性須知.....	vii
提示符號.....	viii
哪裡可以找到更多的產品資訊.....	viii
包裝內容.....	ix

第一章：系統導覽

歡迎	1-1
了解您的個人電腦	1-1
安裝您的個人電腦	1-5
開啟或關閉您的電腦	1-8

第二章：使用 Windows® 7（選配）

第一次啟動	2-1
使用 Windows® 7 桌面	2-2
管理檔案與資料夾	2-7
還原您的系統	2-10
保護您的電腦	2-11
進入 Windows 說明及支援	2-15

第三章：裝置連接

連接 USB 儲存裝置	3-1
連接麥克風與喇叭	3-2
連接多個外接顯示器	3-5
連接高畫質電視 HDTV（選配）	3-7

第四章：使用您的電腦

使用電腦時的適當姿勢	4-1
使用讀卡機	4-2
使用光碟機	4-3
使用多媒體鍵盤（選配）	4-4

第五章：網路連線

有線連接	5-1
無線連接（選配）	5-3

目錄 內容

第六章：使用應用程式（視機型而定）

華碩 AI Manager	6-1
華碩 EPU-4 Engine	6-6
華碩線上更新（ASUS Update）	6-9
華碩 MyLogo2™	6-10
Nero	6-11
還原您的系統（僅限預裝 Windows 作業系統的機器）	6-15

第七章：疑難解決

注意事項

華碩 REACH

謹遵守 REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) 管理規範, 我們會將產品中的化學物質公告在華碩 REACH 網站, 詳細請參考 <http://green.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

電池警語

注意：若更換了不正確電池可能有爆炸的危險。請使用製造商推薦的同種或相同電池。請依照製造商的指示來處理使用過的電池。

安全性須知



在清潔電腦之前，請先關機並移除電源與所有周邊裝置。您可以使用干淨柔軟的海綿或清潔布，沾上少許中性清潔劑與溫水，來擦拭您的個人電腦，接著用干布擦去多餘的水跡。

- 請勿將個人電腦放置於不平坦或不穩定的表面。若個人電腦的機殼損壞，請連絡維修服務人員。
- 請勿在灰塵飛揚或環境髒亂的場所使用個人電腦。請勿在泄漏的可燃氣體附近操作個人電腦。
- 請勿在個人電腦上放置其他物品。請勿將任何物品塞入電腦機件中，以免引起機件短路或電路損毀。
- 請勿將個人電腦放置於具有強大電磁場的環境中。
- 請保持機器在干燥的環境下使用，雨水、濕氣、液體等含有礦物質，將會腐蝕電子線路。請勿在雷電天氣下使用數據機。
- 電池安全警告：請勿將電池丟入火中。請勿將電池的正負極短路。請勿自行拆解電池。
- 請在溫度為 0°C 至 35°C 的環境中使用本電腦。
- 請勿堵塞個人電腦的通風孔，以免因散熱不良而導致系統過熱。
- 請勿使用破損的電源線、附件或其他周邊裝置。
- 為了防止電擊風險，在搬動電腦主機之前，請先將電腦電源插頭暫時從電源插座上拔除。
- 在使用變壓器或電源延長線前，我們建議您先尋求專業人士的協助。這些裝置有可能會干擾接地的迴路。
- 請確定電源的電壓設定已調整到本國/本區域所使用的電壓標準值。若您不確定您所屬區域的供應電壓值為何，請就近詢問當地的電力公司人員。
- 如果電源已損壞，請勿嘗試自行修復。請將其交給專業技術服務人員或經銷商來處理。

提示符號

為了能夠確保您正確地完成主機板設定，請務必注意下面這些會在本手冊中出現的標示符號所代表的特殊含意。



警告：提醒您在進行某一項工作時要注意您本身的安全。



小心：提醒您在進行某一項工作時要注意勿傷害到電腦主機板元件。



重要：此符號表示您必須要遵照手冊所描述之方式完成一項或多項軟硬體之安裝或設定。



注意：提供有助於完成某項工作的訣竅和其他額外的資訊。

哪裡可以找到更多的產品資訊

您可以經由下面所提供的兩個管道來獲得您所使用的華碩產品資訊以及軟硬體的更新資訊等。










1. 華碩網站

您可以到 <http://tw.asus.com> 華碩電腦全球資訊網站取得所有關於華碩軟硬體產品的各項資訊。

2. 其他文件

在您的產品包裝盒中除了本手冊所列舉的標準配件之外，也有可能夾帶有其他的文件，譬如經銷商所附的產品保證單據等。

包裝內容

		
華碩 Essentio 個人電腦	鍵盤 x1	滑鼠 x1
		
電源線 x1	驅動程式與公用程式 光碟 x1	還原光碟 x1
		
Nero 燒錄軟體光碟 x1	安裝指南 x1	華碩保固服務卡 x1
		
天線（選購）x 2		



- 若包裝內容有所損壞或遺失，請速與經銷商聯絡。
- 上述圖中所示物品僅供參考。實際產品規格依不同型號而定。

第一章

系統導覽

歡迎

感謝您購買華碩 CP1130 個人電腦。

華碩 CP1130 個人電腦擁有一流的效能，超凡的可靠性與以使用者為中心的應用程式，並安裝在華碩特別設計的機殼中。




請在安裝您的機殼前先參閱您的華碩保固服務卡。

了解您的個人電腦



本手冊中的機殼圖片描述僅供參考。各連接埠及其位置，與外殼顏色均依不同機型而異。


主機前面板



點選號碼以查看相關描述。

1. 電源按鈕：按下此按鈕啟動您的電腦。
2. 光碟機彈出按鈕：按此按鈕彈出光碟。
3. 光碟機槽位：此處有一部光碟機。
4. 麥克風連接埠（粉紅色）：此連接埠可連接麥克風。
5. 耳機連接埠（草綠色）：該連接埠可連接耳機或喇叭。
6. USB 2.0 連接埠：可連接 USB 裝置，如滑鼠、印表機、掃描機、相機、PDA 等。
7. MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ 卡槽：將 MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ 卡插入此槽。
8. 前面板 I/O 連接埠蓋板。

機殼後面板



點選號碼以查看相關描述。

1. 通風孔：進行空氣流通。




請勿堵住通風孔，並經常為您的電腦通風。

2. 電源連接埠：連接電源線。
3. 音效輸出接頭（草綠色）：您可以連接耳機或喇叭等的音效接收裝置。在四聲道、六聲道、八聲道的喇叭設定模式時，本接頭是作為連接前置主聲道喇叭之用。
4. 麥克風接頭（粉紅色）：此接頭可連接麥克風。
5. 側邊環繞喇叭連接埠（灰色）：在八聲道音效設定下，這個連接埠可以連接側邊環繞喇叭。
6. 後置環繞喇叭連接埠（黑色）：本連接埠在四聲道、六聲道、八聲道設定下是用來連接後置環繞喇叭。
7. 音效輸入接頭（淺藍色）：您可以將磁帶、CD、DVD 播放器等的音效輸出端連接到此音效輸入接頭。
8. 中央聲道與重低音喇叭連接埠（橘色）：這個連接埠可以連接中央聲道與重低音喇叭。
9. RJ-45 連接埠：透過網路中心連接到一個區域網路（LAN）。

網路指示燈說明

Activity/Link 指示燈		速度指示燈	
狀態	描述	狀態	描述
關閉	沒有連線	關閉	連線速度 10Mbps
關閉	已連線	關閉	連線速度 100Mbps
閃光燈	資料傳輸中	綠色	連線速度 1Gbps



網路連接埠



在 2、4、6、8 聲道音效設定上，音效輸出、音效輸入與麥克風接頭的功能會隨著聲道音效設定的改變而改變，如下表所示。

二、四、六或八聲道音效設定

接頭	耳機 / 二聲道喇叭輸出	四聲道喇叭輸出	六聲道喇叭輸出	八聲道喇叭輸出
淺藍色	聲音輸入端	聲音輸入端	聲音輸入端	聲音輸入端
草綠色	聲音輸出端	前置喇叭輸出	前置喇叭輸出	前置喇叭輸出
粉紅色	麥克風輸入端	麥克風輸入端	麥克風輸入端	麥克風輸入端
橘色	-	-	中央重低音喇叭輸出	中央重低音喇叭輸出
黑色	-	後置喇叭輸出	後置喇叭輸出	後置喇叭輸出
灰色	-	-	-	側邊喇叭輸出

10. **USB 2.0 連接埠**：可連接 USB 2.0 裝置如滑鼠、印表機、掃描機、相機、PDA 等。
11. **VGA 連接埠**：此連接埠連接 VGA 相容裝置如 VGA 顯示器。
12. **HDMI 連接埠**：此高畫質多媒體連接埠相容 HDCP，能夠播放 HD DVD，藍光光碟以及其他保護內容。
13. **華碩顯示卡（選配）**：此顯示卡上的顯示連接埠可能隨不同機種而異。
14. **華碩無線網路卡（選配）**：使電腦連線到無線網路。

安裝您的個人電腦

該章節引導您連接主要硬體裝置，例如外部顯示器、鍵盤、滑鼠以及電源線至您的電腦。

連接一個外部顯示器

使用華碩顯示卡（選配）


將您的顯示器連接至華碩獨立顯示卡的顯示連接埠。

請依照以下步驟使用華碩顯示卡連接一個外部顯示器：

1. 將您的顯示器連接至華碩獨立顯示卡的顯示連接埠。
2. 將顯示器插上電源。



華碩獨立顯示卡的顯示連接埠隨機種不同而改變。




使用內建顯示連接埠

將您的顯示器連接至機殼內部顯示連接埠。

請按照以下步驟使用內建顯示連接埠連接一個外部顯示器：


1. 依據實際內部連接埠的類型，選擇一個具備 VGA 連接埠的顯示器連接至後面板上的 VGA 連接埠，或一個具備 DVI-D 連接埠的顯示器連接至 DVI-D 連接埠，或一個具備 HDMI 連接埠的顯示器連接至 HDMI 連接埠。
2. 將顯示器插上電源。



- 若您的電腦裝有華碩顯示卡，則該顯示卡在 BIOS 中被設定為主要顯示裝置。因此，請將您的顯示器連接至顯示卡上的顯示連接埠（請以實際產品顯示卡上的連接埠為主）。
- 若要連接多個外部顯示器，請參閱第三章“連接多個外部顯示器”以獲得更多資訊。

連接 USB 鍵盤與滑鼠

將一個 USB 鍵盤與滑鼠連接至後面板的 USB 連接埠。




連接電源線

將電源線的一端連接至後面板的電源連接埠，另一端插上電源。



本產品系統規格為：100-240Vac，47-63Hz，3.5A。



開啟或關閉您的電腦

本章節引導您在安裝完成後如何開啟或關閉您的電腦。

開啟您的電腦

請按照以下步驟開啟您的電腦：

1. 開啟您的顯示器。
2. 開啟電源開關，然後按下電源按鈕。



電源按鈕



3. 等待直至作業系統自動載入。

關閉您的電腦

請按照以下步驟關閉您的電腦：

1. 關閉所有執行中的程式。
2. 在 Windows® 桌面上點選 .
3. 點選  關閉作業系統。
4. 關閉電源開關。

第二章

使用 Windows® 7（選配）

第一次啟動

當您第一次啟動電腦時，螢幕上會出現一系列畫面以引導你進行 Windows® 7 作業系統的基本設定。

當電腦第一次啟動時，請按照以下步驟操作：

1. 啟動您的電腦。等待幾分鐘直至“設定 Windows”畫面出現。
2. 在下拉選單中選擇您想要的語言，然後點選 下一步。
3. 在下拉選單中選擇您的國家或地區、時區、貨幣以及鍵盤佈局，然後點選 下一步。
4. 輸入使用者名稱與電腦名稱，然後點選 下一步。
5. 輸入所需資訊來設定您的密碼，然後點選 下一步。您也可以不輸入任何資訊，點選 下一步 跳過這一步。





若您想稍後為您的帳戶設定密碼，請參閱本章節「設定使用者帳號及密碼」。

6. 請仔細閱讀許可條款。勾選 **我願意接受許可條款**，然後點選 下一步。
7. 選擇 **使用推薦設定** 或 **僅安裝重要更新** 來為您的電腦進行安全設定。若您想要跳過這一步請選擇 **以後問我**。
8. 請再次確認您的日期與時間設定，然後點選 下一步。系統開始載入新設定並重新啟動。您可以現在開始使用您的電腦。

使用 Windows® 7 桌面



點選開始圖示  > 說明及支援 來獲取更多關於 Windows® 7 作業系統的資訊。



開始功能表

工作列


通知區域

使用開始功能表

開始功能表允許您進入電腦上的程式或其它使用項目。它透過“說明及支援”功能提供您更多 Windows® 7 的資訊。

從開始功能表進入選項

請按照以下步驟由開始功能表進入選項：

1. 在 Windows® 工作列中點選開始圖示 .
2. 在開始功能表中選擇您想要進入的選項。




您可以將您常用的程式釘在開始功能表中成為一個小圖示。更多資訊請參閱本章節「在開始功能表或工作列中新增程式」。

使用 開始使用 選項

開始功能表中的 開始使用 選項包括一些基本操作的資訊，例如個人化 Windows®，新增新使用者，傳輸檔案等，支援您更瞭解如何使用 Windows® 7 作業系統。

請按照以下步驟使用 開始使用：

1. 在 Windows® 工作列中點選開始圖示
 進入開始功能表。
2. 選擇 開始使用 展開一系列任務選項。您也可以點選 開始 > 控制台 > 入門 進入操作。
3. 選擇您想要的任務選項。




使用工作列

工作列允許您進入以及管理已安裝在您的電腦上的程式或選項。

從工作列進入程式

請按照以下步驟從工作列進入程式：

- 在工作列中點選一個圖示進入此程式。再次點選圖示可隱藏此程式。



您可以將您常用的程式釘在開始功能表中成為一個小圖示。更多資訊請參閱本章節「在開始功能表或工作列中新增程式」。

在捷徑中新增選項

當您用滑鼠右鍵點選工作列中的一個圖示時，螢幕上會出現捷徑以提供您快速進入該程式或選項的相關連結。您也可以將所需選項釘在捷徑上，例如您喜愛的網站、經常瀏覽的資料夾、驅動程式或最近播放的媒體檔案。

請按照以下步驟將選項釘在捷徑：

1. 用滑鼠右鍵點選工作列中的一個圖示。
2. 在捷徑中用滑鼠右鍵點選你想要釘入的選項，然後選擇 **將此程式釘選到工作列**。




在捷徑中移除選項

請按照以下步驟在捷徑中移除選項：

1. 用滑鼠右鍵點選工作列中的一個圖示。
2. 在捷徑中用滑鼠右鍵點選你想要移除的選項，然後選擇 **將此程式從工作列取消釘選**。

在開始功能表或工作列中新增程式

請按照以下步驟在開始功能表或工作列中新增程式：

1. 在 Windows® 工作列中點選開始圖示  進入開始功能表。
2. 在開始功能表或工作列中用滑鼠右鍵點選你想要釘入的選項。
3. 選擇 **釘選到工作列** 或 **釘選到開始選單**。




您也可以用滑鼠右鍵點選工作列中一個正在執行的程式的圖示，然後選擇 **將此程式釘選到工作列**。



在開始功能表中移除程式

請按照以下步驟在開始功能表中移除程式：

1. 在 Windows® 工作列中點選開始圖示  進入開始功能表。
2. 在開始功能表中用滑鼠右鍵點選你想要移除的程式。然後選擇 **從開始選單取消釘選**。

在工作列中移除程式




請按照以下步驟在工作列中移除程式：

1. 在工作列中用滑鼠右鍵點選你想要移除的程式，然後選擇 **將此程式從工作列取消釘選**。




使用通知區域

預設的通知區域顯示以下三種圖示：

	作業中心通知 點選該圖示顯示所有警示資訊或通知，以及進入 Windows® 作業中心。
	網路連線 該圖示顯示有線/無線網路連線狀態以及訊號強度。
	音量 點選此圖示調整音量。

顯示通知

請按照以下步驟顯示通知：

- 點選通知圖示 ，然後點選第一行的 **重要訊息 開啟**。





更多資訊請參閱本章節「Windows® 作業中心」。

個人化圖示與通知

您可以選擇在工作列或通知區域顯示或隱藏圖示與通知。

請按照以下步驟個人化圖示或通知：

1. 在通知區域點選箭頭圖示 。
2. 點選 **個人化**。
3. 在下拉選單中選擇您想要自訂的圖示或選項的行為。



管理檔案與資料夾

使用 Windows® 瀏覽器

Windows® 瀏覽器允許您檢視或管理您的檔案與資料夾。

進入 Windows® 瀏覽器

請按照以下步驟進入 Windows® 瀏覽器：

1. 在工作列中點選開始圖示  進入開始功能表。
2. 點選 **電腦** 進入 Windows® 瀏覽器。



瀏覽檔案與資料夾


請按照以下步驟瀏覽檔案與資料夾：

1. 進入 Windows® 瀏覽器。
2. 在功能窗格或檔案清單中尋找所需資料的位置。
3. 在位址列中點選箭頭顯示磁碟機或資料夾。



個人化檔案或資料夾圖示

請按照以下步驟個人化資料夾預覽方式圖示：

1. 進入 Windows® 瀏覽器。
2. 在功能窗格中選擇您所需資料的位置。
3. 在工具列中點選顯示圖示 。
4. 在圖示選單中移動滑塊選擇你想要檢視檔案或資料夾的方式。



您也可以檔案清單上用滑鼠右鍵點選任何一處，在展開的選項中點選 **檢視**，並選擇您想要檢視檔案或資料夾的方式。



排列您的檔案

請按照以下步驟排列您的檔案：

1. 進入 Windows® 瀏覽器。
2. 點選 **排列方式** 顯示下拉選單及選項。
3. 選擇您想要的排列方式。



排序您的檔案

請按照以下步驟排列您的檔案：

1. 進入 Windows® 瀏覽器。
2. 在檔案清單上用滑鼠右鍵點選任何一處。
3. 在出現的選單中選擇 **排序方式**，然後選擇您想要的排列方式。



將檔案進行分組

請按照以下步驟將檔案進行分組：

1. 進入 Windows® 瀏覽器。
2. 在檔案清單上用滑鼠右鍵點選任何一處。
3. 在出現的選單中選擇 **分組方式**，然後選擇您想要的分組方式。




新增一個新資料夾

請按照以下步驟新增一個新資料夾：

1. 進入 Windows® 瀏覽器。
2. 在工具列中點選 **新增**。
3. 輸入新資料夾名稱。




您也可以在檔案清單上用滑鼠右鍵點選任何一處，點選 **新增 > 資料夾**。



備份檔案

設定備份

請按照以下步驟設定備份：

1. 點選  > 所有程式 > 維護 > 備份與還原。
2. 點選 設定備份，然後再點選 下一步。



3. 選擇備份檔案的目標位置，點選 下一步。
4. 選擇 讓 Windows 選擇（推薦）或 讓我選擇。




若您選擇 讓 Windows 選擇，Windows 將不會備份 1GB 或以上的程式，FAT 格式檔案，垃圾桶檔案或臨時檔案。

5. 按照螢幕出現的步驟完成設定。

還原您的系統

Windows 系統還原功能可能會建立還原點，在那裡系統可以在特定時間或日期儲存設定。此功能允許您還原或撤銷您對系統的更改且不影響您的個人資料。

請按照以下步驟還原您的系統：

1. 關閉所有正在執行的程式。
2. 點選  > 所有程式 > 附件 > 系統工具 > 系統還原。
3. 按照螢幕出現的步驟完成設定。

保護您的電腦

使用 Windows® 7 作業中心

Windows® 7 作業中心為您提供警示通知，安全資訊，系統維護資訊，自動疑難解決選項以及修復一些電腦常見問題。



您可以自行制定警示通知。更多資訊請參閱本章節的「自訂圖示與通知」。

進入 Windows® 7 作業中心

請按照以下步驟進入 Windows® 7 作業中心：

1. 點選通知圖示 ，再點選 開啟行動作業中心。



2. 在作業中心裡點選您想要進行的操作。



使用 Windows Update

Windows Update 允許您檢查與安裝最近的更新內容，以增強電腦的安全與效能。

進入 Windows Update

請按照以下步驟進入 Windows Update：

1. 在 Windows® 工作列中點選開始圖示  進入開始功能表。
2. 選擇 所有程式 > Windows Update。
3. 在 Windows Update 畫面中點選您想要進行的操作。




設定使用者帳戶與密碼

您可以為使用您電腦的使用者設定帳戶與密碼。

設定使用者帳戶

請按照以下步驟設定使用者帳戶：

1. 在 Windows 工作列中點選  > 開始使用 > 新增新使用者。
2. 選擇 管理其他帳戶。
3. 選擇 建立一個新帳戶。
4. 輸入新使用者名稱。
5. 選擇 標準使用者 或 系統管理員 作為使用者類型。
6. 完成後點選 建立帳戶。



您也可以 在 控制台 > 使用者帳戶 中做同樣的操作。

設定使用者密碼

請按照以下步驟設定使用者密碼：

1. 選擇您想要設定密碼的使用者。
2. 選擇 **變更您的使用者帳戶**。



3. 輸入密碼並確認。輸入密碼提示。
4. 完成後點選 **變更密碼**。



啟動防毒軟體（視具體機型而定）

部分電腦預裝了趨勢科技網路安全程式（Trend Micro Internet Security）。它是一個第三方防毒軟體，保護您的電腦免受病毒侵襲。該軟體需另行購買。在啟動它之後您將會有一段時間的試用期，通常為 60 天。

請按照以下步驟啟動趨勢科技網路安全（Trend Micro Internet Security）：

1. 執行趨勢科技網路安全（Trend Micro Internet Security）應用程式。
2. 仔細閱讀許可條款，然後點選 **同意並啟動**。
3. 輸入您的郵件地址並選擇您的位置。點選 **下一步**。
4. 點選 **完成** 結束啟動。

進入 Windows® 說明及支援

Windows 說明及支援提供您 Windows® 7 作業平臺中使用應用程式的說明與解決方法。

點選  > **說明及支援** 進入 Windows® 說明及支援。



請確認您已連線網路以獲得最新 Windows 線上支援。


第三章

裝置連接

連接 USB 儲存裝置

個人電腦的前後面板均有 USB 2.0/1.0 連接埠。USB 連接埠允許您連接 USB 裝置，例如儲存裝置。


欲連接 USB 儲存裝置，請將 USB 儲存裝置插入您的電腦。




前面板

後面板

請按照以下步驟移除 USB 儲存裝置：

1. 在 Windows 通知區域中點選  然後點選退出對應裝置。
2. 當出現 可以放心移除硬體 資訊後，將 USB 儲存裝置從電腦上移除。




請勿在資料傳輸過程中移除 USB 儲存裝置。這樣做會導致資料遺失或損壞 USB 儲存裝置。


連接麥克風與喇叭

個人電腦的前後面板均有麥克風連接埠與喇叭連接埠。後面板的音效 I/O 連接埠允許您連接二、四、六、八聲道立體聲喇叭。


連接耳機與話筒




連接二聲道喇叭




連接四聲道喇叭



連接六聲道喇叭



連接八聲道喇叭



連接多個外接顯示器

您的個人電腦視具體機型而定可能配有 VGA、HDMI、DVI 多個連接埠，允許您連接多個外接顯示器。




當您的電腦安裝好顯示卡後，將顯示器接連至顯示卡輸出連接埠。

設定多個顯示器


當您連接多個顯示器後，您可以設定顯示模式。可以讓新增顯示器與主顯示器顯示相同的內容，或作為主顯示器的延伸顯示器以擴充 Windows 桌面。

請按照以下步驟設定多個顯示器：

1. 關閉您的電腦。
2. 將兩個顯示器與您的電腦相連，並將電源線連接至這兩個顯示器。請參閱第一章「設定您的電腦」獲得更多連接顯示器的方法。



對於某些顯示卡，僅被設為主要顯示的顯示器才能在開機自我檢測時顯示出來。雙重顯示功能只有在 Windows 作業系統中運作。

3. 啟動您的電腦。
4. 請參考以下步驟開啟 **螢幕解析度** 進行設定：（由於機型不同，系統功能也會有差異，部分系統的控制台中直接可以看到顯示選項，而沒有個人化選項）
 - 點選  > 控制台 > 個人化 > 顯示 > 螢幕解析度。
 - 用滑鼠右鍵點選桌面，在隨即出現的選單中點選 **個人化 > 顯示 > 螢幕解析度**。
5. 選擇多個顯示器的顯示模式：下拉式選單
 - 在這些顯示器上同步顯示：選擇此項將新增的顯示器作為主顯示器的副本。
 - 延伸這些顯示器：選擇此項將新增的顯示器作為擴充顯示器。這將增加您的電腦使用空間。
 - 只在 1/2 上顯示桌面：選擇此項將僅在顯示器 1 或 2 上顯示桌面。



6. 點選 **套用** 或 **確定**。然後在確認訊息畫面上點選 **保留變更**。



連接高畫質電視 HDTV（選配）

將高畫質電視機與您電腦上的 HDMI 連接埠相連。



- 您需要一條 HDMI 線將高畫質電視機與電腦相連。HDMI 線需另行購買。
- 為得到最佳顯示效果，請確認您的 HDMI 線不長於 15 公尺。



第四章

使用您的電腦

使用電腦時的適當姿勢

使用者需要在使用電腦時保持適當的姿勢，防止腕部，手以及其他關節或肌肉的損傷。本章節將為您提供一些有用的資訊，防止您在使用個人電腦時感到身體不適或受傷。




請參考以下幾項保持適當姿勢：

- 適當放置您的電腦椅，確保您的肘部平行於或略高於鍵盤，使得到舒適的打字位置。
- 調整座椅的高度，確保您的膝蓋略高於您的臀部，使得您的大腿後側得到放鬆。如有需要，請使用腳凳抬高您的膝蓋。
- 調整座椅的後側，使其完全支撐您的脊椎並且稍向後傾斜。
- 挺直坐正，使您的膝蓋，肘部以及臀部成約 90 度。
- 將顯示器放在您的正前方，將顯示器頂部與您的視線持平，使您的視線稍向下。
- 使滑鼠靠近鍵盤，如有需要，請使用肘托以緩解打字時肘部的壓力。
- 請在舒適平整的地方使用您的個人電腦，避開光源，如窗或直射陽光。
- 使用一段時間後請稍作休息。

使用讀卡機

數位相機或其他數位影像裝置，都是採用記憶卡來儲存數位相片或多媒體檔案。視機型而定，本系統的前面板提供一部內建的多合一讀卡機，讓您可以隨時插入這些記憶卡來讀取 / 寫入數位檔案。



請按照以下步驟使用記憶卡：

1. 按下前面板連接埠蓋板上的“PUSH”按鈕。
2. 將記憶卡插入卡槽。



- 記憶卡均有缺口設計，因此只能由一個方向插入。請勿將卡強制插入卡槽以免卡受到損傷。
- 您可以在一個或多個卡槽中插入記憶卡，並逐一使用。請注意每個插槽只能插入一張記憶卡。

3. 在“自動播放”視窗中選擇一個程式來讀取檔案。



- 若您的電腦沒有自動播放功能，請點選 Windows 7 工作列中的開始按鈕，選擇 **電腦**，然後雙按記憶卡圖示進行資料讀取。
- 每個卡槽均有自己的磁碟機圖示，並顯示在 **電腦** 目錄下。
- 當資料被讀取或寫入記憶卡時，讀卡機顯示燈會亮起或閃爍。

4. 完成後用滑鼠右鍵點選記憶卡磁碟機圖示，點選 **退出**，然後移除記憶卡。



請勿在讀取、複製、格式化或移除記憶卡資料時或之後立即移除記憶卡，否則將可能導致資料遺失。



為了防止資料遺失，請在移除記憶卡之前使用通知區域中的 **安全移除硬體** 或退出媒體光碟。

使用光碟機



放入光碟

請按照以下步驟放入光碟：

1. 系統開啟時，按下光碟機上的按鈕退出光碟托盤。
2. 將光碟有印刷圖案的那一面朝上放入。
3. 將托盤推入，關閉光碟機。
4. 從 自動播放 選擇程式來讀取檔案。



若您的電腦沒有自動播放功能，請點選 Windows 7 工作列中的開始按鈕，選擇 電腦，然後雙按 CD/DVD 磁碟機圖示進行資料讀取。

退出光碟

請按照以下步驟退出光碟：

1. 系統開啟時，按下光碟機上的按鈕退出光碟托盤。
 - 按下光碟機上的退出按鈕。
 - 用滑鼠右鍵點選“電腦”畫面中的 CD/DVD 磁碟機圖示，然後點選 退出。
2. 將光碟從托盤中取出。

使用多媒體鍵盤 (選配)



鍵盤依型號而異。以下描述僅供參考。

華碩 SK-2045 鍵盤



按鍵	功能	按鍵	功能
1.	開啟 Windows® 小工具。	12.	按 <Fn + F7> 開啟 Microsoft® MSN，若沒有安裝 MSN，可直接開啟下載頁面。
2.	開啟 Windows® Flip 3D。	13.	按 <Fn + F8> 開啟 Windows® 搜尋畫面。
3.	在 Windows® Photo Viewer 中縮小照片尺寸。	14.	按 <Fn + F9> 播放或暫停 Windows® Media Player。
4.	在 Windows® Photo Viewer 中放大照片尺寸。	15.	按 <Fn + F10> 停止 Windows® Media Player。
5.	同時按下此鍵與 F1-F12 中任一鍵開啟各種功能。	16.	按 <Fn + F11> 返回上一軌。
6.	按 <Fn + F1> 開啟 Microsoft® Word。	17.	按 <Fn + F12> 跳至下一軌。
7.	按 <Fn + F2> 開啟 Microsoft® Excel。	18.	降低音量。
8.	按 <Fn + F3> 開啟 Microsoft® PowerPoint。	19.	增加音量。
9.	按 <Fn + F4> 開啟 Microsoft® Internet Explorer。	20.	開啟或關閉靜音模式。
10.	按 <Fn + F5> 開啟 Microsoft® Outlook。	21.	開啟 Windows® Media Player。
11.	按 <Fn + F6> 開啟 Windows® Internet Explorer 中的我的最愛。	22.	開啟 Windows® Media Center。



這些特殊功能按鍵只能在 Windows® Vista / Windows® 7 作業系統中使用。

第五章

網路連線

有線連接

使用 RJ-45 網路線將您的電腦與 DSL / Cable modem 或區域網路 (LAN) 相連。

透過 DSL / Cable modem 連線網路


請按照以下步驟透過 DSL/Cable modem 連線網路：

1. 設定您的 DSL / Cable modem。



請參閱您的 DSL / Cable modem 手冊。

2. 將 RJ-45 網路線的一端連接至電腦後面板的 LAN (RJ-45) 連接埠，另一端連接至 DSL / Cable modem。



3. 開啟 DSL / Cable modem 與您的電腦。
4. 進行所需網路連線設定。




更多關於網路設定的資訊與支援請洽詢您的網路服務提供商 (ISP)。

透過區域網路連接網路 (LAN)

請按照以下步驟透過區域網路連接網路：

1. 將 RJ-45 網路線的一端連接至電腦后面板的 LAN (RJ-45) 連接埠，另一端連接至區域網路。



2. 啟動您的電腦。
3. 進行所需網路連接設定。




更多關於網路設定的資訊與支援請洽詢您的網路管理員。

無線連接（選配）

透過無線將您的電腦與網路連接。



您需要連接一個無線存取點來建立無線連線。



- 請將外接天線連接至華碩無線網路卡的天線連接埠，以增強無線電訊號的接收範圍與靈敏度。
- 請將天線放置於電腦頂部以獲得最佳無線效能。
- 外接天線為選購配備。

請按照以下步驟連接無線網路：

1. 在通知區域中點選網路圖示  顯示可連線的無線網路。



2. 選擇您想要連接的無線網路，然後點選 **連線**。




3. 若要連接加密的無線網路，您需要輸入網路安全金鑰，然後點選 **確定**。



4. 您的電腦正在連接無線網路，請稍後。



5. 連線成功。畫面中顯示連接狀態，網路圖示  顯示已連線狀態。



第六章

使用應用程式（視機型而定）

華碩 AI Manager

華碩 AI Manager 是一款提供您快速便捷作業的電腦常用應用程式。

安裝 AI Manager

請依照以下步驟安裝 AI Manager：

1. 於光碟機中放入驅動與公用程式光碟，若您有開啟自動播放功能，則會立即顯示驅動程式安裝精靈畫面。



如果自動播放功能未被開啟，請在驅動及公用程式光碟中的 ASUS AI Manager 檔案夾裡雙按 SETUP.EXE 主程式以開啟此功能。

2. 點選 工具程式 標籤，然後點選 華碩 AI Manager。
3. 依照畫面的指示，進行安裝。

啟用 AI Manager


欲開啟 AI Manager，請從 Windows 系統的桌面左下角點選 開始 > 程式集 > ASUS > AI Manager > AI Manager 1.xx.xx。AI Manager 會快速啟動並顯示捷徑列（Quick Bar，如下圖）。



在開啟應用程式後，AI Manager 的小圖示將會顯示在 Windows 桌面下方的工作列中（如右圖）。






使用滑鼠右鍵點選這個圖示，可以在捷徑列與主應用程式之間切換，而且您也可以透過捷徑列或 Windows 工作列中的 AI Manager 小圖示來啟動 AI Manager。



AI Manager 捷徑列 (Quick Bar)


AI Manager 捷徑列的設計為節省桌面空間，並讓您快速開啟華碩工具程式與顯示系統資訊。點選在工具列上的主應用程式、我的最愛、技術支援或系統資訊項目來顯示該項目的選項。



點選放到最大/還原鈕  可以在全螢幕與捷徑列之間做切換；點選縮到最小鈕  則可以將 AI Manager 保留在桌面下方的工具列中；點選關閉鈕  則會離開 AI Manager 程式。

主應用程式 (Main)

主應用程式畫面中提供以下幾個工具程式：AI Disk、AI Security 與 AI Probe。點選主應用程式畫面上的箭頭小圖示來瀏覽主應用程式中的各個工具程式項目。



AI Disk

AI Disk 可讓您很輕鬆地選擇如下圖中的清除網際網路的暫存檔案、清除網際網路的 Cookies、清除資源垃圾桶的檔案、清除最近存取的 URL(S)、清除網站的瀏覽記錄或清除最近開啟的檔案清單項目。在捷徑列上點選 AI Disk 小圖示開啟 AI Disk 畫面，您可以在這裡選擇您所要清除的項目。完成時請點選 套用。



AI Security

AI Security 提供您設定密碼來保護您的裝置如 USB 隨身磁碟、CD/DVD，以防止未經授權下被他人盜取資料。

請依照以下步驟進行裝置的加密：

1. 第一次使用 AI Security 時，您會被要求輸入一組新密碼，請輸入一組最多不超過 20 個字母數字或符號組合而成的密碼。
2. 再次輸入新密碼。
3. 輸入新密碼的提示（建議）。
4. 當完成時，請點選 **確定**。



5. 接著如下圖，選擇您要進行加密的裝置，然後點選 **套用**。
6. 輸入您事先設定的密碼，然後點選 **確定**。



請依照以下步驟解除已加密的裝置：

1. 請取消勾選已加密的裝置名稱，然後點選 **套用**。
2. 輸入您事先已經設定的密碼，然後點選 **確定**。

請依照以下步驟變更密碼：

- 點選 **修改密碼**，然後依照畫面的指示進行變更。

AI Booting

AI Booting 提供您設定開機裝置的優先次序。



請依照以下步驟指定開機順序：

1. 選擇一個裝置，然後點選下方左邊或右邊的按鈕以排定開機順序。
2. 當完成選擇後，請點選 套用。

AI Probe

AI Probe 會自動偵測並顯示主機板與 CPU 的溫度、CPU 風扇的轉速，以及輸出的電壓，您也可以在此調整您所需要的數值。

點選 溫度、電壓 或 風扇轉速 標籤頁，然後選擇其中一項來開啟或變更您所要的數值。



我的最愛

在 **我的最愛** 項目中提供您加入常用的應用程式，保留給您自行從電腦中加入您所要的應用程式項目。



請依照以下步驟加入我的最愛應用程式：

1. 點選 **加入**，然後找到您所要增加至 **我的最愛** 中的應用程式。
2. 點選 **開啟** 檔案所在的視窗位置，應用程式將會增加到 **我的最愛** 中。

在該應用程式小圖示上使用滑鼠右鍵點選，則可以進行開啟、移除該應用程式，或變更名稱，您也可以使用滑鼠左鍵雙按以開啟該程式。

技術支援

在“技術支援”選單畫面中，您可以點選相關的連結來連線至華碩電腦-全球網站、華碩電腦-線上技術支援網站、華碩電腦-線上檔案下載網站或華碩電腦-聯絡資訊。



系統資訊

點選 **系統資訊** 選單可以看到關於您的系統、主機板、處理器、BIOS、安裝的裝置與記憶體的相关資訊。



華碩 EPU-4 Engine

華碩 EPU-4 Engine 可偵測當前電腦負載，並智慧地即時調節電量，為系統提供一套完整的節能方案。它自動調整 CPU、顯示卡、硬碟與 CPU 風扇的用電量。EPU-4 Engine 提供了三種用電模式：自動（最佳省電）（Auto）、高效能（High Performance）與最佳省電（Maximum Power Saving）模式，您可依據自己的使用情況選擇。



關於三種模式的詳細資訊，請參考「**華碩 EPU-4 主畫面**」部分的詳細說明。

安裝華碩 EPU-4

請依據以下步驟安裝 EPU-4 Engine：

1. 將驅動程式與公用程式光碟放入光碟機。若您的電腦開啟了自動播放功能。則 **驅動程式** 選單自動出現。



若自動播放功能未開啟，您可以到驅動程式與公用程式光碟中的 ASUS EPU-4 Engine 檔案夾中雙按 setup.exe 檔案。

2. 點選 ASUS EPU-4 Engine。
3. 接著依據螢幕指示完成安裝。

開啟華碩 EPU-4

請依據以下步驟開啟華碩 EPU-4：

1. 在 Windows 工具列中雙按 ASUS EPU-4 圖示。



- 當您第一次開啟華碩 EPU-4 時，會出現一條訊息，請您校準 EPU 功能。



點選 **校準**，開始校準，請等待幾秒。然後 ASUS EPU-4 主畫面出現。



進行校準可使系統偵測 CPU 內容，以獲得最佳的電能管理方案。

華碩 EPU-4 主畫面



1 CPU 狀態

顯示當前 CPU 功率與 CPU 節能總量。

2 VGA 卡狀態

顯示顯示卡狀態。若主機板不相容您的顯示卡，會出現 **找不到可支援的顯示卡** 的訊息。






請造訪 http://event.asus.com/mb/EPU-4_Engine/ 獲取華碩支援 EPU-4 功能的顯示卡清單。

-
- 3 硬碟狀態
當節能模式啟動時，此處亮起。
-
- 4 風扇狀態
顯示風扇狀態。
-
- 5 二氧化碳減少排放量按鈕
顯示二氧化碳的當前減少排放量或減少排放總量。
-
- 6 模式內容
顯示每種模式的內容。
-
- 7 離開按鈕
關閉華碩 EPU-4 公用程式。
-
- 8 校準按鈕
允許系統偵測硬體內容，以取得最佳電能使用方案。
-
- 9 設定按鈕
點選此按鈕進行模式設定。



詳細資訊請參考「設定模式」部分的詳細說明。

10	模式
	自動（最佳省電）模式 當您選擇此模式，系統依據當前系統狀態自動變更用電模式。
	高效能模式 當您選擇此模式，系統元件將超頻到最大效能。
	最佳省電模式 當您選擇此模式，系統自動為重要元件即時調整最佳用電方案，以節省電能。

華碩線上更新 (ASUS Update)

華碩線上更新程式是一套可以讓您在 Windows 作業系統下，用來管理、儲存與更新主機板 BIOS 檔案的公用程式。



- 在使用華碩線上更新程式之前，請先確認您已經透過內部網路對外連線，或者透過網際網路服務供應商 (ISP) 所提供的連接方式連線到網際網路。
- 隨主機板附贈的驅動程式與公用程式光碟中包含此公用程式。

安裝華碩線上更新程式

請依照以下步驟安裝華碩線上更新程式 (ASUS Update)：

1. 將驅動程式與公用程式光碟放入光碟機，會出現 **驅動程式** 選單。



若“自動播放”功能未開啟，請雙按驅動與應用程式光碟中 ASUS Update 檔案夾下的 setup.exe 檔案。

2. 點選 **公用程式** 標籤，然後點選 **安裝華碩線上更新程式**。
3. 華碩線上更新程式將被複製到您的系統中。



在您要使用華碩線上更新程式來更新 BIOS 程式之前，請先關閉其他所有的 Windows® 應用程式。

更新 BIOS 程式

1. 點選 **開始 > 程式集 > ASUS > ASUS Update > ASUS Update** 執行華碩線上更新主程式。
2. 在下拉式選單中點選下列作業之一：

使用網路更新 BIOS 程式

- a. 選擇 **Update BIOS from the Internet**，然後按下 **Next** 繼續。
- b. 請選擇離您最近的華碩 FTP 站台可避免網路堵塞，或者您也可以直接選擇 **Auto Select** 由系統自行決定。按下 **Next** 繼續。
- c. 接著再選擇您欲下載的 BIOS 版本。按下 **Next** 繼續。



華碩線上更新程式可以自行透過網路下載 BIOS 程式。經常的更新才能得到最新的功能。

使用 BIOS 檔案更新 BIOS 程式

- a. 在下拉式選單中選擇 **Update BIOS from a file**，然後按下 **Next** 繼續。
 - b. 在 **開啟** 視窗中選擇 BIOS 檔案的所在位置，然後點選 **開啟**。
3. 最後再依照螢幕畫面的指示來完成 BIOS 更新的程式。

華碩 MyLogo2™

華碩 MyLogo2™ 應用程式使您能夠客製化啟動圖示。啟動圖示會在開機自我測試時出現。華碩 MyLogo2™ 會在您安裝華碩線上更新程式時一並安裝到您的系統。



- 請造訪華碩官網 tw.asus.com 獲取最新 BIOS 檔案。
- 您可以將檔案存成 GIF 格式作為啟動圖示。

請按照以下步驟進入華碩 MyLogo2™：

1. 執行華碩線上更新程式。請參閱「華碩線上更新」一節。
2. 選擇下拉選單中的選項，然後點選 下一步。
3. 在更新 BIOS 之前請先執行 MyLogo 來置換系統啟動圖示。
4. 在下拉選單中選擇 以檔案更新 BIOS 然後點選 下一步。
5. 按照提示找到新的 BIOS 檔案，然後點選 下一步。華碩 MyLogo 視窗即在螢幕上出現。
6. 在視窗的左面板找到您想要用來作為啟動圖示的圖示，點選 下一步。
7. 在 Ratio 下拉選單中選擇您想要的圖示大小，點選 下一步。
8. 系統開始更新 BIOS，並載入新的啟動圖示。
9. 更新完成後，系統將重新啟動，並在開機自我檢測時顯示新圖示。

Nero

Nero 允許您建立、複製、燒錄、編輯、分享以及更新不同類型的資料。



安裝 Nero（以 Nero 9 為例）

請按照以下步驟安裝 Nero 9：

1. 將 Nero 9 驅動程式光碟插入光碟機。
2. 若您的電腦有自動播放功能，螢幕上會自動跳出主選單。



若您的電腦沒有自動播放功能，請雙按 Nero 9 光碟根目錄下的 SetupX.exe 安裝檔案。


3. 在主選單中點選 Nero 9 Essentials。



4. 選擇安裝精靈的語言，然後點選 下一步。




5. 點選 下一步 繼續。



6. 勾選 我接受授權條款，完成後點選 下一步。



7. 選擇 典型，然後點選 下一步。



8. 勾選 是，我想傳送匿名應用程式資料給 Nero，協助進行改善，然後點選 下一步。



9. 完成後點選 結束。




燒錄檔案

請參考以下步驟燒錄檔案：

1. 在主選單中點選 資料燒錄 > 新增。



2. 選擇您想要燒錄的檔案，點選 新增。



- 選擇您想要燒錄的檔案後，點選 **燒錄** 將已選檔案燒錄至光碟。



更多關於 Nero 9 的使用方法請造訪 Nero 網站 www.nero.com。

還原您的系統 (僅限預裝 Windows 作業系統的機器)

華碩個人電腦還原 DVD 光碟支援您重灌作業系統並將其還原至預設工作狀態。



在還原過程中所有資料將會遺失。在還原系統前，請確認您已備份所有資料，並記錄下所有自訂設定，如網路設定。

請按照以下步驟還原您的電腦：

- 開機時，當顯示 ASUS 標誌，請按下 **<F8>** 鍵進入“Please select boot device”選單。
- 放入還原 DVD 光碟，然後選擇光碟機為開機裝置，按下 **<Enter>** 鍵，然後按任一鍵繼續。
- 等待直至硬碟資訊畫面出現。選擇如何安裝一個新系統，選項有：

Recover System to a partition

本選項將會移除以下您所選擇的分割區（Partition），並允許您保留其他的既有的分割區，以及創建一個新的分割區如磁碟 C。選擇一個分割區後，按 **NEXT** 繼續。

Recover Windows to entire HD

本項目將會還原整顆硬碟成為單一分割區，執行此項目將會覆蓋您硬碟內所有資料，並創建一個全新的分割區，如磁碟 C，選定後，並選擇 **Yes** 繼續。

4. 勾選 **我接受**，然後點選 **下一步**。
5. 接著請依照畫面上的指示，完成還原的動作。
6. 當完成系統還原時，畫面會顯示請您放入產品的驅動與應用程式 DVD 光碟，請放入後並按 **OK** 與重新開機。
7. 在電腦重新開機後，Windows® 7 系統將會開始進行系統設定。請按照畫面上的指示來完成安裝，然後會再重新開機。



華碩個人電腦還原 DVD 光碟僅能使用在本個人電腦，請勿任意使用於其他的電腦上。有關本產品的最新資訊，請上華碩網站 <http://tw.asus.com> 查詢。

快速還原系統

（僅限預裝 Windows 作業系統的機器，且隱藏分割區未破壞）

1. 開啟華碩個人電腦，當顯示 **ASUS** 標誌時，按下 **<F9>** 進入“System Recovery”。
2. 此時畫面顯示 **Windows is loading files**。接著，“Recovery CD/DVD”視窗出現。
3. 按照螢幕上的說明完成還原過程。在系統重新開機後，顯示解析度與系統設定將還原為預設值。

第七章

疑難解決

本章節為您提供您可能遇到的疑難的解決方法。

1. 我的電腦無法開機，並且前面板電源指示燈未亮起。

- 檢查您的電腦是否連接電源。
- 檢查牆上的電源插座是否可用。
- 檢查是否開啟電源。更多資訊請參閱第一章「開啟或關閉您的電腦」。

2. 我的電腦當機。

- 請按照以下步驟關閉無回應的程式：
 1. 同時按下 <Alt> + <Ctrl> + <Delete>，然後點選 工作管理員。
 2. 點選 應用程式。
 3. 選擇未響應程式，然後用滑鼠右鍵點選 工作結束。
- 若鍵盤也無回應，請按住機殼頂部的電源按鈕直至電腦關閉。然後再按下電源按鈕重新啟動電腦。

3. 我無法使用華碩無線網路卡連接無線網路（選配）。

- 請確認您為想要連接的無線網路輸入了正確的網路安全金鑰。
- 將外接天線（選購）連接至華碩無線網路卡上的天線連接埠，並將天線放置在機殼的頂部以獲得最佳無線效能。

4. 數字鍵盤區域的方向鍵不起作用。

請確認數字鎖定指示燈已關閉。當指示燈亮起時這些數字鍵僅被用於輸入數字；若您想要使用該區域中的方向鍵，請按下數字鎖定鍵關閉指示燈。

5. 顯示器無法顯示。

- 請檢查顯示器是否開啟。
- 請確認您的顯示器與電腦上的視訊輸出連接埠正確相連。
- 若您的電腦內建獨立顯示卡，請確認您的顯示器與獨立顯示卡的視訊輸出連接埠相連。
- 請檢查顯示器視訊連接埠上的針腳是否彎曲。若您發現彎曲的針腳，請立即替換顯示器視訊連接埠接線。
- 請檢查您的顯示器是否正確連接電源。
- 更多疑難解決資訊請參考您的顯示器使用手冊。

6. 使用多個顯示器時，僅一個顯示器能顯示。

- 請確認這些顯示器電源已開啟。
- 在開機自我檢測時僅連接至 VGA 連接埠的顯示器可以顯示。雙顯示功能僅在 Windows 系統中適用。
- 若您的電腦安裝了顯示卡，請確認將顯示器連接至顯示卡的輸出連接埠。
- 請檢查多個顯示器是否正確設定。更多資訊請參閱第三章「連接多個外接顯示器」。


7. 我的電腦無法偵測 USB 儲存裝置。

- 當您第一次將 USB 儲存裝置與電腦相連時，Windows 會自動安裝它的驅動程式。完成後請點選進入 **電腦** 來檢查是否偵測到 USB 儲存裝置。
- 將您的 USB 儲存裝置連接至另一台電腦來檢測此 USB 儲存裝置是否損壞。





8. 我想要還原或撤銷對電腦系統的更改，同時不影響我的個人檔案或資料。

Windows® 系統還原功能允許您還原或撤銷對電腦系統的更改，同時不影響您的個人檔案或資料如文檔或圖片。更多資訊請參閱第二章「還原您的電腦」。

9. 高畫質電視上的圖像變形。

- 您的顯示器或高畫質電視的不同解析度會導致圖像變形。請調整螢幕解析度至適合您的高畫質電視。請按照以下步驟改變您的螢幕解析度：
 - 請參考以下任意一項打開螢幕解析度設定；
 - 點選  > 控制台 > 個人化 > 顯示 > 改變顯示器設定。
 - 用滑鼠右鍵點選桌面。選單出現後，點選 個人化 > 顯示 > 改變顯示器設定。
 - 調整解析度。相關資訊請參閱您的高畫質電視的使用手冊。
 - 點選 套用 或 確定。然後在確認資訊中點選 保留變更。

10. 我的喇叭沒有聲音。

- 請確認您將您的喇叭連接至前面板或後面板的音效輸出埠（草綠色）。
- 請確認您的喇叭是否連接電源並開啟。
- 調整喇叭的音量。
- 請確認您沒有啟動靜音模式。
- 若您啟動靜音，音量圖標將顯示為 。若要開啟系統聲音，請點選通知區域的 ，然後點選 。
- 若沒有啟動靜音，點選  滑動卷軸調整音量。
- 將您的喇叭與另一台電腦相連測試它是否正常運作。

11. DVD 光碟機無法讀取光碟。

- 請確認光碟是以標籤面朝上放入光碟機。
- 請確認光碟是否正確放入托盤，尤其是非標準大小的光碟。
- 請檢查光碟是否有所掛上或損壞。

12. DVD 光碟機退出按鈕不起作用。


- 點選  > 電腦。
- 用滑鼠右鍵點選 ，然後在選單中點選 離開。



华硕 Essentio 台式电脑

CP1130

用户手册



C5313

第一版

2010 年 1 月

版权所有 • 不得翻印 © 2010 华硕电脑

本产品的所有部分，包括配件与软件等，其相关知识产权等归华硕电脑公司（以下简称华硕）或授权华硕使用的相关主体所有，未经权利主体许可，不得任意地仿制、拷贝、摘抄或转译。本用户手册没有任何型式的担保、立场表达或其它暗示。若有任何因本用户手册或其所提到之产品信息，所引起直接或间接的数据流失、利益损失或事业终止，华硕及其所属员工恕不为其担负任何责任。除此之外，本用户手册所提到的产品规格及信息只作参考，内容亦会随时更新，恕不另行通知。

下列因素导致的产品故障或损坏不在免费保修范围内：

- A. 因天灾(水灾、火灾、地震、雷击、台风等)、遇不可抗力外力或人为之操作使用不慎造成之损害。
- B. 自行拆装、修理、或将产品送至非华硕认证之维修点进行检测维修。
- C. 用户擅自或请第三人修改、修复、变更规格及安装、添加、扩充非本公司原厂销售、授权或认可之配件所引起之故障与损坏。
- D. 因用户自行安装软件及设置不当所造成之使用问题及故障。
- E. 计算机病毒所造成之问题及故障。
- F. 本公司保修识别标签撕毁或无法辨认，涂改保修服务卡或与产品不符。
- G. 要求华硕提供软件安装服务(用户需自行提供原版软件)、软件故障排除或清除密码等。
- H. 其它不正常使用所造成之问题及故障。

用户手册中所谈论到的产品名称仅做识别之用，而这些名称可能是属于其他公司的注册商标或是版权。

关于产品规格最新的升级信息请您到华硕的官方网站浏览或是直接与华硕公司联络。

目录内容

注意事项	v
安全性须知	vii
提示符号	viii
哪里可以找到更多的产品信息	viii
包装内容	ix

第一章：系统导览

欢迎	1-1
了解您的台式电脑	1-1
安装您的台式电脑	1-5
开启或关闭您的电脑	1-8

第二章：使用 Windows® 7（选配）

第一次启动	2-1
使用 Windows® 7 桌面	2-2
管理文件与文件夹	2-7
还原您的系统	2-10
保护您的电脑	2-11
进入 Windows 帮助和支持	2-15

第三章：设备连接

连接 USB 存储设备	3-1
连接麦克风与喇叭	3-2
连接多个外接显示器	3-5
连接高清电视 HDTV（选配）	3-7

第四章：使用您的电脑

使用电脑时的适当姿势	4-1
使用读卡器	4-2
使用光驱	4-3
使用多媒体键盘（选配）	4-4

第五章：网络连接

有线连接	5-1
无线连接（选配）	5-3

目 录 内 容

第六章：使用应用程序（选配）

华硕 AI Manager	6-1
华硕 EPU-4 Engine.....	6-6
华硕在线升级（ASUS Update）	6-9
华硕 MyLogo2™.....	6-10
Nero	6-11
恢复您的系统（仅限预装 Windows 操作系统的机器）	6-15

第七章：疑难解决

注意事项

REACH

谨遵守 REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) 管理规范, 我们会将产品中的化学物质公告在华硕 REACH 网站, 详细请参考 <http://green.asus.com/english/REACH.htm>

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

电池警告

注意：若更换了不正确电池可能会有爆炸的危险。请使用制造商推荐的同种或相同电池。请依照制造商的指示来处理使用过的电池。



电子信息产品污染控制标示：图中之数字为产品之环保使用期限。仅指电子信息产品中含有的有毒有害物质或元素不致发生外泄或突变从而对环境造成污染或对人身、财产造成严重损害的期限。

有毒有害物质或元素的名称及含量说明标示：

部件名稱	有害物質或元素					
	鉛(Pb)	汞(Hg)	鎘(Cd)	六價鉻 (Cr(VI))	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
印刷電路板及其電子組件	×	○	○	○	○	○
外部信號連接頭及線材	×	○	○	○	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。

×

表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求，然该部件仍符合欧盟指令 2002/95/EC 的规范。

备注：此产品所标示之环保使用期限，系指在一般正常使用状况下。

安全性须知



在清洁电脑之前，请先关机并移除电源与所有外围设备。您可以使用干净柔软的海绵或清洁布，沾上少许中性清洁剂与温水，来擦拭您的台式电脑，接着用干布擦去多余的水迹。

- 请勿将台式电脑放置于不平坦或不稳定的表面。若台式电脑的机箱损坏，请联络维修服务人员。
- 请勿在灰尘飞扬或环境脏乱的场所使用台式电脑。请勿在泄漏的可燃气体附近操作台式电脑。
- 请勿在台式电脑上放置其他物品。请勿将任何物品塞入电脑机件中，以免引起机件短路或电路损毁。
- 请勿将台式电脑放置于具有强大电磁场的环境中。
- 请保持机器在干燥的环境下使用，雨水、湿气、液体等含有矿物质，将会腐蚀电子线路。请勿在雷电天气下使用调制解调器。
- 电池安全警告：请勿将电池丢入火中。请勿将电池的正负极短路。请勿自行拆解电池。
- 请在温度为 0°C 至 35°C 的环境中使用本电脑。
- 请勿堵塞台式电脑的通风孔，以免因散热不良而导致系统过热。
- 请勿使用破损的电源线、附件或其他外围设备。
- 为了防止电击风险，在搬动电脑主机之前，请先将电脑电源插头暂时从电源插座上拔除。
- 在使用电源适配器或电源延长线前，我们建议您先寻求专业人士的协助。这些设备有可能会干扰接地的回路。
- 请确定电源的电压设置已调整到本国/本区域所使用的电压标准值。若您不确定您所属区域的供应电压值为何，请就近询问当地的电力公司人员。
- 如果电源已损坏，请勿尝试自行修复。请将其交给专业技术服务人员或经销商来处理。

提示符号

为了能够确保您正确地完成主板设置，请务必注意下面这些会在本手册中出现的标示符号所代表的特殊含意。



警告：提醒您在进行某一项工作时要注意您本身的安全。



小心：提醒您在进行某一项工作时要注意勿伤害到电脑主板元件。



重要：此符号表示您必须要遵照手册所描述之方式完成一项或多项软硬件的安装或设置。



注意：提供有助于完成某项工作的诀窍和其他额外的信息。

哪里可以找到更多的产品信息

您可以通过下面所提供的两个渠道来获得您所使用的华硕产品信息以及软硬件的更新信息等。





1. 华硕网站

您可以到 <http://www.asus.com.cn> 华硕网站取得所有关于华硕软硬件产品的各项信息。

2. 其他文件

在您的产品包装盒中除了本手册所列举的标准配件之外，也有可能夹带有其他的文件，譬如经销商所附的产品保证单据等。

包装内容

		
华硕 Essentio 台式电脑	键盘 x1	鼠标 x1
		
电源线 x1	驱动程序与应用程序 光盘 x1	恢复光盘 x1 （选配）
		
刻录软件光盘 x1 （选配）	安装向导 x1	华硕保修服务卡 x1
		
天线（选购）x 2		



- 若包装内容有所损坏或丢失，请速与经销商联系。
- 上述图中所示物品仅供参考。实际产品规格依不同型号而定。

第一章

系统导览

欢迎

感谢您购买华硕 CP1130 台式电脑。

华硕 CP1130 台式电脑拥有一流的性能，超凡的可靠性与以用户为中心的应用程序，并安装在华硕特别设计的机箱中。




请在安装您的机箱前先参阅您的华硕保修服务卡。

了解您的台式电脑



本手册中的机箱图片描述仅供参考。各接口及其位置与外壳颜色均依不同机型而变。


主机前面板



点击号码以查看相关描述。

1. 电源按钮：按下此按钮启动您的电脑。
2. 光驱弹出按钮：按此按钮弹出光盘。
3. 光驱槽盖：此处有光驱。
4. 麦克风接口（粉红色）：此接口可连接麦克风。
5. 耳机接口（草绿色）：该接口可连接耳机或喇叭。
6. USB 2.0 接口：可连接 USB 设备，如鼠标、打印机、扫描仪、相机、PDA 等。
7. MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ 卡槽：将 MultiMediaCard / Secure Digital™ / Memory Stick™ / Memory Stick Pro™ 卡插入此槽。
8. 前面板 I/O 接口盖板。

机箱后面板



点击号码以查看相关描述。

1. 通风孔：进行空气流通。




请勿堵住通风孔。经常为您的电脑通风。

2. 电源接口：连接电源线。
3. 音效输出接口（草绿色）：您可以连接耳机或喇叭等的音频接收设备。在四声道、六声道、八声道的喇叭设置模式时，本接头是作为连接前置主声道喇叭之用。
4. 麦克风接口（粉红色）：此接口可连接麦克风。
5. 侧边环绕喇叭接口（灰色）：在八声道音效设置下，这个接口可以连接侧边环绕喇叭。
6. 后置环绕喇叭接口（黑色）：本接口在四声道、六声道、八声道设置下是用来连接后置环绕喇叭。
7. 音频输入接口（浅蓝色）：您可以将磁带、CD、DVD 播放器等的音效输出端连接到此音频输入接口。
8. 中央声道与重低音喇叭接口（橘色）：这个接口可以连接中央声道与重低音喇叭。
9. RJ-45 网络接口：通过网络中心连接到一个局域网（LAN）。

网络指示灯说明

Activity/Link 指示灯		速度指示灯	
状态	描述	状态	描述
关闭	没有连接	关闭	连接速度 10Mbps
关闭	已连接	关闭	连接速度 100Mbps
闪光灯	资料传输中	绿色	连接速度 1Gbps

ACT/LINK 指示灯 速度指示灯



网络接口



在 2、4、6、8 声道音频设置上，音频输出、音频输入与麦克风接头的功能会随着声道音频设置的变化而改变，如下表所示。

二、四、六或八声道音频设置

接头	耳机 / 二声道喇叭输出	四声道喇叭输出	六声道喇叭输出	八声道喇叭输出
浅蓝色	声音输入端	声音输入端	声音输入端	声音输入端
草绿色	声音输出端	前置喇叭输出	前置喇叭输出	前置喇叭输出
粉红色	麦克风输入端	麦克风输入端	麦克风输入端	麦克风输入端
橘色	-	-	中央重低音喇叭输出	中央重低音喇叭输出
黑色	-	后置喇叭输出	后置喇叭输出	后置喇叭输出
灰色	-	-	-	侧边喇叭输出

10. USB 2.0 接口：可连接 USB 2.0 设备，如鼠标、打印机、扫描仪、相机、PDA 等。
11. VGA 接口：此接口连接 VGA 兼容设备，如 VGA 显示器。
12. HDMI 接口：此高清晰多媒体接口兼容 HDCP，能够播放 HD DVD，蓝光光盘以及其他保护内容。
13. 华硕显卡（选配）：此显卡上的显示接口可能随不同机器而变。
14. 华硕无线网卡（选配）：使电脑连接到无线网络。

安装您的台式电脑

该章节引导您连接主要硬件设备，例如外部显示器、键盘、鼠标以及电源线至您的电脑。

连接一个外部显示器

使用华硕显卡（选配）


将您的显示器连接至华硕独立显卡的显示接口。

请依照以下步骤使用华硕显卡连接一个外部显示器：

1. 将您的显示器连接至华硕独立显卡的显示接口。
2. 将显示器插上电源。



华硕独立显卡的显示接口随机型不同而改变。




使用内置显示接口

将您的显示器连接至机箱内部显示接口。

请按照以下步骤使用内置显示接口连接一个外部显示器：


1. 根据实际内部接口的种类，选择一个带有 VGA 接口的显示器连接至后面板上的 VGA 接口，或一个带有 DVI-D 接口的显示器连接至 DVI-D 接口，或一个带有 HDMI 接口的显示器连接至 HDMI 接口。
2. 将显示器插上电源。



- 若您的电脑装有华硕显卡，则该显卡在 BIOS 中被设置为主要显示设备。因此，请将您的显示器连接至显卡上的显示接口（请以实际产品显卡上的接口为主）。
- 若要连接多个外部显示器，请参阅第三章“连接多个外部显示器”以获得更多信息。

连接 USB 键盘与鼠标

将一个 USB 键盘与鼠标连接至后面板的 USB 接口。




连接电源线

将电源线的一端连接至后面板的电源接口，另一端插上电源。



本产品系统规格为：100-240Vac，47-63Hz，3.5A。



开启或关闭您的电脑

本章节引导您在安装完成后如何开启或关闭您的电脑。

开启您的电脑

请按照以下步骤开启您的电脑：

1. 开启您的显示器。
2. 开启电源开关，然后按下电源按钮。



电源按钮



3. 等待直至操作系统自动载入。

关闭您的电脑

请按照以下步骤关闭您的电脑：

1. 关闭所有运行中的程序。
2. 在 Windows® 桌面上点击 .
3. 点击  关闭操作系统。
4. 关闭电源开关。

第二章

使用 Windows® 7（选配）

第一次启动

当您第一次启动电脑时，屏幕上会出现一系列画面以引导您进行 Windows® 7 操作系统的基本设置。

当电脑第一次启动时，请按照以下步骤操作：

1. 启动您的电脑。等待几分钟直至“设置 Windows”画面出现。
2. 在下拉菜单中选择您想要的语言，然后点击【下一步】。
3. 在下拉菜单中选择您的国家或地区、时区、货币以及键盘布局，然后点击【下一步】。
4. 输入用户名与电脑名称，然后点击【下一步】。
5. 输入所需信息来设置您的密码，然后点击【下一步】。您也可以不输入任何信息，点击【下一步】跳过这一步。




若您想稍后为您的帐户设置密码，请参阅本章节“设置用户帐号及密码”。

6. 请仔细阅读许可条款。勾选“我愿意接受许可条款”，然后点击【下一步】。
7. 选择“使用推荐设置”或“仅安装重要更新”来为您的电脑进行安全设置。若您想要跳过这一步请选择【以后问我】。
8. 请再次确认您的日期与时间设置，然后点击【下一步】。系统开始载入新设置并重新启动。您可以现在入门您的电脑。

使用 Windows® 7 桌面



点击开始图标  > 【帮助和支持】来获取更多关于 Windows® 7 操作系统的信息。




使用开始菜单

开始菜单允许您进入电脑上的程序或其它使用项目。它通过“帮助和支持”功能提供您更多 Windows® 7 的信息。

从开始菜单进入选项

请按照以下步骤由开始菜单进入选项：

1. 在 Windows® 任务栏中点击开始图标 .
2. 在开始菜单中选择您想要进入的选项。




您可以将您常用的程序钉在开始菜单中成为一个小图标。更多信息请参阅本章节“在开始菜单或任务栏中添加程序”。

使用“入门”选项

开始菜单中的“入门”选项包括一些基本操作的信息，例如个性化 Windows®，添加新用户，传输文件等，帮助您更了解如何使用 Windows® 7 操作系统。

请按照以下步骤使用“入门”：

1. 在 Windows® 任务栏中点击开始图标
 进入开始菜单。
2. 选择“入门”展开一系列任务选项。
您也可以点击【开始】>【控制面板】>【入门】进入操作。
3. 选择您想要的任务选项。



使用任务栏

任务栏允许您进入以及管理已安装在您的电脑上的程序或选项。

从任务栏进入程序

请按照以下步骤从任务栏进入程序：

- 在任务栏中点击一个图标进入此程序。再次点击图标可隐藏此程序。



您可以将您常用的程序钉在开始菜单中成为一个小图标。更多信息请参阅本章节“在开始菜单或任务栏中添加程序”。

在快捷方式中添加选项

当您用鼠标右键点击任务栏中的一个图标时，屏幕上会出现快捷方式以提供您快速进入该程序或选项的相关链接。您也可以将所需选项钉在快捷方式上，例如您喜爱的网站、经常浏览的文件夹、驱动程序或最近播放的媒体文件。

请按照以下步骤将选项钉在快捷方式：

1. 右击任务栏中的一个图标。
2. 在快捷方式中右击你想要钉入的选项，然后选择“将此程序锁定到任务栏”。




在快捷方式中删除选项

请按照以下步骤在快捷方式中删除选项：

1. 右击任务栏中的一个图标。
2. 在快捷方式中右击你想要删除的选项，然后选择“将此程序从任务栏解锁”。

在开始菜单或任务栏中添加程序

请按照以下步骤在开始菜单或任务栏中添加程序：

1. 在 Windows® 任务栏中点击开始图标  进入开始菜单。
2. 在开始菜单或任务栏中右击你想要钉入的选项。
3. 选择“锁定到任务栏”或“附到开始菜单”。




您也可以右击任务栏中一个正在运行的程序的图标，然后选择“将此程序锁定到任务栏”。



在开始菜单中删除程序


请按照以下步骤在开始菜单中删除程序：

1. 在 Windows® 任务栏中点击开始图标  进入开始菜单。
2. 在开始菜单中右击你想要删除的程序。然后选择“从开始菜单解锁”。

在任务栏中删除程序




请按照以下步骤在任务栏中删除程序：

1. 在任务栏中右击你想要删除的程序，然后选择“将此程序从任务栏解锁”。



使用通知区域

默认的通知区域显示以下三种图标：

	<p>操作中心通知</p> <p>点击该图标显示所有警告信息或通知，以及进入 Windows® 操作中心。</p>
	<p>网络连接</p> <p>该图标显示有线/无线网络连接状态以及信号强度。</p>
	<p>音量</p> <p>点击此图标调节音量。</p>

显示通知

请按照以下步骤显示通知：

- 点击通知图标 ，然后点击第一行的“重要信息”打开。




更多信息请参阅本章节“Windows® 操作中心”。

自定义图标与通知

您可以选择在任务栏或通知区域显示或隐藏图标与通知。

请按照以下步骤自定义图标或通知：

1. 在通知区域点击箭头图标 。
2. 点击“自定义”。
3. 在下拉菜单中选择您想要自定的图标或选项的行为。




管理文件与文件夹

使用 Windows® 浏览器

Windows® 浏览器允许您查看或管理您的文件与文件夹。

进入 Windows® 浏览器

请按照以下步骤进入 Windows® 浏览器：


1. 在任务栏中点击开始图标  进入开始菜单。
2. 点击【计算机】进入 Windows® 浏览器。



浏览文件与文件夹


请按照以下步骤浏览文件与文件夹：


1. 进入 Windows® 浏览器。
2. 在导航面板或视图面板中寻找所需数据的位置。
3. 在地址栏中点击箭头显示磁盘驱动器或文件夹。



自定义文件或文件夹视图

请按照以下步骤自定义文件夹预览方式视图：

1. 进入 Windows® 浏览器。
2. 在导航面板中选择您所需数据的位置。
3. 在工具栏中点击视图图标 。
4. 在视图菜单中滑动滑块选择你想要检视文件或文件夹的方式。



您也可以在视图面板上右击任何一处，在展开的选项中点击【查看】，并选择您想要检视文件或文件夹的方式。



排列您的文件

请按照以下步骤排列您的文件：

1. 进入 Windows® 浏览器。
2. 点击【排列方式】显示下拉菜单及选项。
3. 选择您想要的排列方式。



排序您的文件

请按照以下步骤排列您的文件：

1. 进入 Windows® 浏览器。
2. 在视图面板上右击任何一处。
3. 在出现的菜单中选择【排序方式】，然后选择您想要的排列方式。



分组您的文件

请按照以下步骤分组您的文件：

1. 进入 Windows® 浏览器。
2. 在视图面板上右击任何一处。
3. 在出现的菜单中选择【分组依据】，然后选择您想要的分组方式。




添加一个新文件夹

请按照以下步骤添加一个新文件夹：

1. 进入 Windows® 浏览器。
2. 在工具栏中点击【新建文件夹】。
3. 输入新文件夹名称。




您也可以在视图面板上右击任何一处，点击【新建】>【文件夹】。



备份文件

设置备份

请按照以下步骤设置备份：

1. 点击  > 【所有程序】> 【维护】> 【备份与还原】。
2. 点击【设置备份】，然后再点击【下一步】。



3. 选择备份文件的方位，点击【下一步】。
4. 选择“让 Windows 选择（推荐）”或“让我选择”。




若您选择“让 Windows 选择”，Windows® 将不会备份 1GB 或以上的程序，FAT 格式文件，回收站文件或临时文件。

5. 按照屏幕出现的步骤完成设置。

还原您的系统

Windows® 系统还原功能可能会建立还原点，在那里系统可以在特定时间或日期储存设置。此功能允许您还原或撤销您对系统的更改且不影响您的个人数据。

请按照以下步骤还原您的系统：

1. 关闭所有正在运行的程序。
2. 点击  > 【所有程序】> 【附件】> 【系统工具】> 【系统还原】。
3. 按照屏幕出现的步骤完成设置。

保护您的电脑

使用 Windows® 7 操作中心

Windows® 7 操作中心为您提供警惕通知，安全信息，系统维护信息，自动疑难解决选项以及修复一些电脑常见问题。



您可以自行制定警惕通知。更多信息请参阅本章节的“制定图标与通知”。

进入 Windows® 7 操作中心

请依以下步骤进入 Windows® 7 操作中心：

1. 点击通知图标 ，再点击“打开操作中心”。



2. 在操作中心里点击您想要进行的操作。




使用 Windows Update

Windows Update 允许您检查与安装最近的更新内容，以增强电脑的安全性与性能。

进入 Windows Update

请按照以下步骤进入 Windows Update：

1. 在 Windows® 任务栏中点击开始图标  进入开始菜单。
2. 选择【所有程序】>【Windows Update】。
3. 在 Windows Update 画面中点击您想要进行的操作。




设置用户帐户与密码

您可以为使用您电脑的用户设置帐户与密码。

设置用户帐户

请按照以下步骤设置用户帐户：

- 1. 在 Winodws 任务栏中点击  > 【入门】> 【添加新用户】。
- 2. 选择【管理其他帐户】。
- 3. 选择【建立一个新帐户】。
- 4. 输入新用户名称。
- 5. 选择【标准用户】或【管理员】作为用户类型。
- 6. 完成后点击【创建帐户】。



您也可以在【控制面板】>【用户帐户】做同样的操作。

设置用户密码

请按照以下步骤设置用户密码：

1. 选择您想要设置密码的用户。
2. 选择“为您的帐户创建密码”。



3. 输入密码并确认。输入密码提示。
4. 完成后点击【创建密码】。



激活杀毒软件（视具体机型而定）


部分电脑预装了趋势科技网络安全程序（Trend Micro Internet Security）。它是一个第三方杀毒软件，保护您的电脑免受病毒侵袭。该软件需另行购买。在激活它之后您将会有一段时间的试用期，通常为 60 天。

请按照以下步骤激活趋势科技网络安全（Trend Micro Internet Security）：

1. 执行趋势科技网络安全（Trend Micro Internet Security）应用程序。
2. 仔细阅读许可条款，然后点击【同意并激活】。
3. 输入您的邮件地址并选择您的位置。点击【下一步】。
4. 点击【完成】结束激活。

进入 Windows® 帮助和支持

Windows® 帮助和支持提供您 Window® 7 作业平台中使用应用程序的指导与解决方法。

点击  > 【帮助和支持】进入 Windows® 帮助和支持。



请确认您已连接网络以获得最新 Winows 线上帮助。

第三章

设备连接

连接 USB 存储设备

台式电脑的前后面板均有 USB2.0/1.0 接口。USB 接口允许您连接 USB 设备，例如存储设备。


欲连接 USB 存储设备，请将 USB 存储设备插入您的电脑。



前面板

后面板

请按照以下步骤移除 USB 存储设备：

1. 在 Windows 通知区域点击  然后点击【弹出对应设备】。



2. 当出现“安全地移除硬件”信息后，将 USB 存储设备从电脑上移除。




请勿在数据传输过程中移除 USB 存储设备。这样做会导致数据丢失或损坏 USB 存储设备。


连接麦克风与喇叭

台式电脑的前后面板均有麦克风接口与喇叭接口。后面板的音频 I/O 接口允许您连接二、四、六、八声道立体声喇叭。


连接耳机与话筒




连接二声道喇叭




连接四声道喇叭



连接六声道喇叭



连接八声道喇叭



连接多个外接显示器

您的台式电脑视具体机型而定可能配有 VGA、HDMI、DVI 多个接口，允许您连接多个外接显示器。




当您的电脑安装好显卡后，将显示器接连至显卡输出接口。

设置多个显示器


当您连接多个显示器后，您可以设置显示模式。您可以让添加显示器与主显示器显示相同的内容，或作为主显示器的扩展显示器以扩展 Windows 桌面。

请按照以下步骤设置多个显示器：

1. 关闭您的电脑。
2. 将两个显示器与您的电脑相连，并将电源线连接至这两个显示器。请参阅第一章“设置您的电脑”获得更多连接显示器的方法。



对于某些显卡，仅被设为主要显示的显示器才能在开机自检时显示出来。双重显示功能只有在 Windows 操作系统中运行。

3. 启动您的电脑。
4. 请参考以下步骤开启“屏幕分辨率”进行设置：（由于机型不同，系统功能也会有差异，部分系统的控制面板中直接可以看到显示选项，而没有个性化选项）
 - 点击  >【控制面板】>【个性化】>【显示】>【调整屏幕分辨率】。
 - 右击桌面，在随即出现的菜单中点击【个性化】>【显示】>【调整屏幕分辨率】。
5. 选择多个显示器的显示模式：下拉菜单
 - 复制这些显示：选择此项将添加的显示器作为主显示器的副本。
 - 扩展这些显示：选择此项将添加的显示器作为扩展显示器。这将增加您的电脑使用空间。
 - 只在 1/2 上显示桌面：选择此项将仅在显示器 1 或 2 上显示桌面。



6. 点击【应用】或【确定】。然后在确认信息画面上点击【保留更改】。



连接高清电视 HDTV（选配）

将高清电视机与您电脑上的 HDMI 接口相连。



- 您需要一根 HDMI 线将高清电视机与电脑相连。HDMI 线需另行购买。
- 为得到最佳显示效果，请确认您的 HDMI 线不长于 15 米。



第四章

使用您的电脑

使用电脑时的适当姿势

用户需要在使用电脑时保持适当的姿势，防止腕部，手以及其他关节或肌肉的损伤。本章节将为您提供一些小贴士，防止您在使用台式电脑时感到身体不适或受伤。




请参考以下几项保持适当姿势：

- 适当放置您的电脑椅，确保您的肘部平行于或略高于键盘，使得到舒适的打字位置。
- 调节座椅的高度，确保您的膝盖略高于您的臀部，使得您的大腿后侧得到放松。如有需要，请使用脚凳抬高您的膝盖。
- 调节座椅的后侧，使其完全支撑您的脊椎并且稍向后倾斜。
- 挺直坐正，使您的膝盖，肘部以及臀部成约 90 度。
- 将显示器放在您的正前方，将显示器顶部与您的视线持平，使您的视线稍向下。
- 使鼠标靠近键盘，如有需要，请使用肘托以缓解打字时肘部的压力。
- 请在舒适平整的地方使用您的台式电脑，避开光源，如窗或直射阳光。
- 使用一段时间后请稍作休息。

使用读卡器

数码相机其他的数码影像设备，都是采用存储卡来存储数码相片或媒体文件。选配，本系统的前面板提供一部内置的多合一读卡器，让您可以随时插入这些存储卡来读取/写入数字文件。



请按照以下步骤使用存储卡：

1. 按下前面板接口盖板上的“PUSH”按钮。
2. 将存储卡插入卡槽。



- 因为存储卡上均有缺口设计，因此只能以一个方向插入。请勿将卡强制插入卡槽以免卡受到损伤。
- 您可以在一个或多个卡槽中插入存储卡，并逐一使用。请注意每个插槽只能插入一张存储卡。

3. 在“自动播放”视窗中选择一个程序来读取文件。



- 若您的电脑没有自动播放功能，请点击 Windows 7 任务栏中的开始按钮，选择“计算机”，然后双击存储卡图标进行数据读取。
- 每个卡槽均有自己的驱动器图标，并显示在“计算机”目录下。
- 当数据被读取或写入存储卡时，读卡器显示灯会亮起或闪烁。

4. 完成后右击存储卡图标，点击【弹出】，然后移除存储卡。



请勿在读取、复制、格式化或删除存储卡数据时或之后立即移除存储卡，否则将可能导致数据丢失。



为了防止数据丢失，请在移除存储卡之前使用通知区域中的“安全移除硬件或弹出媒体光盘”。

使用光驱



放入光盘

请按照以下步骤放入光盘：

1. 系统开启时，按下光驱上的按钮退出光盘托盘。
2. 将光盘有印刷图案的那一面朝上放入。
3. 将托盘推入，关闭光驱。
4. 从“自动播放”选择程序来读取文件。



若您的电脑没有“自动播放”功能，请点击 Windows 7 任务栏中的开始按钮，选择“计算机”，然后双击 CD/DVD 驱动器图标进行数据读取。

退出光盘

前按照以下步骤退出光盘：

1. 系统开启时，按下光驱上的按钮退出光盘托盘。
 - 按下光驱上的退出按钮。
 - 右击“计算机”画面中的 CD/DVD 驱动器图标，然后点击【弹出】。
2. 将光盘从托盘中取出。

使用多媒体键盘（选配）



键盘依型号而异。以下描述仅供参考。

华硕 SK-2045 键盘



按键	功能	按键	功能
1.	开启 Windows® 小工具。	12.	按 <Fn + F7> 开启 Microsoft® MSN，若没有安装 MSN，可直接开启下载页面。
2.	开启 Windows® Flip 3D。	13.	按 <Fn + F8> 开启 Windows® 搜索画面。
3.	在 Windows® Photo Viewer 中缩小照片尺寸。	14.	按 <Fn + F9> 播放或暂停 Windows® Media Player。
4.	在 Windows® Photo Viewer 中放大照片尺寸。	15.	按 <Fn + F10> 停止 Windows® Media Player。
5.	同时按下此键与 <F1> ~ <F12> 中任一键开启各种功能。	16.	按 <Fn + F11> 返回上一轨。
6.	按 <Fn + F1> 开启 Microsoft® Word。	17.	按 <Fn + F12> 跳至下一轨。
7.	按 <Fn + F2> 开启 Microsoft® Excel。	18.	降低音量。
8.	按 <Fn + F3> 开启 Microsoft® PowerPoint。	19.	增加音量。
9.	按 <Fn + F4> 开启 Microsoft® Internet Explorer。	20.	开启或关闭静音模式。
10.	按 <Fn + F5> 开启 Microsoft® Outlook。	21.	开启 Windows® Media Player。
11.	按 <Fn + F6> 开启 Windows® Internet Explorer 中的收藏夹。	22.	开启 Windows® Media Center。



这些特殊功能按键只能在 Windows® Vista / Windows® 7 操作系统中使用。

第五章

网络连接

有线连接

使用 RJ-45 网线将您的电脑与 DSL / 线缆调制解调器或局域网 (LAN) 相连。

通过 DSL / 线缆调制解调器连接网络


请按照以下步骤通过 DSL / 线缆调制解调器连接网络：

1. 设置您的 DSL / 线缆调制解调器。



请参阅您的 DSL / 线缆调制解调器手册。

2. 将 RJ-45 网线的一端连接至电脑后面板的 LAN (RJ-45) 接口，另一端连接至 DSL / 线缆调制解调器。



3. 开启 DSL / 线缆调制解调器与您的电脑。
4. 进行所需网络连接设置。




更多关于网络设置的信息与帮助请洽询您的网络服务提供商 (ISP)。

通过局域网连接网络（LAN）

请按照以下步骤通过局域网连接网络：

1. 将 RJ-45 网线的一端连接至电脑后面板的 LAN（RJ-45）接口，另一端连接至局域网。



2. 启动您的电脑。
3. 进行所需网络连接设置。




更多关于网络设置的信息与帮助请洽询您的网络管理员。

无线连接（选配）

通过无线方式将您的电脑与网络连接。




您需要连接一个无线访问点来建立无线连接。



- 请将外接天线连接至华硕无线网卡的天线接口，以增强无线电信号的接收范围与灵敏度。
- 请将天线放置于电脑顶部以获得最佳无线性能。
- 外接天线为选购配置。

请按照以下步骤连接无线网络：

1. 在通知区域中点击网络图标  显示可连接的无线网络。




2. 选择您想要连接的无线网络，然后点击【连接】。



3. 若要连接加密的无线网络，您需要输入网络安全密钥，然后点击【确定】。



4. 您的电脑正在连接无线网络，请稍候。



5. 连接成功。画面中显示连接状态，网络图标  显示已连接状态。



第六章

使用应用程序（选配）



根据机型不同，软件的实际操作界面及功能与介绍会略有不同，同时您的电脑可能并不包含本章节介绍的全部应用软件。

华硕 AI Manager

华硕 AI Manager 是一款提供您快速便捷操作的电脑常用应用程序。

安装 AI Manager

请依照以下步骤安装 AI Manager：

1. 于光驱中放入驱动与应用程序光盘，若您有打开自动播放功能，则会立即显示驱动程序安装向导画面。



如果“自动播放”功能未被打开，请在驱动及应用程序光盘中的 华硕 AI Manager 文件夹里双击 SETUP.EXE 主程序以打开此功能。

2. 点击【应用程序】标签，然后点击【华硕 AI Manager】。
3. 依照画面的指示，进行安装。

启用 AI Manager


欲打开 AI Manager，请从 Windows 系统的桌面左下角点击【开始】>【所有程序】>【ASUS】>【AI Manager】>【AI Manager 1.xx.xx】。AI Manager 会快速启动并显示快捷方式栏（Quick Bar，如下图）。



在打开应用程序后，AI Manager 的小图标将会显示在 Windows 桌面下方的任务栏中（如右图）。



使用鼠标右键点击这个图标，可以在快捷方式栏与主应用程序之间切换，而且您也可以通过快捷方式栏或 Windows 任务栏中的 AI Manager 小图标来启动 AI Manager。



AI Manager 快捷方式栏 (Quick Bar)


AI Manager 快捷方式栏的设计为节省桌面空间，并让您快速打开华硕工具程序与显示系统信息。点击在快捷方式栏上的主应用程序、我的最爱、技术支持或系统信息项目来显示该项目的选项。



点击放到最大/恢复按钮 可以在全屏与快捷方式栏之间做切换；点击缩到最小按钮 则可以将 AI Manager 保留在桌面下方的任务栏中；点击关闭按钮 则会离开 AI Manager 程序。

主应用程序 (Main)

主应用程序画面中提供以下几个工具程序：AI Disk、AI Security 与 AI Probe。点击主应用程序画面上的箭头小图标来浏览主应用程序中的各个工具程序项目。



AI Disk

AI Disk 可让您很轻松地选择如下图中的清除互联网的暂存文件、清除互联网的 Cookies、清除资源回收站的文件、清除最近访问的 URL(S)、清除网站的浏览记录或清除最近打开的文件清单项目。在快捷方式栏上点击 AI Disk 小图标打开 AI Disk 画面，您可以在这里选择您所要清除的项目。完成后请点击 **【应用】**。



AI Security

AI Security 提供您设置密码来保护您的设备如 USB 闪存盘、CD/DVD，以防止未经授权下被他人盗取数据。

请依照以下步骤进行设备的加密：

1. 第一次使用 AI Security 时，您会被要求输入一组新密码，请输入一组最多不超过 20 个字母数字或符号组合而成的密码。
2. 再次输入新密码。
3. 输入新密码的提示（建议）。
4. 当完成时，请点击【确定】。



5. 接着如下图，选择您所要进行加密的设备，然后点击【应用】。
6. 输入您事先设置的密码，然后点击【确定】。



请依照以下步骤解除已加密的设备：

1. 请取消勾选已加密的设备名称，然后点击【应用】。
2. 输入您事先已经设置的密码，然后点击【确定】。

请依照以下步骤变更密码：

- 点击【修改密码】，然后依照画面的指示进行变更。

AI Booting

AI Booting 提供您设置开机设备的优先次序。



请依照以下步骤指定开机顺序：

1. 选择一个设备，然后点击下方左边或右边的按钮以排定开机顺序。
2. 当完成选择后，请点击【应用】。

AI Probe

AI Probe 会自动侦测并显示主板与 CPU 的温度、CPU 风扇的转速，以及输出的电压，您也可以在此调整您所需要的数值。

点击“温度”、“电压”或“风扇转速”标签页，然后选择其中一项来打开或变更您所要的数值。



我的最爱

在“我的最爱”项目中提供您加入常用的应用程序，保留给您自行从电脑中加入您所要的应用程序项目。



请依照以下步骤加入我的最爱应用程序：

1. 点击【加入】，然后找到您所想要增加至“我的最爱”中的应用程序。
2. 点击打开文件所在的窗口位置，应用程序将会增加到“我的最爱”中。

右击该应用程序小图标，则可以打开、移除该应用程序，或变更名称，您也可以使用鼠标左键双击以打开该程序。

技术支持

在“技术支持”菜单画面中，您可以点击相关的链接来连接至华硕电脑-全球网站、华硕电脑-在线技术支持网站、华硕电脑-在线文件下载网站或华硕电脑-联络信息。



系统信息

点击“系统信息”菜单可以看到关于您的系统、主板、处理器、BIOS、安装的设备与内存的相关信息。



华硕 EPU-4 Engine

华硕 EPU-4 可侦测当前电脑负载，并智能地即时调节电量，为系统提供一套完整的节能方案。它自动调整 CPU、显卡、硬盘与 CPU 风扇的用电量。提供了三种用电模式：自动 (Auto)、高性能 (High Performance) 与最节能 (Maximum Power Saving) 模式，您可依据自己的使用情况选择。



关于三种模式的详细信息，请参考“华硕 EPU-主页”部分的详细说明。

安装华硕 EPU-4

请依据以下步骤安装 Engine：

1. 将驱动程序与应用程序光盘放入光驱。若您的电脑打开了自动播放功能。则“驱动程序”菜单自动出现。



若自动播放功能未打开，您可以到驱动程序与应用程序光盘中的 ASUS EPU-文件夹中双击 setup.exe 文件。

2. 点击【ASUS EPU-4 Engine】。
3. 然后依据屏幕指示完成安装。

打开华硕 EPU-4

请依据以下步骤打开华硕 EPU-4：

1. 在 Windows 任务栏中点击 ASUS 图标。



2. 当您第一次打开华硕 EPU-4 时，会出现一条信息，请您校准 EPU 功能。

点击【校准】(Calibrate)，开始校准，请等待几秒。然后 ASUS EPU-4 主页出现。



进行校准可使系统侦测 CPU 属性，以获得最佳的电能管理方案。

华硕 EPU-4 主页



- 1 CPU 状态
显示当前 CPU 电力于 CPU 节能总量。
- 2 VGA 卡状态
显示显卡状态。若主板不兼容您的显卡，会出现“没有侦测到显卡”的信息。






请访问 http://event.asus.com/mb/EPU-4_Engine/ 获取华硕显卡合格供应商列表。

- | | |
|---|------------------------------------|
| 3 | 硬盘状态
当节能模式激活时，此处亮起。 |
| 4 | 风扇状态
显示风扇状态。 |
| 5 | 二氧化碳排放量按钮
显示二氧化碳的当前排放量或总排放量。 |
| 6 | 模式属性
显示每种模式的属性。 |
| 7 | 退出按钮
关闭华硕 EPU-应用程序。 |
| 8 | 校准按钮
允许系统侦测 CPU 属性，以取得最佳电能使用方案。 |
| 9 | 设置按钮
点击此按钮进行模式设置。 |



详细信息请参考“设置模式”部分的详细说明。

10 模式	
	自动模式 当您选择此模式，系统依据当前系统状态自动变更用电模式。
	高性能模式 当您选择此模式，系统元件将超频到最大性能。
	最节能模式 当您选择此模式，系统自动为重要元件即时调整最佳用电方案，以节能。

华硕在线升级（ASUS Update）

华硕在线升级程序是一套可以让您在 Windows 操作系统下，用来管理、存储与升级主板 BIOS 文件的应用程序。



- 在使用华硕在线升级程序之前，请先确认您已经通过内部网络对外连接，或者通过互联网服务供应商（ISP）所提供的连接方式连接到互联网。
- 随主板附赠的驱动程序与应用程序光盘中包含此应用程序。

安装华硕在线升级程序

请依照以下步骤安装华硕在线升级程序（ASUS Update）：

1. 将驱动程序与应用程序光盘放入光驱，会出现“驱动程序”菜单。



若“自动播放”功能未打开，请双击驱动与应用程序光盘中 ASUS Update 文件夹下的 setup.exe 文件。

2. 点击【应用程序】标签，然后点击【安装华硕在线升级程序】。
3. 华硕在线升级程序将被复制到您的系统中。



在您要使用华硕在线升级程序来升级 BIOS 程序之前，请先关闭其他所有的 Windows® 应用程序。

升级 BIOS 程序

1. 点击【开始】>【所有程序】>【ASUS】>【ASUS Update】>【ASUS Update】运行华硕在线升级主程序。
2. 在下拉菜单中点击下列操作之一：

使用网络升级 BIOS 程序

- a. 选择【Update BIOS from the Internet】，然后按下【Next】继续。
- b. 请选择离您最近的华硕 FTP 站台可避免网络堵塞，或者您也可以直接选择【Auto Select】由系统自行决定。按下【Next】继续。
- c. 接着再选择您欲下载的 BIOS 版本。按下【Next】继续。



华硕在线升级程序可以自行通过网络下载 BIOS 程序。经常的升级才能得到最新的功能。

使用 BIOS 文件升级 BIOS 程序

- a. 在下拉菜单中选择【Update BIOS from a file】，然后按下【Next】继续。
 - b. 在“打开”窗口中选择 BIOS 文件的所在位置，然后点击【打开】。
3. 最后再依照屏幕画面的指示来完成 BIOS 升级的程序。

华硕 MyLogo2™

华硕 MyLogo2™ 应用程序使您能够自定义启动图标。启动图标会在开机自检时出现。华硕 MyLogo2™ 会在您安装华硕在线升级程序时一并安装到您的系统。



-
- 请访问华硕官网 www.asus.com.cn 获取最新 BIOS 文件。
 - 您可以将文件存成 GIF 格式作为启动图标。
-

请按照以下步骤进入华硕 MyLogo2™：

1. 运行华硕在线升级程序。请参阅“华硕在线升级”一节。
2. 选择下拉菜单中的选项，然后点击【下一步】。
3. 在升级 BIOS 之前请先运行 MyLogo 来置换系统启动图标。
4. 在下拉菜单中选择【以文件升级 BIOS】然后点击【下一步】。
5. 按照提示找到新的 BIOS 文件，然后点击【下一步】。华硕 MyLogo 窗口即在屏幕上出现。
6. 在窗口的左面板找到您想要用来作为启动图标的图标，点击【下一步】。
7. 在 Ratio 下拉菜单中选择您想要的图标大小，点击【下一步】。
8. 系统开始升级 BIOS，并载入新的启动图标。
9. 升级完成后，系统将重新启动，并在开机自检时显示新图标。

Nero

Nero 允许您创建、复制、刻录、编辑、分享以及升级不同类型的数据。



安装 Nero（以 Nero 9 为例）

请按照以下步骤安装 Nero 9：

1. 将 Nero 9 驱动程序光盘插入光驱。
2. 若您的电脑有自动播放功能，屏幕上会自动跳出主菜单。



若您的电脑没有自动播放功能，请双击 Nero 9 光盘根目录下的 SeupX.exe 安装文件。


3. 在主菜单中点击【Nero 9 Essentials】。



4. 选择安装向导的语言，然后点击【下一步】。




5. 点击【下一步】继续。



6. 勾选“我接受许可证条款”，完成后点击【下一步】。




7. 选择【典型】，然后点击【下一步】。



8. 勾选“是，我想通过向 Nero 传送匿名应用程序数据以帮助”，然后点击【下一步】。



9. 完成后点击【退出】。



刻录文件

请参考以下步骤刻录文件：

1. 在主菜单中点击【数据刻录】>【添加】。



2. 选择您想要刻录的文件，点击【添加】。



3. 选择您想要刻录的文件后，点击【刻录】将已选文件刻录至光盘。



更多关于 Nero 9 的使用方法请访问 Nero 网站 www.nero.com。

恢复您的系统 (仅限预装 Windows 操作系统的机器)

华硕台式电脑恢复 DVD 光盘帮助您重新安装操作系统并将其恢复至默认工作状态。



在恢复过程中所有数据将会丢失。在恢复系统前，请确认您已备份所有数据，并记录下所有自定义设置，如网络设置。

请按照以下步骤恢复您的电脑：

1. 开机时，当显示 ASUS 标志，请按下 <F8> 键进入 “Please select boot device” 菜单。
2. 放入恢复 DVD 光盘，然后选择光驱为开机设备，按下 <Enter> 键，然后按任一键继续。
3. 等待直至硬盘信息画面出现。选择如何安装一个新系统，选项有：

Recover System to a partition

本选项将会移除以下您所选择的分区 (Partition)，并允许您保留其他的既有的分区，以及创建一个新的分区如磁盘 C。选择一个分区后，按【NEXT】继续。

Recover Windows to entire HD

本项目将会恢复整颗硬盘成为单一分区，执行此项目将会复盖您硬盘内所有数据，并创建一个全新的分区，如磁盘 C，选定后，并选择【Yes】继续。

4. 勾选【我接受】，然后点击【下一步】。
5. 接着请依照画面上的指示，完成恢复的动作。
6. 当完成系统恢复时，画面会显示请您放入产品的驱动与应用程序 DVD 光盘，请放入后并按【OK】与重新开机。
7. 在电脑重新开机后，Windows® 7 系统将会开始进行系统设置。请按照画面上的指示来完成安装，然后会再重新开机。



华硕个人电脑恢复光盘仅能使用在本台式电脑，请勿任意使用于其他的电脑上。有关本产品的最新信息，请上华硕网站 <http://www.asus.com.cn> 查询。

快速恢复系统

（仅限预装 Windows 操作系统的机器，且隐藏分区未破坏）

1. 打开华硕台式电脑，当显示 ASUS 标志时，按下 <F9> 进入“System Recovery”。
2. 此时画面显示“Windows is loading files”。接着，“Recovery CD/DVD”窗口出现。
3. 按照屏幕上的说明完成恢复过程。在系统重新开机后，显示分辨率与系统设置将恢复为默认值。

第七章

疑难解决

本章节为您提供您可能遇到的疑难的解决方法。

？ 我的电脑无法开机，并且前面板电源指示灯未亮起。

- 检查您的电脑是否连接电源。
- 检查墙上的电源插座是否可用。
- 检查是否开启电源。更多信息请参阅第一章“开启或关闭您的电脑”。

？ 我的电脑死机。

- 请按照以下步骤关闭无响应的程序：
 1. 同时按下 <Alt> + <Ctrl> + <Delete>，然后点击【任务管理器】。
 2. 点击【应用程序】。
 3. 选择未响应程序，然后用鼠标右键点击【结束任务】。
- 若键盘也无响应，请按住机箱顶部的电源按钮直至电脑关闭。然后再按下电源按钮重新启动电脑。

？ 我无法使用华硕无线网卡连接无线网络（选配）。

- 请确认您为想要连接的无线网络输入了正确的网络安全密钥。
- 将外接天线（选购）连接至华硕无线网卡上的天线接口，并将天线放置在机箱的顶部以获得最佳无线性能。

？ 数字键盘区域的方向键不起作用。

请确认数字锁定指示灯已关闭。当指示灯亮起时这些数字键仅被用于输入数字；若您想要使用该区域中的方向键，请按下数字锁定键关闭指示灯。

? 显示器无法显示。

- 请检查显示器是否开启。
- 请确认您的显示器与电脑上的视频输出接口正确相连。
- 若您的电脑内置独立显卡，请确认您的显示器与独立显卡的视频输出接口相连。
- 请检查显示器视频接口上的针脚是否弯曲。若您发现弯曲的针脚，请立即替换显示器视频接口接线。
- 请检查您的显示器是否正确连接电源。
- 更多疑难解决信息请参考您的显示器使用手册。

? 使用多个显示器时，仅一个显示器能显示。

- 请确认这些显示器电源已开启。
- 在开机自检时仅连接至 VGA 接口的显示器可以显示。双显示功能仅在 Windows 系统中适用。
- 若您的电脑安装了显卡，请确认将显示器连接至显卡的输出接口。
- 请检查多个显示器是否正确设置。更多信息请参阅第三章“连接多个外接显示器”。


? 我的电脑无法侦测 USB 存储设备。

- 当您第一次将 USB 存储设备与电脑相连时，Windows 会自动安装它的驱动程序。完成后请点击进入“计算机”来检查是否侦测到 USB 存储设备。
- 将您的 USB 存储设备连接至另一台电脑来检测此 USB 存储设备是否损坏。





? 我想要还原或撤销对电脑系统的更改，同时不影响我的个人文件或数据。

Windows® 系统还原功能允许您还原或撤销对电脑系统的更改，同时不影响您的个人文件或数据如文档或图片。更多信息请参阅第二章“还原您的电脑”。

？ 高清晰电视上的图像变形。

- 您的显示器或高清晰电视的不同分辨率会导致图像变形。请调节屏幕分辨率至适合您的高清晰电视。请按照以下步骤改变您的屏幕分辨率：
 1. 请参考以下任意一项打开屏幕分辨率设置；
 - 点击  > 【控制面板】> 【个性化】> 【显示】> 【改变显示器设置】。
 - 右击桌面。菜单出现后，点击【个性化】> 【显示】> 【改变显示器设置】。
 2. 调节分辨率。相关信息请参阅您的高清晰电视的使用手册。
 3. 点击【应用】或【确定】。然后在确认信息中点击【保留变更】。



？ 我的喇叭没有声音。

- 请确认您将您的喇叭连接至前面板或后面板的音效输出口（草绿色）。
- 请确认您的喇叭是否连接电源并开启。
- 调节喇叭的音量。
- 请确认您没有启动静音模式。
- 若您启动静音，音量图标将显示为 。若要开启系统声音，请点击通知区域的 ，然后点击 。
- 若没有启动静音，点击  滑动滚轴调节音量。
- 将您的喇叭与另一台电脑相连测试它是否正常运作。

？ DVD 光驱无法读取光盘。

- 请确认光盘是以标签面朝上放入光驱。
- 请确认光盘是否正确放入托盘，尤其是非标准大小的光盘。
- 请检查光盘是否有所损坏。

？ DVD 光驱退出按钮不起作用。

1. 点击  > 【计算机】。
2. 右击 ，然后在菜单中点击【退出】。

