

P6X58D Premium 主機板重要更新

3.7.6 進階電源管理設定 (APM Configuration) (第 3-27 頁)

BIOS SETUP UTILITY	
Power	
APM Configuration	
Restore on AC Power Loss	[Power Off]
Power On By RTC Alarm	[Disabled]
Power On By PCI Devices	[Disabled]
Power On By PCIE Devices	[Disabled]
Power On By PS/2 Keyboard	[Disabled]
Power On By PS/2 Mouse	[Disabled]
Options	
Power Off	
Power On	
Last State	

Restore On AC Power Loss [Power Off]

- [Power On] 系統在電源中斷之後重新開啟。
- [Power Off] 系統在電源中斷之後電源將維持關閉狀態。
- [Last State] 將系統設定回復到電源未中斷之前的狀態。

Power On By RTC Alarm [Disabled]

- [Disabled] 關閉即時時鐘 (RTC) 喚醒功能。
- [Enabled] 當您設為 [Enabled] 時，將出現 RTC Alarm Date (Days) 與 System Times 子項目，您可自行設定時間讓系統自動開機。

Power On By PCI Devices [Disabled]

- [Disabled] 關閉 PME PCI 裝置將系統從 S5 狀態喚醒功能。
- [Enabled] 您可以使用 PCI 網路或數據卡來開機。要使用本功能，ATX 電源供應器必須可以提供至少 1 安培的電流及 +5VSB 的電壓。

Power On By PCIE Devices [Disabled]

- 開啟或關閉 PCIE 裝置的喚醒功能。
- [Disabled] 關閉 PCIE 裝置的喚醒功能。
- [Enabled] 開啟 PCIE 裝置的喚醒功能。

Power On By PS/2 Keyboard [Disabled]

- [Disabled] 關閉使用 PS/2 鍵盤開機功能。
- [Enabled] 啟動使用 PS/2 鍵盤開機功能。要使用本功能，ATX 電源供應器必須可以提供至少 1 安培的電流及 +5VSB 的電壓。

Power On By PS/2 Mouse [Disabled]

- [Disabled] 關閉使用 PS/2 滑鼠開機功能。
- [Enabled] 啟動使用 PS/2 滑鼠開機功能。要使用本功能，ATX 電源供應器必須可以提供至少 1 安培的電流及 +5VSB 的電壓。