

ASUS M4A78 PRO Technical Updates

This is an information update for the user guide that comes with your motherboard package.

2.3.6 Storage Configuration (*page 2-11*)

This menu allows you to configure the SATA devices.



- When SATA is configured as [AHCI] in BIOS, only SATA port 1-4 can be detected. Ensure to install the AHCI driver to detect and use SATA port 5-6 in AHCI mode under OS.

2.3.6 Storage Configuration (第 2-11頁)

本選單用來設定 SATA 裝置。



當 BIOS 程式中將 SATA 設定為 [AHCI]，只有 SATA 1-4 連接埠能被偵測到，在作業系統下，請確認已經安裝 AHCI 驅動程式以偵測並使用 AHCI 模式的 SATA 5-6 連接埠。

2.3.6 Storage Configuration (第 2-11页)

本选单用来设置 SATA 设备。



当 BIOS 程序中将 SATA 设置为 [AHCI]，只有 SATA 1-4 连接端口能被检测到，操作系统下，请确认已经安装 AHCI 驱动程序以检测并使用 AHCI 模式的 SATA 5-6 连接端口。

15G062159XXX