Optical Disc Drive Firmware Upgrade Guide

Follow the instructions below to identify the model of your optical disc drive and upgrade its firmware.

To Identify the ODD model

For Windows XP:

1. Double-click System in the Control Panel.
2. Click the Hardware tab, and then click the Device Manager button.
3. Click the “+” sign before the item DVD/CD-ROM drives, and note down the ODD model, for example:

TSSTcorp CDDVDW TS-L633C ATA Device

HL-DT-ST DVDRAM GA10N ATA Device

HL-DT-ST BDDVDRW CA10N ATA Device

For Windows Vista / Windows 7:

1. Click Start, right-click Computer, and then click Properties.
2. Click Device Manager in the left pane.
3. Click the “+” sign before the item DVD/CD-ROM drives, and note down the ODD model, for example:

TSSTcorp CDDVDW TS-L633C ATA Device

HL-DT-ST DVDRAM GA10N ATA Device

HL-DT-ST BDDVDRW CA10N ATA Device

To upgrade ODD firmware

1. Download the corresponding ODD firmware in the following address

   http://support.asus.com/download/download.aspx?product=20&model=ODD%20Firmware&SLanguage=en-us&os=8
2. Double-click the downloaded executable file to upgrade ODD firmware.