



PIKE2008 IMR Update SBR tool S.O.P

1. Please prepare the USB flash that can boot to DOS.
2. Please decompress(**sbr.zip**) to USB flash
3. Plug PIKE card & USB flash on your system and power on.
4. Boot to DOS.
5. Type FIX, and then press Enter.



6. Update OK!



7. Reboot system