

ASUS EeeBox PC EB1012 Technical Updates

This is an information update for the EeeBox PC EB1012 user manual.


ASUS Easy Update (page 36)

If you use an HDMI display device as an audio output device for the first time, follow the steps below to update the audio driver:

1. From the Windows® notification area, right-click the **ASUS Easy Update** icon.



2. Click **OK** to display the items you can download.



3. Check the box before **Nvidia High Definition Audio** and then click **OK**.

