

How to Update the Firmware.

Step1. Firmware Version check.

1. Please check the version of your Media Player's current firmware before beginning this update. If your Media Player's firmware is the latest version. you will not need to update the firmware.
2. Connect the Media Player to your TV and then turn on the Media Player.
3. Press the SETUP button on the Remote controller and the setup screen will be displayed.
4. Click the **System** item. Check the **System update**→ Rev:01.11P (Current version)

Note : firmware can be restore or downgrade to previous older firmware.

It only effect if you've updated O!Play's firmware Version to Rev:01.17 or later.

Step2. Downloading the latest Firmware.

1. Log onto ASUS SUPPORT web site :

<http://support.asus.com/download/download.aspx?SLanguage=en-us>

2. In the search window. Please Select the Product.(**Multimedia**) Series (**Digital Media Player**). Models(**O!Play HDP-RX**), then click **Search**. Please see image below.




3. When the page open, Please Select your operating system. Then click **Search**. Please see image below.



4. When the next page open, you can find the firmware folder. Please see image below.





5. Please click the firmware folder, Please see image below.



6. **You should make sure that your TV SYSTEM (PAL or NTSC)** .select an appropriate Firmware. then Click the Download from...that's nearest you, a 'File Download' window will probably pop up. Please see image below.




7. Click the save. if save it to your computer's Desktop. Please see image below.



8.The zipped firmware will be downloaded and saved to your Desktop.

Once the zipped firmware (**install.zip**) is downloaded and saved on your desktop,




9.Unzip the compressed firmware to (**install.img**). Then using a blank/ formatted USB Flash Stick to copy or paste the Unzipped firmware file as below:



Step3. To Update the Firmware.

1. Insert the USB Flash Stick(**install.img** inside) to USB port of your Media Player. The System will recognize the firmware in the USB Flash drive automatically.
2. Press the **SETUP** button on the Remote controller and the setup screen will be displayed.
3. Click on the **System** item and press OK. Then navigate to the **system Upgrade** and press OK to start updating.
4. At this moment, the Power LED of O!Play will turn from **BLUE** to **RED** and following screen will be displayed.



New firmware updates is in the process (take about 4 minute).when the update is successfully completed the Media Player will reboot automatically.

WARNING :

DO NOT UNPLUG (Power Cord and USB Flash drive)TURN OFF, OR USE ANY OTHER FEATURE OF YOUR MEDIA PLAYER DURING THE FIRMWARE UPDATE PROCESS. Doing so will cause the writing of the firmware update to the player to be halted and the player may no longer operate properly. If the player stops working, please contact ASUS Authorized Service Provider at 0800-093-456.