

## Supported List of O!Play Gallery

HDD Devices			
Type	Model	Status	Remark
SATA300	ExcelStor J880S	SATA300	WD WD1600AVJS
	Hitachi HDT721025SLA380		WD WD6400AAKS
	Hitachi HDS721010KLA330		WD WD3000GLFS
	Hitachi HDS721050CLA362		WD WD5000ABYS
	Hitachi HDS721010CLA332		WD WD5000ABPS
	Maxtor STM3500320AS		WD WD7500AYPS
	Samsung HD153WI		WD WD2502ABYS
	Samsung HD203WI		WD WD5002ABYS
	Seagate ST3500320AS		WD WD7501AALS
	Seagate ST3750330AS		WD WD10EACS-00ZJB0
	Seagate ST31000333AS		WD WD10EACS-00D6B0
	Seagate ST31500341AS		WD WD20EADS
	Seagate ST3500418AS		WD WD2001FASS
	Seagate ST3750528AS		WD WD10EARS
	Seagate ST31000528AS		WD WD15EARS
	Seagate ST3500320NS		WD WD20EARS
	Seagate ST32000540AS	SATA 6G	Seagate ST31000529AS
	Seagate ST31000340NS		Seagate ST32000641AS
	Seagate ST95005620AS		Seagate ST33000651AS
			WD WD6402AAEX
			WD WD1002FAEX
			WD WD6000HLHX

USB Devices		
Type	Model	
USB 2.0	Adata	C801
	AIGO	L8202
	Apacer	AH221
	Corsair	CMFUSBSRVR
	iMate	combo driver
	Kingston	DT200
	OCZ	Z2B818
	PATRIOT	PEF32GUSB
		XPORTER MAGNUM 210X
	PNY	PFU6016-BC
	Sandisk	SDCZ36-032G-P36
		CZ8
	SILICON POWER	eSATA / USB SSD
	Sony	USM16GL
	TOSHIBA	U2P-008GT
	Transcend	TS16GJV10
USB 3.0	SUPER TALENT	ST3U64SRK
e-SATA	iMate	combo driver

USB Hubs Devices		
Type	Model	
USB 2.0	BELKIN	F5U237
	D-Link	DUB-H7
	SANWA	236SV
	ELECOM	U2H -TM400BBK

External Devices		
Type	Model	
eSATA	DigiFusion	HD-343SSC

	<b>ICY Dock</b>	<b>MB561US-4SB</b>
	<b>Seagate</b>	<b>Free Agent</b>
		<b>Free Agent XTreme 1TB</b>
		<b>Free Agent XTreme 1.5TB</b>
	<b>Stardom</b>	<b>i302</b>
		<b>ST3620-2S-S2</b>
		<b>ST5610</b>
	<b>THERMALTAKE</b>	<b>N0018US</b>
	<b>Vantec</b>	<b>NST-360UFSBK</b>
		<b>NST-D100</b>
	<b>WD</b>	<b>My Book Home</b>
		<b>My Book Studio Edition II</b>
<b>USB 2.0</b>	<b>ASUS</b>	<b>BS-F112</b>
	<b>Buffalo</b>	<b>HD-CE1.0TU2 1TB</b>
		<b>HD-PE500U2 500GB</b>
	<b>DigiFusion</b>	<b>HD-343SSC</b>
	<b>FUJITSU</b>	<b>Wyvo E 500GB</b>
	<b>ICY Dock</b>	<b>MB559US-1S</b>
	<b>Imation</b>	<b>SOHOT PRO 320GB</b>
	<b>Maxtor</b>	<b>9NT3A4-500</b>
		<b>Basics Desktop 1.5TB</b>
	<b>Seagate</b>	<b>Free Agent</b>
		<b>Free Agent 320GB</b>
		<b>Free Agent XTreme 1TB</b>
	<b>Stysen</b>	<b>E01</b>
	<b>Transcend</b>	<b>STOREJET 25F</b>
		<b>STOREJET 25M 250GB</b>
	<b>Vantec</b>	<b>NST-360UFSBK</b>
	<b>WD</b>	<b>My Book Home</b>
		<b>My Book Studio Edition II</b>
		<b>My Passport Essential 500GB</b>
<b>USB 3.0</b>	<b>Agestar</b>	<b>3UB3A8 USB 3.0外接盒</b>
	<b>Buffalo</b>	<b>HD-HX1.0TU3-AP</b>
	<b>CYBER SLIM</b>	<b>S1-U3 USB 3.0外接盒</b>
	<b>DOTOP</b>	<b>DEM-0312</b>
	<b>FReeCOM</b>	<b>HARD DRIVE XS3.0</b>
	<b>I-O DATA</b>	<b>HDJ-UT1.0</b>
		<b>HDJ-UT1.5</b>

## 1.5 Monitor

Monitor Devices		
Type	Model	
HDMI	ASUS	TLW32001D

		<b>TLW42001D</b>
		<b>VE276Q</b>
	<b>Chimei</b>	<b>24EA/H</b>
	<b>Dell</b>	<b>3008FP</b>
		<b>U2410</b>
	<b>EIZO</b>	<b>HD2441W</b>
	<b>Hannsg</b>	<b>HG281D</b>
	<b>JVC</b>	<b>26DS6BJ</b>
	<b>LG</b>	<b>32Lb9D</b>
		<b>L245WP</b>
	<b>Samsung</b>	<b>XL2370</b>
	<b>Sony</b>	<b>KVL-40V300A</b>
	<b>Toshiba</b>	<b>42RV500G</b>

#### **PC Link**

<b>Type</b>	<b>Model</b>
<b>USB3.0</b>	<b>M4A78-E SE</b>
	<b>P8P67 Pro</b>
	<b>M4A87TD/USB3</b>
	<b>P8P67 EVO</b>
	<b>Sabertooth P67</b>

#### **Apple Device**

<b>Type</b>	<b>Model</b>
<b>Apple Cable</b>	<b>Iphone 4 16GB</b>
	<b>Ipod Classic 160GB</b>
	<b>Ipod touch 8G</b>

#### **PC Link**

<b>Type</b>	<b>Model</b>
<b>Bluetooth</b>	<b>Magic-Pro Promini V-touch</b>
<b>USB 2.0</b>	<b>Logitech G19</b>
<b>USB 2.0</b>	<b>I-Rocks KR-6402</b>
<b>USB 2.0</b>	<b>Microsoft Reclusa Wired Gaming</b>
<b>USB 2.0</b>	<b>FILCO FKBN104ML/EB</b>
<b>USB 2.0</b>	<b>Ducky DK9000</b>
<b>Bluetooth</b>	<b>Logitech MX5500 Revolution</b>
<b>USB 2.0</b>	<b>ASUS MS-511U</b>
<b>USB 2.0</b>	<b>Logitech MX3200 Laser</b>
<b>USB 2.0</b>	<b>Logitech Y-RCP140</b>
<b>USB 2.0</b>	<b>T.C.STAR-KIT9901</b>
<b>USB 2.0</b>	<b>Microsoft WIRELESS DESKTOP 3000</b>
<b>USB 2.0</b>	<b>Microsoft Wireless Laser Desktop 6000</b>
<b>USB 2.0</b>	<b>MSI Wireless Combo 630</b>
<b>USB 2.0</b>	<b>Logitech MK260</b>
<b>USB 2.0</b>	<b>Logitech MX-REVOLUTION</b>
<b>USB 2.0</b>	<b>Microsoft Sidewinder X3</b>
<b>USB 2.0</b>	<b>RaZer RZ01-0015</b>

<b>USB 2.0</b>	<b>Razer RZ01-0028</b>
<b>USB 2.0</b>	<b>ASUS Vito W1</b>
<b>USB 2.0</b>	<b>SILVERSTONE SST RVM01B</b>
<b>USB 2.0</b>	<b>ICON7-Z500</b>
<b>USB 2.0</b>	<b>ROCCAT KOVA</b>
<b>USB 2.0</b>	<b>Microsoft Sidewinder X3</b>
<b>USB 2.0</b>	<b>RaZer RZ01-0015</b>