


# ASUS Eee PC Technical Updates

This is an information update for the user guide that comes with your Eee PC package.

## Eee Docking

### Launching Eee @Vibe for the first time

1. For the first time you use Eee @Vibe, you need to launch the utility from **Start > All Program > ASUS > ASUS VIBE > ASUS VIBE**, and a splash screen appears.
2. After the splash screen shows the loading screen during the downloading of the latest Eee @Vibe version from the Server.



The downloading time depends on the network bandwidth:

ADSL 1M: 2 minutes

ADSL 2M: 1 minutes

ADSL 4M: 50 seconds

ADSL 8M: 25 seconds

3. When the downloading is done, click Close to finish Eee @Vibe.
4. The next time you want to start Eee @Vibe, simply click Eee @Vibe from the Eee Docking.

