


# **A50 FW update and Master clear**

## **FW update**

1. Download the latest firmware and unzip the XXX-update.zip
2. Copy the “Garmin” folder to the root directory of your MicroSD card.
3. Insert the MicroSD card in to your A50 device while it is on, and you will see below screen




4. Press OK and make sure you connect a power source to your A50 device. Wait for about 5 minutes and the updating process will be done and will automatically restart your A50 device.

### **Noticed:**


**Please do master clear after firmware update to ensure the update process is 100% complete. (Please backup personal data before master clear to avoid any information missing.)**

# Master Clear


1. Press Setting



2. Press Privacy



3. Press Master Clear



4. Press Delete

**Noticed: please back up your data before Master Clear.**

