

P320 Singapore V4.10.0 release note

Additional features and improvements:

1. Improve system stability.
2. Fix the occasional no sound during calling problem.

Caution:

1. After firmware upgrade, the original files in P320 will not be saved, please backup the files using the Backup software in bonus CD.
2. Please do not upgrade to firmware of different languages and areas.
3. The encrypted files on your SD card may not able to be opened after firmware upgrade, please backup all encrypted files of SD card before firmware upgrade.
4. Please make sure the battery is more than 50%. It is recommended keeping the battery in charge during upgrade.
5. Please avoid using Kingmax series microSD cards and Transcend 4G microSD card to do upgrade.

Upgrade procedure:

1. After downloading P320_V4100_V49_V1110_ZHI, please unzip it.
2. Please directly copy folder “2577” into the root directory of your micorSD card. Please insert microSD card into P320 after the copy.
3. Keep the battery in charge during upgrade procedure.
4. Please follow the steps on the phone to upgrade.
5. Press and hold Volume Down key (on left side, shown below) and reset (on bottom side), the system will boot up. Continue to hold Volume Down key until the screen shows writing percentage.
6. The system will start installation automatically.
7. It will re-start when system installation is completed.
8. System will start upgrading after touch panel calibration and date/time setting.