


## ASUS Z9PE-D8 WS Technical Updates

This is an information update for the user guide that comes with your motherboard package.

#### 4. LSI MegaRAID or Intel RSTe selection jumper (3-pin RAID\_SEL1) (page 2-28)

This jumper allows you to select the PCH SATA RAID mode to use LSI MegaRAID software or Intel® Rapid Storage Technology enterprise 3.0 RAID. Place the jumper caps over pins 1–2 if you want to use the LSI MegaRAID software RAID Utility (default); otherwise, place the jumper caps to pins 2–3 to use the Intel® Rapid Storage Technology Enterprise Option ROM Utility.



**Z9PE-D8 WS RAID setting**

