



SOP for changing jumper positions of HDD Backplane on RS72Xq-E7 series


1. Please loosen six screws (1-2-3-4-5-6), and remove the top cover.



2. After the cover removed, there are 4 jumpers as red circles marked.



3. Moving the 4 jumpers from PIN 1-2 to PIN 2-3 as shown below.



Note: The jumpers must be keeping in PIN 2-3 for optimize the signal strength of HDDs.