## 2.5   Power Menu

The Power menu allows you to reduce power consumption. This feature
turns off the video display and shuts down the hard disk after a period of
inactivity.

```
                Phoenix - Award BIOS CMOS Setup Utility
   Main  Advanced  Power  Boot  Exit
 ┌─────────────────────────────────────────────┬───────────────────────┐
 │                                              │    Select Menu        │
 │   ACPI Suspend Type        [S3(STR)]         │                       │
 │   ACPI APIC Support        [Enabled]         │ Item Specific Help▶▶   │
 │ ▶ APM Configuration                          │                       │
 │ ▶ Hardware Monitor                           │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 │                                              │                       │
 ├──────────────────────────────────────────────────────────────────────┤
 │ F1:Help      ↑↓:Select Item    -/+: Change Value      F5:Setup Defaults│
 │ ESC:Exit     ➡➡:Select Menu    Enter: Select SubMenu  F10:Save and Exit │
 └──────────────────────────────────────────────────────────────────────┘
```

ACPI Suspend Type [S3(STR)]

Allows you to select the ACPI state used for system suspend.
Configuration options: [S1(POS)] [S3(STR)] [S1&S3]

> When installing Windows® 98 SE/Me using a Serial ATA hard disk drive,
> set the **SATA Mode** item in Onboard Device Configuration to
> [[Pseudo-RAID] to enable S1/S3 wake-up. Refer to page 2-23 for
> details.

ACPI APIC Support [Enabled]

Allows you enable or disable the ACPI feature on the operating system.
Configuration options: [Disabled] [Enabled]